Manual No.'19 • PAC-DB-308

MITSUBISHI HEAVY INDUSTRIES

DATA BOOK

MICRO INVERTER PACKAGED AIR-CONDITIONERS

(Split system, air to air heat pump type)

CEILING CASSETTE-4 WAY TYPE

Single type	Twin type	Triple type
FDT100VNAWVH	FDT100VNAWPVH	FDT140VNAWTVH
100VSAWVH	100VSAWPVH	140VSAWTVH
125VNAWVH	125VNAWPVH	
125VSAWVH	125VSAWPVH	
140VNAWVH	140VNAWPVH	
140VSAWVH	140VSAWPVH	

CEILING CASSETTE-4 WAY COMPACT TYPE

Twin type	Triple type
FDTC100VNAWPVH	FDTC140VNAWTVH
100VSAWPVH	140VSAWTVH
125VNAWPVH	
125VSAWPVH	

DUCT CONNECTED-HIGH STATIC PRESSURE TYPE

Single type
FDU100VNAWVH
100VSAWVH
125VNAWVH
125VSAWVH
140VNAWVH
140VSAWVH

DUCT CONNECTED-LOW/MIDDLE STATIC PRESSURE TYPE

Single type	Twin type	Triple type
FDUM100VNAWVH	FDUM100VNAWPVH	FDUM140VNAWTVH
100VSAWVH	100VSAWPVH	140VSAWTVH
125VNAWVH	125VNAWPVH	
125VSAWVH	125VSAWPVH	
140VNAWVH	140VNAWPVH	
140VSAWVH	140VSAWPVH	

CEILING SUSPENDED TYPE

Single type	Twin type	Triple type
FDE100VNAWVH	FDE100VNAWPVH	FDE140VNAWTVH
100VSAWVH	100VSAWPVH	140VSAWTVH
125VNAWVH	125VNAWPVH	
125VSAWVH	125VSAWPVH	
140VNAVWH	140VNAWPVH	
140VSAVWH	140VSAWPVH	

WALL MOUNTED TYPE

Single type	Twin type	Triple type
SRK100VNAWZR	SRK100VNAWPZSX	SRK140VNAWTZSX
100VSAWZR	100VSAWPZSX	140VSAWTZSX
	125VNAWPZSX	
	125VSAWPZSX	
	140VNAWPZR	
	140VSAWPZR	

V Multi System

(OUTDOOR UNIT)	(INDOOR UNIT)	
FDC100VNA-W	FDT50VH	FDE50VH
100VSA-W	60VH	60VH
125VNA-W	71VH	71VH
125VSA-W		
140VNA-W		
140VSA-W		

MITSUBISHI HEAVY INDUSTRIES THERMAL SYSTEMS, LTD.

TABLE OF CONTENTS

1. MICRO INVERTER PACKAGED AIR-CONDITIONERS 2
2. V MULTI SYSTEM 335
3. OPTION PARTS 353

1. MICRO INVERTER PACKAGED AIR-CONDITIONERS

CONTENTS

1.1 SPECIFICATIONS 4
(1) Ceiling cassette-4 way type (FDT) 4
(2) Ceiling cassette-4 way compact type (FDTC) 18
(3) Duct connected-High static pressure type (FDU) 24
(4) Duct connected-Low/Middle static pressure type (FDUM) 30
(5) Ceiling suspended type (FDE) 44
(6) Wall mounted type (SRK) 58
1.2 EXTERIOR DIMENSIONS 68
(1) Indoor units 68
(2) Outdoor units 80
(3) Remote control (Option parts) 81
1.3 ELECTRICAL WIRING 84
(1) Indoor units 84
(2) Outdoor units 93
1.4 NOISE LEVEL 95
1.5 CHARACTERISTICS OF FAN 101
1.6 TEMPERATURE AND VELOCITY DISTRIBUTION 107
1.7 PIPING SYSTEM 116
1.8 RANGE OF USAGE & LIMITATIONS 118
1.9 SELECTION CHART 122
1.9.1 Capacity tables 122
(1) Ceiling cassette-4 way type (FDT) 122
(2) Ceiling cassette-4 way compact type (FDTC) 129
(3) Duct connected-High static pressure type (FDU) 132
(4) Duct connected-Low/Middle static pressure type (FDUM) 135
(5) Ceiling suspended type (FDE) 142
(6) Wall mounted type (SRK) 149
1.9.2 Correction of cooling and heating capacity in relation to air flow rate control (Fan speed) 155
1.9.3 Correction of cooling and heating capacity in relation to one way length of refrigerant piping 155
1.9.4 Height difference between the indoor unit and outdoor unit 155
1.10 APPLICATION DATA 156
1.10.1 Installation of indoor unit 156
(1) Ceiling cassette-4 way type (FDT) 156
(2) Ceiling cassette-4 way compact type (FDTC) 162
(3) Duct connected-High static pressure type (FDU) 170
(4) Duct connected-Low/Middle static pressure type (FDUM) 176
(5) Ceiling suspended type (FDE) 182

(6) Wall mounted type (SRK) 186
(7) Effective range of cool/hot wind (Reference) 194
1.10.2 Electric wiring work installation 195
1.10.3 Installation of wired remote control (Option parts) 199
1.10.4 Installation of outdoor unit 211
1.10.5 Instructions for branching pipe set (DIS-WA1,WB1,TA1,TB1) 215
1.10.6 Safety precautions in handling air-conditioners with flammable refrigerants 218
1.11 TECHNICAL INFORMATION 221
(1) Ceiling cassette-4 way type (FDT) 221
(2) Ceiling cassette-4 way compact type (FDTC) 246
(3) Duct connected-High static pressure type (FDU) 257
(4) Duct connected-Low/Middle static pressure type (FDUM) 268
(5) Ceiling suspended type (FDE) 293
(6) Wall mounted type (SRK) 318

■How to read the model name



1.1 SPECIFICATIONS

(1) Ceiling cassette-4 way type (FDT)

(a) Single type

Item			Model	FDT100VNAWVH	
				Indoor unit **FDT100VH**	Outdoor unit **FDC100VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	2.73	
		Heating		2.54	
	Max power consumption			6.40	
	Running current	Cooling	A	13.2 / 13.8	
		Heating		12.4 / 13.0	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	90	
		Heating		89	
	EER	Cooling		3.66	
	COP	Heating		4.41	
	Sound power level	Cooling	dB(A)	62	69
		Heating			70
	Sound pressure level	Cooling		P-Hi: 47 Hi: 39 Me: 36 Lo: 30	54
		Heating		P-Hi: 47 Hi: 39 Me: 36 Lo: 29	55
	Silent mode sound pressure level			—	48 /44(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 298 x 840 x 840 Panel 35 x 950 x 950	845x970x370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 25 Panel 5	77
Compressor type & Q'ty				—	RMT5126SWP3 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x1
Fan motor (Starting method)			W	140 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 37 Hi: 26 Me: 23 Lo: 17	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-T-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52 (3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") Pipe ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-T-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

Item			Model	FDT100VSAWVH	
				Indoor unit **FDT100VH**	Outdoor unit **FDC100VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	2.73	
		Heating		2.54	
	Max power consumption			10.20	
	Running current	Cooling	A	4.2 / 4.4	
		Heating		3.9 / 4.1	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	94	
		Heating		93	
	EER	Cooling		3.66	
	COP	Heating		4.41	
	Sound power level	Cooling	dB(A)	62	69
		Heating			70
	Sound pressure level	Cooling		P-Hi: 47 Hi: 39 Me: 36 Lo: 30	54
		Heating		P-Hi: 47 Hi: 39 Me: 36 Lo: 29	55
	Silent mode sound pressure level			—	48 /44(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 298 x 840 x 840 Panel 35 x 950 x 950	845x970x370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 25 Panel 5	78
Compressor type & Q'ty				—	RMT5126SWP4 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x1
Fan motor (Starting method)			W	140 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 37 Hi: 26 Me: 23 Lo: 17	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-T-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52 (3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") Pipe ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires		Size x Core number		ϕ 1.6mm x3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-T-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.

PJF000Z589 B

Item			Model	FDT125VNAWVH	
				Indoor unit **FDT125VH**	Outdoor unit **FDC125VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	4.05	
		Heating		3.59	
	Max power consumption			6.40	
	Running current	Cooling	A	18.7 / 19.6	
		Heating		16.8 / 17.5	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	94	
		Heating		93	
	EER	Cooling		3.09	
	COP	Heating		3.90	
	Sound power level	Cooling	dB(A)	63	71
		Heating		64	
	Sound pressure level	Cooling		P-Hi: 48 Hi: 41 Me: 39 Lo: 31	54
		Heating		P-Hi: 48 Hi: 41 Me: 38 Lo: 31	56
	Silent mode sound pressure level			—	48 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 298 x 840 x 840 Panel 35 x 950 x 950	845x970x370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 25 Panel 5	77
Compressor type & Q'ty				—	RMT5126SWP3 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x1
Fan motor (Starting method)			W	140 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 38 Hi: 28 Me: 25 Lo: 18	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-T-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52 (3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") Pipe ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires		Size x Core number		ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-T-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

PJF000Z589 B

Item			Model	FDT125VSAWVH	
				Indoor unit **FDT125VH**	Outdoor unit **FDC125VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	4.05	
		Heating		3.59	
	Max power consumption			10.20	
	Running current	Cooling	A	6.2 / 6.5	
		Heating		5.5 / 5.7	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	94	
		Heating		95	
	EER	Cooling		3.09	
	COP	Heating		3.90	
	Sound power level	Cooling	dB(A)	63	71
		Heating		64	
	Sound pressure level	Cooling		P-Hi: 48 Hi: 41 Me: 39 Lo: 31	54
		Heating		P-Hi: 48 Hi: 41 Me: 38 Lo: 31	56
	Silent mode sound pressure level			—	48 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 298 x 840 x 840 Panel 35 x 950 x 950	845x970x370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 25 Panel 5	78
Compressor type & Q'ty				—	RMT5126SWP4 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x1
Fan motor (Starting method)			W	140 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 38 Hi: 28 Me: 25 Lo: 18	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-T-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52 (3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") Pipe ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires		Size x Core number		ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-T-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.

PJF000Z589 B

Item			Model	FDT140VNAWVH	
				Indoor unit **FDT140VH**	Outdoor unit **FDC140VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	4.79	
		Heating		4.18	
	Max power consumption			6.40	
	Running current	Cooling	A	21.5 / 22.4	
		Heating		18.5 / 19.4	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	97	
		Heating		98	
	EER	Cooling		2.84	
	COP	Heating		3.71	
	Sound power level	Cooling	dB(A)	63	72
		Heating		64	73
	Sound pressure level	Cooling		P-Hi: 48 Hi: 42 Me: 39 Lo: 32	56
		Heating		P-Hi: 48 Hi: 41 Me: 38 Lo: 31	58
	Silent mode sound pressure level			—	49 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 298 x 840 x 840 Panel 35 x 950 x 950	845x970x370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 25 Panel 5	77
Compressor type & Q'ty				—	RMT5126SWP3 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x1
Fan motor (Starting method)			W	140 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 38 Hi: 29 Me: 26 Lo: 19	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-T-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52 (3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") Pipe ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-T-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

PJF000Z589 B

Item			Model	FDT140VSAWVH	
				Indoor unit **FDT140VH**	Outdoor unit **FDC140VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	4.79	
		Heating		4.18	
	Max power consumption			10.20	
	Running current	Cooling	A	7.4 / 7.7	
		Heating		6.6 / 7.0	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	94	
		Heating		91	
	EER	Cooling		2.84	
	COP	Heating		3.71	
	Sound power level	Cooling	dB(A)	63	72
		Heating		64	73
	Sound pressure level	Cooling		P-Hi: 48 Hi: 42 Me: 39 Lo: 32	56
		Heating		P-Hi: 48 Hi: 41 Me: 38 Lo: 31	58
	Silent mode sound pressure level			—	49 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 298 x 840 x 840 Panel 35 x 950 x 950	845x970x370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 25 Panel 5	78
Compressor type & Q'ty				—	RMT5126SWP4 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x1
Fan motor (Starting method)			W	140 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 38 Hi: 29 Me: 26 Lo: 19	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-T-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-T-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.

PJF000Z589 B

(b) Twin type

Item			Model	FDT100VNAWPVH	
				Indoor unit **FDT50VH (2 units)**	Outdoor unit **FDC100VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	2.82	
		Heating		2.73	
	Max power consumption			6.40	
	Running current	Cooling	A	12.4 / 12.9	
		Heating		12.0 / 12.5	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		3.55	
	COP	Heating		4.11	
	Sound power level	Cooling	dB(A)	55	69
		Heating		56	70
	Sound pressure level	Cooling		P-Hi: 41 Hi: 33 Me: 30 Lo: 26	54
		Heating		P-Hi: 42 Hi: 33 Me: 28 Lo: 20	55
	Silent mode sound pressure level			—	48 /44(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 236 x 840 x 840 Panel 35 x 950 x 950	845x970x370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 19 Panel 5	77
Compressor type & Q'ty				—	RMT5126SWP3 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Pre - charged up to the piping length of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x1
Fan motor (Starting method)			W	50 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 22 Hi: 16 Me: 13 Lo: 10	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-T-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires		Size x Core number		ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-T-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U - Branch, ② : Pipe of Branch - I/U

Item			Model	FDT100VSAWPVH	
				Indoor unit **FDT50VH (2 units)**	Outdoor unit **FDC100VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	2.82	
		Heating		2.73	
	Max power consumption			10.20	
	Running current	Cooling	A	4.1 / 4.3	
		Heating		4.0 / 4.2	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	99	
		Heating		98	
	EER	Cooling		3.55	
	COP	Heating		4.11	
	Sound power level	Cooling	dB(A)	55	69
		Heating		56	70
	Sound pressure level	Cooling		P-Hi: 41 Hi: 33 Me: 30 Lo: 26	54
		Heating		P-Hi: 42 Hi: 33 Me: 28 Lo: 20	55
	Silent mode sound pressure level			—	48 /44(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 236 x 840 x 840 Panel 35 x 950 x 950	845x970x370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 19 Panel 5	78
Compressor type & Q'ty				—	RMT5126SWP4 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Pre - charged up to the piping length of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x1
Fan motor (Starting method)			W	50 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 22 Hi: 16 Me: 13 Lo: 10	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-T-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-T-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U - Branch, ② : Pipe of Branch - I/U

PJF000Z589 B

Item			Model	FDT125VNAWPVH	
				Indoor unit **FDT60VH (2 units)**	Outdoor unit **FDC125VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	3.79	
		Heating		3.31	
	Max power consumption			6.40	
	Running current	Cooling	A	16.6 / 17.4	
		Heating		14.5 / 15.2	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		3.30	
	COP	Heating		4.23	
	Sound power level	Cooling	dB(A)	58	71
		Heating		59	
	Sound pressure level	Cooling		P-Hi: 44 Hi: 34 Me: 30 Lo: 27	54
		Heating		P-Hi: 44 Hi: 34 Me: 30 Lo: 20	56
	Silent mode sound pressure level			—	48 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 236 x 840 x 840 Panel 35 x 950 x 950	845x970x370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 21 Panel 5	77
Compressor type & Q'ty				—	RMT5126SWP3 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Pre - charged up to the piping length of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x1
Fan motor (Starting method)			W	50 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 26 Hi: 17 Me: 14 Lo: 11	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-T-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires		Size x Core number		ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-T-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U - Branch, ② : Pipe of Branch - I/U

PJF000Z589 B

Item			Model	FDT125VSAWPVH	
				Indoor unit **FDT60VH (2 units)**	Outdoor unit **FDC125VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	3.79	
		Heating		3.31	
	Max power consumption			10.20	
	Running current	Cooling	A	5.5 / 5.8	
		Heating		4.8 / 5.1	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		3.30	
	COP	Heating		4.23	
	Sound power level	Cooling	dB(A)	58	71
		Heating		59	
	Sound pressure level	Cooling		P-Hi: 44 Hi: 34 Me: 30 Lo: 27	54
		Heating		P-Hi: 44 Hi: 34 Me: 30 Lo: 20	56
	Silent mode sound pressure level			—	48 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 236 x 840 x 840 Panel 35 x 950 x 950	845x970x370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 21 Panel 5	78
Compressor type & Q'ty				—	RMT5126SWP4 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Pre - charged up to the piping length of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x1
Fan motor (Starting method)			W	50 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 26 Hi: 17 Me: 14 Lo: 11	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-T-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires		Size x Core number		ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-T-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U - Branch, ② : Pipe of Branch - I/U

PJF000Z589 B

Item			Model	FDT140VNAWPVH	
				Indoor unit **FDT71VH (2 units)**	Outdoor unit **FDC140VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	4.22	
		Heating		3.57	
	Max power consumption			6.40	
	Running current	Cooling	A	18.5 / 19.4	
		Heating		15.7 / 16.4	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		3.22	
	COP	Heating		4.34	
	Sound power level	Cooling	dB(A)	59	72
		Heating		60	73
	Sound pressure level	Cooling		P-Hi: 46 Hi: 34 Me: 31 Lo: 26	56
		Heating			58
	Silent mode sound pressure level			—	49 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 236 x 840 x 840 Panel 35 x 950 x 950	845x970x370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 21 Panel 5	77
Compressor type & Q'ty				—	RMT5126SWP3 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Pre - charged up to the piping length of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x1
Fan motor (Starting method)			W	50 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 28 Hi: 18 Me: 15 Lo: 12	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-T-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ②ϕ 15.88(5/8")x1.0 ①ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires		Size x Core number		ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-T-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U - Branch, ② : Pipe of Branch - I/U

Item			Model	FDT140VSAWPVH	
				Indoor unit **FDT71VH (2 units)**	Outdoor unit **FDC140VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	4.22	
		Heating		3.57	
	Max power consumption			10.20	
	Running current	Cooling	A	6.2 / 6.5	
		Heating		5.2 / 5.5	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		3.22	
	COP	Heating		4.34	
	Sound power level	Cooling	dB(A)	59	72
		Heating		60	73
	Sound pressure level	Cooling		P-Hi: 46 Hi: 34 Me: 31 Lo: 26	56
		Heating			58
	Silent mode sound pressure level			—	49 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 236 x 840 x 840 Panel 35 x 950 x 950	845x970x370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 21 Panel 5	78
Compressor type & Q'ty				—	RMT5126SWP4 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Pre - charged up to the piping length of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x1
Fan motor (Starting method)			W	50 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 28 Hi: 18 Me: 15 Lo: 12	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-T-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ②ϕ 15.88(5/8")x1.0 ①ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires		Size x Core number		ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-T-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U - Branch, ② : Pipe of Branch - I/U

PJF000Z589 B

(c) Triple type

Item			Model	FDT140VNAWTVH	
				Indoor unit **FDT50VH (3 units)**	Outdoor unit **FDC140VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	4.22	
		Heating		3.57	
	Max power consumption			6.40	
	Running current	Cooling	A	18.5 / 19.4	
		Heating		15.7 / 16.4	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		3.22	
	COP	Heating		3.88	
	Sound power level	Cooling	dB(A)	55	72
		Heating		56	73
	Sound pressure level	Cooling		P-Hi: 41 Hi: 33 Me: 30 Lo: 26	56
		Heating		P-Hi: 42 Hi: 33 Me: 28 Lo: 20	58
	Silent mode sound pressure level			—	49 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 236 x 840 x 840 Panel 35 x 950 x 950	845x970x370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 19 Panel 5	77
Compressor type & Q'ty				—	RMT5126SWP3 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Pre - charged up to the piping length of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x1
Fan motor (Starting method)			W	50 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 22 Hi: 16 Me: 13 Lo: 10	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-T-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-T-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is three indoor units are combined and run together.
(7) Branching pipe set "DIS-TB1G"×1(Option). ① : Pipe of O/U - Branch, ② : Pipe of Branch - I/U

Item			Model	FDT140VSAWTVH	
				Indoor unit **FDT50VH (3 units)**	Outdoor unit **FDC140VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	4.22	
		Heating		3.57	
	Max power consumption			10.20	
	Running current	Cooling	A	6.2 / 6.5	
		Heating		5.2 / 5.5	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		3.22	
	COP	Heating		3.88	
	Sound power level	Cooling	dB(A)	55	72
		Heating		56	73
	Sound pressure level	Cooling		P-Hi: 41 Hi: 33 Me: 30 Lo: 26	56
		Heating		P-Hi: 42 Hi: 33 Me: 28 Lo: 20	58
	Silent mode sound pressure level			—	49 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 236 x 840 x 840 Panel 35 x 950 x 950	845x970x370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 19 Panel 5	78
Compressor type & Q'ty				—	RMT5126SWP4 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Pre - charged up to the piping length of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x1
Fan motor (Starting method)			W	50 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 22 Hi: 16 Me: 13 Lo: 10	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-T-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires		Size x Core number		ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-T-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is three indoor units are combined and run together.
(7) Branching pipe set "DIS-TB1G"×1(Option). ① : Pipe of O/U - Branch, ② : Pipe of Branch - I/U

(2) Ceiling cassette-4 way compact type (FDTC)

(a) Twin type

Item			Model	FDTC100VNAWPVH	
				Indoor unit **FDTC50VH (2 units)**	Outdoor unit **FDC100VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	3.15	
		Heating		3.05	
	Max power consumption			6.40	
	Running current	Cooling	A	13.8 / 14.5	
		Heating		13.4 / 14.0	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		3.17	
	COP	Heating		3.67	
	Sound power level	Cooling	dB(A)	59	69
		Heating			70
	Sound pressure level	Cooling		P-Hi: 44 Hi 40 Me: 35 Lo: 27	54
		Heating			55
	Silent mode sound pressure level			—	48 / 44 (Normal / Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 248 x 570 x 570 Panel 10 x 620 x 620	845x970x370
Exterior appearance (Munsell color) (RAL color)				Fine snow (8.0Y9.3/0.1) near equivalent (RAL 9001) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 14 Panel 2.5	77
Compressor type & Q'ty				—	RMT5126SWP3 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x 1
Fan motor (Starting method)			W	50 < Direct line start >	86 (Direct line start)
Air flow		Cooling	m^3/min	P-Hi: 13 Hi: 11 Me: 9 Lo: 7	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A, RC-E5, RCH-E3 Wireless : RCN-TC-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		I/U ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 O/U ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher) / Max.15 (Outdoor unit is lower)	
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				OA Spacer : TC-OAS-E2 , TC-OAD-E , Motion sensor : LB-TC-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27℃	19℃	35℃	24℃	ISO5151-T1
Heating	20℃	—	7℃	6℃	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U - Branch, ② : Pipe of Branch - I/U

Item			Model	FDTC100VSAWPVH	
				Indoor unit **FDTC50VH (2 units)**	Outdoor unit **FDC100VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	3.15	
		Heating		3.05	
	Max power consumption			10.20	
	Running current	Cooling	A	4.6 / 4.9	
		Heating		4.4 / 4.7	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	98	
		Heating		99	
	EER	Cooling		3.17	
	COP	Heating		3.67	
	Sound power level	Cooling	dB(A)	59	69
		Heating			70
	Sound pressure level	Cooling		P-Hi: 44 Hi 40 Me: 35 Lo: 27	54
		Heating			55
	Silent mode sound pressure level			—	48 / 44 (Normal / Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 248 x 570 x 570 Panel 10 x 620 x 620	845x970x370
Exterior appearance (Munsell color) (RAL color)				Fine snow (8.0Y9.3/0.1) near equivalent (RAL 9001) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 14 Panel 2.5	78
Compressor type & Q'ty				—	RMT5126SWP4 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x 1
Fan motor (Starting method)			W	50 < Direct line start >	86 (Direct line start)
Air flow		Cooling	m^3/min	P-Hi: 13 Hi: 11 Me: 9 Lo: 7	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A, RC-E5, RCH-E3 Wireless : RCN-TC-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		I/U ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 O/U ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher) / Max.15 (Outdoor unit is lower)	
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				OA Spacer : TC-OAS-E2 , TC-OAD-E , Motion sensor : LB-TC-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27℃	19℃	35℃	24℃	ISO5151-T1
Heating	20℃	—	7℃	6℃	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U - Branch, ② : Pipe of Branch - I/U

Item			Model	FDTC125VNAWPVH	
				Indoor unit **FDTC60VH (2 units)**	Outdoor unit **FDC125VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	4.90	
		Heating		4.30	
	Max power consumption			6.40	
	Running current	Cooling	A	21.5 / 22.5	
		Heating		18.9 / 19.7	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		2.55	
	COP	Heating		3.26	
	Sound power level	Cooling	dB(A)	59	71
		Heating			
	Sound pressure level	Cooling		P-Hi: 44 Hi 40 Me: 35 Lo: 27	54
		Heating			56
	Silent mode sound pressure level			—	48 / 45 (Normal / Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 248 x 570 x 570 Panel 10 x 620 x 620	845x970x370
Exterior appearance (Munsell color) (RAL color)				Fine snow (8.0Y9.3/0.1) near equivalent (RAL 9001) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 14 Panel 2.5	77
Compressor type & Q'ty				—	RMT5126SWP3 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x 1
Fan motor (Starting method)			W	50 < Direct line start >	86 (Direct line start)
Air flow		Cooling	m^3/min	P-Hi: 13 Hi: 11 Me: 9 Lo: 7	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A, RC-E5, RCH-E3 Wireless : RCN-TC-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		I/U ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 O/U ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher) / Max.15 (Outdoor unit is lower)	
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				OA Spacer : TC-OAS-E2 , TC-OAD-E , Motion sensor : LB-TC-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27℃	19℃	35℃	24℃	ISO5151-T1
Heating	20℃	—	7℃	6℃	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U - Branch, ② : Pipe of Branch - I/U

Item			Model	FDTC125VSAWPVH	
				Indoor unit **FDTC60VH (2 units)**	Outdoor unit **FDC125VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	4.90	
		Heating		4.30	
	Max power consumption			10.20	
	Running current	Cooling	A	7.1 / 7.5	
		Heating		6.3 / 6.6	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		2.55	
	COP	Heating		3.26	
	Sound power level	Cooling	dB(A)	59	71
		Heating			
	Sound pressure level	Cooling		P-Hi: 44 Hi 40 Me: 35 Lo: 27	54
		Heating			56
	Silent mode sound pressure level			—	48 / 45 (Normal / Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 248 x 570 x 570 Panel 10 x 620 x 620	845x970x370
Exterior appearance (Munsell color) (RAL color)				Fine snow (8.0Y9.3/0.1) near equivalent (RAL 9001) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 14 Panel 2.5	78
Compressor type & Q'ty				—	RMT5126SWP4 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x 1
Fan motor (Starting method)			W	50 < Direct line start >	86 (Direct line start)
Air flow		Cooling	m^3/min	P-Hi: 13 Hi: 11 Me: 9 Lo: 7	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A, RC-E5, RCH-E3 Wireless : RCN-TC-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		I/U ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 O/U ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher) / Max.15 (Outdoor unit is lower)	
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				OA Spacer : TC-OAS-E2 , TC-OAD-E , Motion sensor : LB-TC-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27℃	19℃	35℃	24℃	ISO5151-T1
Heating	20℃	—	7℃	6℃	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U - Branch, ② : Pipe of Branch - I/U

PJF000Z517 B

(b) Triple type

Item			Model	FDTC140VNAWTVH	
				Indoor unit **FDTC50VH (3 units)**	Outdoor unit **FDC140VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	4.75	
		Heating		4.60	
	Max power consumption			6.40	
	Running current	Cooling	A	20.9 / 21.8	
		Heating		20.2 / 21.1	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		2.86	
	COP	Heating		3.37	
	Sound power level	Cooling	dB(A)	59	72
		Heating			73
	Sound pressure level	Cooling		P-Hi: 44 Hi 40 Me: 35 Lo: 27	56
		Heating			58
	Silent mode sound pressure level			—	49 / 45 (Normal / Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 248 x 570 x 570 Panel 10 x 620 x 620	845x970x370
Exterior appearance (Munsell color) (RAL color)				Fine snow (8.0Y9.3/0.1) near equivalent (RAL 9001) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 14 Panel 2.5	77
Compressor type & Q'ty				—	RMT5126SWP3 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x 1
Fan motor (Starting method)			W	50 < Direct line start >	86 (Direct line start)
Air flow		Cooling	m^3/min	P-Hi: 13 Hi: 11 Me: 9 Lo: 7	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A, RC-E5, RCH-E3 Wireless : RCN-TC-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		I/U ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 O/U ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher) / Max.15 (Outdoor unit is lower)	
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				OA Spacer : TC-OAS-E2 , TC-OAD-E , Motion sensor : LB-TC-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27℃	19℃	35℃	24℃	ISO5151-T1
Heating	20℃	—	7℃	6℃	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U - Branch, ② : Pipe of Branch - I/U

Item			Model	FDTC140VSAWTVH	
				Indoor unit **FDTC50VH (3 units)**	Outdoor unit **FDC140VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	4.75	
		Heating		4.60	
	Max power consumption			10.20	
	Running current	Cooling	A	6.9 / 7.3	
		Heating		6.7 / 7.1	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		2.86	
	COP	Heating		3.37	
	Sound power level	Cooling	dB(A)	59	72
		Heating			73
	Sound pressure level	Cooling		P-Hi: 44 Hi 40 Me: 35 Lo: 27	56
		Heating			58
	Silent mode sound pressure level			—	49 / 45 (Normal / Silent)
Exterior dimensions (Height x Width x Depth)			mm	Unit 248 x 570 x 570 Panel 10 x 620 x 620	845x970x370
Exterior appearance (Munsell color) (RAL color)				Fine snow (8.0Y9.3/0.1) near equivalent (RAL 9001) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	Unit 14 Panel 2.5	78
Compressor type & Q'ty				—	RMT5126SWP4 x 1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Turbo fan x1	Propeller fan x 1
Fan motor (Starting method)			W	50 < Direct line start >	86 (Direct line start)
Air flow		Cooling	m^3/min	P-Hi: 13 Hi: 11 Me: 9 Lo: 7	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x1(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A, RC-E5, RCH-E3 Wireless : RCN-TC-5AW-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		I/U ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 O/U ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher) / Max.15 (Outdoor unit is lower)	
	Drain hose			Hose connectable with VP25(O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 850	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				OA Spacer : TC-OAS-E2 , TC-OAD-E , Motion sensor : LB-TC-5W-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27℃	19℃	35℃	24℃	ISO5151-T1
Heating	20℃	—	7℃	6℃	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U - Branch, ② : Pipe of Branch - I/U

(3) Duct connected-High static pressure type (FDU)
Single type

Item			Model	FDU100VNAWVH	
				Indoor unit **FDU100VH**	Outdoor unit **FDC100VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	2.99	
		Heating		2.66	
	Max power consumption			6.40	
	Running current	Cooling	A	14.3 / 14.9	
		Heating		12.7 / 13.3	
	Inrush current, max current			5, 26	
	Power factor	Cooling	%	91	
		Heating		91	
	EER	Cooling		3.35	
	COP	Heating		4.21	
	Sound power level	Cooling	dB(A)	65	69
		Heating			70
	Sound pressure level	Cooling		P-Hi: 44 Hi: 38 Me: 36 Lo: 30	54
		Heating			55
	Silent mode sound pressure level			—	48 / 44(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 1,370 × 740	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	54	77
Compressor type & Q'ty				—	RMT5126SWP3 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×3	Propeller fan ×1
Fan motor (Starting method)			W	100 + 130 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 36 Hi: 28 Me: 25 Lo: 19	75
		Heating			73
Available external static pressure			Pa	Standard: 60 Max: 200	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires		Size x Core number		ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27℃	19℃	35℃	24℃	60Pa	ISO5151-T1
Heating	20℃	—	7℃	6℃		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) When wireless remote control is used, fan is 3 speed setting (Hi-Me-Lo) only.
(6) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(7) The factory E.S.P. setting is set within the range of 80 - 150 Pa.If SW8-4 is turned to "ON",
E.S.P. setting range can be changed to 10 - 200 Pa.(For RC-EX3A and RC-E5 only)

Item			Model	FDU100VSAWVH	
				Indoor unit **FDU100VH**	Outdoor unit **FDC100VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	2.99	
		Heating		2.66	
	Max power consumption			10.20	
	Running current	Cooling	A	4.6 / 4.9	
		Heating		4.1 / 4.3	
	Inrush current, max current			5, 17	
	Power factor	Cooling	%	93	
		Heating		93	
	EER	Cooling		3.35	
	COP	Heating		4.21	
	Sound power level	Cooling	dB(A)	65	69
		Heating			70
	Sound pressure level	Cooling		P-Hi: 44 Hi: 38 Me: 36 Lo: 30	54
		Heating			55
	Silent mode sound pressure level			—	48 / 44(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 1,370 × 740	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	54	78
Compressor type & Q'ty				—	RMT5126SWP4 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×3	Propeller fan ×1
Fan motor (Starting method)			W	100 + 130 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 36 Hi: 28 Me: 25 Lo: 19	75
		Heating			73
Available external static pressure			Pa	Standard: 60 Max: 200	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27℃	19℃	35℃	24℃	60Pa	ISO5151-T1
Heating	20℃	—	7℃	6℃		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) When wireless remote control is used, fan is 3 speed setting (Hi-Me-Lo) only.
(6) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(7) The factory E.S.P. setting is set within the range of 80 - 150 Pa.If SW8-4 is turned to "ON",
E.S.P. setting range can be changed to 10 - 200 Pa.(For RC-EX3A and RC-E5 only)

Item			Model	FDU125VNAWVH	
				Indoor unit **FDU125VH**	Outdoor unit **FDC125VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	4.36	
		Heating		3.69	
	Max power consumption			6.40	
	Running current	Cooling	A	20.4 / 21.3	
		Heating		17.8 / 18.6	
	Inrush current, max current			5, 26	
	Power factor	Cooling	%	93	
		Heating		90	
	EER	Cooling		2.87	
	COP	Heating		3.79	
	Sound power level	Cooling	dB(A)	67	71
		Heating			
	Sound pressure level	Cooling		P-Hi: 45 Hi: 40 Me: 34 Lo: 29	54
		Heating			56
	Silent mode sound pressure level			—	48 / 45 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 1,370 × 740	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	54	77
Compressor type & Q'ty				—	RMT5126SWP3 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×3	Propeller fan ×1
Fan motor (Starting method)			W	100 + 200 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 39 Hi: 32 Me: 26 Lo: 20	75
		Heating			73
Available external static pressure			Pa	Standard: 60 Max: 200	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27℃	19℃	35℃	24℃	60Pa	ISO5151-T1
Heating	20℃	—	7℃	6℃		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) When wireless remote control is used, fan is 3 speed setting (Hi-Me-Lo) only.
(6) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(7) The factory E.S.P. setting is set within the range of 80 - 150 Pa.If SW8-4 is turned to "ON",
E.S.P. setting range can be changed to 10 - 200 Pa.(For RC-EX3A and RC-E5 only)

Item			Model	FDU125VSAWVH	
				Indoor unit **FDU125VH**	Outdoor unit **FDC125VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	4.36	
		Heating		3.69	
	Max power consumption			10.20	
	Running current	Cooling	A	6.8 / 7.2	
		Heating		5.9 / 6.2	
	Inrush current, max current			5, 17	
	Power factor	Cooling	%	92	
		Heating		90	
	EER	Cooling		2.87	
	COP	Heating		3.79	
	Sound power level	Cooling	dB(A)	67	71
		Heating			
	Sound pressure level	Cooling		P-Hi: 45 Hi: 40 Me: 34 Lo: 29	54
		Heating			56
	Silent mode sound pressure level			—	48 / 45 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 1,370 × 740	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	54	78
Compressor type & Q'ty				—	RMT5126SWP4 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×3	Propeller fan ×1
Fan motor (Starting method)			W	100 + 200 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 39 Hi: 32 Me: 26 Lo: 20	75
		Heating			73
Available external static pressure			Pa	Standard: 60 Max: 200	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires		Size x Core number		ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27℃	19℃	35℃	24℃	60Pa	ISO5151-T1
Heating	20℃	—	7℃	6℃		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) When wireless remote control is used, fan is 3 speed setting (Hi-Me-Lo) only.
(6) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(7) The factory E.S.P. setting is set within the range of 80 - 150 Pa.If SW8-4 is turned to "ON", E.S.P. setting range can be changed to 10 - 200 Pa.(For RC-EX3A and RC-E5 only)

Item			Model	FDU140VNAWVH	
				Indoor unit **FDU140VH**	Outdoor unit **FDC140VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	5.13	
		Heating		4.21	
	Max power consumption			6.40	
	Running current	Cooling	A	23.7 / 24.8	
		Heating		20.3 / 21.3	
	Inrush current, max current			5, 27	
	Power factor	Cooling	%	94	
		Heating		90	
	EER	Cooling		2.65	
	COP	Heating		3.68	
	Sound power level	Cooling	dB(A)	70	72
		Heating			73
	Sound pressure level	Cooling		P-Hi: 47 Hi: 40 Me: 35 Lo: 30	56
		Heating			58
	Silent mode sound pressure level			—	49 / 45 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 1,370 × 740	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	54	77
Compressor type & Q'ty				—	RMT5126SWP3 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×3	Propeller fan ×1
Fan motor (Starting method)			W	100 + 200 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 48 Hi: 35 Me: 28 Lo: 22	75
		Heating			73
Available external static pressure			Pa	Standard: 60 Max: 200	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires		Size x Core number		ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27℃	19℃	35℃	24℃	60Pa	ISO5151-T1
Heating	20℃	—	7℃	6℃		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) When wireless remote control is used, fan is 3 speed setting (Hi-Me-Lo) only.
(6) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(7) The factory E.S.P. setting is set within the range of 80 - 150 Pa.If SW8-4 is turned to "ON",
E.S.P. setting range can be changed to 10 - 200 Pa.(For RC-EX3A and RC-E5 only)

Item			Model	FDU140VSAWVH	
				Indoor unit **FDU140VH**	Outdoor unit **FDC140VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	5.13	
		Heating		4.21	
	Max power consumption			10.20	
	Running current	Cooling	A	8.1 / 8.6	
		Heating		6.8 / 7.2	
	Inrush current, max current			5, 18	
	Power factor	Cooling	%	91	
		Heating		89	
	EER	Cooling		2.65	
	COP	Heating		3.68	
	Sound power level	Cooling	dB(A)	70	72
		Heating			73
	Sound pressure level	Cooling		P-Hi: 47 Hi: 40 Me: 35 Lo: 30	56
		Heating			58
	Silent mode sound pressure level			—	49 / 45 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 1,370 × 740	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	54	78
Compressor type & Q'ty				—	RMT5126SWP4 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×3	Propeller fan ×1
Fan motor (Starting method)			W	100 + 200 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 48 Hi: 35 Me: 28 Lo: 22	75
		Heating			73
Available external static pressure			Pa	Standard: 60 Max: 200	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping		m	—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mmx 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27℃	19℃	35℃	24℃	60Pa	ISO5151-T1
Heating	20℃	—	7℃	6℃		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) When wireless remote control is used, fan is 3 speed setting (Hi-Me-Lo) only.
(6) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(7) The factory E.S.P. setting is set within the range of 80 - 150 Pa.If SW8-4 is turned to "ON",
E.S.P. setting range can be changed to 10 - 200 Pa.(For RC-EX3A and RC-E5 only)

(4) Duct connected-Low / Middle static pressure type (FDUM)

(a) Single type

Item			Model	FDUM100VNAWVH	
				Indoor unit **FDUM100VH**	Outdoor unit **FDC100VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	2.99	
		Heating		2.66	
	Max power consumption			6.40	
	Running current	Cooling	A	14.3 / 14.9	
		Heating		12.7 / 13.3	
	Inrush current, max current			5, 26	
	Power factor	Cooling	%	91	
		Heating		91	
	EER	Cooling		3.35	
	COP	Heating		4.21	
	Sound power level	Cooling	dB(A)	65	69
		Heating			70
	Sound pressure level	Cooling		P-Hi: 44 Hi: 38 Me: 36 Lo: 30	54
		Heating			55
	Silent mode sound pressure level			—	48 / 44 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 1,370 × 740	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	54	77
Compressor type & Q'ty				—	RMT5126SWP3 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×3	Propeller fan ×1
Fan motor (Starting method)			W	100 + 130 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 36 Hi: 28 Me: 25 Lo: 19	75
		Heating			73
Available external static pressure			Pa	Standard: 60 Max: 100	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm×3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Filter set : UM-FL3EF , Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27°C	19°C	35°C	24°C	60Pa	ISO5151-T1
Heating	20°C	—	7°C	6°C		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Static pressure of option air filter "UM-FL3EF" is 5Pa initially.
(7) The external static pressure setting can be changed to 10-100Pa. (For RC-EX3A and RC-E5 only)

Item			Model	FDUM100VSAWVH	
				Indoor unit **FDUM100VH**	Outdoor unit **FDC100VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	2.99	
		Heating		2.66	
	Max power consumption			10.20	
	Running current	Cooling	A	4.6 / 4.9	
		Heating		4.1 / 4.3	
	Inrush current, max current			5, 17	
	Power factor	Cooling	%	93	
		Heating		93	
	EER	Cooling		3.35	
	COP	Heating		4.21	
	Sound power level	Cooling	dB(A)	65	69
		Heating			70
	Sound pressure level	Cooling		P-Hi: 44 Hi: 38 Me: 36 Lo: 30	54
		Heating			55
	Silent mode sound pressure level			—	48 / 44 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 1,370 × 740	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	54	78
Compressor type & Q'ty				—	RMT5126SWP4 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×3	Propeller fan ×1
Fan motor (Starting method)			W	100 + 130 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 36 Hi: 28 Me: 25 Lo: 19	75
		Heating			73
Available external static pressure			Pa	Standard: 60 Max: 100	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm×3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Filter set : UM-FL3EF , Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27°C	19°C	35°C	24°C	60Pa	ISO5151-T1
Heating	20°C	—	7°C	6°C		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Static pressure of option air filter "UM-FL3EF" is 5Pa initially.
(7) The external static pressure setting can be changed to 10-100Pa. (For RC-EX3A and RC-E5 only)

PJG000Z491 B

Item			Model	FDUM125VNAWVH	
				Indoor unit **FDUM125VH**	Outdoor unit **FDC125VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	4.36	
		Heating		3.69	
	Max power consumption			6.40	
	Running current	Cooling	A	20.4 / 21.3	
		Heating		17.8 / 18.6	
	Inrush current, max current			5, 26	
	Power factor	Cooling	%	93	
		Heating		90	
	EER	Cooling		2.87	
	COP	Heating		3.79	
	Sound power level	Cooling	dB(A)	67	71
		Heating			
	Sound pressure level	Cooling		P-Hi: 45 Hi: 40 Me: 34 Lo: 29	54
		Heating			56
	Silent mode sound pressure level			—	48 / 45 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 1,370 × 740	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	54	77
Compressor type & Q'ty				—	RMT5126SWP3 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×3	Propeller fan ×1
Fan motor (Starting method)			W	100 + 200 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 39 Hi: 32 Me: 26 Lo: 20	75
		Heating			73
Available external static pressure			Pa	Standard: 60 Max: 100	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm×3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Filter set : UM-FL3EF , Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27°C	19°C	35°C	24°C	60Pa	ISO5151-T1
Heating	20°C	—	7°C	6°C		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Static pressure of option air filter "UM-FL3EF" is 5Pa initially.
(7) The external static pressure setting can be changed to 10-100Pa. (For RC-EX3A and RC-E5 only)

PJG000Z491 B

Item			Model	FDUM125VSAWVH	
				Indoor unit **FDUM125VH**	Outdoor unit **FDC125VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	4.36	
		Heating		3.69	
	Max power consumption			10.20	
	Running current	Cooling	A	6.8 / 7.2	
		Heating		5.9 / 6.2	
	Inrush current, max current			5, 17	
	Power factor	Cooling	%	92	
		Heating		90	
	EER	Cooling		2.87	
	COP	Heating		3.79	
	Sound power level	Cooling	dB(A)	67	71
		Heating			
	Sound pressure level	Cooling		P-Hi: 45 Hi: 40 Me: 34 Lo: 29	54
		Heating			56
	Silent mode sound pressure level			—	48 / 45 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 1,370 × 740	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	54	78
Compressor type & Q'ty				—	RMT5126SWP4 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×3	Propeller fan ×1
Fan motor (Starting method)			W	100 + 200 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 39 Hi: 32 Me: 26 Lo: 20	75
		Heating			73
Available external static pressure			Pa	Standard: 60 Max: 100	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm×3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Filter set : UM-FL3EF , Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		External static pressure of indoor unit	Standards
	DB	WB	DB	WB		
Cooling	27°C	19°C	35°C	24°C	60Pa	ISO5151-T1
Heating	20°C	—	7°C	6°C		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Static pressure of option air filter "UM-FL3EF" is 5Pa initially.
(7) The external static pressure setting can be changed to 10-100Pa. (For RC-EX3A and RC-E5 only)

PJG000Z491 B

Item			Model	FDUM140VNAWVH	
				Indoor unit **FDUM140VH**	Outdoor unit **FDC140VNA-W**
Power source				1 Phase, 220-240V - 50Hz / 220V - 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	5.13	
		Heating		4.21	
	Max power consumption			6.40	
	Running current	Cooling	A	23.7 / 24.8	
		Heating		20.3 / 21.3	
	Inrush current, max current			5, 27	
	Power factor	Cooling	%	94	
		Heating		90	
	EER	Cooling		2.65	
	COP	Heating		3.68	
	Sound power level	Cooling	dB(A)	70	72
		Heating			73
	Sound pressure level	Cooling		P-Hi: 47 Hi: 40 Me: 35 Lo: 30	56
		Heating			58
	Silent mode sound pressure level			—	49 / 45 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 1,370 × 740	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	54	77
Compressor type & Q'ty				—	RMT5126SWP3 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×3	Propeller fan ×1
Fan motor (Starting method)			W	100 + 200 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 48 Hi: 35 Me: 28 Lo: 22	75
		Heating			73
Available external static pressure			Pa	Standard: 60 Max: 100	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm×3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Filter set : UM-FL3EF , Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27°C	19°C	35°C	24°C	60Pa	ISO5151-T1
Heating	20°C	—	7°C	6°C		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Static pressure of option air filter "UM-FL3EF" is 5Pa initially.
(7) The external static pressure setting can be changed to 10-100Pa. (For RC-EX3A and RC-E5 only)

PJG000Z491 B

Item			Model	FDUM140VSAWVH	
				Indoor unit **FDUM140VH**	Outdoor unit **FDC140VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	5.13	
		Heating		4.21	
	Max power consumption			10.20	
	Running current	Cooling	A	8.1 / 8.6	
		Heating		6.8 / 7.2	
	Inrush current, max current			5, 18	
	Power factor	Cooling	%	91	
		Heating		89	
	EER	Cooling		2.65	
	COP	Heating		3.68	
	Sound power level	Cooling	dB(A)	70	72
		Heating			73
	Sound pressure level	Cooling		P-Hi: 47 Hi: 40 Me: 35 Lo: 30	56
		Heating			58
	Silent mode sound pressure level			—	49 / 45 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 1,370 × 740	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	54	78
Compressor type & Q'ty				—	RMT5126SWP4 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×3	Propeller fan ×1
Fan motor (Starting method)			W	100 + 200 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 48 Hi: 35 Me: 28 Lo: 22	75
		Heating			73
Available external static pressure			Pa	Standard: 60 Max: 100	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm×3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Filter set : UM-FL3EF , Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27°C	19°C	35°C	24°C	60Pa	ISO5151-T1
Heating	20°C	—	7°C	6°C		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Static pressure of option air filter "UM-FL3EF" is 5Pa initially.
(7) The external static pressure setting can be changed to 10-100Pa. (For RC-EX3A and RC-E5 only)

PJG000Z491 B

(b) Twin type

Item			Model	FDUM100VNAWPVH	
				Indoor unit **FDUM50VH (2 units)**	Outdoor unit **FDC100VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	3.25	
		Heating		3.04	
	Max power consumption			6.40	
	Running current	Cooling	A	14.6 / 15.2	
		Heating		13.6 / 14.2	
	Inrush current, max current			5, 26	
	Power factor	Cooling	%	97	
		Heating		97	
	EER	Cooling		3.08	
	COP	Heating		3.68	
	Sound power level	Cooling	dB(A)	60	69
		Heating			70
	Sound pressure level	Cooling		P-Hi: 37 Hi: 32 Me: 29 Lo: 26	54
		Heating			55
	Silent mode sound pressure level			—	48 / 44 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 750 × 635	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	29	77
Compressor type & Q'ty				—	RMT5126SWP3 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×1	Propeller fan ×1
Fan motor (Starting method)			W	100 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 13 Hi: 10 Me: 9 Lo: 8	75
		Heating			73
Available external static pressure			Pa	Standard: 35 Max: 100	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm×3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Filter set : UM-FL1EF , Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27℃	19℃	35℃	24℃	35Pa	ISO5151-T1
Heating	20℃	—	7℃	6℃		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U
(8) Static pressure of option air filter "UM-FL1EF" is 5Pa initially.
(9) The external static pressure setting can be changed to 10-100Pa. (For RC-EX3A and RC-E5 only)

Item			Model	FDUM100VSAWPVH	
				Indoor unit **FDUM50VH (2 units)**	Outdoor unit **FDC100VSA-W**
Power source				3 Phase, 380-415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	3.25	
		Heating		3.04	
	Max power consumption			10.20	
	Running current	Cooling	A	4.9 / 5.2	
		Heating		4.6 / 4.8	
	Inrush current, max current			5, 17	
	Power factor	Cooling	%	95	
		Heating		96	
	EER	Cooling		3.08	
	COP	Heating		3.68	
	Sound power level	Cooling	dB(A)	60	69
		Heating			70
	Sound pressure level	Cooling		P-Hi: 37 Hi: 32 Me: 29 Lo: 26	54
		Heating			55
	Silent mode sound pressure level			—	48 / 44 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 750 × 635	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	29	78
Compressor type & Q'ty				—	RMT5126SWP4 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×1	Propeller fan ×1
Fan motor (Starting method)			W	100 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 13 Hi: 10 Me: 9 Lo: 8	75
		Heating			73
Available external static pressure			Pa	Standard: 35 Max: 100	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm×3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Filter set : UM-FL1EF , Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27℃	19℃	35℃	24℃	35Pa	ISO5151-T1
Heating	20℃	—	7℃	6℃		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U
(8) Static pressure of option air filter "UM-FL1EF" is 5Pa initially.
(9) The external static pressure setting can be changed to 10-100Pa. (For RC-EX3A and RC-E5 only)

Item			Model	FDUM125VNAWPVH	
				Indoor unit **FDUM60VH (2 units)**	Outdoor unit **FDC125VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	4.53	
		Heating		3.52	
	Max power consumption			6.40	
	Running current	Cooling	A	20.3 / 21.2	
		Heating		15.8 / 16.5	
	Inrush current, max current			5, 26	
	Power factor	Cooling	%	97	
		Heating		97	
	EER	Cooling		2.76	
	COP	Heating		3.98	
	Sound power level	Cooling	dB(A)	60	71
		Heating			
	Sound pressure level	Cooling		P-Hi: 36 Hi: 31 Me: 28 Lo: 25	54
		Heating			56
	Silent mode sound pressure level			—	48 / 45 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 950 × 635	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	34	77
Compressor type & Q'ty				—	RMT5126SWP3 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×2	Propeller fan ×1
Fan motor (Starting method)			W	130 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 20 Hi: 15 Me: 13 Lo: 10	75
		Heating			73
Available external static pressure			Pa	Standard: 35 Max: 100	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm×3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Filter set : UM-FL2EF , Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27℃	19℃	35℃	24℃	35Pa	ISO5151-T1
Heating	20℃	—	7℃	6℃		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U
(8) Static pressure of option air filter "UM-FL2EF" is 5Pa initially.
(9) The external static pressure setting can be changed to 10-100Pa. (For RC-EX3A and RC-E5 only)

PJG000Z491 B

Item			Model	FDUM125VSAWPVH	
				Indoor unit **FDUM60VH (2 units)**	Outdoor unit **FDC125VSA-W**
Power source				3 Phase, 380-415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	4.53	
		Heating		3.52	
	Max power consumption			10.20	
	Running current	Cooling	A	6.7 / 7.0	
		Heating		5.2 / 5.5	
	Inrush current, max current			5, 17	
	Power factor	Cooling	%	98	
		Heating		97	
	EER	Cooling		2.76	
	COP	Heating		3.98	
	Sound power level	Cooling	dB(A)	60	71
		Heating			
	Sound pressure level	Cooling		P-Hi: 36 Hi: 31 Me: 28 Lo: 25	54
		Heating			56
	Silent mode sound pressure level			—	48 / 45 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 950 × 635	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	34	78
Compressor type & Q'ty				—	RMT5126SWP4 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×2	Propeller fan ×1
Fan motor (Starting method)			W	130 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 20 Hi: 15 Me: 13 Lo: 10	75
		Heating			73
Available external static pressure			Pa	Standard: 35 Max: 100	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm×3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Filter set : UM-FL2EF , Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27℃	19℃	35℃	24℃	35Pa	ISO5151-T1
Heating	20℃	—	7℃	6℃		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U
(8) Static pressure of option air filter "UM-FL2EF" is 5Pa initially.
(9) The external static pressure setting can be changed to 10-100Pa. (For RC-EX3A and RC-E5 only)

Item			Model	FDUM140VNAWTVH	
				Indoor unit **FDUM71VH (2 units)**	Outdoor unit **FDC140VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	5.02	
		Heating		4.20	
	Max power consumption			6.40	
	Running current	Cooling	A	22.5 / 23.5	
		Heating		18.8 / 19.7	
	Inrush current, max current			5, 27	
	Power factor	Cooling	%	97	
		Heating		97	
	EER	Cooling		2.71	
	COP	Heating		3.69	
	Sound power level	Cooling	dB(A)	65	72
		Heating			73
	Sound pressure level	Cooling		P-Hi: 38 Hi: 33 Me: 29 Lo: 25	56
		Heating			58
	Silent mode sound pressure level			—	49 / 45 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 950 × 635	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	34	77
Compressor type & Q'ty				—	RMT5126SWP3 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×2	Propeller fan ×1
Fan motor (Starting method)			W	130 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 24 Hi: 19 Me: 15 Lo: 10	75
		Heating			73
Available external static pressure			Pa	Standard: 35 Max: 100	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ②ϕ 15.88(5/8")x1.0 ①ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm×3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Filter set : UM-FL2EF , Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27℃	19℃	35℃	24℃	35Pa	ISO5151-T1
Heating	20℃	—	7℃	6℃		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U
(8) Static pressure of option air filter "UM-FL2EF" is 5Pa initially.
(9) The external static pressure setting can be changed to 10-100Pa. (For RC-EX3A and RC-E5 only)

Item			Model	FDUM140VSAWPVH	
				Indoor unit **FDUM71VH (2 units)**	Outdoor unit **FDC140VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60H	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	5.02	
		Heating		4.20	
	Max power consumption			10.20	
	Running current	Cooling	A	7.5 / 7.9	
		Heating		6.1 / 6.4	
	Inrush current, max current			5, 18	
	Power factor	Cooling	%	97	
		Heating		99	
	EER	Cooling		2.71	
	COP	Heating		3.69	
	Sound power level	Cooling	dB(A)	65	72
		Heating			73
	Sound pressure level	Cooling		P-Hi: 38 Hi: 33 Me: 29 Lo: 25	56
		Heating			58
	Silent mode sound pressure level			—	49 / 45 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 950 × 635	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	34	78
Compressor type & Q'ty				—	RMT5126SWP4 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×2	Propeller fan ×1
Fan motor (Starting method)			W	130 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 24 Hi: 19 Me: 15 Lo: 10	75
		Heating			73
Available external static pressure			Pa	Standard: 35 Max: 100	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ②ϕ 15.88(5/8")x1.0 ①ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm×3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Filter set : UM-FL2EF , Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27℃	19℃	35℃	24℃	35Pa	ISO5151-T1
Heating	20℃	—	7℃	6℃		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U
(8) Static pressure of option air filter "UM-FL2EF" is 5Pa initially.
(9) The external static pressure setting can be changed to 10-100Pa. (For RC-EX3A and RC-E5 only)

(c) Triple type

Item			Model	FDUM140VNAWTVH	
				Indoor unit **FDUM50VH (3 units)**	Outdoor unit **FDC140VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	5.02	
		Heating		4.20	
	Max power consumption			6.40	
	Running current	Cooling	A	22.5 / 23.5	
		Heating		18.8 / 19.7	
	Inrush current, max current			5, 27	
	Power factor	Cooling	%	97	
		Heating		97	
	EER	Cooling		2.71	
	COP	Heating		3.69	
	Sound power level	Cooling	dB(A)	60	72
		Heating			73
	Sound pressure level	Cooling		P-Hi: 37 Hi: 32 Me: 29 Lo: 26	56
		Heating			58
	Silent mode sound pressure level			—	49 / 45 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 750 × 635	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	29	77
Compressor type & Q'ty				—	RMT5126SWP3 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×1	Propeller fan ×1
Fan motor (Starting method)			W	100 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 13 Hi: 10 Me: 9 Lo: 8	75
		Heating			73
Available external static pressure			Pa	Standard: 35 Max: 100	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm×3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Filter set : UM-FL1EF , Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27℃	19℃	35℃	24℃	35Pa	ISO5151-T1
Heating	20℃	—	7℃	6℃		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is three indoor units are combined and run together.
(7) Branching pipe set "DIS-TA1G"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U
(8) Static pressure of option air filter "UM-FL1EF" is 5Pa initially.
(9) The external static pressure setting can be changed to 10-100Pa. (For RC-EX3A and RC-E5 only)

Item			Model	FDUM140VSAWTVH	
				Indoor unit **FDUM50VH (3 units)**	Outdoor unit **FDC140VSA-W**
Power source				3 Phase, 380-415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	5.02	
		Heating		4.20	
	Max power consumption			10.20	
	Running current	Cooling	A	7.5 / 7.9	
		Heating		6.1 / 6.4	
	Inrush current, max current			5, 18	
	Power factor	Cooling	%	97	
		Heating		99	
	EER	Cooling		2.71	
	COP	Heating		3.69	
	Sound power level	Cooling	dB(A)	60	72
		Heating			73
	Sound pressure level	Cooling		P-Hi: 37 Hi: 32 Me: 29 Lo: 26	56
		Heating			58
	Silent mode sound pressure level			—	49 / 45 (Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	280 × 750 × 635	845 × 970 × 370
Exterior appearance (Munsell color) (RAL color)				—	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	29	78
Compressor type & Q'ty				—	RMT5126SWP4 (Twin rotary type)×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan ×1	Propeller fan ×1
Fan motor (Starting method)			W	100 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 13 Hi: 10 Me: 9 Lo: 8	75
		Heating			73
Available external static pressure			Pa	Standard: 35 Max: 100	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Procure locally	—
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20 (Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A,RC-E5,RCH-E3 Wireless : RCN-KIT4-E2	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35 (1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable VP25 (I.D.25, O.D.32)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	Built-in drain pump , 600	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm×3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Filter set : UM-FL1EF , Motion sensor : LB-KIT	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	External static pressure of indoor unit	Standards
Cooling	27℃	19℃	35℃	24℃	35Pa	ISO5151-T1
Heating	20℃	—	7℃	6℃		ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is three indoor units are combined and run together.
(7) Branching pipe set "DIS-TA1G"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U
(8) Static pressure of option air filter "UM-FL1EF" is 5Pa initially.
(9) The external static pressure setting can be changed to 10-100Pa. (For RC-EX3A and RC-E5 only)

(5) Ceiling suspended type (FDE)

(a) Single type

Item			Model	FDE100VNAWVH	
				Indoor unit **FDE100VH**	Outdoor unit **FDC100VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	2.85	
		Heating		2.54	
	Max power consumption			6.40	
	Running current	Cooling	A	13.8 / 14.4	
		Heating		12.4 / 13.0	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	90	
		Heating		89	
	EER	Cooling		3.51	
	COP	Heating		4.41	
	Sound power level	Cooling	dB(A)	64	69
		Heating			70
	Sound pressure level	Cooling		P-Hi: 48 Hi: 43 Me: 38 Lo: 34	54
		Heating			55
	Silent mode sound pressure level			—	48 /44(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	250 x 1,620 x 690	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	43	77
Compressor type & Q'ty				—	RMT5126SWP3 (Twin rotary type)x1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan x4	Propeller fan x1
Fan motor (Starting method)			W	80 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 32 Hi: 26 Me: 21 Lo: 16.5	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Pocket plastic net x2(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-E-E3	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D) Connecting method	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52 (3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP20(O.D.26)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27℃	19℃	35℃	24℃	ISO5151-T1
Heating	20℃	—	7℃	6℃	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

PFA004Z088 B

Item			Model	FDE100VSAWVH	
				Indoor unit **FDE100VH**	Outdoor unit **FDC100VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	2.85	
		Heating		2.54	
	Max power consumption			10.20	
	Running current	Cooling	A	4.6 / 4.8	
		Heating		4.0 / 4.2	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	90	
		Heating		91	
	EER	Cooling		3.51	
	COP	Heating		4.41	
	Sound power level	Cooling	dB(A)	64	69
		Heating			70
	Sound pressure level	Cooling		P-Hi: 48 Hi: 43 Me: 38 Lo: 34	54
		Heating			55
	Silent mode sound pressure level			—	48 /44(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	250 x 1,620 x 690	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	43	78
Compressor type & Q'ty				—	RMT5126SWP4 (Twin rotary type)x1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan x4	Propeller fan x1
Fan motor (Starting method)			W	80 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 32 Hi: 26 Me: 21 Lo: 16.5	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Pocket plastic net x2(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-E-E3	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D) Connecting method	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52 (3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP20(O.D.26)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27℃	19℃	35℃	24℃	ISO5151-T1
Heating	20℃	—	7℃	6℃	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.

PFA004Z088 B

Item			Model	FDE125VNAWVH	
				Indoor unit **FDE125VH**	Outdoor unit **FDC125VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	4.45	
		Heating		3.74	
	Max power consumption			6.40	
	Running current	Cooling	A	20.4 / 21.3	
		Heating		17.5 / 18.3	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	95	
		Heating		93	
	EER	Cooling		2.81	
	COP	Heating		3.74	
	Sound power level	Cooling	dB(A)	64	71
		Heating			
	Sound pressure level	Cooling		P-Hi: 48 Hi: 45 Me: 40 Lo: 35	54
		Heating			56
	Silent mode sound pressure level			—	48 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	250 x 1,620 x 690	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	43	77
Compressor type & Q'ty				—	RMT5126SWP3 (Twin rotary type)x1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan x4	Propeller fan x1
Fan motor (Starting method)			W	80 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 32 Hi: 29 Me: 23 Lo: 17	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Pocket plastic net x2(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-E-E3	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D) Connecting method	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52 (3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP20(O.D.26)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27℃	19℃	35℃	24℃	ISO5151-T1
Heating	20℃	—	7℃	6℃	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

PFA004Z088 B

Item			Model	FDE125VSAWVH	
				Indoor unit **FDE125VH**	Outdoor unit **FDC125VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	4.45	
		Heating		3.74	
	Max power consumption			10.20	
	Running current	Cooling	A	6.9 / 7.3	
		Heating		5.9 / 6.2	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	93	
		Heating		91	
	EER	Cooling		2.81	
	COP	Heating		3.74	
	Sound power level	Cooling	dB(A)	64	71
		Heating			
	Sound pressure level	Cooling		P-Hi: 48 Hi: 45 Me: 40 Lo: 35	54
		Heating			56
	Silent mode sound pressure level			—	48 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	250 x 1,620 x 690	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	43	78
Compressor type & Q'ty				—	RMT5126SWP4 (Twin rotary type)x1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan x4	Propeller fan x1
Fan motor (Starting method)			W	80 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 32 Hi: 29 Me: 23 Lo: 17	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Pocket plastic net x2(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-E-E3	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D) Connecting method	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52 (3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP20(O.D.26)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27℃	19℃	35℃	24℃	ISO5151-T1
Heating	20℃	—	7℃	6℃	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.

PFA004Z088 B

Item			Model	FDE140VNAWVH	
				Indoor unit **FDE140VH**	Outdoor unit **FDC140VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	5.05	
		Heating		4.18	
	Max power consumption			6.40	
	Running current	Cooling	A	22.2 / 23.2	
		Heating		18.4 / 19.2	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		2.69	
	COP	Heating		3.71	
	Sound power level	Cooling	dB(A)	65	72
		Heating			73
	Sound pressure level	Cooling		P-Hi: 49 Hi: 45 Me: 40 Lo: 36	56
		Heating			58
	Silent mode sound pressure level			—	49 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	250 x 1,620 x 690	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	43	77
Compressor type & Q'ty				—	RMT5126SWP3 (Twin rotary type)x1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan x4	Propeller fan x1
Fan motor (Starting method)			W	90 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 34 Hi: 29 Me: 23 Lo: 18	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x2(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-E-E3	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52 (3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP20(O.D.26)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-E	

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

PFA004Z088 B

Item			Model	FDE140VSAWVH	
				Indoor unit **FDE140VH**	Outdoor unit **FDC140VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	5.05	
		Heating		4.18	
	Max power consumption			10.20	
	Running current	Cooling	A	7.8 / 8.2	
		Heating		6.5 / 6.8	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	94	
		Heating		93	
	EER	Cooling		2.69	
	COP	Heating		3.71	
	Sound power level	Cooling	dB(A)	65	72
		Heating			73
	Sound pressure level	Cooling		P-Hi: 49 Hi: 45 Me: 40 Lo: 36	56
		Heating			58
	Silent mode sound pressure level			—	49 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	250 x 1,620 x 690	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	43	78
Compressor type & Q'ty				—	RMT5126SWP4 (Twin rotary type)x1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	Straight fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan x4	Propeller fan x1
Fan motor (Starting method)			W	90 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 34 Hi: 29 Me: 23 Lo: 18	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Pocket plastic net x2(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-E-E3	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52 (3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP20(O.D.26)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-E	

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.

PFA004Z088 B

(b) Twin type

Item			Model	FDE100VNAWPVH	
				Indoor unit **FDE50VH (2 units)**	Outdoor unit **FDC100VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.3(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	3.12	
		Heating		2.99	
	Max power consumption			6.40	
	Running current	Cooling	A	14.0 / 14.6	
		Heating		13.4 / 14.0	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	97	
		Heating		97	
	EER	Cooling		3.21	
	COP	Heating		3.75	
	Sound power level	Cooling	dB(A)	60	69
		Heating			70
	Sound pressure level	Cooling		P-Hi: 46 Hi: 38 Me: 36 Lo: 31	54
		Heating			55
	Silent mode sound pressure level			—	48 /44(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	210 x 1,070 x 690	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	28	77
Compressor type & Q'ty				—	RMT5126SWP3 (Twin rotary type)x1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan x2	Propeller fan x1
Fan motor (Starting method)			W	30 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 13 Hi: 10 Me: 9 Lo: 7	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x2(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-E-E3	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35(1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88 (5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP20(O.D.26)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U

PFA004Z088 B

Item			Model	FDE100VSAWPVH	
				Indoor unit **FDE50VH (2 units)**	Outdoor unit **FDC100VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	3.12	
		Heating		2.99	
	Max power consumption			10.20	
	Running current	Cooling	A	4.6 / 4.8	
		Heating		4.4 / 4.6	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	98	
		Heating		98	
	EER	Cooling		3.21	
	COP	Heating		3.75	
	Sound power level	Cooling	dB(A)	60	69
		Heating			70
	Sound pressure level	Cooling		P-Hi: 46 Hi: 38 Me: 36 Lo: 31	54
		Heating			55
	Silent mode sound pressure level			—	48 /44(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	210 x 1,070 x 690	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	28	78
Compressor type & Q'ty				—	RMT5126SWP4 (Twin rotary type)x1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan x2	Propeller fan x1
Fan motor (Starting method)			W	30 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 13 Hi: 10 Me: 9 Lo: 7	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Pocket plastic net x2(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-E-E3	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35(1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88 (5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP20(O.D.26)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U

PFA004Z088 B

Item			Model	FDE125VNAWPVH	
				Indoor unit **FDE60VH (2 units)**	Outdoor unit **FDC125VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [4.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	4.16	
		Heating		3.54	
	Max power consumption			6.40	
	Running current	Cooling	A	18.3 / 19.1	
		Heating		15.5 / 16.3	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		3.00	
	COP	Heating		3.95	
	Sound power level	Cooling	dB(A)	60	71
		Heating			
	Sound pressure level	Cooling		P-Hi: 47 Hi: 41 Me: 37 Lo: 32	54
		Heating			56
	Silent mode sound pressure level			—	48 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	210 x 1,320 x 690	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	33	77
Compressor type & Q'ty				—	RMT5126SWP3 (Twin rotary type)x1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan x4	Propeller fan x1
Fan motor (Starting method)			W	50 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 20 Hi: 16 Me: 13 Lo: 10	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Possible	—
Air filter, Quality / Quantity				Pocket plastic net x2(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-E-E3	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35(1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88 (5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP20(O.D.26)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U

PFA004Z088 B

Item			Model	FDE125VSAWPVH	
				Indoor unit **FDE60VH (2 units)**	Outdoor unit **FDC125VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	4.16	
		Heating		3.54	
	Max power consumption			10.20	
	Running current	Cooling	A	6.1 / 6.4	
		Heating		5.2 / 5.5	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	99	
		Heating		98	
	EER	Cooling		3.00	
	COP	Heating		3.95	
	Sound power level	Cooling	dB(A)	60	71
		Heating			
	Sound pressure level	Cooling		P-Hi: 47 Hi: 41 Me: 37 Lo: 32	54
		Heating			56
	Silent mode sound pressure level			—	49 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	210 x 1,320 x 690	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	33	78
Compressor type & Q'ty				—	RMT5126SWP4 (Twin rotary type)x1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan x4	Propeller fan x1
Fan motor (Starting method)			W	50 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 20 Hi: 16 Me: 13 Lo: 10	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Pocket plastic net x2(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-E-E3	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35(1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88 (5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP20(O.D.26)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U

PFA004Z088 B

Item			Model	FDE140VNAWPVH	
				Indoor unit **FDE71VH (2 units)**	Outdoor unit **FDC140VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	4.74	
		Heating		4.21	
	Max power consumption			6.40	
	Running current	Cooling	A	20.8 / 21.8	
		Heating		18.5 / 19.3	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		2.87	
	COP	Heating		3.68	
	Sound power level	Cooling	dB(A)	60	72
		Heating			73
	Sound pressure level	Cooling		P-Hi: 47 Hi: 41 Me: 37 Lo: 32	56
		Heating			58
	Silent mode sound pressure level			—	49 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	210 x 1,320 x 690	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	33	77
Compressor type & Q'ty				—	RMT5126SWP3 (Twin rotary type)x1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan x4	Propeller fan x1
Fan motor (Starting method)			W	50 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 20 Hi: 16 Me: 13 Lo: 10	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Pocket plastic net x2(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-E-E3	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52(3/8") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ②ϕ 15.88(5/8")x1.0 ①ϕ 15.88 (5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP20(O.D.26)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U

PFA004Z088 B

Item			Model	FDE140VSAWPVH	
				Indoor unit **FDE71VH (2 units)**	Outdoor unit **FDC140VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	4.74	
		Heating		3.21	
	Max power consumption			10.20	
	Running current	Cooling	A	6.9 / 7.3	
		Heating		6.2 / 6.5	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	99	
		Heating		98	
	EER	Cooling		2.87	
	COP	Heating		3.68	
	Sound power level	Cooling	dB(A)	60	72
		Heating			73
	Sound pressure level	Cooling		P-Hi: 47 Hi: 41 Me: 37 Lo: 32	56
		Heating			58
	Silent mode sound pressure level			—	49 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	210 x 1,320 x 690	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	33	78
Compressor type & Q'ty				—	RMT5126SWP4 (Twin rotary type)x1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan x4	Propeller fan x1
Fan motor (Starting method)			W	50 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 20 Hi: 16 Me: 13 Lo: 10	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Pocket plastic net x2(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-E-E3	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52(3/8") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ②ϕ 15.88(5/8")x1.0 ①ϕ 15.88 (5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP20(O.D.26)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1G"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U

PFA004Z088 B

(c) Triple type

Item			Model	FDE140VNAWTVH	
				Indoor unit **FDE50VH (3 units)**	Outdoor unit **FDC140VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	4.74	
		Heating		4.21	
	Max power consumption			6.40	
	Running current	Cooling	A	20.8 / 21.8	
		Heating		18.5 / 19.3	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		2.87	
	COP	Heating		3.68	
	Sound power level	Cooling	dB(A)	60	72
		Heating			73
	Sound pressure level	Cooling		P-Hi: 46 Hi: 38 Me: 36 Lo: 31	56
		Heating			58
	Silent mode sound pressure level			—	49 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	210 x 1,070 x 690	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	28	77
Compressor type & Q'ty				—	RMT5126SWP3 (Twin rotary type)x1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan x2	Propeller fan x1
Fan motor (Starting method)			W	30 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 13 Hi: 10 Me: 9 Lo: 7	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Pocket plastic net x2(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-E-E3	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35(1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88 (5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP20(O.D.26)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-TA1G"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U

PFA004Z088 B

Item			Model	FDE140VSAWTVH	
				Indoor unit **FDE50VH (3 units)**	Outdoor unit **FDC140VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	4.74	
		Heating		3.21	
	Max power consumption			10.20	
	Running current	Cooling	A	6.9 / 7.3	
		Heating		6.2 / 6.5	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	99	
		Heating		98	
	EER	Cooling		2.87	
	COP	Heating		3.68	
	Sound power level	Cooling	dB(A)	60	72
		Heating			73
	Sound pressure level	Cooling		P-Hi: 46 Hi: 38 Me: 36 Lo: 31	56
		Heating			58
	Silent mode sound pressure level			—	49 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	210 x 1,070 x 690	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	28	78
Compressor type & Q'ty				—	RMT5126SWP4 (Twin rotary type)x1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Centrifugal fan x2	Propeller fan x1
Fan motor (Starting method)			W	30 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi: 13 Hi: 10 Me: 9 Lo: 7	75
		Heating			73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Pocket plastic net x2(Washable)	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-E-E3	
	Room temperature control			Thermostat by electronics	
	Operation display			—	
Safety equipments				Overload protection for fan motor Frost protection thermostat Internal thermostat for fan motor Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35(1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88 (5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP20(O.D.26)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Drain hose	—
Option parts				Motion sensor : LB-E	

Notes (1) The data are measured at the following conditions.

The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27℃	19℃	35℃	24℃	ISO5151-T1
Heating	20℃	—	7℃	6℃	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-TA1G"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U

(6) Wall mounted type (SRK)

(a) Single type

Item				Model	SRK100VNAWZR	
					Indoor unit **SRK100ZR-W**	Outdoor unit **FDC100VNA-W**
Power source					1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)			kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)			kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption		Cooling	kW	3.19	
			Heating		3.04	
	Max power consumption				6.40	
	Running current		Cooling	A	14.3 / 14.9	
			Heating		13.6 / 14.2	
	Inrush current, max current				5, 24	
	Power factor		Cooling	%	97	
			Heating		97	
	EER		Cooling		3.13	
	COP		Heating		3.68	
	Sound power level		Cooling	dB(A)	63	69
			Heating			70
	Sound pressure level		Cooling		P-Hi: 48 Hi: 45 Me: 40 Lo: 27	54
			Heating		P-Hi: 48 Hi: 43 Me: 38 Lo: 30	55
	Silent mode sound pressure level				—	48 /44(Normal/Silent)
Exterior dimensions (Height x Width x Depth)				mm	339 x 1,197 x 262	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)					Fine snow (8.0Y9.3/0.1) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight				kg	16.5	77
Compressor type & Q'ty					—	RMT5126SWP3×1
Compressor motor (Starting method)				kW	—	Direct line start
Refrigerant oil (Amount, type)				L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)				kg	R32 3.3 in outdoor unit (Pre-charged up to the piping length of 30m)	
Heat exchanger					Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control					Electronic expansion valve	
Fan type & Q'ty					Tangential fan x 1	Propeller fan x1
Fan motor (Starting method)				W	56 x 1 < Direct line start >	86 < Direct line start >
Air flow			Cooling	m^3/min	Hi: 24.5 Me: 21.3 Lo: 17.6 ULo: 10.4	75
			Heating		Hi: 27.5 Me: 23.2 Lo: 19.1 ULo: 13.6	73
Available external static pressure				Pa	0	0
Outside air intake					Not possible	—
Air filter, Quality / Quantity					Polypropylene net (Washable) x 2	—
Shock & vibration absorber					Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater				W	—	20(Crank case heater)
Operation control	Remote control				(Option) Wired : RC-EX3A, RC-E5 , RCH-E3 Interface kit : SC-BIKN2-E	
	Room temperature control				Thermostat by electronics	
	Operation display				RUN: Green, TIMER: Yellow, ECO: Blue	
Safety equipments					Internal thermostat for fan motor Frost protection thermostat Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)		Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52 (3/8")x0.8 O/U ϕ 9.52 (3/8")	
			Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method				Flare piping	Flare piping
	Attached length of piping				—	—
	Insulation for piping				Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length			m	Max.50	
	Vertical height diff. between O/U and I/U			m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose				Hose connectable with VP16	Hole size ϕ 20 x 3pcs
Drain pump, max lift height				mm	—	—
Recommended breaker size				A	—	
L.R.A. (Locked rotor ampere)				A	5.0	
Interconnecting wires		Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number					IPX0	IP24
Standard accessories					Mounting kit, Clean filter	—
Option parts					—	

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

Item			Model	SRK100VSAWZR	
				Indoor unit **SRK100ZR-W**	Outdoor unit **FDC100VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	3.19	
		Heating		3.04	
	Max power consumption			10.20	
	Running current	Cooling	A	4.8 / 5.1	
		Heating		4.6 / 4.8	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	95	
		Heating		96	
	EER	Cooling		3.13	
	COP	Heating		3.68	
	Sound power level	Cooling	dB(A)	63	69
		Heating			70
	Sound pressure level	Cooling		P-Hi: 48 Hi: 45 Me: 40 Lo: 27	54
		Heating		P-Hi: 48 Hi: 43 Me: 38 Lo: 30	55
	Silent mode sound pressure level			—	48 /44(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	339 x 1,197 x 262	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Fine snow (8.0Y9.3/0.1) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	16.5	78
Compressor type & Q'ty				—	RMT5126SWP4×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Pre-charged up to the piping length of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Tangential fan x1	Propeller fan x1
Fan motor (Starting method)			W	56 x 1 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	Hi: 24.5 Me: 21.3 Lo: 17.6 ULo: 10.4	75
		Heating		Hi: 27.5 Me: 23.2 Lo: 19.1 ULo: 13.6	73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Polypropylene net (Washable) x 2	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A, RC-E5 , RCH-E3 Interface kit : SC-BIKN2-E	
	Room temperature control			Thermostat by electronics	
	Operation display			RUN: Green, TIMER: Yellow, ECO: Blue	
Safety equipments				Internal thermostat for fan motor Frost protection thermostat Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52 (3/8") Pipe ϕ 9.52 (3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ϕ 15.88(5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping			—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP16	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Clean filter	—
Option parts				—	

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.

PCA001Z857 A

(b) Twin type

Item			Model	SRK100VNAWPZSX	
				Indoor unit **SRK50ZSX-W (2 units)**	Outdoor unit **FDC100VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	2.89	
		Heating		2.61	
	Max power consumption			6.40	
	Running current	Cooling	A	12.7 / 13.3	
		Heating		11.5 / 12.0	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		3.46	
	COP	Heating		4.29	
	Sound power level	Cooling	dB(A)	59	69
		Heating		62	70
	Sound pressure level	Cooling		P-Hi: 44 Hi: 39 Me: 31 Lo: 22	54
		Heating		P-Hi: 46 Hi: 41 Me: 33 Lo: 23	55
	Silent mode sound pressure level			—	48 /44(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	305 x 920 x 220	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Fine snow (8.0Y9.3/0.1) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	13	77
Compressor type & Q'ty				—	RMT5126SWP3×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Pre-charged up to the piping length of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Tangential fan x1	Propeller fan x1
Fan motor (Starting method)			W	42 x 1 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	Hi: 14.3 Me: 12.4 Lo: 7.8 ULo: 5.4	75
		Heating		Hi: 17.3 Me: 14.3 Lo: 9.8 ULo: 6.2	73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Polypropylene net (Washable) x 2	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A, RC-E5 , RCH-E3 Interface kit : SC-BIKN2-E	
	Room temperature control			Thermostat by electronics	
	Operation display			RUN: Green, TIMER: Yellow, ECO: Blue	
Safety equipments				Internal thermostat for fan motor Frost protection thermostat Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35(1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88 (5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping			—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP16	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Clean filter	—
Option parts				—	

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U

PCA001Z857 A

Item			Model	SRK100VSAWPZSX	
				Indoor unit **SRK50ZSX-W (2 units)**	Outdoor unit **FDC100VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.) - 11.2(Max.)]	
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.) - 12.5(Max.)]	
	Power consumption	Cooling	kW	2.89	
		Heating		2.61	
	Max power consumption			10.20	
	Running current	Cooling	A	4.2 / 4.4	
		Heating		3.8 / 4.0	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		3.46	
	COP	Heating		4.29	
	Sound power level	Cooling	dB(A)	59	69
		Heating		62	70
	Sound pressure level	Cooling		P-Hi: 44 Hi: 39 Me: 31 Lo: 22	54
		Heating		P-Hi: 46 Hi: 41 Me: 33 Lo: 23	55
	Silent mode sound pressure level			—	48 /44(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	305 x 920 x 220	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Fine snow (8.0Y9.3/0.1) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	13	78
Compressor type & Q'ty				—	RMT5126SWP4×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Pre-charged up to the piping length of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Tangential fan x1	Propeller fan x1
Fan motor (Starting method)			W	42 x 1 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	Hi: 14.3 Me: 12.4 Lo: 7.8 ULo: 5.4	75
		Heating		Hi: 17.3 Me: 14.3 Lo: 9.8 ULo: 6.2	73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Polypropylene net (Washable) x 2	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A, RC-E5 , RCH-E3 Interface kit : SC-BIKN2-E	
	Room temperature control			Thermostat by electronics	
	Operation display			RUN: Green, TIMER: Yellow, ECO: Blue	
Safety equipments				Internal thermostat for fan motor Frost protection thermostat Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35(1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88 (5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping			—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP16	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Clean filter	—
Option parts				—	

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U

PCA001Z857 A

Item			Model	SRK125VNAWPZSX	
				Indoor unit **SRK60ZSX-W (2 units)**	Outdoor unit **FDC125VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	4.54	
		Heating		3.58	
	Max power consumption			6.40	
	Running current	Cooling	A	19.9 / 20.8	
		Heating		15.7 / 16.4	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		2.76	
	COP	Heating		3.91	
	Sound power level	Cooling	dB(A)	62	71
		Heating		63	
	Sound pressure level	Cooling		P-Hi: 44 Hi: 41 Me: 33 Lo: 22	54
		Heating		P-Hi: 46 Hi: 42 Me: 34 Lo: 23	56
	Silent mode sound pressure level			—	48 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	305 x 920 x 220	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Fine snow (8.0Y9.3/0.1) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	13	77
Compressor type & Q'ty				—	RMT5126SWP3×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Pre-charged up to the piping length of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Tangential fan x1	Propeller fan x1
Fan motor (Starting method)			W	42 x 1 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	Hi: 16.3 Me: 13.4 Lo: 8.9 ULo: 5.4	75
		Heating		Hi: 17.8 Me: 13.7 Lo: 10.9 ULo: 6.2	73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Polypropylene net (Washable) x 2	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A, RC-E5 , RCH-E3 Interface kit : SC-BIKN2-E	
	Room temperature control			Thermostat by electronics	
	Operation display			RUN: Green, TIMER: Yellow, ECO: Blue	
Safety equipments				Internal thermostat for fan motor Frost protection thermostat Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35(1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88 (5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping			—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP16	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Clean filter	—
Option parts				—	

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U

PCA001Z857 A

Item			Model	SRK125VSAWPZSX	
				Indoor unit **SRK60ZSX-W (2 units)**	Outdoor unit **FDC125VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.) - 14.0(Max.)]	
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.) - 16.0(Max.)]	
	Power consumption	Cooling	kW	4.54	
		Heating		3.58	
	Max power consumption			10.20	
	Running current	Cooling	A	6.6 / 7.0	
		Heating		5.2 / 5.5	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		2.76	
	COP	Heating		3.91	
	Sound power level	Cooling	dB(A)	62	71
		Heating		63	
	Sound pressure level	Cooling		P-Hi: 46 Hi: 41 Me: 33 Lo: 22	54
		Heating		P-Hi: 46 Hi: 42 Me: 34 Lo: 23	56
	Silent mode sound pressure level			—	48 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	305 x 920 x 220	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Fine snow (8.0Y9.3/0.1) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	13	78
Compressor type & Q'ty				—	RMT5126SWP4×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Pre-charged up to the piping length of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Tangential fan x1	Propeller fan x1
Fan motor (Starting method)			W	42 x 1 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	Hi: 16.3 Me: 13.4 Lo: 8.9 ULo: 5.4	75
		Heating		Hi: 17.8 Me: 13.7 Lo: 10.9 ULo: 6.2	73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Polypropylene net (Washable) x 2	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A, RC-E5 , RCH-E3 Interface kit : SC-BIKN2-E	
	Room temperature control			Thermostat by electronics	
	Operation display			RUN: Green, TIMER: Yellow, ECO: Blue	
Safety equipments				Internal thermostat for fan motor Frost protection thermostat Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35(1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88 (5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping			—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP16	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Clean filter	—
Option parts				—	

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U

PCA001Z857 A

Item			Model	SRK140VNAWPZR	
				Indoor unit **SRK71ZR-W (2 units)**	Outdoor unit **FDC140VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	4.26	
		Heating		4.03	
	Max power consumption			6.40	
	Running current	Cooling	A	18.7 / 19.6	
		Heating		17.7 / 18.5	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		3.19	
	COP	Heating		3.85	
	Sound power level	Cooling	dB(A)	57	72
		Heating		60	73
	Sound pressure level	Cooling		P-Hi: 44 Hi: 41 Me: 37 Lo: 25	56
		Heating		P-Hi: 46 Hi: 39 Me: 35 Lo: 28	58
	Silent mode sound pressure level			—	49 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	339 x 1,197 x 262	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Fine snow (8.0Y9.3/0.1) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	15.5	77
Compressor type & Q'ty				—	RMT5126SWP3×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Pre-charged up to the piping length of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Tangential fan x1	Propeller fan x1
Fan motor (Starting method)			W	56 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	Hi: 20.5 Me: 18.6 Lo: 16.2 ULo: 10.4	75
		Heating		Hi: 25.0 Me: 19.8 Lo: 17.3 ULo: 13.3	73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Polypropylene net (Washable) x 2	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A, RC-E5 , RCH-E3 Interface kit : SC-BIKN2-E	
	Room temperature control			Thermostat by electronics	
	Operation display			RUN: Green , TIMER: Yellow , HI POWER: Green , 3D AUTO: Orange	
Safety equipments				Internal thermostat for fan motor Frost protection thermostat Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52(3/8") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ②ϕ 15.88(5/8")x1.0 ①ϕ 15.88 (5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping			Liquid line : 0.78 / Gas line : 0.72	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with (VP16)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Clean filter (Allergen clear filter ×1 , Photocatalytic washable deodorizing filter × 1)	
Option parts				—	

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27℃	19℃	35℃	24℃	ISO5151-T1
Heating	20℃	—	7℃	6℃	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U

PCA001Z857 A

Item			Model	SRK140VSAWPZR	
				Indoor unit **SRK71ZR-W (2 units)**	Outdoor unit **FDC140VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	4.26	
		Heating		4.03	
	Max power consumption			10.20	
	Running current	Cooling	A	6.2 / 6.5	
		Heating		5.9 / 6.2	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		3.19	
	COP	Heating		3.85	
	Sound power level	Cooling	dB(A)	57	72
		Heating		60	73
	Sound pressure level	Cooling		P-Hi: 44 Hi: 41 Me: 37 Lo: 25	56
		Heating		P-Hi: 46 Hi: 39 Me: 35 Lo: 28	58
	Silent mode sound pressure level			—	49 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	339 x 1,197 x 262	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Fine snow (8.0Y9.3/0.1) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	15.5	78
Compressor type & Q'ty				—	RMT5126SWP4×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Pre-charged up to the piping length of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Tangential fan x1	Propeller fan x1
Fan motor (Starting method)			W	56 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	Hi: 20.5 Me: 18.6 Lo: 16.2 ULo: 10.4	75
		Heating		Hi: 25.0 Me: 19.8 Lo: 17.3 ULo: 13.3	73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Polypropylene net (Washable) x 2	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A, RC-E5 , RCH-E3 Interface kit : SC-BIKN2-E	
	Room temperature control			Thermostat by electronics	
	Operation display			RUN: Green , TIMER: Yellow , HI POWER: Green , 3D AUTO: Orange	
Safety equipments				Internal thermostat for fan motor Frost protection thermostat Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 9.52(3/8") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 15.88 (5/8") ②ϕ 15.88(5/8")x1.0 ①ϕ 15.88 (5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping			Liquid line : 0.78 / Gas line : 0.72	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with (VP16)	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Clean filter (Allergen clear filter ×1 , Photocatalytic washable deodorizing filter × 1)	
Option parts				—	

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27℃	19℃	35℃	24℃	ISO5151-T1
Heating	20℃	—	7℃	6℃	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-WA1"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U

PCA001Z857 A

(c) Triple type

Item			Model	SRK140VNAWTZSX	
				Indoor unit **SRK50ZSX-W (3 units)**	Outdoor unit **FDC140VNA-W**
Power source				1 Phase, 220 - 240V 50Hz / 220V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	4.26	
		Heating		3.74	
	Max power consumption			6.40	
	Running current	Cooling	A	18.7 / 19.6	
		Heating		16.4 / 17.2	
	Inrush current, max current			5, 24	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		3.19	
	COP	Heating		4.14	
	Sound power level	Cooling	dB(A)	57	72
		Heating		62	73
	Sound pressure level	Cooling		P-Hi: 44 Hi: 39 Me: 31 Lo: 22	56
		Heating		P-Hi: 46 Hi: 41 Me: 33 Lo: 23	58
	Silent mode sound pressure level			—	49 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	305 x 920 x 220	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Fine snow (8.0Y9.3/0.1) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	13	77
Compressor type & Q'ty				—	RMT5126SWP3×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Pre-charged up to the piping length of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Tangential fan x1	Propeller fan x1
Fan motor (Starting method)			W	42 x 1 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	Hi: 14.3 Me: 12.4 Lo: 7.8 ULo: 5.4	75
		Heating		Hi: 17.3 Me: 14.3 Lo: 9.8 ULo: 6.2	73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Polypropylene net (Washable) x 2	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A, RC-E5 , RCH-E3 Interface kit : SC-BIKN2-E	
	Room temperature control			Thermostat by electronics	
	Operation display			RUN: Green, TIMER: Yellow, ECO: Blue	
Safety equipments				Internal thermostat for fan motor Frost protection thermostat Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35(1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88 (5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping			—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP16	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Clean filter	—
Option parts				—	

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-TA1"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U

PCA001Z857 A

Item			Model	SRK140VSAWTZSX	
				Indoor unit **SRK50ZSX-W (3 units)**	Outdoor unit **FDC140VSA-W**
Power source				3 Phase, 380 - 415V 50Hz / 380V 60Hz	
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.) - 14.5(Max.)]	
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.) - 16.5(Max.)]	
	Power consumption	Cooling	kW	4.26	
		Heating		3.74	
	Max power consumption			10.20	
	Running current	Cooling	A	18.7 / 19.6	
		Heating		16.4 / 17.2	
	Inrush current, max current			5, 15	
	Power factor	Cooling	%	99	
		Heating		98	
	EER	Cooling		3.19	
	COP	Heating		4.14	
	Sound power level	Cooling	dB(A)	59	72
		Heating		62	73
	Sound pressure level	Cooling		P-Hi: 44 Hi: 39 Me: 31 Lo: 22	56
		Heating		P-Hi: 46 Hi: 41 Me: 33 Lo: 23	58
	Silent mode sound pressure level			—	49 /45(Normal/Silent)
Exterior dimensions (Height x Width x Depth)			mm	305 x 920 x 220	845 x 970 x 370
Exterior appearance (Munsell color) (RAL color)				Fine snow (8.0Y9.3/0.1) near equivalent (RAL 9003) near equivalent	Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	13	78
Compressor type & Q'ty				—	RMT5126SWP4×1
Compressor motor (Starting method)			kW	—	Direct line start
Refrigerant oil (Amount, type)			L	—	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Pre-charged up to the piping length of 30m)	
Heat exchanger				Louver fin & inner grooved tubing	M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve	
Fan type & Q'ty				Tangential fan x1	Propeller fan x1
Fan motor (Starting method)			W	42 x 1 < Direct line start >	86 < Direct line start >
Air flow		Cooling	m^3/min	Hi: 14.3 Me: 12.4 Lo: 7.8 ULo: 5.4	75
		Heating		Hi: 17.3 Me: 14.3 Lo: 9.8 ULo: 6.2	73
Available external static pressure			Pa	0	0
Outside air intake				Not possible	—
Air filter, Quality / Quantity				Polypropylene net (Washable) x 2	—
Shock & vibration absorber				Rubber sleeve(for fan motor)	Rubber sleeve (for fan motor & compressor)
Electric heater			W	—	20(Crank case heater)
Operation control	Remote control			(Option) Wired : RC-EX3A, RC-E5 , RCH-E3 Interface kit : SC-BIKN2-E	
	Room temperature control			Thermostat by electronics	
	Operation display			RUN: Green, TIMER: Yellow, ECO: Blue	
Safety equipments				Internal thermostat for fan motor Frost protection thermostat Abnormal discharge temperature protection	
Installation data	Refrigerant piping size (O.D)	Liquid line	mm	I/U ϕ 6.35(1/4") ②ϕ 9.52(3/8")x0.8 ①ϕ 9.52(3/8")x0.8 O/U ϕ 9.52 (3/8")	
		Gas line		ϕ 12.7 (1/2") ②ϕ 12.7(1/2")x0.8 ①ϕ 15.88 (5/8")x1.0 ϕ 15.88 (5/8")	
	Connecting method			Flare piping	Flare piping
	Attached length of piping			—	—
	Insulation for piping			Necessary (both Liquid & Gas lines)	
	Refrigerant line (one way) length		m	Max.50	
	Vertical height diff. between O/U and I/U		m	Max.50 (Outdoor unit is higher)	Max.15 (Outdoor unit is lower)
	Drain hose			Hose connectable with VP16	Hole size ϕ 20 x 3pcs
Drain pump, max lift height			mm	—	—
Recommended breaker size			A	—	
L.R.A. (Locked rotor ampere)			A	5.0	
Interconnecting wires	Size x Core number			ϕ 1.6mm x 3 cores + earth cable / Terminal block (Screw fixing type)	
IP number				IPX0	IP24
Standard accessories				Mounting kit, Clean filter	—
Option parts				—	

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Select the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.
(6) Indoor unit specifications for one unit. Capacity and operation data is two indoor units are combined and run together.
(7) Branching pipe set "DIS-TA1"×1(Option). ① : Pipe of O/U-Branch, ② : Pipe of Branch-I/U

PCA001Z857 A

1.2 EXTERIOR DIMENSIONS

(1) Indoor units

(a) Ceiling cassette-4 way type (FDT)

Models FDT50VH, 60VH, 71VH



Notes (1) The model name label is attached to the control box lid.
(2) Suspension bolt pitch P1,P2 is adjustable by a pattern of the right table.
(3) Draft prevention function (※) is provided on the panel T-PSAE-5AW-E only.

PJF000Z552

Models FDT100VH, 125VH, 140VH



PJF000Z553

(b) Ceiling cassette-4 way compact type (FDTC)

Models FDTC50VH, 60VH



PJF000Z515 A

(c) Duct connected-High static pressure type(FDU)

Models FDU100VH, 125VH, 140VH



Symbol	Content	
A	Gas piping	ϕ15.88 (5/8") (Flare)
B	Liquid piping	ϕ9.52 (3/8") (Flare)
C_1	Drain piping	VP25 (O.D.32)
C_2	Drain piping (Gravity drainage)	VP20
D	Hole for wiring	
E	Suspension bolts	M10
F	Outside air opening for ducting	(Knock out)
G	Air outlet opening for ducting	(Knock out)
H	Inspection hole	(450×450)



Unit:mm

Space for installation and service

Select either of two cases to keep space for installation and services.

(Case 1) From side of unit



Notes (a) There must not be obstacle to draw out 2 fan units. For fan units maintenance, refer to page 171.

(b) Install refrigerant pipes, drain pipe, and wiring so as not to cross ▨ marked area.

(c) The case that pipes are installed to upper (bottom) of fan unit, keep space of 60mm or more to upper (bottom) of unit.

(Case 2) From bottom of unit



Note (1) The model name label is attached on the lid of the control box.

PJG000Z579

(d) Duct connected-Low / Middle static pressure type (FDUM)

Model FDUM50VH



Symbol	Content	
A	Gas piping	φ12.7 (1/2") (Flare)
B	Liquid piping	φ6.35 (1/4") (Flare)
C1	Drain piping	VP25 (O.D.32)
C2	Drain piping (Gravity drainage)	VP20
D	Hole for wiring	
E	Suspension bolts	(M10)
F	Outside air opening for ducting	(φ150) (Knock out)
G	Air outlet opening for ducting	(φ125) (Knock out)
H	Inspection opening	(450×450)

Note (1) The model name label is attached on the lid of the control box.





View M



Unit:mm

Space for installation and service

Select either of two cases to keep space for installation and services.

(Case 1) From side of unit



Notes (a) There must not be obstacle to draw out fan unit. For fan unit maintenance, refer to page 177.
(b) Install refrigerant pipes, drain pipe, and wiring so as not to cross ▨ marked area.
(c) The case that pipes are installed to upper (bottom) of fan unit, keep space of 60mm or more to upper (bottom) of unit.

(Case 2) From bottom of unit



PJG000Z485

Models FDUM60VH, 70VH



Symbol	Content		
	Model	60	71
A	Gas piping	φ12.7 (1/2") (Flare)	φ15.88 (5/8") (Flare)
B	Liquid piping	φ6.35 (1/4") (Flare)	φ9.52 (3/8") (Flare)
C1	Drain piping	VP25 (O.D.32)	
C2	Drain piping (Gravity drainage)	VP20	
D	Hole for wiring		
E	Suspension bolts	(M10)	
F	Outside air opening for ducting	(φ150) (Knock out)	
G	Air outlet opening for ducting	(φ125) (Knock out)	
H	Inspection opening	(450×450)	

Note (1) The model name label is attached on the lid of the control box.







Space for installation and service

Select either of two cases to keep space for installation and services.

(Case 1) From side of unit



Notes (a) There must not be obstacle to draw out fan unit. For fan unit maintenance, refer to page 177.

(b) Install refrigerant pipes, drain pipe, and wiring so as not to cross ▨ marked area.

(c) The case that pipes are installed to upper (bottom) of fan unit, keep space of 60mm or more to upper (bottom) of unit.

(Case 2) From bottom of unit



PJG000Z486

Models FDUM100VH, 125VH, 140VH



Symbol	Content	
A	Gas piping	φ15.88(5/8") (Flare)
B	Liquid piping	φ9.52(3/8") (Flare)
C_1	Drain piping	VP25(O.D.32)
C_2	Drain piping (Gravity drainage)	VP20
D	Hole for wiring	
E	Suspension bolts	(M10)
F	Outside air opening for ducting	(φ150) (Knock out)
G	Air outlet opening for ducting	(φ125) (Knock out)
H	Inspection opening	(450×450)



Unit:mm

Space for installation and service

Select either of two cases to keep space for installation and services.

(Case 1) From side of unit



Notes (a) There must not be obstacle to draw out 2 fan units. For fan units maintenance, refer to page 177.

(b) Install refrigerant pipes, drain pipe, and wiring so as not to cross ▨ marked area.

(c) The case that pipes are installed to upper (bottom) of fan unit, keep space of 60mm or more to upper (bottom) of unit.

(Case 2) From bottom of unit



Note(1) The model name label is attached on the lid of the control box.

PJG000Z487

(e) Ceiling suspended type (FDE)

Model FDE50VH



PFA004Z084

Models FDE60VH, 71VH



Symbol	Model	Content	
		FDE60	FDE71
A	Gas piping	ϕ12.7 (1/2") (Flare)	ϕ15.88 (5/8") (Flare)
B	Liquid piping	ϕ6.35 (1/4") (Flare)	ϕ9.52 (3/8") (Flare)
C 1,2	Drain piping	VP20	
D	Hole for suspension bolts	(M10 or M8)	
E	Back cutout	PE cover	
F	Top cutout	Plate cover	
G	Hole for drain piping (for left back)	(Knock out)	

PFA004Z085

Models FDE100VH, 125VH, 140VH



Symbol	Content	
A	Gas piping	ϕ15.88 (5/8") (Flare)
B	Liquid piping	ϕ9.52 (3/8") (Flare)
C 1,2	Drain piping	VP20
D	Hole for suspension bolt	(M10 or M8)
E	Back cutout	PE cover
F	Top cutout	Plate cover
G	Hole for drain piping (for left back)	(Knock out)

PFA004Z086

(f) Wall mounted type (SRK)

Models SRK50ZSX-W, 60ZSX-W



RLF000Z202

Models SRK71ZR-W, 100ZR-W

Symbol	Content	
A	Gas piping	ϕ15.88 (5/8") (Flare)
B	Liquid piping	SRK 71 ϕ6.35 (1/4") (Flare) SRK 100 ϕ9.52 (3/8") (Flare)
C	Hole on wall for right rear piping	(ϕ65)
D	Hole on wall for left rear piping	(ϕ65)
E	Drain hose	VP16
F	Outlet for wiring (on both side)	
G	Outlet for piping (on both side)	





Notes (1) The model name label is attached on the underside of the indoor unit.
(2) To connect the wired remote control, the interface kit (SC-BIKN2-E) is required.

Unit:mm









Space for installation and service when viewing from the front

RLD000Z005 A

(2) Outdoor units

Model FDC100VNA-W, 125VNA-W, 140VNA-W

100VSA-W, 125VSA-W, 140VSA-W



PCA001Z853

(3) Remote control (Option parts)

(a) Wired remote control

Model RC-EX3A

Dimensions (Viewed from front)



Installation space



Secure minimum spaces for disassembling the case.
Upper left and Upper right sides
……30mm or more
Bottom side…120mm or more
If using L-shaped screwdriver, 50mm or more is available.

● Do not install the remote control at following places.

1) It could cause break-down or deformation of remote control.
   - Where it is exposed to direct sunlight
   - Where the ambient temperature becomes 0 °C or below, or 40 °C or above
   - Where the surface is not flat
   - Where the strength of installation area is insufficient
2) Moisture may be attached to internal parts of the remote control, resulting in a display failure.
   - Place with high humidity where condensation occurs on the remote control
   - Where the remote control gets wet
3) Accurate room temperature may not be detected using the temperature sensor of the remote control.
   - Where the average room temperature cannot be detected
   - Place near the equipment to generate heat
   - Place affected by outside air in opening/closing the door
   - Place exposed to direct sunlight or wind from air-conditioner
   - Where the difference between wall and room temperature is large
4) When you are using the automatic grille up and down panel in the IU, you may not be able to confirm the up and down motion.
   - Where the IU cannot be visually confirmed

R/C cable:0.3mm²x2 cores

When the cable length is longer than 100 m, the max size for wires used in the R/C case is 0.5 mm² . Connect them to wires of larger size near the outside of R/C. When wires are connected, take measures to prevent water, etc. from entering inside.

≦ 200 m	0.5 mm² x 2 cores
≦ 300m	0.75 mm² x 2 cores
≦ 400m	1.25 mm² x 2 cores
≦ 600m	2.0 mm² x 2 cores

● When installing the unit at a hospital, telecommunication facility, etc., take measures to suppress electric noises.

It could cause malfunction or break-down due to hazardous effects on the inverter, private power generator, high frequency medical equipment, radio communication equipment, etc.
The influences transmitted from the remote control to medical or communication equipment could disrupt medical activities, video broadcasting or cause noise interference.

Adapted RoHS directive

PJZ000Z333

Model RC-E5

Exposed mounting



Exterior appearance (Munsell color)	Pearl white (N8.5) near equivalent

Wiring outlet
Cut off the upper thin part of remote control lower case with a nipper or knife, and grind burrs with a file etc.



The peeling-off length of sheath

Pulling out from upper left	Pulling out from center
X wiring : 215mm Y wiring : 195mm	X wiring : 170mm Y wiring : 190mm

Embedded mounting



Remote control installation dimensions



1) Installation screw for remote control
M4 screw (2 pieces)

Unit:mm

Wiring specifications

1) If the prolongation is over 100m, change to the size below.
But, wiring in the remote control case should be under 0.5mm². Change the wire size outside of the case according to wire connecting. Waterproof treatment is necessary at the wire connecting section. Be careful about contact failure.

Length	Wiring thickness
100 to 200m	0.5mm²×2 cores
Under 300m	0.75mm²×2 cores
Under 400m	1.25mm²×2 cores
Under 600m	2.0mm²×2 cores

PJZ000Z295

(b) Wireless remote control

RCN-E2(Option parts) (Except SRK series)

Unit: mm



SRK series only

Unit: mm



1.3 ELECTRICAL WIRING

(1) Indoor units

(a) Ceiling cassette-4 way type (FDT)

Models FDT50VH, 60VH, 71VH, 100VH, 125VH, 140VH



PJF000Z554

(b) Ceiling casette-4 way compact type (FDTC)

Models FDTC50VH, 60VH

Meaning of marks

Item	Description
AM1-4	Draft prevention function motor
CNB-Z	Connector
DM	Drain pump motor
F1,2	Fuse
FMi	Fan motor
FS	Float switch
HS	Humidity sensor
LED･2	Indication lamp (Green-Nomal operation)
LED･3	Indication lamp (Red-Inspection)
LM1-4	Louver motor
PIS	Motion sensor
SW2	Remote control communication address
SW5	Plural units Master／Slave setting
SW6	Model capacity setting
SW7-1	Operation check,drain pump motor test run
TB1	Terminal block (Power source) (□mark)
TB2	Terminal block (Signal line) (□mark)
Thc	Temperature sensor (Remote control)
Thi-A	Temperature sensor (Return air)
Thi-R1,2,3	Temperature sensor (Heat exchanger)

Color marks

Mark	Color	Mark	Color
BK	Black	WH	White
BL	Blue	YE	Yellow
BR	Brown	GY	Gray
OR	Orange	YE／GN	Yellow／Green
RD	Red		



Notes 1. - - - indicates wiring on site.
2. See the wiring diagram of outdoor unit about the line between indoor unit and outdoor unit.
3. Use twin core cord (0.3mm²) at remote control line.
4. Do not put remote control line alongside power source line.
5. Draft prevention function (※1) is provided on the panel TC-PSAE-5AW-E only.

PJF000Z516 A

(c) Duct connected-High static pressure type (FDU)

Models FDU100VH, 125VH, 140VH

Meaning of marks

Item	Description
CNB-Z	Connector
DM	Drain pump motor
F1,3,4	Fuse
FMi1,2	Fan motor
FS	Float switch
L	Reactor
LED･2	Indication lamp (Green-Normal operation)
LED･3	Indication lamp (Red-Inspection)
PIS	Motion sensor
SW2	Remote control communication address
SW5	Plural units Master／Slave setting
SW6	Model capacity setting
SW7-1	Operation check,drain pump motor test run
TB1	Terminal block (Power source) (□mark)
TB2	Terminal block (Signal line) (□mark)
Thc	Temperature sensor (Remote control)
Thi-A	Temperature sensor (Return air)
Thi-R1,2,3	Temperature sensor (Heat exchanger)
■mark	Closed-end connector

Color Marks

Mark	Color
BK	Black
BL	Blue
RD	Red
WH	White
YE	Yellow
YE／GN	Yellow／Green



Notes 1. ——indicates wiring on site.
2. See the wiring diagram of outdoor unit about the line between indoor unit and outdoor unit.
3. Use twin core cord (0.3mm^2) at remote control line.
See spec sheet of remote control in case that the total length is more than 100m.
4. Do not put remote control line alongside power source line.
5. Section 1 (※1) shows electric circuit of motion sensor (Option) .

PJG000Z580

(d) Duct connected-Low / Middle static pressure type (FDUM)

Model FDUM50VH



Notes 1. ---- indicates wiring on site.
2. See the wiring diagram of outdoor unit about the line between indoor unit and outdoor unit.
3. Use twin core cord (0.3mm^2) at remote control line.
See spec sheet of remote control in case that the total length is more than 100m.
4. Do not put remote control line alongside power source line.
5. Section 1 (※1) shows electric circuit of motion sensor (Option).

PJG000Z488

Models FDUM60VH, 71VH



Notes 1. ——— indicates wiring on site.
2. See the wiring diagram of outdoor unit about the line between indoor unit and outdoor unit.
3. Use twin core cord (0.3mm²) at remote control line.
See spec sheet of remote control in case that the total length is more than 100m.
4. Do not put remote control line alongside power source line.
5. Section 1 (※1) shows electric circuit of motion sensor (Option).

PJG000Z489

Models FDUM100VH, 125VH, 140VH

Meaning of marks

Item	Description
CNB-Z	Connector
DM	Drain pump motor
F1,3,4	Fuse
FMi1,2	Fan motor
FS	Float switch
L	Reactor
LED･2	Indication lamp (Green-Normal operation)
LED･3	Indication lamp (Red-Inspection)
PIS	Motion sensor
SW2	Remote control communication address
SW5	Plural units Master／Slave setting
SW6	Model capacity setting
SW7-1	Operation check,drain pump motor test run
TB1	Terminal block (Power source) (□mark)
TB2	Terminal block (Signal line) (□mark)
Thc	Temperature sensor (Remote control)
Thi-A	Temperature sensor (Return air)
Thi-R1,2,3	Temperature sensor (Heat exchanger)
■mark	Closed-end connector

Color Marks

Mark	Color
BK	Black
BL	Blue
BR	Brown
OR	Orange
RD	Red
WH	White
YE	Yellow
YE／GN	Yellow／Green



Notes 1. ---- indicates wiring on site.
2. See the wiring diagram of outdoor unit about the line between indoor unit and outdoor unit.
3. Use twin core cord (0.3mm^2) at remote control line.
See spec sheet of remote control in case that the total length is more than 100m.
4. Do not put remote control line alongside power source line.
5. Section 1 (※1) shows electric circuit of motion sensor (Option).

PJG000Z490

(e) Ceiling suspended type (FDE)

Models FDE50VH, 60VH, 71VH, 100VH, 125VH, 140VH



Color marks

Mark	Color
BK	Black
BL	Blue
BR	Brown
OR	Orange
PK	Pink
RD	Red
WH	White
YE	Yellow
YE/GN	Yellow/Green

Meaning of marks

Item	Description
CNB-Z	Connector
F1-3	Fuse
FMi	Fan motor
L	Reactor
LED•2	Indication lamp (Green-Normal operation)
LED•3	Indication lamp (Red-Inspection)
LM	Louver motor
PIS	Motion sensor
SW2	Remote control communication address
SW5	Plural units Master/Slave setting
SW6	Model capacity setting
SW7-1	Operation check,drain pump motor test run
SW8-1	Anti-freeze control
TB1	Terminal block (Power source) (□mark)
TB2	Terminal block (Signal line) (□mark)
Thc	Temperature sensor (Remote control)
Thi-A	Temperature sensor (Return air)
Thi-R1,2,3	Temperature sensor (Heat exchanger)

Notes 1. ----- indicates wiring on site.
2. See the wiring diagram of outdoor unit about the line between indoor unit and outdoor unit.
3. Use twin core cord (0.3mm²) at remote control line. See spec sheet of remote control in case that the total length is more than 100m.
4. Do not put remote control line alongside power source line.
5. Section 1 (※1) shows electric circuit of motion sensor (Option).

PFA004Z087

(f) Wall mounted type (SRK)

Models SRK50ZSX-W, 60ZSX-W

Item	Description
	Connector
CNE	
CNF	
CNG	
CNJ	
CNL	
CNM	
CNP	
CNS	
CNU	
CNX	
CNY	
CNZ	



RWA000Z413

Models SRK71ZR-W, 100ZR-W

Item	Description
CNE	Connector
CNF	
CNG	
CNM	
CNS	
CNU	
CNX	
CNY	
FMi	Fan motor
SM_1	Flap motor
$LM_{1,2}$	Louver motor
Th1	Room temperature sensor
$Th2_{1,2}$	Heat exchanger temperature sensor
Th3	Humidity sensor
DS	Diode stack
F	Fuse
TB	Terminal block
Va	Varistor

Color Marks

Mark	Color
BK	Black
BL	Blue
RD	Red
WH	White
Y	Yellow
Y／G	Yellow／Green



RWA000Z417A

(2) Outdoor units

Models FDC100VNA-W, 125VNA-W, 140VNA-W

Meaning of marks

Item	Description
CH	Crankcase heater
CM	Compressor motor
CN	Connector
CT1	Current sensor
EEVC	Expansion valve for cooling
EEVH	Expansion valve for heating
F	Fuse
FM1	Fan motor
IPM	Intelligent power module
LED1	Indication lamp (GREEN)
LED2	Indication lamp (RED)
L1,2	Reactor
PSL	Low pressure sensor
SW1	Switch
SW3,5,7	Local setting switch
TB	Terminal block
THo-A	Temperature sensor (Outdoor air)
THo-D	Temperature sesor (Discharge pipe)
THo-R1,R2	Temperature sensor (Heat exchanger)
THo-S	Temperature sensor (Suction pipe)
20S	Solenoid valve for 4-way valve
52X1	Auxiliary relay
52X3	Auxiliary relay
52X11	Auxiliary relay (for 20S)
52X14	Auxiliary relay (for CH)
52X15	Auxiliary relay
63H1	High pressure switch

Color marks

Mark	Color
BK	Black
BL	Blue
BR	Brown
GN	Green
OR	Orange
RD	Red
WH	White
Y	Yellow
Y/GN	Yellow/Green



Power cable, indoor-outdoor connecting wires

Model	MAX over current (A)	Power cable size (mm^2)	Power cable length (m)	indoor-outdoor wire size x number	Earth wire size (mm)
100	24	5.5	22	ϕ1.6mm x 3	ϕ1.6
125					
140					

※At the connection with the duct type indoor unit.

Model	MAX over current (A)	Power cable size (mm^2)	Power cable length (m)	indoor-outdoor wire size x number	Earth wire size (mm)
100	26	5.5	20	ϕ1.6mm x 3	ϕ1.6
125					
140	27				

Local setting switch SW3,5,7 (Set up at shipment OFF)

SW3-1	Defrost control change	The defrost operation interval becomes shorter by turning ON this switch. This switch should be turned ON in the area where outside temperature becomes below the freezing point.
SW3-2	Snow guard fan control	When this switch is turned ON, the outdoor unit fan will run for 30 seconds in every 10 minutes, when outdoor temperature falls to 3°C or lower and the compressor is not running when the unit is used in a very snowy country, set this switch to ON.
SW3-3,4	Trial operation	Method of trial operation ①Trial operation can be performed by using SW3-3,4. ②Compressor will be in the operation when SW3-3 is ON. ③Cooling trial operation will be performed when SW3-4 is OFF, and heating trial operation when SW3-4 is ON ④Be sure to turn OFF SW3-3 after the trial operation is finished.
SW5-2	High height difference operation control	Set this switch to ON when outdoor unit is installed at a position higher than indoor unit by 30m or more.
SW7-2	Defrost control change	Set this switch to ON when managing unit operation by remote control connected external equipment.
SW7-3	Lower noise silent mode	Upper limit of compressor speed and fan speed becomes lower in silent mode.

- The specifications shown in the above table are for units without heaters. For units with heaters, refer to the installation instructions or the construction instructions of the indoor unit.
- Switchgear of circuit breaker capacity which is calculated from MAX. over current should be chosen along the regulations in each country.
- The cable specifications are based on the assumption that a metal or plastic conduit is used with no more than three cables contained in a conduit and a voltage drop is 2%. For an installation falling outside of these conditions, please follow the internal cabling regulations. Adapt it to the regulation in effect in each country.

PCA001Z854

Models FDC100VSA-W, 125VSA-W, 140VSA-W

Meaning of marks

Item	Description
CH	Crankcase heater
CM	Compressor motor
CN	Connector
EEVC	Expansion valve for cooling
EEVH	Expansion valve for heating
F	Fuse
FM1	Fan motor
IPM	Intelligent power module
L	Reactor
LED1	Indication lamp (GREEN)
LED2	Indication lamp (RED)
PSL	Low pressure sensor
SW1	Switch
SW3,5,7	Local setting switch
TB	Terminal block
THo-A	Temperature sensor (Outdoor air)
THo-D	Temperature sensor (Discharge pipe)
THo-R1,R2	Temperature sensor (Heat exchanger)
THo-S	Temperature sensor (Suction pipe)
20S	Solenoid valve for 4-way valve
52X1	Auxiliary relay
52X2	Auxiliary relay
52X6	Auxiliary relay (for FM1)
52X11	Auxiliary relay (for 20S)
52X14	Auxiliary relay (for CH)
52X15	Auxiliary relay
63H1	High pressure switch

Color marks

Mark	Color
BK	Black
BL	Blue
BR	Brown
GN	Green
OR	Orange
RD	Red
WH	White
Y	Yellow
Y/GN	Yellow/Green



Local setting switch SW3,5,7 (Set up at shipment OFF)

SW3-1	Defrost control change	The defrost operation interval becomes shorter by turning ON this switch. This switch should be turned ON in the area where outside temperature becomes below the freezing point.
SW3-2	Snow guard fan control	When this switch is turned ON, the outdoor unit fan will run for 30 seconds in every 10 minutes, when outdoor temperature falls to 3°C or lower and the compressor is not running when the unit is used in a very snowy country, set this switch to ON.
SW3-3,4	Trial operation	Method of trial operation ①Trial operation can be performed by using SW3-3,4. ②Compressor will be in the operation when SW3-3 is ON. ③Cooling trial operation will be performed when SW3-4 is OFF, and heating trial operation when SW3-4 is ON ④Be sure to turn OFF SW3-3 after the trial operation is finished.
SW5-2	High height difference operation control	Set this switch to ON when outdoor unit is installed at a position higher than indoor unit by 30m or more.
SW7-2	Defrost control change	Set this switch to ON when managing unit operation by remote control connected external equipment.
SW7-3	Lower noise silent mode	Upper limit of compressor speed and fan speed becomes lower in silent mode.

Power cable, indoor-outdoor connecting wires

Model	MAX over current (A)	Power cable size (mm^2)	Power cable length (m)	indoor-outdoor wire size x number	Earth wire size (mm)
100	15	3.5	46	ϕ1.6mm x 3	ϕ1.6
125					
140					

※At the connection with the duct type indoor unit.

Model	MAX over current (A)	Power cable size (mm^2)	Power cable length (m)	indoor-outdoor wire size x number	Earth wire size (mm)
100	17	3.5	40	ϕ1.6mm x 3	ϕ1.6
125					
140	18		38		

- The specifications shown in the above table are for units without heaters. For units with heaters, refer to the installation instructions or the construction instructions of the indoor unit.
- Switchgear of circuit breaker capacity which is calculated from MAX. over current should be chosen along the regulations in each country.
- The cable specifications are based on the assumption that a metal or plastic conduit is used with no more than three cables contained in a conduit and a voltage drop is 2%. For an installation falling outside of these conditions, please follow the internal cabling regulations. Adapt it to the regulation in effect in each country.

PCA001Z855

1.4. NOISE LEVEL

Notes(1) The data are based on the following conditions.
Ambient air temperature: Indoor unit 27℃WB. Outdoor unit 35℃DB.
(2) The data in the chart are measured in an anechoic room.
(3) The noise levels measured in the field are usually higher than the data because of reflection.

Measured based on JIS B 8616
Mike position



Mike (in front & below unit)

(1) Indoor units

(a) Ceiling cassette-4way type (FDT)

(i) Sound power level

Model FDT50VH
Noise level Cooling : 55 dB (A)
Heating : 56 dB (A)



Model FDT60VH
Noise level Cooling : 58 dB (A)
Heating : 59 dB (A)



Model FDT71VH
Noise level Cooling : 59 dB (A)
Heating : 60 dB (A)



Model FDT100VH
Noise level Cooling : 62 dB (A)
Heating : 62 dB (A)



Models FDT125VH,140VH
Noise level Cooling : 63 dB (A)
Heating : 64 dB (A)



(ii) Sound pressure level

Model FDT50VH

Noise level 41 dB(A) at P-Hi
33 dB(A) at Hi
30 dB(A) at Me
26 dB(A) at Lo

Cooling



Noise level 42 dB(A) at P-Hi
33 dB(A) at Hi
28 dB(A) at Me
20 dB(A) at Lo

Heating



Model FDT60VH

Noise level 44 dB(A) at P-Hi
34 dB(A) at Hi
30 dB(A) at Me
27 dB(A) at Lo

Cooling



Noise level 44 dB(A) at P-Hi
34 dB(A) at Hi
30 dB(A) at Me
20 dB(A) at Lo

Heating



Model FDT71VH

Noise level 46 dB (A) at P-Hi
34 dB (A) at Hi
31 dB (A) at Me
26 dB (A) at Lo

Cooling



Noise level 46 dB (A) at P-Hi
34 dB (A) at Hi
31 dB (A) at Me
26 dB (A) at Lo

Heating



Model FDT100VH

Noise level 47 dB (A) at P-Hi
39 dB (A) at Hi
36 dB (A) at Me
30 dB (A) at Lo

Cooling



Noise level 47 dB (A) at P-Hi
39 dB (A) at Hi
36 dB (A) at Me
29 dB (A) at Lo

Heating



Models FDT125VH,140VH

Noise level 49 dB (A) at P-Hi
41[42] dB (A) at Hi
39 dB (A) at Me
31[32] dB (A) at Lo

Cooling



Noise level 48 dB (A) at P-Hi
41 dB (A) at Hi
38 dB (A) at Me
31 dB (A) at Lo

Heating



Note (1) Values in [ ] are for the FDT140VH

(b) Ceiling cassette-4 way compact type (FDTC)

Measured based on JIS B 8616
Mike position as right



Model FDTC50VH

Noise level 44 dB(A) at P-Hi
40 dB(A) at Hi
35 dB(A) at Me
27 dB(A) at Lo



Model FDTC60VH

Noise level 44 dB(A) at P-Hi
40 dB(A) at Hi
35 dB(A) at Me
27 dB(A) at Lo



(c) Duct connected-High static pressure type (FDU)

Measured based on JIS B 8616
Mike position as right



Model FDU100VH

Noise level 44 dB(A) at P-Hi
38 dB(A) at Hi
36 dB(A) at Me
30 dB(A) at Lo



Model FDU125VH

Noise level 45 dB(A) at P-Hi
40 dB(A) at Hi
34 dB(A) at Me
29 dB(A) at Lo



Model FDU140VH

Noise level 47 dB(A) at P-Hi
40 dB(A) at Hi
35 dB(A) at Me
30 dB(A) at Lo



(d) Duct connected-Low/Middle static pressure type (FDUM)



Measured based on JIS B 8616
Mike position as right

Model FDUM50VH

Noise level 37 dB(A) at P-Hi
32 dB(A) at Hi
29 dB(A) at Me
26 dB(A) at Lo



Model FDUM60VH

Noise level 36 dB(A) at P-Hi
31 dB(A) at Hi
28 dB(A) at Me
25 dB(A) at Lo



Model FDUM71VH

Noise level 38 dB(A) at P-Hi
33 dB(A) at Hi
29 dB(A) at Me
25 dB(A) at Lo



Model FDUM100VH

Noise level 44 dB(A) at P-Hi
38 dB(A) at Hi
36 dB(A) at Me
30 dB(A) at Lo



Model FDUM125VH

Noise level 45 dB(A) at P-Hi
40 dB(A) at Hi
34 dB(A) at Me
29 dB(A) at Lo



Model FDUM140VH

Noise level 47 dB(A) at P-Hi
40 dB(A) at Hi
35 dB(A) at Me
30 dB(A) at Lo



(e) Ceiling suspended type (FDE)



Measured based on JIS B 8616
Mike position as right

Model FDE50VH

Noise level 46 dB(A) at P-Hi
38 dB(A) at Hi
36 dB(A) at Me
31 dB(A) at Lo



Models FDE60VH, 71VH

Noise level 47 dB(A) at P-Hi
41 dB(A) at Hi
37 dB(A) at Me
32 dB(A) at Lo



Model FDE100VH

Noise level 48 dB(A) at P-Hi
43 dB(A) at Hi
38 dB(A) at Me
34 dB(A) at Lo



Model FDE125VH

Noise level 48 dB(A) at P-Hi
45 dB(A) at Hi
40 dB(A) at Me
35 dB(A) at Lo



Model FDE140VH

Noise level 49 dB(A) at P-Hi
45 dB(A) at Hi
40 dB(A) at Me
36 dB(A) at Lo



(f) Wall mounted type (SRK)

Measured based on JIS C 9612
Mike position as right



Model SRK50ZSX-W

Cooling noise level Hi : 44 dB (A)
Heating noise level Hi : 46 dB (A)



Model SRK60ZSX-W

Cooling noise level Hi : 46 dB (A)
Heating noise level Hi : 46 dB (A)



Model SRK71ZR-W

Cooling noise level Hi : 44 dB (A)
Heating noise level Hi : 46 dB (A)



Model SRK100ZR-W

Cooling noise level Hi : 48 dB (A)
Heating noise level Hi : 48 dB (A)



(2) Outdoor units

Measured based on JIS B 8616
Mike position: at highest noise level in position as mentioned below
Distance from front side 1m
Height 1m

(a) Sound power level

Models FDC100VNA-W,100VSA-W
Cooling noise level 69 dB (A)
Heating noise level 70 dB (A)



Models FDC125VNA-W,125VSA-W
Cooling noise level 71 dB (A)
Heating noise level 71 dB (A)



Models FDC140VNA-W,140VSA-W
Cooling noise level 72 dB (A)
Heating noise level 73 dB (A)



(b) Sound pressure level

(i) Rating mode

Models FDC100VNA-W,100VSA-W
Cooling noise level 54 dB (A)
Heating noise level 55 dB (A)



Models FDC125VNA-W,125VSA-W
Cooling noise level 54 dB (A)
Heating noise level 56 dB (A)



Models FDC140VNA-W,140VSA-W
Cooling noise level 56 dB (A)
Heating noise level 58 dB (A)



1.5 CHARACTERISTICS OF FAN

(1) Duct connected-High static static pressure type (FDU)

- Characteristic FAN (1) shows air flow vs. External Static Pressure (E.S.P.) range where settings of E.S.P. are maximum E.S.P. (SW8-4 OFF : 150Pa, SW8-4 ON : 200Pa) , rated E.S.P., and minimum E.S.P. (SW8-4 OFF : 80Pa, SW8-4 ON : 10Pa)
- Characteristic FAN (2) shows air flow vs E.S.P. curve when set fan tap is set P-Hi with each setting of E.S.P. by remote control.
- External Static Pressure (E.S.P.) can be set by wired remote control.
- You can set required E.S.P. by wired remote control which calculate it with the set air flow rate and pressure loss of the duct connected.

Model FDU100VH

■SW8-4 : OFF (Range of use limitation : Setting 80Pa-150Pa)

Characteristic FAN (1)



Characteristic FAN (2)



■SW8-4 : ON (Range of use limitation : Setting 10Pa-200Pa)

Characteristic FAN (1)



Characteristic FAN (2)



Model FDU125VH

■SW8-4 : OFF (Range of use limitation : Setting 80Pa-150Pa)

Characteristic FAN (1)



Characteristic FAN (2)



■SW8-4 : ON (Range of use limitation : Setting 10Pa-200Pa)

Characteristic FAN (1)



Characteristic FAN (2)



Model FDU140VH

■SW8-4 : OFF (Range of use limitation : Setting 80Pa-150Pa)

Characteristic FAN (1)



Characteristic FAN (2)



■SW8-4 : ON (Range of use limitation : Setting 10Pa-200Pa)

Characteristic FAN (1)



Characteristic FAN (2)



(2) Duct connected-Low / Middle static pressure type (FDUM)

- Characteristic FAN (1) shows air flow vs. External Static Pressure (E.S.P.) range where settings of E.S.P. are maximum E.S.P. (100Pa) , rated E.S.P., and minimum E.S.P. (10Pa)
- Characteristic FAN (2) shows air flow vs E.S.P. curve when set fan tap is set P-Hi with each setting of E.S.P by remote control.
- External Static Pressure (E.S.P.) can be set by wired remote control.
- You can set required E.S.P. by wired remote control which calculate it with the set air flow rate and pressure loss of the duct connected.

Model FDUM50VH

Characteristic FAN(1)



Characteristic FAN(2)



Model FDUM60VH

Characteristic FAN(1)



Characteristic FAN(2)



Model FDUM71VH

Characteristic FAN(1)



Characteristic FAN(2)



Model FDUM100VH

Characteristic FAN(1)



Characteristic FAN(2)



Model FDUM125VH

Characteristic FAN(1)



Characteristic FAN(2)



Model FDUM140VH

Characteristic FAN(1)



Characteristic FAN(2)



1.6 TEMPERATURE AND VELOCITY DISTRIBUTION

Indoor temperature
Cooling 27°CDB / 19°CWB
Heating 20°CDB
Note: These figures represent the typical main range of temperature and velocity distribution at the center of air outlet within the published conditions.
In the actual installation, they may differ from the typical figures under the influence of air temperature conditions, ceiling height, operation conditions and obstacles.

(1) Ceiling cassette-4 way type (FDT)

Model FDT50VH

Cooling Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



Heating Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



Models FDT60VH, 71VH

Cooling Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



Heating Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



Models FDT100VH, 125VH, 140VH

Cooling Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



Heating Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



(2) Ceiling casstte-4 way compact type (FDTC)

Model FDTC50VH

Cooling Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



Heating Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



Model FDTC60VH

Cooling Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



Heating Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



(3) Ceiling suspended type (FDE)

Model FDE50VH

Cooling Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



Heating Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



Models FDE60, 71VH

Cooling Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



Heating Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



Models FDE100, 125VH

Cooling Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



Heating Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



Model FDE140VH

Cooling Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



Heating Air flow: P-Hi

Louver position



Temperature distribution



Velocity distribution



1.7 PIPING SYSTEM

(1) Single type

Models 100, 125, 140



(2) Twin type

Models 100, 125, 140



(3) Triple type

Model 140



Preset point of the protective devices

Parts name	Mark	Equipped unit	100, 125, 140 model
Temperature sensor (for protection over-loading in heating)	**Thi-R (Tho-A)**	Indoor unit	OFF 63˚C (OFF 16˚C) ON 56˚C (ON 17˚C)
Temperature sensor (for frost prevention)	**Thi-R (Th2)**		OFF 1.0˚C (OFF 2.5˚C) ON 10˚C (ON 8˚C)
Temperature sensor (for protection high pressure in cooling.)	**Tho-R**	Outdoor unit	OFF 51˚C ON 65˚C
Temperature sensor (for detecting dis-charge pipe temp.)	**Tho-D**	Outdoor unit	OFF 115˚C ON 85˚C
High pressure switch (for protection)	**63H1**	Outdoor unit	OFF 4.15MPa ON 3.15MPa

Note (1) Values in ( ) are for the SRK models.

1.8 RANGE OF USAGE & LIMITATIONS

Operating temperature range		See next page.
		When used below -5℃, install a snow hood (locally procured).
Recommendable area to install		Considering to get sufficient heating capacity, the area where the averaged lowest ambient air temperature in day time during winter is above 0℃, and it has no accumulation of snow.
Installation site		The limitations of installation space are shown in the page for exterior dimensions. Install the indoor unit at least 2.5m higher than the floor surface.
Temperature and humidity conditions surrounding the indoor unit in the ceiling (Note 2)		Model FDE Dew point temperature : 23℃ or less, relative hummdity : 80% or less Other models Dew point temperature : 28℃ or less, relative hummdity : 80% or less
Limitations on unit and piping installation		See pages 120 and 121.
Compressor ON-OFF cycling	Cycle Time	7 minutes or more (from OFF to OFF) or (from ON to ON)
	Stop Time	3 minutes or more
Power source	Voltage range	Rating ±10%
	Voltage drop at start-up	Min.85% of rating
	Phase-to-phase imbalance	3% or less

Note 1. Do not install the unit in places which :
1) Flammable gas may leak.
2) Carbon fiber, metal particles, powder, etc. are floating.
3) Cosmetic or special sprays are used frequently.
4) Exposed to oil splashes or steam (e.g. kitchen and machine plant).
5) Exposed to sea breeze (e.g. coastal area) or calcium chloride (e.g. snow melting agent).
6) Exposed to ammonia substance (e.g. organic fertilizer).
7) Matters affecting devices, such as sulfuric gas, chlorine gas, acid, alkali, etc. may generate or accumulate.
8) Chimney smoke is hanging.
9) Sucking the exhaust gas from heat exchanger.
10) Adjacent to equipment generating electromagnetic waves or high frequency waves.
11) There is light beams that affect the receiving device of indoor unit in case of the wireless specification.
12) Snow falls heavily.
13) At an elevation of 1000 meters or higher.
14) On mobile machine (e.g. vehicle, ship, etc.)
15) Splashed with water to indoor unit (e.g. laundry room).
16) Indoor units of twin and triple specifications separately in a room with partition.

Note 2. If ambient temperature and humidity exceed the above conditions, add polyurethane foam insulation (10mm or thicker) on the outer plate of indoor unit.

Note 3. Both gas and liquid pipes need to be coverd with 20mm or thicker heat insulation materials at the place where humidity exceeds 70%.

Note 4. When snow accumulate, install a snow hood on site.

Note 5. The indoor unit shall be installed in a room with minimum installation area or more according to the refrigerant charge amount. (for details, refer to installation sheet)

PCA001Z858

Operating temperature range

■ **Cooling**



■ **Heating**



Decline in cooling and heating capacity or operation stop may occur when the outdoor unit is installed in places where natural wind can increase or decrease its design air flow rate.

PCA001Z858

"CAUTION" Cooling operation under low outdoor air temperature conditions

PAC models can be operated in cooling mode at low outdoor air temperature condition within above temperature range. However in case of severely low temperature conditions if the following precaution is not observed, it may not be operated in spite of operable temperature range mentioned above and cooling capacity may not be established under certain conditions.

[Precaution]

In case of severely low temperature condition

1) Install the outdoor unit at the place where strong wind cannot blow directly into the outdoor unit.
2) If there is no installation place where can prevent strong wind from directly blowing into the outdoor unit, mount the flex flow adapter (prepared as option part) or like such devices onto the outdoor unit in order to divert the strong wind.

[Reason]

Under the low outdoor air temperature conditions of -5°C or lower, the outdoor fan is controlled at lower or lowest speed by outdoor fan control, but if strong wind directly blow into the outdoor unit, the outdoor heat exchanger temperature will drop more.

This makes high and low pressures to drop as well. This low pressure drop makes the indoor heat exchanger temperature to drop and will activate anti-frost control at indoor heat exchanger at frequent intervals, that cooling operation may not be established for any given time.

Limitation on unit and piping installation - single,twin.

Descriptions	Model for outdoor units		Dimensional limitations	Marks appearing in the drawing	
				Single type	Twin type
One-way pipe length	100V・125V・140V		≦ 50m	L	L＋L 1＋L 2
Main pipe length	100V・125V・140V		≦ 50m		L
One-way pipe length after the first branching point	100V・125V・140V		≦ 30m		L 1, L 2
Difference of pipe length after the first branching point			≦ 10m		L 1-L 2 L 2-L 1
Total pipe length after the second branching point			≦ 15m		
Elevation difference between indoor and outdoor units	When the outdoor unit is positioned higher	100V・125V・140V	≦ 30m (≦50m) ＊	H	H
	When the outdoor unit is positioned lower	100V・125V・140V	≦ 15m		
Elevation difference among indoor units			≦ 0.5m		h

Single type



Twin type



Twin type

Model for outdoor units	Branch piping set(option)
100V・125V・140V	DIS-WA1G

Notes

(1) A riser pipe must be part of the main.

A branching pipe set should be installed horizontally at a point as close to an indoor unit as possible.

(2) In case of the outdoor unit is positioned higher, dimensional limitation change from 30m to 50m by changing SW5-2 of outdoor unit control PCB to ON. (＊ mark)

Limitation on unit and piping installation - triple.

Triple type (in case of 140V)	One-way pipe length difference from the first branching point to the indoor unit		Marks appearing in the drawing	
			＜ 3m	≧ 3m
Descriptions	Model for outdoor units	Dimensional limitations	Triple type A	Triple type B
One-way pipe length	140V	≦ 50m	L＋L1＋L2＋L3	L＋La＋L1＋L2＋L3 ※1
Main pipe length	140V	≦ 50m	L	L
Piping length between the first branching point and the second branching point		≦ 5m		La
One-way pipe length between the first branching point and indoor units		≦ 30m	L1, L2, L3	L1 ※1
One-way pipe length from the first branching point to indoor units through the second branching point		≦ 27m		La＋L2 , La＋L3 ※1
Piping length difference from the first branching point to indoor unit		＜ 3m	L1－L2, L1－L3, L2－L3	
		3m ≦ , ≦ 10m		L1－（La＋L2）, L1－（La＋L3） ※1
One-way pipe length difference from the second branching point to indoor unit		≦ 10m		L2－L3, L3－L2
Elevation difference between indoor and outdoor units	When the outdoor unit is positioned higher	≦ 30m (≦ 50m) ＊	H	H
	When the outdoor unit is positioned lower	≦ 15m		
Elevation difference among indoor units		≦ 0.5m	h1, h2, h3	h1, h2, h3

Triple type A



Triple type B



※1 Install the indoor units so that L＋L1 becomes the longest one-way pipe. Keep the pipe length difference between L1 and (La＋L2) or (La＋L3) within 10m.

Triple type

Model for outdoor units	Branch piping set(option)		
	Type A	Type B	
	Branch pipe	First Branch	Second Branch
140V	DIS-TA1G	DIS-WA1G	DIS-WA1G

Notes

(1) A riser pipe must be part of the main.
A branching pipe set should be installed horizontally at a point as close to an indoor unit as possible.

(2) In case of the outdoor unit is positioned higher, dimensional limitation change from 30m to 50m by changing SW5-2 of outdoor unit control PCB to ON. (＊ mark)

1.9 SELECTION CHART

Correct the cooling and heating capacity in accordance with the operating conditions. The net cooling and heating capacity can be obtained in the following way.

Net capacity = Capacity shown in the capacity tables (1.9.1) × Correction factors shown in the table (1.9.2) (1.9.3) (1.9.4).

Caution: In case that the cooling operation during low outdoor air temperature below -5℃ is expected, install the outdoor unit where it is not influenced by natural wind. Otherwise protection control by low pressure will be activated much more frequently and it will cause insufficient capacity or breakdown of the compressor in worst case.

1.9.1 Capacity tables

(1) Ceiling cassette-4 way type (FDT)

(a) Single type

Model FDT100VNAWVH Indoor unit FDT100VH Outdoor unit FDC100VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.56	11.60	8.50	11.92	8.36	12.55	8.77	13.18	8.44
-10							10.67	8.46	11.23	8.40	11.53	8.26	12.13	8.68	12.73	8.36
-5							10.31	8.36	10.85	8.30	11.35	8.21	12.35	8.73	13.36	8.47
0					8.55	7.34	10.33	8.36	11.22	8.40	11.56	8.27	12.25	8.70	12.93	8.39
5					9.01	7.49	10.41	8.39	11.11	8.37	11.44	8.24	12.09	8.67	12.74	8.36
11					9.41	7.61	10.44	8.39	10.96	8.33	11.36	8.22	12.15	8.68	12.94	8.39
13					9.80	7.74	10.47	8.40	10.81	8.29	11.27	8.19	12.20	8.69	13.13	8.43
15					10.19	7.87	10.50	8.41	10.66	8.25	11.19	8.17	12.26	8.70	13.32	8.47
17					9.83	7.75	10.59	8.44	10.97	8.33	11.40	8.23	12.26	8.71	13.13	8.43
19					10.26	7.89	10.67	8.46	11.27	8.41	11.61	8.28	12.27	8.71	12.94	8.39
21					10.08	7.83	10.56	8.43	11.15	8.38	11.49	8.25	12.15	8.68	12.82	8.37
23					9.90	7.77	10.45	8.40	11.04	8.35	11.37	8.22	12.03	8.66	12.70	8.35
25			9.79	8.29	9.81	7.74	10.40	8.38	10.98	8.33	11.31	8.20	11.97	8.64	12.63	8.34
27			9.62	8.22	9.72	7.71	10.35	8.37	10.92	8.32	11.39	8.22	11.86	8.62		
29			9.42	8.15	9.49	7.64	10.11	8.30	10.69	8.25	11.16	8.17	11.63	8.57		
31			9.21	8.08	9.26	7.57	9.87	8.23	10.46	8.19	10.93	8.11	11.39	8.52		
33	7.82	7.17	8.42	7.79	9.03	7.49	9.64	8.17	10.23	8.13	10.70	8.05	11.16	8.47		
35	7.68	7.12	8.24	7.73	8.80	7.42	9.40	8.10	10.00	8.07	10.46	7.99	10.93	8.42		
37	7.59	7.09	8.11	7.69	8.63	7.37	9.18	8.04	9.72	8.00	10.15	7.91	10.57	8.34		
39	7.50	7.05	7.98	7.64	8.46	7.32	8.95	7.98	9.44	7.93	9.83	7.84	10.22	8.27		
41	7.40	7.02	7.85	7.60	8.29	7.26	8.72	7.92	9.16	7.86	9.51	7.76	9.86	8.20		
43	7.31	6.98	7.72	7.55	8.12	7.21	8.50	7.86	8.88	7.78	9.19	7.69	9.50	8.13		
46	7.17	6.93	7.52	7.37	7.87	7.14	8.16	7.77	8.46	7.68	8.71	7.58	8.97	8.02		
50	5.60	5.49	5.73	5.62	5.90	5.78	6.05	5.93	6.17	6.05	6.28	6.15	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature ℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PJF000Z588 A

Model FDT100VSAWVH Indoor unit FDT100VH Outdoor unit FDC100VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.56	11.60	8.50	11.92	8.36	12.55	8.77	13.18	8.44
-10							10.67	8.46	11.23	8.40	11.53	8.26	12.13	8.68	12.73	8.36
-5							10.31	8.36	10.85	8.30	11.35	8.21	12.35	8.73	13.36	8.47
0					8.55	7.34	10.33	8.36	11.22	8.40	11.56	8.27	12.25	8.70	12.93	8.39
5					9.01	7.49	10.41	8.39	11.11	8.37	11.44	8.24	12.09	8.67	12.74	8.36
11					9.41	7.61	10.44	8.39	10.96	8.33	11.36	8.22	12.15	8.68	12.94	8.39
13					9.80	7.74	10.47	8.40	10.81	8.29	11.27	8.19	12.20	8.69	13.13	8.43
15					10.19	7.87	10.50	8.41	10.66	8.25	11.19	8.17	12.26	8.70	13.32	8.47
17					9.83	7.75	10.59	8.44	10.97	8.33	11.40	8.23	12.26	8.71	13.13	8.43
19					10.26	7.89	10.67	8.46	11.27	8.41	11.61	8.28	12.27	8.71	12.94	8.39
21					10.08	7.83	10.56	8.43	11.15	8.38	11.49	8.25	12.15	8.68	12.82	8.37
23					9.90	7.77	10.45	8.40	11.04	8.35	11.37	8.22	12.03	8.66	12.70	8.35
25			9.79	8.29	9.81	7.74	10.40	8.38	10.98	8.33	11.31	8.20	11.97	8.64	12.63	8.34
27			9.62	8.22	9.72	7.71	10.35	8.37	10.92	8.32	11.39	8.22	11.86	8.62		
29			9.42	8.15	9.49	7.64	10.11	8.30	10.69	8.25	11.16	8.17	11.63	8.57		
31			9.21	8.08	9.26	7.57	9.87	8.23	10.46	8.19	10.93	8.11	11.39	8.52		
33	7.82	7.17	8.42	7.79	9.03	7.49	9.64	8.17	10.23	8.13	10.70	8.05	11.16	8.47		
35	7.68	7.12	8.24	7.73	8.80	7.42	9.40	8.10	10.00	8.07	10.46	7.99	10.93	8.42		
37	7.59	7.09	8.11	7.69	8.63	7.37	9.18	8.04	9.72	8.00	10.15	7.91	10.57	8.34		
39	7.50	7.05	7.98	7.64	8.46	7.32	8.95	7.98	9.44	7.93	9.83	7.84	10.22	8.27		
41	7.40	7.02	7.85	7.60	8.29	7.26	8.72	7.92	9.16	7.86	9.51	7.76	9.86	8.20		
43	7.31	6.98	7.72	7.55	8.12	7.21	8.50	7.86	8.88	7.78	9.19	7.69	9.50	8.13		
46	7.17	6.93	7.52	7.37	7.87	7.14	8.16	7.77	8.46	7.68	8.71	7.58	8.97	8.02		
50	5.60	5.49	5.73	5.62	5.90	5.78	6.05	5.93	6.17	6.05	6.28	6.15	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature ℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PJF000Z588 A

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃CDB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

Model FDT125VNAWVH Indoor unit FDT125VH Outdoor unit FDC125VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	10.20	15.78	10.16	16.21	9.99	17.06	10.34	17.92	9.93
-10							14.51	10.04	15.27	9.99	15.68	9.82	16.50	10.19	17.32	9.78
-5							14.03	9.87	14.75	9.82	15.43	9.74	16.80	10.27	18.16	9.99
0					11.63	8.66	14.05	9.88	15.26	9.99	15.73	9.84	16.65	10.23	17.58	9.85
5					12.26	8.88	14.16	9.91	15.11	9.94	15.56	9.78	16.44	10.17	17.33	9.79
11					12.79	9.08	14.20	9.93	14.91	9.87	15.44	9.75	16.52	10.19	17.59	9.85
13					13.33	9.28	14.24	9.94	14.70	9.81	15.33	9.71	16.59	10.21	17.86	9.91
15					13.86	9.48	14.29	9.96	14.50	9.74	15.22	9.68	16.67	10.23	18.12	9.98
17					13.37	9.30	14.40	10.00	14.91	9.88	15.50	9.77	16.68	10.24	17.86	9.91
19					13.95	9.52	14.51	10.03	15.33	10.01	15.78	9.85	16.69	10.24	17.59	9.85
21					13.71	9.43	14.36	9.98	15.17	9.96	15.62	9.80	16.53	10.19	17.43	9.81
23					13.47	9.33	14.22	9.93	15.01	9.91	15.46	9.75	16.36	10.15	17.27	9.77
25			13.32	9.98	13.34	9.29	14.15	9.91	14.93	9.88	15.38	9.73	16.28	10.13	17.18	9.75
27			13.09	9.89	13.22	9.24	14.07	9.88	14.85	9.86	15.49	9.76	16.13	10.09		
29			12.81	9.77	12.91	9.12	13.75	9.78	14.54	9.75	15.18	9.67	15.81	10.00		
31			12.53	9.65	12.60	9.01	13.43	9.67	14.23	9.65	14.86	9.57	15.50	9.91		
33	10.63	8.57	11.45	9.21	12.28	8.89	13.11	9.56	13.91	9.56	14.55	9.47	15.18	9.83		
35	10.45	8.50	11.21	9.12	11.97	8.78	12.79	9.46	13.60	9.46	14.23	9.38	14.86	9.75		
37	10.32	8.44	11.03	9.05	11.74	8.70	12.48	9.36	13.22	9.34	13.80	9.25	14.38	9.62		
39	10.20	8.39	10.85	8.97	11.51	8.61	12.17	9.26	12.84	9.22	13.36	9.13	13.89	9.50		
41	10.07	8.33	10.67	8.90	11.28	8.53	11.87	9.16	12.45	9.11	12.93	9.00	13.41	9.38		
43	9.94	8.28	10.49	8.84	11.04	8.45	11.56	9.07	12.07	8.99	12.50	8.88	12.92	9.26		
46	9.75	8.20	10.22	8.73	10.70	8.33	11.10	8.92	11.50	8.83	11.85	8.70	12.20	9.09		
50	7.61	7.33	7.79	7.64	8.02	7.45	8.23	8.07	8.40	7.98	8.54	7.85	8.68	8.31		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PJF000Z588 Ⓐ

Model FDT125VSAWVH Indoor unit FDT125VH Outdoor unit FDC125VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	10.20	15.78	10.16	16.21	9.99	17.06	10.34	17.92	9.93
-10							14.51	10.04	15.27	9.99	15.68	9.82	16.50	10.19	17.32	9.78
-5							14.03	9.87	14.75	9.82	15.43	9.74	16.80	10.27	18.16	9.99
0					11.63	8.66	14.05	9.88	15.26	9.99	15.73	9.84	16.65	10.23	17.58	9.85
5					12.26	8.88	14.16	9.91	15.11	9.94	15.56	9.78	16.44	10.17	17.33	9.79
11					12.79	9.08	14.20	9.93	14.91	9.87	15.44	9.75	16.52	10.19	17.59	9.85
13					13.33	9.28	14.24	9.94	14.70	9.81	15.33	9.71	16.59	10.21	17.86	9.91
15					13.86	9.48	14.29	9.96	14.50	9.74	15.22	9.68	16.67	10.23	18.12	9.98
17					13.37	9.30	14.40	10.00	14.91	9.88	15.50	9.77	16.68	10.24	17.86	9.91
19					13.95	9.52	14.51	10.03	15.33	10.01	15.78	9.85	16.69	10.24	17.59	9.85
21					13.71	9.43	14.36	9.98	15.17	9.96	15.62	9.80	16.53	10.19	17.43	9.81
23					13.47	9.33	14.22	9.93	15.01	9.91	15.46	9.75	16.36	10.15	17.27	9.77
25			13.32	9.98	13.34	9.29	14.15	9.91	14.93	9.88	15.38	9.73	16.28	10.13	17.18	9.75
27			13.09	9.89	13.22	9.24	14.07	9.88	14.85	9.86	15.49	9.76	16.13	10.09		
29			12.81	9.77	12.91	9.12	13.75	9.78	14.54	9.75	15.18	9.67	15.81	10.00		
31			12.53	9.65	12.60	9.01	13.43	9.67	14.23	9.65	14.86	9.57	15.50	9.91		
33	10.63	8.57	11.45	9.21	12.28	8.89	13.11	9.56	13.91	9.56	14.55	9.47	15.18	9.83		
35	10.45	8.50	11.21	9.12	11.97	8.78	12.79	9.46	13.60	9.46	14.23	9.38	14.86	9.75		
37	10.32	8.44	11.03	9.05	11.74	8.70	12.48	9.36	13.22	9.34	13.80	9.25	14.38	9.62		
39	10.20	8.39	10.85	8.97	11.51	8.61	12.17	9.26	12.84	9.22	13.36	9.13	13.89	9.50		
41	10.07	8.33	10.67	8.90	11.28	8.53	11.87	9.16	12.45	9.11	12.93	9.00	13.41	9.38		
43	9.94	8.28	10.49	8.84	11.04	8.45	11.56	9.07	12.07	8.99	12.50	8.88	12.92	9.26		
46	9.75	8.20	10.22	8.73	10.70	8.33	11.10	8.92	11.50	8.83	11.85	8.70	12.20	9.09		
50	7.61	7.33	7.79	7.64	8.02	7.45	8.23	8.07	8.40	7.98	8.54	7.85	8.68	8.31		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PJF000Z588 Ⓐ

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

Model FDT140VNAWVH Indoor unit FDT140VH Outdoor unit FDC140VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	10.45	15.78	10.43	16.21	10.27	17.06	10.65	17.92	10.27
-10							14.51	10.28	15.27	10.25	15.68	10.09	16.50	10.49	17.32	10.12
-5							14.03	10.10	14.75	10.08	15.43	10.01	16.80	10.58	18.16	10.33
0					11.63	8.85	14.05	10.11	15.26	10.25	15.73	10.11	16.65	10.53	17.58	10.18
5					12.26	9.08	14.16	10.15	15.11	10.20	15.56	10.05	16.44	10.47	17.33	10.12
11					12.79	9.28	14.20	10.17	14.91	10.13	15.44	10.02	16.52	10.49	17.59	10.19
13					13.33	9.49	14.24	10.18	14.70	10.06	15.33	9.98	16.59	10.52	17.86	10.25
15					13.86	9.70	14.29	10.20	14.50	9.99	15.22	9.95	16.67	10.54	18.12	10.32
17					13.37	9.51	14.40	10.24	14.91	10.13	15.50	10.04	16.68	10.54	17.86	10.26
19					13.95	9.73	14.51	10.28	15.33	10.27	15.78	10.13	16.69	10.54	17.59	10.19
21					13.71	9.64	14.36	10.22	15.17	10.22	15.62	10.08	16.53	10.50	17.43	10.15
23					13.47	9.54	14.22	10.17	15.01	10.16	15.46	10.02	16.36	10.45	17.27	10.10
25			13.32	10.18	13.34	9.50	14.15	10.15	14.93	10.14	15.38	10.00	16.28	10.43	17.18	10.08
27			13.09	10.08	13.22	9.45	14.07	10.12	14.85	10.11	15.49	10.03	16.13	10.38		
29			12.81	9.96	12.91	9.33	13.75	10.01	14.54	10.00	15.18	9.93	15.81	10.29		
31			12.53	9.84	12.60	9.21	13.43	9.89	14.23	9.90	14.86	9.83	15.50	10.20		
33	10.63	8.73	11.45	9.38	12.28	9.09	13.11	9.78	13.91	9.80	14.55	9.73	15.18	10.11		
35	10.45	8.65	11.21	9.29	11.97	8.97	12.79	9.67	13.60	9.69	14.23	9.63	14.86	10.03		
37	10.32	8.59	11.03	9.21	11.74	8.89	12.48	9.57	13.22	9.57	13.80	9.50	14.38	9.89		
39	10.20	8.53	10.85	9.14	11.51	8.80	12.17	9.47	12.84	9.45	13.36	9.37	13.89	9.76		
41	10.07	8.48	10.67	9.07	11.28	8.72	11.87	9.37	12.45	9.33	12.93	9.24	13.41	9.64		
43	9.94	8.42	10.49	9.00	11.04	8.63	11.56	9.27	12.07	9.21	12.50	9.11	12.92	9.51		
46	9.75	8.34	10.22	8.89	10.70	8.51	11.10	9.12	11.50	9.03	11.85	8.92	12.20	9.33		
50	7.61	7.44	7.79	7.64	8.02	7.59	8.23	8.07	8.40	8.13	8.54	8.02	8.68	8.49		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PJF000Z588 Ⓐ

Model FDT140VSAWVH Indoor unit FDT140VH Outdoor unit FDC140VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	10.45	15.78	10.43	16.21	10.27	17.06	10.65	17.92	10.27
-10							14.51	10.28	15.27	10.25	15.68	10.09	16.50	10.49	17.32	10.12
-5							14.03	10.10	14.75	10.08	15.43	10.01	16.80	10.58	18.16	10.33
0					11.63	8.85	14.05	10.11	15.26	10.25	15.73	10.11	16.65	10.53	17.58	10.18
5					12.26	9.08	14.16	10.15	15.11	10.20	15.56	10.05	16.44	10.47	17.33	10.12
11					12.79	9.28	14.20	10.17	14.91	10.13	15.44	10.02	16.52	10.49	17.59	10.19
13					13.33	9.49	14.24	10.18	14.70	10.06	15.33	9.98	16.59	10.52	17.86	10.25
15					13.86	9.70	14.29	10.20	14.50	9.99	15.22	9.95	16.67	10.54	18.12	10.32
17					13.37	9.51	14.40	10.24	14.91	10.13	15.50	10.04	16.68	10.54	17.86	10.26
19					13.95	9.73	14.51	10.28	15.33	10.27	15.78	10.13	16.69	10.54	17.59	10.19
21					13.71	9.64	14.36	10.22	15.17	10.22	15.62	10.08	16.53	10.50	17.43	10.15
23					13.47	9.54	14.22	10.17	15.01	10.16	15.46	10.02	16.36	10.45	17.27	10.10
25			13.32	10.18	13.34	9.50	14.15	10.15	14.93	10.14	15.38	10.00	16.28	10.43	17.18	10.08
27			13.09	10.08	13.22	9.45	14.07	10.12	14.85	10.11	15.49	10.03	16.13	10.38		
29			12.81	9.96	12.91	9.33	13.75	10.01	14.54	10.00	15.18	9.93	15.81	10.29		
31			12.53	9.84	12.60	9.21	13.43	9.89	14.23	9.90	14.86	9.83	15.50	10.20		
33	10.63	8.73	11.45	9.38	12.28	9.09	13.11	9.78	13.91	9.80	14.55	9.73	15.18	10.11		
35	10.45	8.65	11.21	9.29	11.97	8.97	12.79	9.67	13.60	9.69	14.23	9.63	14.86	10.03		
37	10.32	8.59	11.03	9.21	11.74	8.89	12.48	9.57	13.22	9.57	13.80	9.50	14.38	9.89		
39	10.20	8.53	10.85	9.14	11.51	8.80	12.17	9.47	12.84	9.45	13.36	9.37	13.89	9.76		
41	10.07	8.48	10.67	9.07	11.28	8.72	11.87	9.37	12.45	9.33	12.93	9.24	13.41	9.64		
43	9.94	8.42	10.49	9.00	11.04	8.63	11.56	9.27	12.07	9.21	12.50	9.11	12.92	9.51		
46	9.75	8.34	10.22	8.89	10.70	8.51	11.10	9.12	11.50	9.03	11.85	8.92	12.20	9.33		
50	7.61	7.44	7.79	7.64	8.02	7.59	8.23	8.07	8.40	8.13	8.54	8.02	8.68	8.49		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PJF000Z588 Ⓐ

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heatin mode in which the outside air tem erature is 0℃DB or less, the com ressor o erates at maximum fre uenc .

(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.

(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

(b) Twin type

Model FDT100VNAWPVH Indoor unit FDT50VH (2 units) Outdoor unit FDC100VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	9.25	11.60	9.16	11.92	8.99	12.55	9.49	13.18	9.12
-10							10.67	9.16	11.23	9.07	11.53	8.91	12.13	9.42	12.73	9.06
-5							10.31	9.08	10.85	8.98	11.35	8.87	12.35	9.46	13.36	9.14
0					8.55	7.99	10.33	9.08	11.22	9.07	11.56	8.92	12.25	9.44	12.93	9.08
5					9.01	8.11	10.41	9.10	11.11	9.04	11.44	8.89	12.09	9.41	12.74	9.06
11					9.41	8.22	10.44	9.11	10.96	9.01	11.36	8.87	12.15	9.42	12.94	9.08
13					9.80	8.33	10.47	9.12	10.81	8.98	11.27	8.86	12.20	9.43	13.13	9.11
15					10.19	8.44	10.50	9.12	10.66	8.94	11.19	8.84	12.26	9.44	13.32	9.14
17					9.83	8.34	10.59	9.14	10.97	9.01	11.40	8.88	12.26	9.44	13.13	9.11
19					10.26	8.46	10.67	9.16	11.27	9.08	11.61	8.93	12.27	9.44	12.94	9.09
21					10.08	8.41	10.56	9.14	11.15	9.05	11.49	8.90	12.15	9.42	12.82	9.07
23					9.90	8.36	10.45	9.11	11.04	9.03	11.37	8.88	12.03	9.40	12.70	9.05
25			9.79	8.92	9.81	8.33	10.40	9.10	10.98	9.01	11.31	8.86	11.97	9.39	12.63	9.04
27			9.62	8.86	9.72	8.31	10.35	9.08	10.92	9.00	11.39	8.88	11.86	9.37		
29			9.42	8.80	9.49	8.24	10.11	9.03	10.69	8.95	11.16	8.83	11.63	9.33		
31			9.21	8.73	9.26	8.18	9.87	8.97	10.46	8.90	10.93	8.78	11.39	9.29		
33	7.82	7.66	8.42	8.25	9.03	8.12	9.64	8.92	10.23	8.85	10.70	8.74	11.16	9.26		
35	7.68	7.53	8.24	8.08	8.80	8.06	9.40	8.86	10.00	8.80	10.46	8.69	10.93	9.22		
37	7.59	7.44	8.11	7.95	8.63	8.01	9.18	8.81	9.72	8.74	10.15	8.63	10.57	9.16		
39	7.50	7.35	7.98	7.82	8.46	7.97	8.95	8.76	9.44	8.68	9.83	8.57	10.22	9.10		
41	7.40	7.25	7.85	7.69	8.29	7.92	8.72	8.55	9.16	8.62	9.51	8.50	9.86	9.05		
43	7.31	7.16	7.72	7.56	8.12	7.88	8.50	8.33	8.88	8.56	9.19	8.44	9.50	8.99		
46	7.17	7.03	7.52	7.37	7.87	7.71	8.16	8.00	8.46	8.29	8.71	8.36	8.97	8.79		
50	5.60	5.49	5.73	5.62	5.90	5.78	6.05	5.93	6.17	6.05	6.28	6.15	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PJF000Z588 Ⓐ

Model FDT100VSAWPVH Indoor unit FDT50VH (2 units) Outdoor unit FDC100VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	9.25	11.60	9.16	11.92	8.99	12.55	9.49	13.18	9.12
-10							10.67	9.16	11.23	9.07	11.53	8.91	12.13	9.42	12.73	9.06
-5							10.31	9.08	10.85	8.98	11.35	8.87	12.35	9.46	13.36	9.14
0					8.55	7.99	10.33	9.08	11.22	9.07	11.56	8.92	12.25	9.44	12.93	9.08
5					9.01	8.11	10.41	9.10	11.11	9.04	11.44	8.89	12.09	9.41	12.74	9.06
11					9.41	8.22	10.44	9.11	10.96	9.01	11.36	8.87	12.15	9.42	12.94	9.08
13					9.80	8.33	10.47	9.12	10.81	8.98	11.27	8.86	12.20	9.43	13.13	9.11
15					10.19	8.44	10.50	9.12	10.66	8.94	11.19	8.84	12.26	9.44	13.32	9.14
17					9.83	8.34	10.59	9.14	10.97	9.01	11.40	8.88	12.26	9.44	13.13	9.11
19					10.26	8.46	10.67	9.16	11.27	9.08	11.61	8.93	12.27	9.44	12.94	9.09
21					10.08	8.41	10.56	9.14	11.15	9.05	11.49	8.90	12.15	9.42	12.82	9.07
23					9.90	8.36	10.45	9.11	11.04	9.03	11.37	8.88	12.03	9.40	12.70	9.05
25			9.79	8.92	9.81	8.33	10.40	9.10	10.98	9.01	11.31	8.86	11.97	9.39	12.63	9.04
27			9.62	8.86	9.72	8.31	10.35	9.08	10.92	9.00	11.39	8.88	11.86	9.37		
29			9.42	8.80	9.49	8.24	10.11	9.03	10.69	8.95	11.16	8.83	11.63	9.33		
31			9.21	8.73	9.26	8.18	9.87	8.97	10.46	8.90	10.93	8.78	11.39	9.29		
33	7.82	7.66	8.42	8.25	9.03	8.12	9.64	8.92	10.23	8.85	10.70	8.74	11.16	9.26		
35	7.68	7.53	8.24	8.08	8.80	8.06	9.40	8.86	10.00	8.80	10.46	8.69	10.93	9.22		
37	7.59	7.44	8.11	7.95	8.63	8.01	9.18	8.81	9.72	8.74	10.15	8.63	10.57	9.16		
39	7.50	7.35	7.98	7.82	8.46	7.97	8.95	8.76	9.44	8.68	9.83	8.57	10.22	9.10		
41	7.40	7.25	7.85	7.69	8.29	7.92	8.72	8.55	9.16	8.62	9.51	8.50	9.86	9.05		
43	7.31	7.16	7.72	7.56	8.12	7.88	8.50	8.33	8.88	8.56	9.19	8.44	9.50	8.99		
46	7.17	7.03	7.52	7.37	7.87	7.71	8.16	8.00	8.46	8.29	8.71	8.36	8.97	8.79		
50	5.60	5.49	5.73	5.62	5.90	5.78	6.05	5.93	6.17	6.05	6.28	6.15	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PJF000Z588 Ⓐ

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

Model FDT125VNAWPVH Indoor unit FDT60VH (2 units) Outdoor unit FDC125VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	12.60	15.78	12.57	16.21	12.41	17.06	13.09	17.92	12.72
-10							14.51	12.44	15.27	12.41	15.68	12.26	16.50	12.94	17.32	12.58
-5							14.03	12.28	14.75	12.25	15.43	12.19	16.80	13.01	18.16	12.78
0					11.63	10.74	14.05	12.29	15.26	12.41	15.73	12.27	16.65	12.98	17.58	12.64
5					12.26	10.96	14.16	12.33	15.11	12.36	15.56	12.22	16.44	12.92	17.33	12.58
11					12.79	11.15	14.20	12.34	14.91	12.30	15.44	12.19	16.52	12.94	17.59	12.64
13					13.33	11.34	14.24	12.36	14.70	12.24	15.33	12.16	16.59	12.96	17.86	12.71
15					13.86	11.53	14.29	12.37	14.50	12.17	15.22	12.12	16.67	12.98	18.12	12.77
17					13.37	11.35	14.40	12.41	14.91	12.30	15.50	12.21	16.68	12.98	17.86	12.71
19					13.95	11.56	14.51	12.44	15.33	12.43	15.78	12.29	16.69	12.99	17.59	12.64
21					13.71	11.47	14.36	12.39	15.17	12.38	15.62	12.24	16.53	12.94	17.43	12.61
23					13.47	11.39	14.22	12.35	15.01	12.33	15.46	12.19	16.36	12.90	17.27	12.57
25			13.32	12.05	13.34	11.34	14.15	12.32	14.93	12.31	15.38	12.17	16.28	12.88	17.18	12.55
27			13.09	11.96	13.22	11.30	14.07	12.30	14.85	12.28	15.49	12.20	16.13	12.84		
29			12.81	11.85	12.91	11.19	13.75	12.20	14.54	12.18	15.18	12.11	15.81	12.76		
31			12.53	11.74	12.60	11.08	13.43	12.09	14.23	12.09	14.86	12.02	15.50	12.68		
33	10.63	10.39	11.45	11.22	12.28	10.97	13.11	11.99	13.91	11.99	14.55	11.93	15.18	12.59		
35	10.45	10.24	11.21	10.98	11.97	10.86	12.79	11.89	13.60	11.90	14.23	11.84	14.86	12.51		
37	10.32	10.12	11.03	10.81	11.74	10.78	12.48	11.79	13.22	11.79	13.80	11.71	14.38	12.39		
39	10.20	9.99	10.85	10.63	11.51	10.70	12.17	11.70	12.84	11.67	13.36	11.59	13.89	12.27		
41	10.07	9.87	10.67	10.46	11.28	10.62	11.87	11.60	12.45	11.56	12.93	11.47	13.41	12.15		
43	9.94	9.74	10.49	10.28	11.04	10.54	11.56	11.33	12.07	11.45	12.50	11.35	12.92	12.03		
46	9.75	9.56	10.22	10.02	10.70	10.42	11.10	10.88	11.50	11.27	11.85	11.17	12.20	11.86		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PJF000Z588 Ⓐ

Model FDT125VSAWPVH Indoor unit FDT60VH (2 units) Outdoor unit FDC125VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	12.60	15.78	12.57	16.21	12.41	17.06	13.09	17.92	12.72
-10							14.51	12.44	15.27	12.41	15.68	12.26	16.50	12.94	17.32	12.58
-5							14.03	12.28	14.75	12.25	15.43	12.19	16.80	13.01	18.16	12.78
0					11.63	10.74	14.05	12.29	15.26	12.41	15.73	12.27	16.65	12.98	17.58	12.64
5					12.26	10.96	14.16	12.33	15.11	12.36	15.56	12.22	16.44	12.92	17.33	12.58
11					12.79	11.15	14.20	12.34	14.91	12.30	15.44	12.19	16.52	12.94	17.59	12.64
13					13.33	11.34	14.24	12.36	14.70	12.24	15.33	12.16	16.59	12.96	17.86	12.71
15					13.86	11.53	14.29	12.37	14.50	12.17	15.22	12.12	16.67	12.98	18.12	12.77
17					13.37	11.35	14.40	12.41	14.91	12.30	15.50	12.21	16.68	12.98	17.86	12.71
19					13.95	11.56	14.51	12.44	15.33	12.43	15.78	12.29	16.69	12.99	17.59	12.64
21					13.71	11.47	14.36	12.39	15.17	12.38	15.62	12.24	16.53	12.94	17.43	12.61
23					13.47	11.39	14.22	12.35	15.01	12.33	15.46	12.19	16.36	12.90	17.27	12.57
25			13.32	12.05	13.34	11.34	14.15	12.32	14.93	12.31	15.38	12.17	16.28	12.88	17.18	12.55
27			13.09	11.96	13.22	11.30	14.07	12.30	14.85	12.28	15.49	12.20	16.13	12.84		
29			12.81	11.85	12.91	11.19	13.75	12.20	14.54	12.18	15.18	12.11	15.81	12.76		
31			12.53	11.74	12.60	11.08	13.43	12.09	14.23	12.09	14.86	12.02	15.50	12.68		
33	10.63	10.39	11.45	11.22	12.28	10.97	13.11	11.99	13.91	11.99	14.55	11.93	15.18	12.59		
35	10.45	10.24	11.21	10.98	11.97	10.86	12.79	11.89	13.60	11.90	14.23	11.84	14.86	12.51		
37	10.32	10.12	11.03	10.81	11.74	10.78	12.48	11.79	13.22	11.79	13.80	11.71	14.38	12.39		
39	10.20	9.99	10.85	10.63	11.51	10.70	12.17	11.70	12.84	11.67	13.36	11.59	13.89	12.27		
41	10.07	9.87	10.67	10.46	11.28	10.62	11.87	11.60	12.45	11.56	12.93	11.47	13.41	12.15		
43	9.94	9.74	10.49	10.28	11.04	10.54	11.56	11.33	12.07	11.45	12.50	11.35	12.92	12.03		
46	9.75	9.56	10.22	10.02	10.70	10.42	11.10	10.88	11.50	11.27	11.85	11.17	12.20	11.86		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PJF000Z588 Ⓐ

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

Model FDT140VNAWPVH Indoor unit FDT71VH (2 units) Outdoor unit FDC140VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	12.69	15.78	12.62	16.21	12.43	17.06	13.12	17.92	12.70
-10							14.51	12.55	15.27	12.48	15.68	12.30	16.50	12.99	17.32	12.58
-5							14.03	12.41	14.75	12.34	15.43	12.23	16.80	13.06	18.16	12.74
0					11.63	10.88	14.05	12.42	15.26	12.48	15.73	12.31	16.65	13.03	17.58	12.63
5					12.26	11.08	14.16	12.45	15.11	12.43	15.56	12.26	16.44	12.98	17.33	12.58
11					12.79	11.25	14.20	12.46	14.91	12.38	15.44	12.24	16.52	13.00	17.59	12.63
13					13.33	11.42	14.24	12.47	14.70	12.32	15.33	12.21	16.59	13.02	17.86	12.68
15					13.86	11.59	14.29	12.49	14.50	12.27	15.22	12.18	16.67	13.03	18.12	12.73
17					13.37	11.43	14.40	12.52	14.91	12.38	15.50	12.25	16.68	13.03	17.86	12.68
19					13.95	11.62	14.51	12.55	15.33	12.49	15.78	12.32	16.69	13.04	17.59	12.63
21					13.71	11.54	14.36	12.51	15.17	12.45	15.62	12.28	16.53	13.00	17.43	12.60
23					13.47	11.46	14.22	12.47	15.01	12.41	15.46	12.24	16.36	12.96	17.27	12.57
25			13.32	12.17	13.34	11.42	14.15	12.44	14.93	12.39	15.38	12.22	16.28	12.95	17.18	12.55
27			13.09	12.09	13.22	11.38	14.07	12.42	14.85	12.36	15.49	12.25	16.13	12.91		
29			12.81	11.99	12.91	11.28	13.75	12.33	14.54	12.28	15.18	12.17	15.81	12.84		
31			12.53	11.89	12.60	11.18	13.43	12.24	14.23	12.19	14.86	12.09	15.50	12.77		
33	10.63	10.42	11.45	11.22	12.28	11.09	13.11	12.15	13.91	12.11	14.55	12.01	15.18	12.70		
35	10.45	10.24	11.21	10.98	11.97	10.99	12.79	12.06	13.60	12.03	14.23	11.93	14.86	12.64		
37	10.32	10.12	11.03	10.81	11.74	10.92	12.48	11.98	13.22	11.93	13.80	11.82	14.38	12.53		
39	10.20	9.99	10.85	10.63	11.51	10.84	12.17	11.89	12.84	11.83	13.36	11.72	13.89	12.43		
41	10.07	9.87	10.67	10.46	11.28	10.77	11.87	11.63	12.45	11.73	12.93	11.61	13.41	12.33		
43	9.94	9.74	10.49	10.28	11.04	10.70	11.56	11.33	12.07	11.63	12.50	11.51	12.92	12.23		
46	9.75	9.56	10.22	10.02	10.70	10.48	11.10	10.88	11.50	11.27	11.85	11.36	12.20	11.95		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PJF000Z588 Ⓐ

Model FDT140VSAWPVH Indoor unit FDT71VH (2 units) Outdoor unit FDC140VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	12.69	15.78	12.62	16.21	12.43	17.06	13.12	17.92	12.70
-10							14.51	12.55	15.27	12.48	15.68	12.30	16.50	12.99	17.32	12.58
-5							14.03	12.41	14.75	12.34	15.43	12.23	16.80	13.06	18.16	12.74
0					11.63	10.88	14.05	12.42	15.26	12.48	15.73	12.31	16.65	13.03	17.58	12.63
5					12.26	11.08	14.16	12.45	15.11	12.43	15.56	12.26	16.44	12.98	17.33	12.58
11					12.79	11.25	14.20	12.46	14.91	12.38	15.44	12.24	16.52	13.00	17.59	12.63
13					13.33	11.42	14.24	12.47	14.70	12.32	15.33	12.21	16.59	13.02	17.86	12.68
15					13.86	11.59	14.29	12.49	14.50	12.27	15.22	12.18	16.67	13.03	18.12	12.73
17					13.37	11.43	14.40	12.52	14.91	12.38	15.50	12.25	16.68	13.03	17.86	12.68
19					13.95	11.62	14.51	12.55	15.33	12.49	15.78	12.32	16.69	13.04	17.59	12.63
21					13.71	11.54	14.36	12.51	15.17	12.45	15.62	12.28	16.53	13.00	17.43	12.60
23					13.47	11.46	14.22	12.47	15.01	12.41	15.46	12.24	16.36	12.96	17.27	12.57
25			13.32	12.17	13.34	11.42	14.15	12.44	14.93	12.39	15.38	12.22	16.28	12.95	17.18	12.55
27			13.09	12.09	13.22	11.38	14.07	12.42	14.85	12.36	15.49	12.25	16.13	12.91		
29			12.81	11.99	12.91	11.28	13.75	12.33	14.54	12.28	15.18	12.17	15.81	12.84		
31			12.53	11.89	12.60	11.18	13.43	12.24	14.23	12.19	14.86	12.09	15.50	12.77		
33	10.63	10.42	11.45	11.22	12.28	11.09	13.11	12.15	13.91	12.11	14.55	12.01	15.18	12.70		
35	10.45	10.24	11.21	10.98	11.97	10.99	12.79	12.06	13.60	12.03	14.23	11.93	14.86	12.64		
37	10.32	10.12	11.03	10.81	11.74	10.92	12.48	11.98	13.22	11.93	13.80	11.82	14.38	12.53		
39	10.20	9.99	10.85	10.63	11.51	10.84	12.17	11.89	12.84	11.83	13.36	11.72	13.89	12.43		
41	10.07	9.87	10.67	10.46	11.28	10.77	11.87	11.63	12.45	11.73	12.93	11.61	13.41	12.33		
43	9.94	9.74	10.49	10.28	11.04	10.70	11.56	11.33	12.07	11.63	12.50	11.51	12.92	12.23		
46	9.75	9.56	10.22	10.02	10.70	10.48	11.10	10.88	11.50	11.27	11.85	11.36	12.20	11.95		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PJF000Z588 Ⓐ

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

(c) Triple type

Model FDT140VNAWTVH Indoor unit FDT50VH (3 units) Outdoor unit FDC140VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	13.50	15.78	13.37	16.21	13.14	17.06	13.94	17.92	13.43
-10							14.51	13.39	15.27	13.26	15.68	13.03	16.50	13.84	17.32	13.35
-5							14.03	13.27	14.75	13.14	15.43	12.98	16.80	13.89	18.16	13.46
0					11.63	11.40	14.05	13.28	15.26	13.25	15.73	13.04	16.65	13.87	17.58	13.38
5					12.26	11.83	14.16	13.31	15.11	13.22	15.56	13.01	16.44	13.83	17.33	13.35
11					12.79	11.98	14.20	13.32	14.91	13.18	15.44	12.99	16.52	13.85	17.59	13.38
13					13.33	12.12	14.24	13.33	14.70	13.13	15.33	12.96	16.59	13.86	17.86	13.42
15					13.86	12.26	14.29	13.33	14.50	13.09	15.22	12.94	16.67	13.87	18.12	13.45
17					13.37	12.13	14.40	13.36	14.91	13.18	15.50	13.00	16.68	13.87	17.86	13.42
19					13.95	12.29	14.51	13.39	15.33	13.27	15.78	13.05	16.69	13.87	17.59	13.38
21					13.71	12.22	14.36	13.35	15.17	13.23	15.62	13.02	16.53	13.85	17.43	13.36
23					13.47	12.15	14.22	13.32	15.01	13.20	15.46	12.99	16.36	13.82	17.27	13.34
25			13.32	12.94	13.34	12.12	14.15	13.30	14.93	13.18	15.38	12.97	16.28	13.81	17.18	13.33
27			13.09	12.82	13.22	12.09	14.07	13.29	14.85	13.16	15.49	13.00	16.13	13.78		
29			12.81	12.55	12.91	12.01	13.75	13.21	14.54	13.10	15.18	12.93	15.81	13.73		
31			12.53	12.28	12.60	11.92	13.43	13.14	14.23	13.03	14.86	12.87	15.50	13.68		
33	10.63	10.42	11.45	11.22	12.28	11.84	13.11	12.84	13.91	12.97	14.55	12.81	15.18	13.63		
35	10.45	10.24	11.21	10.98	11.97	11.73	12.79	12.53	13.60	12.90	14.23	12.75	14.86	13.58		
37	10.32	10.12	11.03	10.81	11.74	11.50	12.48	12.23	13.22	12.82	13.80	12.67	14.38	13.51		
39	10.20	9.99	10.85	10.63	11.51	11.28	12.17	11.93	12.84	12.58	13.36	12.59	13.89	13.43		
41	10.07	9.87	10.67	10.46	11.28	11.05	11.87	11.63	12.45	12.20	12.93	12.51	13.41	13.14		
43	9.94	9.74	10.49	10.28	11.04	10.82	11.56	11.33	12.07	11.83	12.50	12.25	12.92	12.67		
46	9.75	9.56	10.22	10.02	10.70	10.48	11.10	10.88	11.50	11.27	11.85	11.61	12.20	11.95		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PJF000Z588 Ⓐ

Model FDT140VSAWTVH Indoor unit FDT50VH (3 units) Outdoor unit FDC140VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	13.50	15.78	13.37	16.21	13.14	17.06	13.94	17.92	13.43
-10							14.51	13.39	15.27	13.26	15.68	13.03	16.50	13.84	17.32	13.35
-5							14.03	13.27	14.75	13.14	15.43	12.98	16.80	13.89	18.16	13.46
0					11.63	11.40	14.05	13.28	15.26	13.25	15.73	13.04	16.65	13.87	17.58	13.38
5					12.26	11.83	14.16	13.31	15.11	13.22	15.56	13.01	16.44	13.83	17.33	13.35
11					12.79	11.98	14.20	13.32	14.91	13.18	15.44	12.99	16.52	13.85	17.59	13.38
13					13.33	12.12	14.24	13.33	14.70	13.13	15.33	12.96	16.59	13.86	17.86	13.42
15					13.86	12.26	14.29	13.33	14.50	13.09	15.22	12.94	16.67	13.87	18.12	13.45
17					13.37	12.13	14.40	13.36	14.91	13.18	15.50	13.00	16.68	13.87	17.86	13.42
19					13.95	12.29	14.51	13.39	15.33	13.27	15.78	13.05	16.69	13.87	17.59	13.38
21					13.71	12.22	14.36	13.35	15.17	13.23	15.62	13.02	16.53	13.85	17.43	13.36
23					13.47	12.15	14.22	13.32	15.01	13.20	15.46	12.99	16.36	13.82	17.27	13.34
25			13.32	12.94	13.34	12.12	14.15	13.30	14.93	13.18	15.38	12.97	16.28	13.81	17.18	13.33
27			13.09	12.82	13.22	12.09	14.07	13.29	14.85	13.16	15.49	13.00	16.13	13.78		
29			12.81	12.55	12.91	12.01	13.75	13.21	14.54	13.10	15.18	12.93	15.81	13.73		
31			12.53	12.28	12.60	11.92	13.43	13.14	14.23	13.03	14.86	12.87	15.50	13.68		
33	10.63	10.42	11.45	11.22	12.28	11.84	13.11	12.84	13.91	12.97	14.55	12.81	15.18	13.63		
35	10.45	10.24	11.21	10.98	11.97	11.73	12.79	12.53	13.60	12.90	14.23	12.75	14.86	13.58		
37	10.32	10.12	11.03	10.81	11.74	11.50	12.48	12.23	13.22	12.82	13.80	12.67	14.38	13.51		
39	10.20	9.99	10.85	10.63	11.51	11.28	12.17	11.93	12.84	12.58	13.36	12.59	13.89	13.43		
41	10.07	9.87	10.67	10.46	11.28	11.05	11.87	11.63	12.45	12.20	12.93	12.51	13.41	13.14		
43	9.94	9.74	10.49	10.28	11.04	10.82	11.56	11.33	12.07	11.83	12.50	12.25	12.92	12.67		
46	9.75	9.56	10.22	10.02	10.70	10.48	11.10	10.88	11.50	11.27	11.85	11.61	12.20	11.95		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PJF000Z588 Ⓐ

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

(2) Ceiling cassette-4 way compact type (FDTC)

(a) Twin type

Model FDTC100VNAWPVH Indoor unit FDTC50VH (2 units) Outdoor unit FDC100VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.25	11.60	8.31	11.92	8.24	12.55	8.59	13.18	8.41
-10							10.67	8.10	11.23	8.15	11.53	8.08	12.13	8.43	12.73	8.26
-5							10.31	7.95	10.85	7.99	11.35	8.01	12.35	8.52	13.36	8.47
0					8.55	6.91	10.33	7.96	11.22	8.15	11.56	8.10	12.25	8.48	12.93	8.33
5					9.01	7.11	10.41	7.99	11.11	8.10	11.44	8.05	12.09	8.42	12.74	8.27
11					9.41	7.29	10.44	8.01	10.96	8.04	11.36	8.01	12.15	8.44	12.94	8.33
13					9.80	7.46	10.47	8.02	10.81	7.98	11.27	7.98	12.20	8.46	13.13	8.40
15					10.19	7.64	10.50	8.03	10.66	7.92	11.19	7.95	12.26	8.48	13.32	8.46
17					9.83	7.48	10.59	8.07	10.97	8.04	11.40	8.03	12.26	8.48	13.13	8.40
19					10.26	7.67	10.67	8.10	11.27	8.17	11.61	8.11	12.27	8.49	12.94	8.33
21					10.08	7.59	10.56	8.06	11.15	8.12	11.49	8.07	12.15	8.44	12.82	8.29
23					9.90	7.51	10.45	8.01	11.04	8.07	11.37	8.02	12.03	8.40	12.70	8.25
25			9.79	7.91	9.81	7.47	10.40	7.99	10.98	8.05	11.31	8.00	11.97	8.38	12.63	8.23
27			9.62	7.83	9.72	7.43	10.35	7.97	10.92	8.02	11.39	8.03	11.86	8.34		
29			9.42	7.73	9.49	7.32	10.11	7.87	10.69	7.93	11.16	7.94	11.63	8.25		
31			9.21	7.63	9.26	7.22	9.87	7.77	10.46	7.84	10.93	7.85	11.39	8.17		
33	7.82	6.72	8.42	7.25	9.03	7.12	9.64	7.67	10.23	7.74	10.70	7.76	11.16	8.08		
35	7.68	6.66	8.24	7.16	8.80	7.02	9.40	7.57	10.00	7.65	10.46	7.67	10.93	8.00		
37	7.59	6.61	8.11	7.10	8.63	6.94	9.18	7.48	9.72	7.54	10.15	7.54	10.57	7.88		
39	7.50	6.56	7.98	7.04	8.46	6.87	8.95	7.39	9.44	7.43	9.83	7.42	10.22	7.75		
41	7.40	6.52	7.85	6.98	8.29	6.79	8.72	7.30	9.16	7.32	9.51	7.30	9.86	7.63		
43	7.31	6.47	7.72	6.92	8.12	6.72	8.50	7.21	8.88	7.21	9.19	7.18	9.50	7.51		
46	7.17	6.40	7.52	6.82	7.87	6.61	8.16	7.07	8.46	7.05	8.71	7.01	8.97	7.33		
50	5.60	5.49	5.73	5.62	5.90	5.78	6.05	5.93	6.17	6.05	6.28	6.15	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PJF000Z586 B

Model FDTC100VSAWPVH Indoor unit FDTC50VH (2 units) Outdoor unit FDC100VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.25	11.60	8.31	11.92	8.24	12.55	8.59	13.18	8.41
-10							10.67	8.10	11.23	8.15	11.53	8.08	12.13	8.43	12.73	8.26
-5							10.31	7.95	10.85	7.99	11.35	8.01	12.35	8.52	13.36	8.47
0					8.55	6.91	10.33	7.96	11.22	8.15	11.56	8.10	12.25	8.48	12.93	8.33
5					9.01	7.11	10.41	7.99	11.11	8.10	11.44	8.05	12.09	8.42	12.74	8.27
11					9.41	7.29	10.44	8.01	10.96	8.04	11.36	8.01	12.15	8.44	12.94	8.33
13					9.80	7.46	10.47	8.02	10.81	7.98	11.27	7.98	12.20	8.46	13.13	8.40
15					10.19	7.64	10.50	8.03	10.66	7.92	11.19	7.95	12.26	8.48	13.32	8.46
17					9.83	7.48	10.59	8.07	10.97	8.04	11.40	8.03	12.26	8.48	13.13	8.40
19					10.26	7.67	10.67	8.10	11.27	8.17	11.61	8.11	12.27	8.49	12.94	8.33
21					10.08	7.59	10.56	8.06	11.15	8.12	11.49	8.07	12.15	8.44	12.82	8.29
23					9.90	7.51	10.45	8.01	11.04	8.07	11.37	8.02	12.03	8.40	12.70	8.25
25			9.79	7.91	9.81	7.47	10.40	7.99	10.98	8.05	11.31	8.00	11.97	8.38	12.63	8.23
27			9.62	7.83	9.72	7.43	10.35	7.97	10.92	8.02	11.39	8.03	11.86	8.34		
29			9.42	7.73	9.49	7.32	10.11	7.87	10.69	7.93	11.16	7.94	11.63	8.25		
31			9.21	7.63	9.26	7.22	9.87	7.77	10.46	7.84	10.93	7.85	11.39	8.17		
33	7.82	6.72	8.42	7.25	9.03	7.12	9.64	7.67	10.23	7.74	10.70	7.76	11.16	8.08		
35	7.68	6.66	8.24	7.16	8.80	7.02	9.40	7.57	10.00	7.65	10.46	7.67	10.93	8.00		
37	7.59	6.61	8.11	7.10	8.63	6.94	9.18	7.48	9.72	7.54	10.15	7.54	10.57	7.88		
39	7.50	6.56	7.98	7.04	8.46	6.87	8.95	7.39	9.44	7.43	9.83	7.42	10.22	7.75		
41	7.40	6.52	7.85	6.98	8.29	6.79	8.72	7.30	9.16	7.32	9.51	7.30	9.86	7.63		
43	7.31	6.47	7.72	6.92	8.12	6.72	8.50	7.21	8.88	7.21	9.19	7.18	9.50	7.51		
46	7.17	6.40	7.52	6.82	7.87	6.61	8.16	7.07	8.46	7.05	8.71	7.01	8.97	7.33		
50	5.60	5.49	5.73	5.62	5.90	5.78	6.05	5.93	6.17	6.05	6.28	6.15	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PJF000Z586 B

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

Model FDTC125VNAWPVH Indoor unit FDTC60VH (2 units) Outdoor unit FDC125VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	9.64	15.78	9.68	16.21	9.55	17.06	9.80	17.92	9.47
-10							14.51	9.43	15.27	9.47	15.68	9.34	16.50	9.59	17.32	9.27
-5							14.03	9.22	14.75	9.25	15.43	9.24	16.80	9.70	18.16	9.55
0					11.63	8.03	14.05	9.23	15.26	9.46	15.73	9.35	16.65	9.65	17.58	9.36
5					12.26	8.30	14.16	9.28	15.11	9.40	15.56	9.28	16.44	9.57	17.33	9.27
11					12.79	8.54	14.20	9.30	14.91	9.31	15.44	9.24	16.52	9.60	17.59	9.36
13					13.33	8.79	14.24	9.31	14.70	9.23	15.33	9.19	16.59	9.63	17.86	9.45
15					13.86	9.04	14.29	9.33	14.50	9.14	15.22	9.15	16.67	9.65	18.12	9.54
17					13.37	8.81	14.40	9.38	14.91	9.31	15.50	9.26	16.68	9.66	17.86	9.45
19					13.95	9.08	14.51	9.43	15.33	9.49	15.78	9.38	16.69	9.66	17.59	9.36
21					13.71	8.97	14.36	9.37	15.17	9.42	15.62	9.31	16.53	9.60	17.43	9.31
23					13.47	8.86	14.22	9.30	15.01	9.36	15.46	9.25	16.36	9.54	17.27	9.25
25			13.32	9.44	13.34	8.80	14.15	9.27	14.93	9.32	15.38	9.21	16.28	9.51	17.18	9.22
27			13.09	9.32	13.22	8.74	14.07	9.24	14.85	9.29	15.49	9.26	16.13	9.46		
29			12.81	9.18	12.91	8.60	13.75	9.10	14.54	9.16	15.18	9.13	15.81	9.34		
31			12.53	9.04	12.60	8.46	13.43	8.97	14.23	9.03	14.86	9.01	15.50	9.23		
33	10.63	7.99	11.45	8.51	12.28	8.31	13.11	8.83	13.91	8.90	14.55	8.88	15.18	9.11		
35	10.45	7.89	11.21	8.39	11.97	8.17	12.79	8.70	13.60	8.78	14.23	8.76	14.86	9.00		
37	10.32	7.83	11.03	8.31	11.74	8.07	12.48	8.57	13.22	8.63	13.80	8.60	14.38	8.84		
39	10.20	7.76	10.85	8.22	11.51	7.97	12.17	8.45	12.84	8.48	13.36	8.43	13.89	8.67		
41	10.07	7.70	10.67	8.14	11.28	7.87	11.87	8.33	12.45	8.33	12.93	8.27	13.41	8.51		
43	9.94	7.64	10.49	8.05	11.04	7.77	11.56	8.21	12.07	8.18	12.50	8.12	12.92	8.35		
46	9.75	7.54	10.22	7.93	10.70	7.62	11.10	8.03	11.50	7.97	11.85	7.88	12.20	8.12		
50	7.61	6.52	7.79	6.86	8.02	6.55	8.23	6.98	8.40	6.89	8.54	6.79	8.68	7.08		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PJF000Z586 B

Model FDTC125VSAWPVH Indoor unit FDTC60VH (2 units) Outdoor unit FDC125VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	9.64	15.78	9.68	16.21	9.55	17.06	9.80	17.92	9.47
-10							14.51	9.43	15.27	9.47	15.68	9.34	16.50	9.59	17.32	9.27
-5							14.03	9.22	14.75	9.25	15.43	9.24	16.80	9.70	18.16	9.55
0					11.63	8.03	14.05	9.23	15.26	9.46	15.73	9.35	16.65	9.65	17.58	9.36
5					12.26	8.30	14.16	9.28	15.11	9.40	15.56	9.28	16.44	9.57	17.33	9.27
11					12.79	8.54	14.20	9.30	14.91	9.31	15.44	9.24	16.52	9.60	17.59	9.36
13					13.33	8.79	14.24	9.31	14.70	9.23	15.33	9.19	16.59	9.63	17.86	9.45
15					13.86	9.04	14.29	9.33	14.50	9.14	15.22	9.15	16.67	9.65	18.12	9.54
17					13.37	8.81	14.40	9.38	14.91	9.31	15.50	9.26	16.68	9.66	17.86	9.45
19					13.95	9.08	14.51	9.43	15.33	9.49	15.78	9.38	16.69	9.66	17.59	9.36
21					13.71	8.97	14.36	9.37	15.17	9.42	15.62	9.31	16.53	9.60	17.43	9.31
23					13.47	8.86	14.22	9.30	15.01	9.36	15.46	9.25	16.36	9.54	17.27	9.25
25			13.32	9.44	13.34	8.80	14.15	9.27	14.93	9.32	15.38	9.21	16.28	9.51	17.18	9.22
27			13.09	9.32	13.22	8.74	14.07	9.24	14.85	9.29	15.49	9.26	16.13	9.46		
29			12.81	9.18	12.91	8.60	13.75	9.10	14.54	9.16	15.18	9.13	15.81	9.34		
31			12.53	9.04	12.60	8.46	13.43	8.97	14.23	9.03	14.86	9.01	15.50	9.23		
33	10.63	7.99	11.45	8.51	12.28	8.31	13.11	8.83	13.91	8.90	14.55	8.88	15.18	9.11		
35	10.45	7.89	11.21	8.39	11.97	8.17	12.79	8.70	13.60	8.78	14.23	8.76	14.86	9.00		
37	10.32	7.83	11.03	8.31	11.74	8.07	12.48	8.57	13.22	8.63	13.80	8.60	14.38	8.84		
39	10.20	7.76	10.85	8.22	11.51	7.97	12.17	8.45	12.84	8.48	13.36	8.43	13.89	8.67		
41	10.07	7.70	10.67	8.14	11.28	7.87	11.87	8.33	12.45	8.33	12.93	8.27	13.41	8.51		
43	9.94	7.64	10.49	8.05	11.04	7.77	11.56	8.21	12.07	8.18	12.50	8.12	12.92	8.35		
46	9.75	7.54	10.22	7.93	10.70	7.62	11.10	8.03	11.50	7.97	11.85	7.88	12.20	8.12		
50	7.61	6.52	7.79	6.86	8.02	6.55	8.23	6.98	8.40	6.89	8.54	6.79	8.68	7.08		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PJF000Z586 B

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

(b) Triple type

Model FDTC140VNAWTVH Indoor unit FDTC50VH (3 units) Outdoor unit FDC140VNA-W

Cool Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.72	15.78	11.79	16.21	11.70	17.06	12.24	17.92	12.00
-10							14.51	11.53	15.27	11.59	15.68	11.49	16.50	12.04	17.32	11.81
-5							14.03	11.33	14.75	11.38	15.43	11.40	16.80	12.15	18.16	12.08
0					11.63	9.85	14.05	11.34	15.26	11.58	15.73	11.51	16.65	12.09	17.58	11.89
5					12.26	10.11	14.16	11.38	15.11	11.52	15.56	11.44	16.44	12.02	17.33	11.81
11					12.79	10.35	14.20	11.40	14.91	11.44	15.44	11.40	16.52	12.05	17.59	11.90
13					13.33	10.58	14.24	11.42	14.70	11.36	15.33	11.36	16.59	12.07	17.86	11.98
15					13.86	10.82	14.29	11.43	14.50	11.28	15.22	11.32	16.67	12.10	18.12	12.07
17					13.37	10.60	14.40	11.48	14.91	11.44	15.50	11.42	16.68	12.10	17.86	11.98
19					13.95	10.86	14.51	11.53	15.33	11.61	15.78	11.53	16.69	12.11	17.59	11.90
21					13.71	10.75	14.36	11.47	15.17	11.55	15.62	11.47	16.53	12.05	17.43	11.84
23					13.47	10.64	14.22	11.41	15.01	11.48	15.46	11.41	16.36	11.99	17.27	11.79
25			13.32	11.20	13.34	10.59	14.15	11.38	14.93	11.45	15.38	11.38	16.28	11.96	17.18	11.76
27			13.09	11.09	13.22	10.54	14.07	11.35	14.85	11.42	15.49	11.42	16.13	11.91		
29			12.81	10.95	12.91	10.40	13.75	11.21	14.54	11.30	15.18	11.30	15.81	11.80		
31			12.53	10.82	12.60	10.26	13.43	11.08	14.23	11.17	14.86	11.18	15.50	11.69		
33	10.63	9.54	11.45	10.32	12.28	10.13	13.11	10.95	13.91	11.05	14.55	11.06	15.18	11.58		
35	10.45	9.45	11.21	10.21	11.97	9.99	12.79	10.83	13.60	10.93	14.23	10.94	14.86	11.47		
37	10.32	9.39	11.03	10.12	11.74	9.89	12.48	10.70	13.22	10.78	13.80	10.78	14.38	11.30		
39	10.20	9.33	10.85	10.04	11.51	9.79	12.17	10.58	12.84	10.63	13.36	10.62	13.89	11.14		
41	10.07	9.26	10.67	9.96	11.28	9.69	11.87	10.46	12.45	10.49	12.93	10.46	13.41	10.97		
43	9.94	9.20	10.49	9.88	11.04	9.60	11.56	10.34	12.07	10.34	12.50	10.30	12.92	10.81		
46	9.75	9.11	10.22	9.76	10.70	9.45	11.10	10.16	11.50	10.13	11.85	10.07	12.20	10.57		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heat Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PJF000Z586 B

Model FDTC140VSAWTVH Indoor unit FDTC50VH (3 units) Outdoor unit FDC140VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.72	15.78	11.79	16.21	11.70	17.06	12.24	17.92	12.00
-10							14.51	11.53	15.27	11.59	15.68	11.49	16.50	12.04	17.32	11.81
-5							14.03	11.33	14.75	11.38	15.43	11.40	16.80	12.15	18.16	12.08
0					11.63	9.85	14.05	11.34	15.26	11.58	15.73	11.51	16.65	12.09	17.58	11.89
5					12.26	10.11	14.16	11.38	15.11	11.52	15.56	11.44	16.44	12.02	17.33	11.81
11					12.79	10.35	14.20	11.40	14.91	11.44	15.44	11.40	16.52	12.05	17.59	11.90
13					13.33	10.58	14.24	11.42	14.70	11.36	15.33	11.36	16.59	12.07	17.86	11.98
15					13.86	10.82	14.29	11.43	14.50	11.28	15.22	11.32	16.67	12.10	18.12	12.07
17					13.37	10.60	14.40	11.48	14.91	11.44	15.50	11.42	16.68	12.10	17.86	11.98
19					13.95	10.86	14.51	11.53	15.33	11.61	15.78	11.53	16.69	12.11	17.59	11.90
21					13.71	10.75	14.36	11.47	15.17	11.55	15.62	11.47	16.53	12.05	17.43	11.84
23					13.47	10.64	14.22	11.41	15.01	11.48	15.46	11.41	16.36	11.99	17.27	11.79
25			13.32	11.20	13.34	10.59	14.15	11.38	14.93	11.45	15.38	11.38	16.28	11.96	17.18	11.76
27			13.09	11.09	13.22	10.54	14.07	11.35	14.85	11.42	15.49	11.42	16.13	11.91		
29			12.81	10.95	12.91	10.40	13.75	11.21	14.54	11.30	15.18	11.30	15.81	11.80		
31			12.53	10.82	12.60	10.26	13.43	11.08	14.23	11.17	14.86	11.18	15.50	11.69		
33	10.63	9.54	11.45	10.32	12.28	10.13	13.11	10.95	13.91	11.05	14.55	11.06	15.18	11.58		
35	10.45	9.45	11.21	10.21	11.97	9.99	12.79	10.83	13.60	10.93	14.23	10.94	14.86	11.47		
37	10.32	9.39	11.03	10.12	11.74	9.89	12.48	10.70	13.22	10.78	13.80	10.78	14.38	11.30		
39	10.20	9.33	10.85	10.04	11.51	9.79	12.17	10.58	12.84	10.63	13.36	10.62	13.89	11.14		
41	10.07	9.26	10.67	9.96	11.28	9.69	11.87	10.46	12.45	10.49	12.93	10.46	13.41	10.97		
43	9.94	9.20	10.49	9.88	11.04	9.60	11.56	10.34	12.07	10.34	12.50	10.30	12.92	10.81		
46	9.75	9.11	10.22	9.76	10.70	9.45	11.10	10.16	11.50	10.13	11.85	10.07	12.20	10.57		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PJF000Z586 B

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

(3) Duct connected-High static pressure type (FDU)

Model FDU100VNAWVH Indoor unit FDU100VH Outdoor unit FDC100VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.14	11.60	8.06	11.92	7.90	12.55	8.26	13.18	7.90
-10							10.67	8.04	11.23	7.97	11.53	7.81	12.13	8.18	12.73	7.82
-5							10.31	7.95	10.85	7.87	11.35	7.77	12.35	8.22	13.36	7.93
0					8.55	7.00	10.33	7.95	11.22	7.96	11.56	7.82	12.25	8.20	12.93	7.85
5					9.01	7.14	10.41	7.97	11.11	7.93	11.44	7.79	12.09	8.17	12.74	7.82
11					9.41	7.26	10.44	7.98	10.96	7.90	11.36	7.77	12.15	8.18	12.94	7.86
13					9.80	7.38	10.47	7.99	10.81	7.86	11.27	7.75	12.20	8.19	13.13	7.89
15					10.19	7.50	10.50	8.00	10.66	7.82	11.19	7.73	12.26	8.20	13.32	7.92
17					9.83	7.38	10.59	8.02	10.97	7.90	11.40	7.78	12.26	8.20	13.13	7.89
19					10.26	7.52	10.67	8.04	11.27	7.98	11.61	7.83	12.27	8.20	12.94	7.86
21					10.08	7.46	10.56	8.01	11.15	7.95	11.49	7.80	12.15	8.18	12.82	7.84
23					9.90	7.41	10.45	7.98	11.04	7.92	11.37	7.77	12.03	8.16	12.70	7.82
25			9.79	7.94	9.81	7.38	10.40	7.97	10.98	7.90	11.31	7.76	11.97	8.14	12.63	7.81
27			9.62	7.88	9.72	7.35	10.35	7.96	10.92	7.89	11.39	7.78	11.86	8.12		
29			9.42	7.81	9.49	7.28	10.11	7.89	10.69	7.83	11.16	7.72	11.63	8.08		
31			9.21	7.74	9.26	7.21	9.87	7.83	10.46	7.77	10.93	7.67	11.39	8.03		
33	7.82	6.89	8.42	7.47	9.03	7.14	9.64	7.77	10.23	7.71	10.70	7.61	11.16	7.99		
35	7.68	6.84	8.24	7.41	8.80	7.08	9.40	7.71	10.00	7.66	10.46	7.56	10.93	7.94		
37	7.59	6.81	8.11	7.36	8.63	7.03	9.18	7.65	9.72	7.59	10.15	7.49	10.57	7.88		
39	7.50	6.77	7.98	7.32	8.46	6.98	8.95	7.59	9.44	7.52	9.83	7.42	10.22	7.81		
41	7.40	6.74	7.85	7.28	8.29	6.93	8.72	7.54	9.16	7.46	9.51	7.35	9.86	7.75		
43	7.31	6.70	7.72	7.23	8.12	6.88	8.50	7.48	8.88	7.39	9.19	7.28	9.50	7.68		
46	7.17	6.65	7.52	7.17	7.87	6.81	8.16	7.40	8.46	7.30	8.71	7.18	8.97	7.59		
50	5.60	5.49	5.73	5.62	5.90	5.78	6.05	5.93	6.17	6.05	6.28	6.15	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PJG000Z649

Model FDU100VSAWVH Indoor unit FDU100VH Outdoor unit FDC100VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.14	11.60	8.06	11.92	7.90	12.55	8.26	13.18	7.90
-10							10.67	8.04	11.23	7.97	11.53	7.81	12.13	8.18	12.73	7.82
-5							10.31	7.95	10.85	7.87	11.35	7.77	12.35	8.22	13.36	7.93
0					8.55	7.00	10.33	7.95	11.22	7.96	11.56	7.82	12.25	8.20	12.93	7.85
5					9.01	7.14	10.41	7.97	11.11	7.93	11.44	7.79	12.09	8.17	12.74	7.82
11					9.41	7.26	10.44	7.98	10.96	7.90	11.36	7.77	12.15	8.18	12.94	7.86
13					9.80	7.38	10.47	7.99	10.81	7.86	11.27	7.75	12.20	8.19	13.13	7.89
15					10.19	7.50	10.50	8.00	10.66	7.82	11.19	7.73	12.26	8.20	13.32	7.92
17					9.83	7.38	10.59	8.02	10.97	7.90	11.40	7.78	12.26	8.20	13.13	7.89
19					10.26	7.52	10.67	8.04	11.27	7.98	11.61	7.83	12.27	8.20	12.94	7.86
21					10.08	7.46	10.56	8.01	11.15	7.95	11.49	7.80	12.15	8.18	12.82	7.84
23					9.90	7.41	10.45	7.98	11.04	7.92	11.37	7.77	12.03	8.16	12.70	7.82
25			9.79	7.94	9.81	7.38	10.40	7.97	10.98	7.90	11.31	7.76	11.97	8.14	12.63	7.81
27			9.62	7.88	9.72	7.35	10.35	7.96	10.92	7.89	11.39	7.78	11.86	8.12		
29			9.42	7.81	9.49	7.28	10.11	7.89	10.69	7.83	11.16	7.72	11.63	8.08		
31			9.21	7.74	9.26	7.21	9.87	7.83	10.46	7.77	10.93	7.67	11.39	8.03		
33	7.82	6.89	8.42	7.47	9.03	7.14	9.64	7.77	10.23	7.71	10.70	7.61	11.16	7.99		
35	7.68	6.84	8.24	7.41	8.80	7.08	9.40	7.71	10.00	7.66	10.46	7.56	10.93	7.94		
37	7.59	6.81	8.11	7.36	8.63	7.03	9.18	7.65	9.72	7.59	10.15	7.49	10.57	7.88		
39	7.50	6.77	7.98	7.32	8.46	6.98	8.95	7.59	9.44	7.52	9.83	7.42	10.22	7.81		
41	7.40	6.74	7.85	7.28	8.29	6.93	8.72	7.54	9.16	7.46	9.51	7.35	9.86	7.75		
43	7.31	6.70	7.72	7.23	8.12	6.88	8.50	7.48	8.88	7.39	9.19	7.28	9.50	7.68		
46	7.17	6.65	7.52	7.17	7.87	6.81	8.16	7.40	8.46	7.30	8.71	7.18	8.97	7.59		
50	5.60	5.49	5.73	5.62	5.90	5.78	6.05	5.93	6.17	6.05	6.28	6.15	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PJG000Z649

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

Model FDU125VNAWVH Indoor unit FDU125VH Outdoor unit FDC125VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.74	15.78	11.81	16.21	11.72	17.06	12.26	17.92	12.03
-10							14.51	11.54	15.27	11.61	15.68	11.51	16.50	12.06	17.32	11.83
-5							14.03	11.34	14.75	11.40	15.43	11.42	16.80	12.17	18.16	12.11
0					11.63	9.86	14.05	11.36	15.26	11.60	15.73	11.53	16.65	12.12	17.58	11.92
5					12.26	10.13	14.16	11.40	15.11	11.54	15.56	11.46	16.44	12.04	17.33	11.83
11					12.79	10.36	14.20	11.42	14.91	11.46	15.44	11.42	16.52	12.07	17.59	11.92
13					13.33	10.60	14.24	11.43	14.70	11.38	15.33	11.38	16.59	12.10	17.86	12.01
15					13.86	10.83	14.29	11.45	14.50	11.30	15.22	11.34	16.67	12.12	18.12	12.09
17					13.37	10.61	14.40	11.50	14.91	11.46	15.50	11.44	16.68	12.13	17.86	12.01
19					13.95	10.87	14.51	11.54	15.33	11.63	15.78	11.55	16.69	12.13	17.59	11.92
21					13.71	10.76	14.36	11.48	15.17	11.56	15.62	11.49	16.53	12.07	17.43	11.87
23					13.47	10.66	14.22	11.42	15.01	11.50	15.46	11.43	16.36	12.01	17.27	11.81
25			13.32	11.21	13.34	10.60	14.15	11.39	14.93	11.47	15.38	11.40	16.28	11.98	17.18	11.79
27			13.09	11.10	13.22	10.55	14.07	11.36	14.85	11.44	15.49	11.44	16.13	11.93		
29			12.81	10.97	12.91	10.41	13.75	11.23	14.54	11.31	15.18	11.32	15.81	11.82		
31			12.53	10.83	12.60	10.28	13.43	11.10	14.23	11.19	14.86	11.20	15.50	11.71		
33	10.63	9.55	11.45	10.33	12.28	10.14	13.11	10.97	13.91	11.07	14.55	11.08	15.18	11.60		
35	10.45	9.46	11.21	10.22	11.97	10.00	12.79	10.84	13.60	10.94	14.23	10.96	14.86	11.49		
37	10.32	9.40	11.03	10.14	11.74	9.90	12.48	10.72	13.22	10.80	13.80	10.80	14.38	11.32		
39	10.20	9.34	10.85	10.05	11.51	9.81	12.17	10.60	12.84	10.65	13.36	10.64	13.89	11.16		
41	10.07	9.27	10.67	9.97	11.28	9.71	11.87	10.48	12.45	10.50	12.93	10.48	13.41	10.99		
43	9.94	9.21	10.49	9.89	11.04	9.61	11.56	10.36	12.07	10.36	12.50	10.32	12.92	10.83		
46	9.75	9.12	10.22	9.77	10.70	9.46	11.10	10.18	11.50	10.14	11.85	10.09	12.20	10.59		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PJG000Z649

Model FDU125VSAWVH Indoor unit FDU125VH Outdoor unit FDC125VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.74	15.78	11.81	16.21	11.72	17.06	12.26	17.92	12.03
-10							14.51	11.54	15.27	11.61	15.68	11.51	16.50	12.06	17.32	11.83
-5							14.03	11.34	14.75	11.40	15.43	11.42	16.80	12.17	18.16	12.11
0					11.63	9.86	14.05	11.36	15.26	11.60	15.73	11.53	16.65	12.12	17.58	11.92
5					12.26	10.13	14.16	11.40	15.11	11.54	15.56	11.46	16.44	12.04	17.33	11.83
11					12.79	10.36	14.20	11.42	14.91	11.46	15.44	11.42	16.52	12.07	17.59	11.92
13					13.33	10.60	14.24	11.43	14.70	11.38	15.33	11.38	16.59	12.10	17.86	12.01
15					13.86	10.83	14.29	11.45	14.50	11.30	15.22	11.34	16.67	12.12	18.12	12.09
17					13.37	10.61	14.40	11.50	14.91	11.46	15.50	11.44	16.68	12.13	17.86	12.01
19					13.95	10.87	14.51	11.54	15.33	11.63	15.78	11.55	16.69	12.13	17.59	11.92
21					13.71	10.76	14.36	11.48	15.17	11.56	15.62	11.49	16.53	12.07	17.43	11.87
23					13.47	10.66	14.22	11.42	15.01	11.50	15.46	11.43	16.36	12.01	17.27	11.81
25			13.32	11.21	13.34	10.60	14.15	11.39	14.93	11.47	15.38	11.40	16.28	11.98	17.18	11.79
27			13.09	11.10	13.22	10.55	14.07	11.36	14.85	11.44	15.49	11.44	16.13	11.93		
29			12.81	10.97	12.91	10.41	13.75	11.23	14.54	11.31	15.18	11.32	15.81	11.82		
31			12.53	10.83	12.60	10.28	13.43	11.10	14.23	11.19	14.86	11.20	15.50	11.71		
33	10.63	9.55	11.45	10.33	12.28	10.14	13.11	10.97	13.91	11.07	14.55	11.08	15.18	11.60		
35	10.45	9.46	11.21	10.22	11.97	10.00	12.79	10.84	13.60	10.94	14.23	10.96	14.86	11.49		
37	10.32	9.40	11.03	10.14	11.74	9.90	12.48	10.72	13.22	10.80	13.80	10.80	14.38	11.32		
39	10.20	9.34	10.85	10.05	11.51	9.81	12.17	10.60	12.84	10.65	13.36	10.64	13.89	11.16		
41	10.07	9.27	10.67	9.97	11.28	9.71	11.87	10.48	12.45	10.50	12.93	10.48	13.41	10.99		
43	9.94	9.21	10.49	9.89	11.04	9.61	11.56	10.36	12.07	10.36	12.50	10.32	12.92	10.83		
46	9.75	9.12	10.22	9.77	10.70	9.46	11.10	10.18	11.50	10.14	11.85	10.09	12.20	10.59		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PJG000Z649

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.

(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.

(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

Model FDU140VNAWVH Indoor unit FDU140VH Outdoor unit FDC140VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.79	15.78	11.75	16.21	11.58	17.06	12.15	17.92	11.76
-10							14.51	11.63	15.27	11.59	15.68	11.43	16.50	12.00	17.32	11.62
-5							14.03	11.48	14.75	11.43	15.43	11.36	16.80	12.08	18.16	11.82
0					11.63	10.06	14.05	11.49	15.26	11.59	15.73	11.44	16.65	12.04	17.58	11.68
5					12.26	10.27	14.16	11.52	15.11	11.54	15.56	11.39	16.44	11.99	17.33	11.63
11					12.79	10.46	14.20	11.53	14.91	11.48	15.44	11.36	16.52	12.01	17.59	11.69
13					13.33	10.64	14.24	11.55	14.70	11.42	15.33	11.33	16.59	12.03	17.86	11.75
15					13.86	10.83	14.29	11.56	14.50	11.36	15.22	11.29	16.67	12.05	18.12	11.81
17					13.37	10.66	14.40	11.60	14.91	11.48	15.50	11.38	16.68	12.05	17.86	11.75
19					13.95	10.86	14.51	11.63	15.33	11.61	15.78	11.46	16.69	12.05	17.59	11.69
21					13.71	10.78	14.36	11.59	15.17	11.56	15.62	11.41	16.53	12.01	17.43	11.65
23					13.47	10.69	14.22	11.54	15.01	11.51	15.46	11.36	16.36	11.97	17.27	11.61
25			13.32	11.36	13.34	10.65	14.15	11.52	14.93	11.49	15.38	11.34	16.28	11.95	17.18	11.59
27			13.09	11.26	13.22	10.61	14.07	11.49	14.85	11.46	15.49	11.37	16.13	11.91		
29			12.81	11.15	12.91	10.50	13.75	11.39	14.54	11.37	15.18	11.28	15.81	11.83		
31			12.53	11.05	12.60	10.39	13.43	11.29	14.23	11.27	14.86	11.19	15.50	11.75		
33	10.63	9.79	11.45	10.63	12.28	10.28	13.11	11.19	13.91	11.18	14.55	11.10	15.18	11.67		
35	10.45	9.72	11.21	10.54	11.97	10.17	12.79	11.09	13.60	11.09	14.23	11.01	14.86	11.59		
37	10.32	9.66	11.03	10.47	11.74	10.09	12.48	11.00	13.22	10.98	13.80	10.89	14.38	11.48		
39	10.20	9.61	10.85	10.41	11.51	10.01	12.17	10.90	12.84	10.87	13.36	10.77	13.89	11.36		
41	10.07	9.56	10.67	10.34	11.28	9.93	11.87	10.81	12.45	10.76	12.93	10.66	13.41	11.24		
43	9.94	9.51	10.49	10.27	11.04	9.86	11.56	10.72	12.07	10.65	12.50	10.54	12.92	11.13		
46	9.75	9.43	10.22	10.02	10.70	9.74	11.10	10.58	11.50	10.49	11.85	10.37	12.20	10.96		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PJG000Z649

Model FDU140VSAWVH Indoor unit FDU140VH Outdoor unit FDC140VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.79	15.78	11.75	16.21	11.58	17.06	12.15	17.92	11.76
-10							14.51	11.63	15.27	11.59	15.68	11.43	16.50	12.00	17.32	11.62
-5							14.03	11.48	14.75	11.43	15.43	11.36	16.80	12.08	18.16	11.82
0					11.63	10.06	14.05	11.49	15.26	11.59	15.73	11.44	16.65	12.04	17.58	11.68
5					12.26	10.27	14.16	11.52	15.11	11.54	15.56	11.39	16.44	11.99	17.33	11.63
11					12.79	10.46	14.20	11.53	14.91	11.48	15.44	11.36	16.52	12.01	17.59	11.69
13					13.33	10.64	14.24	11.55	14.70	11.42	15.33	11.33	16.59	12.03	17.86	11.75
15					13.86	10.83	14.29	11.56	14.50	11.36	15.22	11.29	16.67	12.05	18.12	11.81
17					13.37	10.66	14.40	11.60	14.91	11.48	15.50	11.38	16.68	12.05	17.86	11.75
19					13.95	10.86	14.51	11.63	15.33	11.61	15.78	11.46	16.69	12.05	17.59	11.69
21					13.71	10.78	14.36	11.59	15.17	11.56	15.62	11.41	16.53	12.01	17.43	11.65
23					13.47	10.69	14.22	11.54	15.01	11.51	15.46	11.36	16.36	11.97	17.27	11.61
25			13.32	11.36	13.34	10.65	14.15	11.52	14.93	11.49	15.38	11.34	16.28	11.95	17.18	11.59
27			13.09	11.26	13.22	10.61	14.07	11.49	14.85	11.46	15.49	11.37	16.13	11.91		
29			12.81	11.15	12.91	10.50	13.75	11.39	14.54	11.37	15.18	11.28	15.81	11.83		
31			12.53	11.05	12.60	10.39	13.43	11.29	14.23	11.27	14.86	11.19	15.50	11.75		
33	10.63	9.79	11.45	10.63	12.28	10.28	13.11	11.19	13.91	11.18	14.55	11.10	15.18	11.67		
35	10.45	9.72	11.21	10.54	11.97	10.17	12.79	11.09	13.60	11.09	14.23	11.01	14.86	11.59		
37	10.32	9.66	11.03	10.47	11.74	10.09	12.48	11.00	13.22	10.98	13.80	10.89	14.38	11.48		
39	10.20	9.61	10.85	10.41	11.51	10.01	12.17	10.90	12.84	10.87	13.36	10.77	13.89	11.36		
41	10.07	9.56	10.67	10.34	11.28	9.93	11.87	10.81	12.45	10.76	12.93	10.66	13.41	11.24		
43	9.94	9.51	10.49	10.27	11.04	9.86	11.56	10.72	12.07	10.65	12.50	10.54	12.92	11.13		
46	9.75	9.43	10.22	10.02	10.70	9.74	11.10	10.58	11.50	10.49	11.85	10.37	12.20	10.96		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PJG000Z649

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

(4) Duct connected-Low / Middle static pressure type (FDUM)

(a) Single type

Model FDUM100VNAWVH Indoor unit FDUM100VH Outdoor unit FDC100VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.14	11.60	8.06	11.92	7.90	12.55	8.26	13.18	7.90
-10							10.67	8.04	11.23	7.97	11.53	7.81	12.13	8.18	12.73	7.82
-5							10.31	7.95	10.85	7.87	11.35	7.77	12.35	8.22	13.36	7.93
0					8.55	7.00	10.33	7.95	11.22	7.96	11.56	7.82	12.25	8.20	12.93	7.85
5					9.01	7.14	10.41	7.97	11.11	7.93	11.44	7.79	12.09	8.17	12.74	7.82
11					9.41	7.26	10.44	7.98	10.96	7.90	11.36	7.77	12.15	8.18	12.94	7.86
13					9.80	7.38	10.47	7.99	10.81	7.86	11.27	7.75	12.20	8.19	13.13	7.89
15					10.19	7.50	10.50	8.00	10.66	7.82	11.19	7.73	12.26	8.20	13.32	7.92
17					9.83	7.38	10.59	8.02	10.97	7.90	11.40	7.78	12.26	8.20	13.13	7.89
19					10.26	7.52	10.67	8.04	11.27	7.98	11.61	7.83	12.27	8.20	12.94	7.86
21					10.08	7.46	10.56	8.01	11.15	7.95	11.49	7.80	12.15	8.18	12.82	7.84
23					9.90	7.41	10.45	7.98	11.04	7.92	11.37	7.77	12.03	8.16	12.70	7.82
25			9.79	7.94	9.81	7.38	10.40	7.97	10.98	7.90	11.31	7.76	11.97	8.14	12.63	7.81
27			9.62	7.88	9.72	7.35	10.35	7.96	10.92	7.89	11.39	7.78	11.86	8.12		
29			9.42	7.81	9.49	7.28	10.11	7.89	10.69	7.83	11.16	7.72	11.63	8.08		
31			9.21	7.74	9.26	7.21	9.87	7.83	10.46	7.77	10.93	7.67	11.39	8.03		
33	7.82	6.89	8.42	7.47	9.03	7.14	9.64	7.77	10.23	7.71	10.70	7.61	11.16	7.99		
35	7.68	6.84	8.24	7.41	8.80	7.08	9.40	7.71	10.00	7.66	10.46	7.56	10.93	7.94		
37	7.59	6.81	8.11	7.36	8.63	7.03	9.18	7.65	9.72	7.59	10.15	7.49	10.57	7.88		
39	7.50	6.77	7.98	7.32	8.46	6.98	8.95	7.59	9.44	7.52	9.83	7.42	10.22	7.81		
41	7.40	6.74	7.85	7.28	8.29	6.93	8.72	7.54	9.16	7.46	9.51	7.35	9.86	7.75		
43	7.31	6.70	7.72	7.23	8.12	6.88	8.50	7.48	8.88	7.39	9.19	7.28	9.50	7.68		
46	7.17	6.65	7.52	7.17	7.87	6.81	8.16	7.40	8.46	7.30	8.71	7.18	8.97	7.59		
50	5.60	5.49	5.73	5.62	5.90	5.78	6.05	5.93	6.17	6.05	6.28	6.15	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature ℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PJG000Z623 A

Model FDUM100VSAWVH Indoor unit FDUM100VH Outdoor unit FDC100VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.14	11.60	8.06	11.92	7.90	12.55	8.26	13.18	7.90
-10							10.67	8.04	11.23	7.97	11.53	7.81	12.13	8.18	12.73	7.82
-5							10.31	7.95	10.85	7.87	11.35	7.77	12.35	8.22	13.36	7.93
0					8.55	7.00	10.33	7.95	11.22	7.96	11.56	7.82	12.25	8.20	12.93	7.85
5					9.01	7.14	10.41	7.97	11.11	7.93	11.44	7.79	12.09	8.17	12.74	7.82
11					9.41	7.26	10.44	7.98	10.96	7.90	11.36	7.77	12.15	8.18	12.94	7.86
13					9.80	7.38	10.47	7.99	10.81	7.86	11.27	7.75	12.20	8.19	13.13	7.89
15					10.19	7.50	10.50	8.00	10.66	7.82	11.19	7.73	12.26	8.20	13.32	7.92
17					9.83	7.38	10.59	8.02	10.97	7.90	11.40	7.78	12.26	8.20	13.13	7.89
19					10.26	7.52	10.67	8.04	11.27	7.98	11.61	7.83	12.27	8.20	12.94	7.86
21					10.08	7.46	10.56	8.01	11.15	7.95	11.49	7.80	12.15	8.18	12.82	7.84
23					9.90	7.41	10.45	7.98	11.04	7.92	11.37	7.77	12.03	8.16	12.70	7.82
25			9.79	7.94	9.81	7.38	10.40	7.97	10.98	7.90	11.31	7.76	11.97	8.14	12.63	7.81
27			9.62	7.88	9.72	7.35	10.35	7.96	10.92	7.89	11.39	7.78	11.86	8.12		
29			9.42	7.81	9.49	7.28	10.11	7.89	10.69	7.83	11.16	7.72	11.63	8.08		
31			9.21	7.74	9.26	7.21	9.87	7.83	10.46	7.77	10.93	7.67	11.39	8.03		
33	7.82	6.89	8.42	7.47	9.03	7.14	9.64	7.77	10.23	7.71	10.70	7.61	11.16	7.99		
35	7.68	6.84	8.24	7.41	8.80	7.08	9.40	7.71	10.00	7.66	10.46	7.56	10.93	7.94		
37	7.59	6.81	8.11	7.36	8.63	7.03	9.18	7.65	9.72	7.59	10.15	7.49	10.57	7.88		
39	7.50	6.77	7.98	7.32	8.46	6.98	8.95	7.59	9.44	7.52	9.83	7.42	10.22	7.81		
41	7.40	6.74	7.85	7.28	8.29	6.93	8.72	7.54	9.16	7.46	9.51	7.35	9.86	7.75		
43	7.31	6.70	7.72	7.23	8.12	6.88	8.50	7.48	8.88	7.39	9.19	7.28	9.50	7.68		
46	7.17	6.65	7.52	7.17	7.87	6.81	8.16	7.40	8.46	7.30	8.71	7.18	8.97	7.59		
50	5.60	5.49	5.73	5.62	5.90	5.78	6.05	5.93	6.17	6.05	6.28	6.15	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature ℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PJG000Z623 A

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

Model FDUM125VNAWVH Indoor unit FDUM125VH Outdoor unit FDC125VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.74	15.78	11.81	16.21	11.72	17.06	12.26	17.92	12.03
-10							14.51	11.54	15.27	11.61	15.68	11.51	16.50	12.06	17.32	11.83
-5							14.03	11.34	14.75	11.40	15.43	11.42	16.80	12.17	18.16	12.11
0					11.63	9.86	14.05	11.36	15.26	11.60	15.73	11.53	16.65	12.12	17.58	11.92
5					12.26	10.13	14.16	11.40	15.11	11.54	15.56	11.46	16.44	12.04	17.33	11.83
11					12.79	10.36	14.20	11.42	14.91	11.46	15.44	11.42	16.52	12.07	17.59	11.92
13					13.33	10.60	14.24	11.43	14.70	11.38	15.33	11.38	16.59	12.10	17.86	12.01
15					13.86	10.83	14.29	11.45	14.50	11.30	15.22	11.34	16.67	12.12	18.12	12.09
17					13.37	10.61	14.40	11.50	14.91	11.46	15.50	11.44	16.68	12.13	17.86	12.01
19					13.95	10.87	14.51	11.54	15.33	11.63	15.78	11.55	16.69	12.13	17.59	11.92
21					13.71	10.76	14.36	11.48	15.17	11.56	15.62	11.49	16.53	12.07	17.43	11.87
23					13.47	10.66	14.22	11.42	15.01	11.50	15.46	11.43	16.36	12.01	17.27	11.81
25			13.32	11.21	13.34	10.60	14.15	11.39	14.93	11.47	15.38	11.40	16.28	11.98	17.18	11.79
27			13.09	11.10	13.22	10.55	14.07	11.36	14.85	11.44	15.49	11.44	16.13	11.93		
29			12.81	10.97	12.91	10.41	13.75	11.23	14.54	11.31	15.18	11.32	15.81	11.82		
31			12.53	10.83	12.60	10.28	13.43	11.10	14.23	11.19	14.86	11.20	15.50	11.71		
33	10.63	9.55	11.45	10.33	12.28	10.14	13.11	10.97	13.91	11.07	14.55	11.08	15.18	11.60		
35	10.45	9.46	11.21	10.22	11.97	10.00	12.79	10.84	13.60	10.94	14.23	10.96	14.86	11.49		
37	10.32	9.40	11.03	10.14	11.74	9.90	12.48	10.72	13.22	10.80	13.80	10.80	14.38	11.32		
39	10.20	9.34	10.85	10.05	11.51	9.81	12.17	10.60	12.84	10.65	13.36	10.64	13.89	11.16		
41	10.07	9.27	10.67	9.97	11.28	9.71	11.87	10.48	12.45	10.50	12.93	10.48	13.41	10.99		
43	9.94	9.21	10.49	9.89	11.04	9.61	11.56	10.36	12.07	10.36	12.50	10.32	12.92	10.83		
46	9.75	9.12	10.22	9.77	10.70	9.46	11.10	10.18	11.50	10.14	11.85	10.09	12.20	10.59		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PJG000Z623 A

Model FDUM125VSAWVH Indoor unit FDUM125VH Outdoor unit FDC125VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.74	15.78	11.81	16.21	11.72	17.06	12.26	17.92	12.03
-10							14.51	11.54	15.27	11.61	15.68	11.51	16.50	12.06	17.32	11.83
-5							14.03	11.34	14.75	11.40	15.43	11.42	16.80	12.17	18.16	12.11
0					11.63	9.86	14.05	11.36	15.26	11.60	15.73	11.53	16.65	12.12	17.58	11.92
5					12.26	10.13	14.16	11.40	15.11	11.54	15.56	11.46	16.44	12.04	17.33	11.83
11					12.79	10.36	14.20	11.42	14.91	11.46	15.44	11.42	16.52	12.07	17.59	11.92
13					13.33	10.60	14.24	11.43	14.70	11.38	15.33	11.38	16.59	12.10	17.86	12.01
15					13.86	10.83	14.29	11.45	14.50	11.30	15.22	11.34	16.67	12.12	18.12	12.09
17					13.37	10.61	14.40	11.50	14.91	11.46	15.50	11.44	16.68	12.13	17.86	12.01
19					13.95	10.87	14.51	11.54	15.33	11.63	15.78	11.55	16.69	12.13	17.59	11.92
21					13.71	10.76	14.36	11.48	15.17	11.56	15.62	11.49	16.53	12.07	17.43	11.87
23					13.47	10.66	14.22	11.42	15.01	11.50	15.46	11.43	16.36	12.01	17.27	11.81
25			13.32	11.21	13.34	10.60	14.15	11.39	14.93	11.47	15.38	11.40	16.28	11.98	17.18	11.79
27			13.09	11.10	13.22	10.55	14.07	11.36	14.85	11.44	15.49	11.44	16.13	11.93		
29			12.81	10.97	12.91	10.41	13.75	11.23	14.54	11.31	15.18	11.32	15.81	11.82		
31			12.53	10.83	12.60	10.28	13.43	11.10	14.23	11.19	14.86	11.20	15.50	11.71		
33	10.63	9.55	11.45	10.33	12.28	10.14	13.11	10.97	13.91	11.07	14.55	11.08	15.18	11.60		
35	10.45	9.46	11.21	10.22	11.97	10.00	12.79	10.84	13.60	10.94	14.23	10.96	14.86	11.49		
37	10.32	9.40	11.03	10.14	11.74	9.90	12.48	10.72	13.22	10.80	13.80	10.80	14.38	11.32		
39	10.20	9.34	10.85	10.05	11.51	9.81	12.17	10.60	12.84	10.65	13.36	10.64	13.89	11.16		
41	10.07	9.27	10.67	9.97	11.28	9.71	11.87	10.48	12.45	10.50	12.93	10.48	13.41	10.99		
43	9.94	9.21	10.49	9.89	11.04	9.61	11.56	10.36	12.07	10.36	12.50	10.32	12.92	10.83		
46	9.75	9.12	10.22	9.77	10.70	9.46	11.10	10.18	11.50	10.14	11.85	10.09	12.20	10.59		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PJG000Z623 A

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

Model FDUM140VNAWVH Indoor unit FDUM140VH Outdoor unit FDC140VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.79	15.78	11.75	16.21	11.58	17.06	12.15	17.92	11.76
-10							14.51	11.63	15.27	11.59	15.68	11.43	16.50	12.00	17.32	11.62
-5							14.03	11.48	14.75	11.43	15.43	11.36	16.80	12.08	18.16	11.82
0					11.63	10.06	14.05	11.49	15.26	11.59	15.73	11.44	16.65	12.04	17.58	11.68
5					12.26	10.27	14.16	11.52	15.11	11.54	15.56	11.39	16.44	11.99	17.33	11.63
11					12.79	10.46	14.20	11.53	14.91	11.48	15.44	11.36	16.52	12.01	17.59	11.69
13					13.33	10.64	14.24	11.55	14.70	11.42	15.33	11.33	16.59	12.03	17.86	11.75
15					13.86	10.83	14.29	11.56	14.50	11.36	15.22	11.29	16.67	12.05	18.12	11.81
17					13.37	10.66	14.40	11.60	14.91	11.48	15.50	11.38	16.68	12.05	17.86	11.75
19					13.95	10.86	14.51	11.63	15.33	11.61	15.78	11.46	16.69	12.05	17.59	11.69
21					13.71	10.78	14.36	11.59	15.17	11.56	15.62	11.41	16.53	12.01	17.43	11.65
23					13.47	10.69	14.22	11.54	15.01	11.51	15.46	11.36	16.36	11.97	17.27	11.61
25			13.32	11.36	13.34	10.65	14.15	11.52	14.93	11.49	15.38	11.34	16.28	11.95	17.18	11.59
27			13.09	11.26	13.22	10.61	14.07	11.49	14.85	11.46	15.49	11.37	16.13	11.91		
29			12.81	11.15	12.91	10.50	13.75	11.39	14.54	11.37	15.18	11.28	15.81	11.83		
31			12.53	11.05	12.60	10.39	13.43	11.29	14.23	11.27	14.86	11.19	15.50	11.75		
33	10.63	9.79	11.45	10.63	12.28	10.28	13.11	11.19	13.91	11.18	14.55	11.10	15.18	11.67		
35	10.45	9.72	11.21	10.54	11.97	10.17	12.79	11.09	13.60	11.09	14.23	11.01	14.86	11.59		
37	10.32	9.66	11.03	10.47	11.74	10.09	12.48	11.00	13.22	10.98	13.80	10.89	14.38	11.48		
39	10.20	9.61	10.85	10.41	11.51	10.01	12.17	10.90	12.84	10.87	13.36	10.77	13.89	11.36		
41	10.07	9.56	10.67	10.34	11.28	9.93	11.87	10.81	12.45	10.76	12.93	10.66	13.41	11.24		
43	9.94	9.51	10.49	10.27	11.04	9.86	11.56	10.72	12.07	10.65	12.50	10.54	12.92	11.13		
46	9.75	9.43	10.22	10.02	10.70	9.74	11.10	10.58	11.50	10.49	11.85	10.37	12.20	10.96		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PJG000Z623 Ⓐ

Model FDUM140VSAWVH Indoor unit FDUM140VH Outdoor unit FDC140VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.79	15.78	11.75	16.21	11.58	17.06	12.15	17.92	11.76
-10							14.51	11.63	15.27	11.59	15.68	11.43	16.50	12.00	17.32	11.62
-5							14.03	11.48	14.75	11.43	15.43	11.36	16.80	12.08	18.16	11.82
0					11.63	10.06	14.05	11.49	15.26	11.59	15.73	11.44	16.65	12.04	17.58	11.68
5					12.26	10.27	14.16	11.52	15.11	11.54	15.56	11.39	16.44	11.99	17.33	11.63
11					12.79	10.46	14.20	11.53	14.91	11.48	15.44	11.36	16.52	12.01	17.59	11.69
13					13.33	10.64	14.24	11.55	14.70	11.42	15.33	11.33	16.59	12.03	17.86	11.75
15					13.86	10.83	14.29	11.56	14.50	11.36	15.22	11.29	16.67	12.05	18.12	11.81
17					13.37	10.66	14.40	11.60	14.91	11.48	15.50	11.38	16.68	12.05	17.86	11.75
19					13.95	10.86	14.51	11.63	15.33	11.61	15.78	11.46	16.69	12.05	17.59	11.69
21					13.71	10.78	14.36	11.59	15.17	11.56	15.62	11.41	16.53	12.01	17.43	11.65
23					13.47	10.69	14.22	11.54	15.01	11.51	15.46	11.36	16.36	11.97	17.27	11.61
25			13.32	11.36	13.34	10.65	14.15	11.52	14.93	11.49	15.38	11.34	16.28	11.95	17.18	11.59
27			13.09	11.26	13.22	10.61	14.07	11.49	14.85	11.46	15.49	11.37	16.13	11.91		
29			12.81	11.15	12.91	10.50	13.75	11.39	14.54	11.37	15.18	11.28	15.81	11.83		
31			12.53	11.05	12.60	10.39	13.43	11.29	14.23	11.27	14.86	11.19	15.50	11.75		
33	10.63	9.79	11.45	10.63	12.28	10.28	13.11	11.19	13.91	11.18	14.55	11.10	15.18	11.67		
35	10.45	9.72	11.21	10.54	11.97	10.17	12.79	11.09	13.60	11.09	14.23	11.01	14.86	11.59		
37	10.32	9.66	11.03	10.47	11.74	10.09	12.48	11.00	13.22	10.98	13.80	10.89	14.38	11.48		
39	10.20	9.61	10.85	10.41	11.51	10.01	12.17	10.90	12.84	10.87	13.36	10.77	13.89	11.36		
41	10.07	9.56	10.67	10.34	11.28	9.93	11.87	10.81	12.45	10.76	12.93	10.66	13.41	11.24		
43	9.94	9.51	10.49	10.27	11.04	9.86	11.56	10.72	12.07	10.65	12.50	10.54	12.92	11.13		
46	9.75	9.43	10.22	10.02	10.70	9.74	11.10	10.58	11.50	10.49	11.85	10.37	12.20	10.96		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PJG000Z623 Ⓐ

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

(b) Twin type

Model FDUM100VNAWPVH Indoor unit FDUM50VH (2 units) Outdoor unit FDC100VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.26	11.60	8.32	11.92	8.25	12.55	8.60	13.18	8.43
-10							10.67	8.11	11.23	8.16	11.53	8.10	12.13	8.45	12.73	8.28
-5							10.31	7.96	10.85	8.01	11.35	8.02	12.35	8.53	13.36	8.49
0					8.55	6.92	10.33	7.97	11.22	8.16	11.56	8.11	12.25	8.49	12.93	8.35
5					9.01	7.12	10.41	8.01	11.11	8.12	11.44	8.06	12.09	8.43	12.74	8.28
11					9.41	7.30	10.44	8.02	10.96	8.05	11.36	8.03	12.15	8.46	12.94	8.35
13					9.80	7.47	10.47	8.03	10.81	7.99	11.27	8.00	12.20	8.48	13.13	8.41
15					10.19	7.65	10.50	8.04	10.66	7.93	11.19	7.96	12.26	8.50	13.32	8.48
17					9.83	7.49	10.59	8.08	10.97	8.06	11.40	8.04	12.26	8.50	13.13	8.41
19					10.26	7.68	10.67	8.11	11.27	8.18	11.61	8.13	12.27	8.50	12.94	8.35
21					10.08	7.60	10.56	8.07	11.15	8.13	11.49	8.08	12.15	8.46	12.82	8.31
23					9.90	7.52	10.45	8.02	11.04	8.08	11.37	8.03	12.03	8.41	12.70	8.27
25			9.79	7.92	9.81	7.48	10.40	8.00	10.98	8.06	11.31	8.01	11.97	8.39	12.63	8.25
27			9.62	7.84	9.72	7.44	10.35	7.98	10.92	8.04	11.39	8.04	11.86	8.35		
29			9.42	7.74	9.49	7.34	10.11	7.88	10.69	7.94	11.16	7.95	11.63	8.27		
31			9.21	7.64	9.26	7.23	9.87	7.78	10.46	7.85	10.93	7.86	11.39	8.18		
33	7.82	6.73	8.42	7.25	9.03	7.13	9.64	7.68	10.23	7.76	10.70	7.77	11.16	8.10		
35	7.68	6.66	8.24	7.17	8.80	7.03	9.40	7.58	10.00	7.66	10.46	7.68	10.93	8.02		
37	7.59	6.62	8.11	7.11	8.63	6.95	9.18	7.49	9.72	7.55	10.15	7.56	10.57	7.89		
39	7.50	6.57	7.98	7.05	8.46	6.88	8.95	7.40	9.44	7.44	9.83	7.44	10.22	7.76		
41	7.40	6.52	7.85	6.99	8.29	6.80	8.72	7.31	9.16	7.33	9.51	7.31	9.86	7.64		
43	7.31	6.48	7.72	6.92	8.12	6.73	8.50	7.22	8.88	7.22	9.19	7.20	9.50	7.52		
46	7.17	6.41	7.52	6.83	7.87	6.62	8.16	7.08	8.46	7.06	8.71	7.02	8.97	7.34		
50	5.60	5.49	5.73	5.62	5.90	5.78	6.05	5.93	6.17	6.05	6.28	6.15	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PJG000Z623 A

Model FDUM100VSAWPVH Indoor unit FDUM50VH (2 units) Outdoor unit FDC100VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.26	11.60	8.32	11.92	8.25	12.55	8.60	13.18	8.43
-10							10.67	8.11	11.23	8.16	11.53	8.10	12.13	8.45	12.73	8.28
-5							10.31	7.96	10.85	8.01	11.35	8.02	12.35	8.53	13.36	8.49
0					8.55	6.92	10.33	7.97	11.22	8.16	11.56	8.11	12.25	8.49	12.93	8.35
5					9.01	7.12	10.41	8.01	11.11	8.12	11.44	8.06	12.09	8.43	12.74	8.28
11					9.41	7.30	10.44	8.02	10.96	8.05	11.36	8.03	12.15	8.46	12.94	8.35
13					9.80	7.47	10.47	8.03	10.81	7.99	11.27	8.00	12.20	8.48	13.13	8.41
15					10.19	7.65	10.50	8.04	10.66	7.93	11.19	7.96	12.26	8.50	13.32	8.48
17					9.83	7.49	10.59	8.08	10.97	8.06	11.40	8.04	12.26	8.50	13.13	8.41
19					10.26	7.68	10.67	8.11	11.27	8.18	11.61	8.13	12.27	8.50	12.94	8.35
21					10.08	7.60	10.56	8.07	11.15	8.13	11.49	8.08	12.15	8.46	12.82	8.31
23					9.90	7.52	10.45	8.02	11.04	8.08	11.37	8.03	12.03	8.41	12.70	8.27
25			9.79	7.92	9.81	7.48	10.40	8.00	10.98	8.06	11.31	8.01	11.97	8.39	12.63	8.25
27			9.62	7.84	9.72	7.44	10.35	7.98	10.92	8.04	11.39	8.04	11.86	8.35		
29			9.42	7.74	9.49	7.34	10.11	7.88	10.69	7.94	11.16	7.95	11.63	8.27		
31			9.21	7.64	9.26	7.23	9.87	7.78	10.46	7.85	10.93	7.86	11.39	8.18		
33	7.82	6.73	8.42	7.25	9.03	7.13	9.64	7.68	10.23	7.76	10.70	7.77	11.16	8.10		
35	7.68	6.66	8.24	7.17	8.80	7.03	9.40	7.58	10.00	7.66	10.46	7.68	10.93	8.02		
37	7.59	6.62	8.11	7.11	8.63	6.95	9.18	7.49	9.72	7.55	10.15	7.56	10.57	7.89		
39	7.50	6.57	7.98	7.05	8.46	6.88	8.95	7.40	9.44	7.44	9.83	7.44	10.22	7.76		
41	7.40	6.52	7.85	6.99	8.29	6.80	8.72	7.31	9.16	7.33	9.51	7.31	9.86	7.64		
43	7.31	6.48	7.72	6.92	8.12	6.73	8.50	7.22	8.88	7.22	9.19	7.20	9.50	7.52		
46	7.17	6.41	7.52	6.83	7.87	6.62	8.16	7.08	8.46	7.06	8.71	7.02	8.97	7.34		
50	5.60	5.49	5.73	5.62	5.90	5.78	6.05	5.93	6.17	6.05	6.28	6.15	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PJG000Z623 A

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

Model FDUM125VNAWPVH Indoor unit FDUM60VH (2 units) Outdoor unit FDC125VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.22	15.78	11.24	16.21	11.10	17.06	11.59	17.92	11.27
-10							14.51	11.04	15.27	11.05	15.68	10.92	16.50	11.41	17.32	11.10
-5							14.03	10.86	14.75	10.86	15.43	10.84	16.80	11.51	18.16	11.34
0					11.63	9.48	14.05	10.87	15.26	11.05	15.73	10.94	16.65	11.46	17.58	11.18
5					12.26	9.73	14.16	10.91	15.11	10.99	15.56	10.88	16.44	11.40	17.33	11.11
11					12.79	9.94	14.20	10.93	14.91	10.92	15.44	10.84	16.52	11.42	17.59	11.18
13					13.33	10.15	14.24	10.94	14.70	10.85	15.33	10.80	16.59	11.44	17.86	11.25
15					13.86	10.37	14.29	10.96	14.50	10.77	15.22	10.76	16.67	11.47	18.12	11.33
17					13.37	10.17	14.40	11.00	14.91	10.92	15.50	10.86	16.68	11.47	17.86	11.26
19					13.95	10.41	14.51	11.04	15.33	11.07	15.78	10.96	16.69	11.47	17.59	11.18
21					13.71	10.31	14.36	10.99	15.17	11.02	15.62	10.90	16.53	11.42	17.43	11.13
23					13.47	10.21	14.22	10.93	15.01	10.96	15.46	10.85	16.36	11.37	17.27	11.09
25			13.32	10.81	13.34	10.16	14.15	10.90	14.93	10.93	15.38	10.82	16.28	11.35	17.18	11.07
27			13.09	10.71	13.22	10.11	14.07	10.88	14.85	10.90	15.49	10.86	16.13	11.30		
29			12.81	10.58	12.91	9.98	13.75	10.76	14.54	10.79	15.18	10.75	15.81	11.20		
31			12.53	10.46	12.60	9.86	13.43	10.64	14.23	10.68	14.86	10.64	15.50	11.10		
33	10.63	9.25	11.45	9.99	12.28	9.73	13.11	10.52	13.91	10.57	14.55	10.54	15.18	11.01		
35	10.45	9.17	11.21	9.89	11.97	9.61	12.79	10.41	13.60	10.46	14.23	10.43	14.86	10.91		
37	10.32	9.11	11.03	9.81	11.74	9.52	12.48	10.30	13.22	10.33	13.80	10.29	14.38	10.77		
39	10.20	9.05	10.85	9.74	11.51	9.43	12.17	10.19	12.84	10.20	13.36	10.14	13.89	10.62		
41	10.07	9.00	10.67	9.66	11.28	9.34	11.87	10.08	12.45	10.07	12.93	10.00	13.41	10.48		
43	9.94	8.94	10.49	9.59	11.04	9.25	11.56	9.97	12.07	9.94	12.50	9.86	12.92	10.34		
46	9.75	8.85	10.22	9.48	10.70	9.12	11.10	9.81	11.50	9.75	11.85	9.66	12.20	10.14		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PJG000Z623 Ⓐ

Model FDUM125VSAWPVH Indoor unit FDUM60VH (2 units) Outdoor unit FDC125VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.22	15.78	11.24	16.21	11.10	17.06	11.59	17.92	11.27
-10							14.51	11.04	15.27	11.05	15.68	10.92	16.50	11.41	17.32	11.10
-5							14.03	10.86	14.75	10.86	15.43	10.84	16.80	11.51	18.16	11.34
0					11.63	9.48	14.05	10.87	15.26	11.05	15.73	10.94	16.65	11.46	17.58	11.18
5					12.26	9.73	14.16	10.91	15.11	10.99	15.56	10.88	16.44	11.40	17.33	11.11
11					12.79	9.94	14.20	10.93	14.91	10.92	15.44	10.84	16.52	11.42	17.59	11.18
13					13.33	10.15	14.24	10.94	14.70	10.85	15.33	10.80	16.59	11.44	17.86	11.25
15					13.86	10.37	14.29	10.96	14.50	10.77	15.22	10.76	16.67	11.47	18.12	11.33
17					13.37	10.17	14.40	11.00	14.91	10.92	15.50	10.86	16.68	11.47	17.86	11.26
19					13.95	10.41	14.51	11.04	15.33	11.07	15.78	10.96	16.69	11.47	17.59	11.18
21					13.71	10.31	14.36	10.99	15.17	11.02	15.62	10.90	16.53	11.42	17.43	11.13
23					13.47	10.21	14.22	10.93	15.01	10.96	15.46	10.85	16.36	11.37	17.27	11.09
25			13.32	10.81	13.34	10.16	14.15	10.90	14.93	10.93	15.38	10.82	16.28	11.35	17.18	11.07
27			13.09	10.71	13.22	10.11	14.07	10.88	14.85	10.90	15.49	10.86	16.13	11.30		
29			12.81	10.58	12.91	9.98	13.75	10.76	14.54	10.79	15.18	10.75	15.81	11.20		
31			12.53	10.46	12.60	9.86	13.43	10.64	14.23	10.68	14.86	10.64	15.50	11.10		
33	10.63	9.25	11.45	9.99	12.28	9.73	13.11	10.52	13.91	10.57	14.55	10.54	15.18	11.01		
35	10.45	9.17	11.21	9.89	11.97	9.61	12.79	10.41	13.60	10.46	14.23	10.43	14.86	10.91		
37	10.32	9.11	11.03	9.81	11.74	9.52	12.48	10.30	13.22	10.33	13.80	10.29	14.38	10.77		
39	10.20	9.05	10.85	9.74	11.51	9.43	12.17	10.19	12.84	10.20	13.36	10.14	13.89	10.62		
41	10.07	9.00	10.67	9.66	11.28	9.34	11.87	10.08	12.45	10.07	12.93	10.00	13.41	10.48		
43	9.94	8.94	10.49	9.59	11.04	9.25	11.56	9.97	12.07	9.94	12.50	9.86	12.92	10.34		
46	9.75	8.85	10.22	9.48	10.70	9.12	11.10	9.81	11.50	9.75	11.85	9.66	12.20	10.14		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PJG000Z623 Ⓐ

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

Model FDUM140VNAWPVH Indoor unit FDUM71VH (2 units) Outdoor unit FDC140VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	12.20	15.78	12.19	16.21	12.04	17.06	12.66	17.92	12.32
-10							14.51	12.03	15.27	12.02	15.68	11.88	16.50	12.50	17.32	12.17
-5							14.03	11.87	14.75	11.85	15.43	11.80	16.80	12.58	18.16	12.38
0					11.63	10.37	14.05	11.87	15.26	12.02	15.73	11.89	16.65	12.54	17.58	12.23
5					12.26	10.59	14.16	11.91	15.11	11.97	15.56	11.84	16.44	12.48	17.33	12.17
11					12.79	10.79	14.20	11.93	14.91	11.90	15.44	11.80	16.52	12.51	17.59	12.24
13					13.33	10.99	14.24	11.94	14.70	11.83	15.33	11.77	16.59	12.53	17.86	12.30
15					13.86	11.19	14.29	11.95	14.50	11.76	15.22	11.73	16.67	12.55	18.12	12.37
17					13.37	11.01	14.40	11.99	14.91	11.90	15.50	11.82	16.68	12.55	17.86	12.30
19					13.95	11.23	14.51	12.03	15.33	12.04	15.78	11.91	16.69	12.55	17.59	12.24
21					13.71	11.13	14.36	11.98	15.17	11.99	15.62	11.86	16.53	12.51	17.43	12.20
23					13.47	11.04	14.22	11.93	15.01	11.93	15.46	11.81	16.36	12.46	17.27	12.16
25			13.32	11.68	13.34	11.00	14.15	11.91	14.93	11.91	15.38	11.78	16.28	12.44	17.18	12.13
27			13.09	11.58	13.22	10.95	14.07	11.88	14.85	11.88	15.49	11.82	16.13	12.40		
29			12.81	11.47	12.91	10.84	13.75	11.77	14.54	11.78	15.18	11.72	15.81	12.31		
31			12.53	11.35	12.60	10.72	13.43	11.66	14.23	11.68	14.86	11.62	15.50	12.22		
33	10.63	10.04	11.45	10.92	12.28	10.60	13.11	11.55	13.91	11.58	14.55	11.52	15.18	12.13		
35	10.45	9.97	11.21	10.82	11.97	10.49	12.79	11.45	13.60	11.48	14.23	11.43	14.86	12.05		
37	10.32	9.91	11.03	10.75	11.74	10.40	12.48	11.35	13.22	11.35	13.80	11.30	14.38	11.92		
39	10.20	9.86	10.85	10.63	11.51	10.32	12.17	11.24	12.84	11.23	13.36	11.17	13.89	11.79		
41	10.07	9.80	10.67	10.46	11.28	10.24	11.87	11.14	12.45	11.11	12.93	11.04	13.41	11.66		
43	9.94	9.74	10.49	10.28	11.04	10.15	11.56	11.04	12.07	11.00	12.50	10.91	12.92	11.53		
46	9.75	9.56	10.22	10.02	10.70	10.03	11.10	10.88	11.50	10.82	11.85	10.72	12.20	11.34		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PJG000Z623 A

Model FDUM140VSAWPVH Indoor unit FDUM71VH (2 units) Outdoor unit FDC140VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	12.20	15.78	12.19	16.21	12.04	17.06	12.66	17.92	12.32
-10							14.51	12.03	15.27	12.02	15.68	11.88	16.50	12.50	17.32	12.17
-5							14.03	11.87	14.75	11.85	15.43	11.80	16.80	12.58	18.16	12.38
0					11.63	10.37	14.05	11.87	15.26	12.02	15.73	11.89	16.65	12.54	17.58	12.23
5					12.26	10.59	14.16	11.91	15.11	11.97	15.56	11.84	16.44	12.48	17.33	12.17
11					12.79	10.79	14.20	11.93	14.91	11.90	15.44	11.80	16.52	12.51	17.59	12.24
13					13.33	10.99	14.24	11.94	14.70	11.83	15.33	11.77	16.59	12.53	17.86	12.30
15					13.86	11.19	14.29	11.95	14.50	11.76	15.22	11.73	16.67	12.55	18.12	12.37
17					13.37	11.01	14.40	11.99	14.91	11.90	15.50	11.82	16.68	12.55	17.86	12.30
19					13.95	11.23	14.51	12.03	15.33	12.04	15.78	11.91	16.69	12.55	17.59	12.24
21					13.71	11.13	14.36	11.98	15.17	11.99	15.62	11.86	16.53	12.51	17.43	12.20
23					13.47	11.04	14.22	11.93	15.01	11.93	15.46	11.81	16.36	12.46	17.27	12.16
25			13.32	11.68	13.34	11.00	14.15	11.91	14.93	11.91	15.38	11.78	16.28	12.44	17.18	12.13
27			13.09	11.58	13.22	10.95	14.07	11.88	14.85	11.88	15.49	11.82	16.13	12.40		
29			12.81	11.47	12.91	10.84	13.75	11.77	14.54	11.78	15.18	11.72	15.81	12.31		
31			12.53	11.35	12.60	10.72	13.43	11.66	14.23	11.68	14.86	11.62	15.50	12.22		
33	10.63	10.04	11.45	10.92	12.28	10.60	13.11	11.55	13.91	11.58	14.55	11.52	15.18	12.13		
35	10.45	9.97	11.21	10.82	11.97	10.49	12.79	11.45	13.60	11.48	14.23	11.43	14.86	12.05		
37	10.32	9.91	11.03	10.75	11.74	10.40	12.48	11.35	13.22	11.35	13.80	11.30	14.38	11.92		
39	10.20	9.86	10.85	10.63	11.51	10.32	12.17	11.24	12.84	11.23	13.36	11.17	13.89	11.79		
41	10.07	9.80	10.67	10.46	11.28	10.24	11.87	11.14	12.45	11.11	12.93	11.04	13.41	11.66		
43	9.94	9.74	10.49	10.28	11.04	10.15	11.56	11.04	12.07	11.00	12.50	10.91	12.92	11.53		
46	9.75	9.56	10.22	10.02	10.70	10.03	11.10	10.88	11.50	10.82	11.85	10.72	12.20	11.34		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PJG000Z623 A

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

(c) Triple type

Model FDUM140VNAWTVH Indoor unit FDUM50VH (3 units) Outdoor unit FDC140VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.74	15.78	11.81	16.21	11.72	17.06	12.26	17.92	12.03
-10							14.51	11.54	15.27	11.61	15.68	11.51	16.50	12.06	17.32	11.83
-5							14.03	11.34	14.75	11.40	15.43	11.42	16.80	12.17	18.16	12.11
0					11.63	9.86	14.05	11.36	15.26	11.60	15.73	11.53	16.65	12.12	17.58	11.92
5					12.26	10.13	14.16	11.40	15.11	11.54	15.56	11.46	16.44	12.04	17.33	11.83
11					12.79	10.36	14.20	11.42	14.91	11.46	15.44	11.42	16.52	12.07	17.59	11.92
13					13.33	10.60	14.24	11.43	14.70	11.38	15.33	11.38	16.59	12.10	17.86	12.01
15					13.86	10.83	14.29	11.45	14.50	11.30	15.22	11.34	16.67	12.12	18.12	12.09
17					13.37	10.61	14.40	11.50	14.91	11.46	15.50	11.44	16.68	12.13	17.86	12.01
19					13.95	10.87	14.51	11.54	15.33	11.63	15.78	11.55	16.69	12.13	17.59	11.92
21					13.71	10.76	14.36	11.48	15.17	11.56	15.62	11.49	16.53	12.07	17.43	11.87
23					13.47	10.66	14.22	11.42	15.01	11.50	15.46	11.43	16.36	12.01	17.27	11.81
25			13.32	11.21	13.34	10.60	14.15	11.39	14.93	11.47	15.38	11.40	16.28	11.98	17.18	11.79
27			13.09	11.10	13.22	10.55	14.07	11.36	14.85	11.44	15.49	11.44	16.13	11.93		
29			12.81	10.97	12.91	10.41	13.75	11.23	14.54	11.31	15.18	11.32	15.81	11.82		
31			12.53	10.83	12.60	10.28	13.43	11.10	14.23	11.19	14.86	11.20	15.50	11.71		
33	10.63	9.55	11.45	10.33	12.28	10.14	13.11	10.97	13.91	11.07	14.55	11.08	15.18	11.60		
35	10.45	9.46	11.21	10.22	11.97	10.00	12.79	10.84	13.60	10.94	14.23	10.96	14.86	11.49		
37	10.32	9.40	11.03	10.14	11.74	9.90	12.48	10.72	13.22	10.80	13.80	10.80	14.38	11.32		
39	10.20	9.34	10.85	10.05	11.51	9.81	12.17	10.60	12.84	10.65	13.36	10.64	13.89	11.16		
41	10.07	9.27	10.67	9.97	11.28	9.71	11.87	10.48	12.45	10.50	12.93	10.48	13.41	10.99		
43	9.94	9.21	10.49	9.89	11.04	9.61	11.56	10.36	12.07	10.36	12.50	10.32	12.92	10.83		
46	9.75	9.12	10.22	9.77	10.70	9.46	11.10	10.18	11.50	10.14	11.85	10.09	12.20	10.59		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PJG000Z623 Ⓐ

Model FDUM140VSAWTVH Indoor unit FDUM50VH (3 units) Outdoor unit FDC140VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.74	15.78	11.81	16.21	11.72	17.06	12.26	17.92	12.03
-10							14.51	11.54	15.27	11.61	15.68	11.51	16.50	12.06	17.32	11.83
-5							14.03	11.34	14.75	11.40	15.43	11.42	16.80	12.17	18.16	12.11
0					11.63	9.86	14.05	11.36	15.26	11.60	15.73	11.53	16.65	12.12	17.58	11.92
5					12.26	10.13	14.16	11.40	15.11	11.54	15.56	11.46	16.44	12.04	17.33	11.83
11					12.79	10.36	14.20	11.42	14.91	11.46	15.44	11.42	16.52	12.07	17.59	11.92
13					13.33	10.60	14.24	11.43	14.70	11.38	15.33	11.38	16.59	12.10	17.86	12.01
15					13.86	10.83	14.29	11.45	14.50	11.30	15.22	11.34	16.67	12.12	18.12	12.09
17					13.37	10.61	14.40	11.50	14.91	11.46	15.50	11.44	16.68	12.13	17.86	12.01
19					13.95	10.87	14.51	11.54	15.33	11.63	15.78	11.55	16.69	12.13	17.59	11.92
21					13.71	10.76	14.36	11.48	15.17	11.56	15.62	11.49	16.53	12.07	17.43	11.87
23					13.47	10.66	14.22	11.42	15.01	11.50	15.46	11.43	16.36	12.01	17.27	11.81
25			13.32	11.21	13.34	10.60	14.15	11.39	14.93	11.47	15.38	11.40	16.28	11.98	17.18	11.79
27			13.09	11.10	13.22	10.55	14.07	11.36	14.85	11.44	15.49	11.44	16.13	11.93		
29			12.81	10.97	12.91	10.41	13.75	11.23	14.54	11.31	15.18	11.32	15.81	11.82		
31			12.53	10.83	12.60	10.28	13.43	11.10	14.23	11.19	14.86	11.20	15.50	11.71		
33	10.63	9.55	11.45	10.33	12.28	10.14	13.11	10.97	13.91	11.07	14.55	11.08	15.18	11.60		
35	10.45	9.46	11.21	10.22	11.97	10.00	12.79	10.84	13.60	10.94	14.23	10.96	14.86	11.49		
37	10.32	9.40	11.03	10.14	11.74	9.90	12.48	10.72	13.22	10.80	13.80	10.80	14.38	11.32		
39	10.20	9.34	10.85	10.05	11.51	9.81	12.17	10.60	12.84	10.65	13.36	10.64	13.89	11.16		
41	10.07	9.27	10.67	9.97	11.28	9.71	11.87	10.48	12.45	10.50	12.93	10.48	13.41	10.99		
43	9.94	9.21	10.49	9.89	11.04	9.61	11.56	10.36	12.07	10.36	12.50	10.32	12.92	10.83		
46	9.75	9.12	10.22	9.77	10.70	9.46	11.10	10.18	11.50	10.14	11.85	10.09	12.20	10.59		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PJG000Z623 Ⓐ

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

(5) Ceiling susponded type (FDE)

(a) Single type

Model FDE100VNAWVH Indoor unit FDE100VH Outdoor unit FDC100VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.94	11.60	8.97	11.92	8.89	12.55	9.34	13.18	9.14
-10							10.67	8.80	11.23	8.83	11.53	8.75	12.13	9.20	12.73	9.01
-5							10.31	8.66	10.85	8.69	11.35	8.69	12.35	9.27	13.36	9.20
0					8.55	7.54	10.33	8.67	11.22	8.83	11.56	8.76	12.25	9.24	12.93	9.07
5					9.01	7.73	10.41	8.70	11.11	8.79	11.44	8.72	12.09	9.18	12.74	9.01
11					9.41	7.89	10.44	8.71	10.96	8.73	11.36	8.69	12.15	9.20	12.94	9.07
13					9.80	8.05	10.47	8.73	10.81	8.67	11.27	8.66	12.20	9.22	13.13	9.13
15					10.19	8.22	10.50	8.74	10.66	8.62	11.19	8.63	12.26	9.24	13.32	9.19
17					9.83	8.07	10.59	8.77	10.97	8.73	11.40	8.70	12.26	9.24	13.13	9.13
19					10.26	8.25	10.67	8.80	11.27	8.85	11.61	8.78	12.27	9.24	12.94	9.07
21					10.08	8.17	10.56	8.76	11.15	8.80	11.49	8.74	12.15	9.21	12.82	9.03
23					9.90	8.10	10.45	8.72	11.04	8.76	11.37	8.69	12.03	9.17	12.70	9.00
25			9.79	8.53	9.81	8.06	10.40	8.70	10.98	8.74	11.31	8.67	11.97	9.15	12.63	8.98
27			9.62	8.45	9.72	8.02	10.35	8.68	10.92	8.71	11.39	8.70	11.86	9.11		
29			9.42	8.36	9.49	7.93	10.11	8.59	10.69	8.63	11.16	8.62	11.63	9.03		
31			9.21	8.26	9.26	7.83	9.87	8.50	10.46	8.54	10.93	8.54	11.39	8.96		
33	7.82	7.29	8.42	7.91	9.03	7.74	9.64	8.41	10.23	8.46	10.70	8.45	11.16	8.88		
35	7.68	7.23	8.24	7.83	8.80	7.64	9.40	8.32	10.00	8.38	10.46	8.37	10.93	8.81		
37	7.59	7.18	8.11	7.77	8.63	7.57	9.18	8.23	9.72	8.27	10.15	8.26	10.57	8.69		
39	7.50	7.14	7.98	7.72	8.46	7.50	8.95	8.15	9.44	8.17	9.83	8.15	10.22	8.58		
41	7.40	7.10	7.85	7.66	8.29	7.44	8.72	8.06	9.16	8.07	9.51	8.04	9.86	8.47		
43	7.31	7.05	7.72	7.56	8.12	7.37	8.50	7.98	8.88	7.97	9.19	7.93	9.50	8.36		
46	7.17	6.99	7.52	7.37	7.87	7.27	8.16	7.86	8.46	7.82	8.71	7.77	8.97	8.19		
50	5.60	5.49	5.73	5.62	5.90	5.78	6.05	5.93	6.17	6.05	6.28	6.15	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature ℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PFA004Z110 A

Model FDE100VSAWVH Indoor unit FDE100VH Outdoor unit FDC100VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.94	11.60	8.97	11.92	8.89	12.55	9.34	13.18	9.14
-10							10.67	8.80	11.23	8.83	11.53	8.75	12.13	9.20	12.73	9.01
-5							10.31	8.66	10.85	8.69	11.35	8.69	12.35	9.27	13.36	9.20
0					8.55	7.54	10.33	8.67	11.22	8.83	11.56	8.76	12.25	9.24	12.93	9.07
5					9.01	7.73	10.41	8.70	11.11	8.79	11.44	8.72	12.09	9.18	12.74	9.01
11					9.41	7.89	10.44	8.71	10.96	8.73	11.36	8.69	12.15	9.20	12.94	9.07
13					9.80	8.05	10.47	8.73	10.81	8.67	11.27	8.66	12.20	9.22	13.13	9.13
15					10.19	8.22	10.50	8.74	10.66	8.62	11.19	8.63	12.26	9.24	13.32	9.19
17					9.83	8.07	10.59	8.77	10.97	8.73	11.40	8.70	12.26	9.24	13.13	9.13
19					10.26	8.25	10.67	8.80	11.27	8.85	11.61	8.78	12.27	9.24	12.94	9.07
21					10.08	8.17	10.56	8.76	11.15	8.80	11.49	8.74	12.15	9.21	12.82	9.03
23					9.90	8.10	10.45	8.72	11.04	8.76	11.37	8.69	12.03	9.17	12.70	9.00
25			9.79	8.53	9.81	8.06	10.40	8.70	10.98	8.74	11.31	8.67	11.97	9.15	12.63	8.98
27			9.62	8.45	9.72	8.02	10.35	8.68	10.92	8.71	11.39	8.70	11.86	9.11		
29			9.42	8.36	9.49	7.93	10.11	8.59	10.69	8.63	11.16	8.62	11.63	9.03		
31			9.21	8.26	9.26	7.83	9.87	8.50	10.46	8.54	10.93	8.54	11.39	8.96		
33	7.82	7.29	8.42	7.91	9.03	7.74	9.64	8.41	10.23	8.46	10.70	8.45	11.16	8.88		
35	7.68	7.23	8.24	7.83	8.80	7.64	9.40	8.32	10.00	8.38	10.46	8.37	10.93	8.81		
37	7.59	7.18	8.11	7.77	8.63	7.57	9.18	8.23	9.72	8.27	10.15	8.26	10.57	8.69		
39	7.50	7.14	7.98	7.72	8.46	7.50	8.95	8.15	9.44	8.17	9.83	8.15	10.22	8.58		
41	7.40	7.10	7.85	7.66	8.29	7.44	8.72	8.06	9.16	8.07	9.51	8.04	9.86	8.47		
43	7.31	7.05	7.72	7.56	8.12	7.37	8.50	7.98	8.88	7.97	9.19	7.93	9.50	8.36		
46	7.17	6.99	7.52	7.37	7.87	7.27	8.16	7.86	8.46	7.82	8.71	7.77	8.97	8.19		
50	5.60	5.49	5.73	5.62	5.90	5.78	6.05	5.93	6.17	6.05	6.28	6.15	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature ℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PFA004Z110 A

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃CDB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

Model FDE125VNAWVH Indoor unit FDE125VH Outdoor unit FDC125VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	10.58	15.78	10.65	16.21	10.54	17.06	10.93	17.92	10.67
-10							14.51	10.38	15.27	10.44	15.68	10.33	16.50	10.72	17.32	10.46
-5							14.03	10.17	14.75	10.22	15.43	10.23	16.80	10.83	18.16	10.75
0					11.63	8.84	14.05	10.18	15.26	10.43	15.73	10.35	16.65	10.78	17.58	10.55
5					12.26	9.12	14.16	10.23	15.11	10.37	15.56	10.28	16.44	10.70	17.33	10.47
11					12.79	9.36	14.20	10.24	14.91	10.28	15.44	10.24	16.52	10.73	17.59	10.56
13					13.33	9.60	14.24	10.26	14.70	10.20	15.33	10.19	16.59	10.76	17.86	10.65
15					13.86	9.85	14.29	10.28	14.50	10.11	15.22	10.15	16.67	10.79	18.12	10.74
17					13.37	9.62	14.40	10.33	14.91	10.29	15.50	10.26	16.68	10.79	17.86	10.65
19					13.95	9.89	14.51	10.38	15.33	10.46	15.78	10.37	16.69	10.79	17.59	10.56
21					13.71	9.78	14.36	10.31	15.17	10.39	15.62	10.31	16.53	10.73	17.43	10.50
23					13.47	9.66	14.22	10.25	15.01	10.33	15.46	10.24	16.36	10.67	17.27	10.45
25			13.32	10.22	13.34	9.61	14.15	10.22	14.93	10.29	15.38	10.21	16.28	10.64	17.18	10.42
27			13.09	10.10	13.22	9.55	14.07	10.19	14.85	10.26	15.49	10.26	16.13	10.59		
29			12.81	9.96	12.91	9.41	13.75	10.05	14.54	10.13	15.18	10.13	15.81	10.47		
31			12.53	9.82	12.60	9.27	13.43	9.92	14.23	10.00	14.86	10.01	15.50	10.36		
33	10.63	8.67	11.45	9.30	12.28	9.13	13.11	9.78	13.91	9.88	14.55	9.88	15.18	10.24		
35	10.45	8.58	11.21	9.19	11.97	8.99	12.79	9.65	13.60	9.75	14.23	9.76	14.86	10.13		
37	10.32	8.51	11.03	9.10	11.74	8.89	12.48	9.52	13.22	9.60	13.80	9.59	14.38	9.96		
39	10.20	8.45	10.85	9.02	11.51	8.78	12.17	9.40	12.84	9.45	13.36	9.43	13.89	9.79		
41	10.07	8.38	10.67	8.93	11.28	8.68	11.87	9.28	12.45	9.30	12.93	9.27	13.41	9.63		
43	9.94	8.32	10.49	8.85	11.04	8.58	11.56	9.15	12.07	9.15	12.50	9.11	12.92	9.46		
46	9.75	8.23	10.22	8.72	10.70	8.43	11.10	8.97	11.50	8.93	11.85	8.87	12.20	9.22		
50	7.61	7.19	7.79	7.64	8.02	7.33	8.23	7.88	8.40	7.80	8.54	7.71	8.68	8.11		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PFA004Z110 Ⓐ

Model FDE125VSAWVH Indoor unit FDE125VH Outdoor unit FDC125VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	10.58	15.78	10.65	16.21	10.54	17.06	10.93	17.92	10.67
-10							14.51	10.38	15.27	10.44	15.68	10.33	16.50	10.72	17.32	10.46
-5							14.03	10.17	14.75	10.22	15.43	10.23	16.80	10.83	18.16	10.75
0					11.63	8.84	14.05	10.18	15.26	10.43	15.73	10.35	16.65	10.78	17.58	10.55
5					12.26	9.12	14.16	10.23	15.11	10.37	15.56	10.28	16.44	10.70	17.33	10.47
11					12.79	9.36	14.20	10.24	14.91	10.28	15.44	10.24	16.52	10.73	17.59	10.56
13					13.33	9.60	14.24	10.26	14.70	10.20	15.33	10.19	16.59	10.76	17.86	10.65
15					13.86	9.85	14.29	10.28	14.50	10.11	15.22	10.15	16.67	10.79	18.12	10.74
17					13.37	9.62	14.40	10.33	14.91	10.29	15.50	10.26	16.68	10.79	17.86	10.65
19					13.95	9.89	14.51	10.38	15.33	10.46	15.78	10.37	16.69	10.79	17.59	10.56
21					13.71	9.78	14.36	10.31	15.17	10.39	15.62	10.31	16.53	10.73	17.43	10.50
23					13.47	9.66	14.22	10.25	15.01	10.33	15.46	10.24	16.36	10.67	17.27	10.45
25			13.32	10.22	13.34	9.61	14.15	10.22	14.93	10.29	15.38	10.21	16.28	10.64	17.18	10.42
27			13.09	10.10	13.22	9.55	14.07	10.19	14.85	10.26	15.49	10.26	16.13	10.59		
29			12.81	9.96	12.91	9.41	13.75	10.05	14.54	10.13	15.18	10.13	15.81	10.47		
31			12.53	9.82	12.60	9.27	13.43	9.92	14.23	10.00	14.86	10.01	15.50	10.36		
33	10.63	8.67	11.45	9.30	12.28	9.13	13.11	9.78	13.91	9.88	14.55	9.88	15.18	10.24		
35	10.45	8.58	11.21	9.19	11.97	8.99	12.79	9.65	13.60	9.75	14.23	9.76	14.86	10.13		
37	10.32	8.51	11.03	9.10	11.74	8.89	12.48	9.52	13.22	9.60	13.80	9.59	14.38	9.96		
39	10.20	8.45	10.85	9.02	11.51	8.78	12.17	9.40	12.84	9.45	13.36	9.43	13.89	9.79		
41	10.07	8.38	10.67	8.93	11.28	8.68	11.87	9.28	12.45	9.30	12.93	9.27	13.41	9.63		
43	9.94	8.32	10.49	8.85	11.04	8.58	11.56	9.15	12.07	9.15	12.50	9.11	12.92	9.46		
46	9.75	8.23	10.22	8.72	10.70	8.43	11.10	8.97	11.50	8.93	11.85	8.87	12.20	9.22		
50	7.61	7.19	7.79	7.64	8.02	7.33	8.23	7.88	8.40	7.80	8.54	7.71	8.68	8.11		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PFA004Z110 Ⓐ

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

Model FDE140VNAWVH Indoor unit FDE140VH Outdoor unit FDC140VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	10.84	15.78	10.90	16.21	10.80	17.06	11.22	17.92	10.96
-10							14.51	10.64	15.27	10.69	15.68	10.59	16.50	11.02	17.32	10.76
-5							14.03	10.44	14.75	10.48	15.43	10.49	16.80	11.13	18.16	11.04
0					11.63	9.08	14.05	10.45	15.26	10.69	15.73	10.61	16.65	11.07	17.58	10.85
5					12.26	9.35	14.16	10.49	15.11	10.63	15.56	10.54	16.44	11.00	17.33	10.76
11					12.79	9.58	14.20	10.51	14.91	10.54	15.44	10.50	16.52	11.02	17.59	10.85
13					13.33	9.82	14.24	10.53	14.70	10.46	15.33	10.45	16.59	11.05	17.86	10.94
15					13.86	10.06	14.29	10.54	14.50	10.38	15.22	10.41	16.67	11.08	18.12	11.03
17					13.37	9.84	14.40	10.59	14.91	10.55	15.50	10.52	16.68	11.08	17.86	10.94
19					13.95	10.10	14.51	10.64	15.33	10.72	15.78	10.63	16.69	11.09	17.59	10.85
21					13.71	9.99	14.36	10.58	15.17	10.65	15.62	10.57	16.53	11.03	17.43	10.80
23					13.47	9.88	14.22	10.52	15.01	10.59	15.46	10.50	16.36	10.97	17.27	10.74
25			13.32	10.44	13.34	9.83	14.15	10.49	14.93	10.55	15.38	10.47	16.28	10.94	17.18	10.72
27			13.09	10.33	13.22	9.78	14.07	10.45	14.85	10.52	15.49	10.51	16.13	10.89		
29			12.81	10.19	12.91	9.64	13.75	10.32	14.54	10.40	15.18	10.39	15.81	10.77		
31			12.53	10.06	12.60	9.50	13.43	10.19	14.23	10.27	14.86	10.27	15.50	10.66		
33	10.63	8.87	11.45	9.54	12.28	9.36	13.11	10.06	13.91	10.15	14.55	10.15	15.18	10.55		
35	10.45	8.78	11.21	9.43	11.97	9.22	12.79	9.93	13.60	10.02	14.23	10.03	14.86	10.44		
37	10.32	8.72	11.03	9.35	11.74	9.12	12.48	9.80	13.22	9.87	13.80	9.87	14.38	10.27		
39	10.20	8.66	10.85	9.26	11.51	9.02	12.17	9.68	12.84	9.73	13.36	9.71	13.89	10.11		
41	10.07	8.60	10.67	9.18	11.28	8.92	11.87	9.56	12.45	9.58	12.93	9.55	13.41	9.95		
43	9.94	8.53	10.49	9.10	11.04	8.82	11.56	9.44	12.07	9.44	12.50	9.39	12.92	9.78		
46	9.75	8.44	10.22	8.98	10.70	8.68	11.10	9.26	11.50	9.22	11.85	9.15	12.20	9.55		
50	7.61	7.42	7.79	7.64	8.02	7.59	8.23	8.07	8.40	8.11	8.54	8.02	8.68	8.45		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PFA004Z110 Ⓐ

Model FDE140VSAWVH Indoor unit FDE140VH Outdoor unit FDC140VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	10.84	15.78	10.90	16.21	10.80	17.06	11.22	17.92	10.96
-10							14.51	10.64	15.27	10.69	15.68	10.59	16.50	11.02	17.32	10.76
-5							14.03	10.44	14.75	10.48	15.43	10.49	16.80	11.13	18.16	11.04
0					11.63	9.08	14.05	10.45	15.26	10.69	15.73	10.61	16.65	11.07	17.58	10.85
5					12.26	9.35	14.16	10.49	15.11	10.63	15.56	10.54	16.44	11.00	17.33	10.76
11					12.79	9.58	14.20	10.51	14.91	10.54	15.44	10.50	16.52	11.02	17.59	10.85
13					13.33	9.82	14.24	10.53	14.70	10.46	15.33	10.45	16.59	11.05	17.86	10.94
15					13.86	10.06	14.29	10.54	14.50	10.38	15.22	10.41	16.67	11.08	18.12	11.03
17					13.37	9.84	14.40	10.59	14.91	10.55	15.50	10.52	16.68	11.08	17.86	10.94
19					13.95	10.10	14.51	10.64	15.33	10.72	15.78	10.63	16.69	11.09	17.59	10.85
21					13.71	9.99	14.36	10.58	15.17	10.65	15.62	10.57	16.53	11.03	17.43	10.80
23					13.47	9.88	14.22	10.52	15.01	10.59	15.46	10.50	16.36	10.97	17.27	10.74
25			13.32	10.44	13.34	9.83	14.15	10.49	14.93	10.55	15.38	10.47	16.28	10.94	17.18	10.72
27			13.09	10.33	13.22	9.78	14.07	10.45	14.85	10.52	15.49	10.51	16.13	10.89		
29			12.81	10.19	12.91	9.64	13.75	10.32	14.54	10.40	15.18	10.39	15.81	10.77		
31			12.53	10.06	12.60	9.50	13.43	10.19	14.23	10.27	14.86	10.27	15.50	10.66		
33	10.63	8.87	11.45	9.54	12.28	9.36	13.11	10.06	13.91	10.15	14.55	10.15	15.18	10.55		
35	10.45	8.78	11.21	9.43	11.97	9.22	12.79	9.93	13.60	10.02	14.23	10.03	14.86	10.44		
37	10.32	8.72	11.03	9.35	11.74	9.12	12.48	9.80	13.22	9.87	13.80	9.87	14.38	10.27		
39	10.20	8.66	10.85	9.26	11.51	9.02	12.17	9.68	12.84	9.73	13.36	9.71	13.89	10.11		
41	10.07	8.60	10.67	9.18	11.28	8.92	11.87	9.56	12.45	9.58	12.93	9.55	13.41	9.95		
43	9.94	8.53	10.49	9.10	11.04	8.82	11.56	9.44	12.07	9.44	12.50	9.39	12.92	9.78		
46	9.75	8.44	10.22	8.98	10.70	8.68	11.10	9.26	11.50	9.22	11.85	9.15	12.20	9.55		
50	7.61	7.42	7.79	7.64	8.02	7.59	8.23	8.07	8.40	8.11	8.54	8.02	8.68	8.45		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PFA004Z110 Ⓐ

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

(b) Twin type

Model FDE100VNAWPVH Indoor unit FDE50VH (2 units) Outdoor unit FDC100VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.10	11.60	8.14	11.92	8.07	12.55	8.40	13.18	8.21
-10							10.67	7.96	11.23	7.99	11.53	7.92	12.13	8.25	12.73	8.06
-5							10.31	7.81	10.85	7.84	11.35	7.85	12.35	8.33	13.36	8.27
0					8.55	6.79	10.33	7.82	11.22	7.99	11.56	7.93	12.25	8.29	12.93	8.13
5					9.01	6.99	10.41	7.85	11.11	7.95	11.44	7.88	12.09	8.24	12.74	8.07
11					9.41	7.16	10.44	7.86	10.96	7.89	11.36	7.85	12.15	8.26	12.94	8.13
13					9.80	7.34	10.47	7.88	10.81	7.83	11.27	7.82	12.20	8.28	13.13	8.19
15					10.19	7.51	10.50	7.89	10.66	7.77	11.19	7.79	12.26	8.30	13.32	8.25
17					9.83	7.35	10.59	7.92	10.97	7.89	11.40	7.87	12.26	8.30	13.13	8.19
19					10.26	7.54	10.67	7.96	11.27	8.01	11.61	7.95	12.27	8.30	12.94	8.13
21					10.08	7.46	10.56	7.91	11.15	7.96	11.49	7.90	12.15	8.26	12.82	8.09
23					9.90	7.38	10.45	7.87	11.04	7.92	11.37	7.86	12.03	8.22	12.70	8.05
25			9.79	7.79	9.81	7.34	10.40	7.85	10.98	7.89	11.31	7.83	11.97	8.20	12.63	8.03
27			9.62	7.71	9.72	7.30	10.35	7.82	10.92	7.87	11.39	7.86	11.86	8.16		
29			9.42	7.61	9.49	7.20	10.11	7.73	10.69	7.78	11.16	7.78	11.63	8.07		
31			9.21	7.51	9.26	7.10	9.87	7.63	10.46	7.69	10.93	7.69	11.39	7.99		
33	7.82	6.63	8.42	7.14	9.03	7.00	9.64	7.53	10.23	7.60	10.70	7.60	11.16	7.91		
35	7.68	6.56	8.24	7.06	8.80	6.90	9.40	7.44	10.00	7.51	10.46	7.51	10.93	7.83		
37	7.59	6.52	8.11	7.00	8.63	6.83	9.18	7.35	9.72	7.40	10.15	7.39	10.57	7.71		
39	7.50	6.47	7.98	6.94	8.46	6.75	8.95	7.26	9.44	7.29	9.83	7.28	10.22	7.59		
41	7.40	6.43	7.85	6.88	8.29	6.68	8.72	7.17	9.16	7.19	9.51	7.16	9.86	7.47		
43	7.31	6.38	7.72	6.82	8.12	6.61	8.50	7.09	8.88	7.08	9.19	7.05	9.50	7.36		
46	7.17	6.31	7.52	6.73	7.87	6.50	8.16	6.96	8.46	6.93	8.71	6.88	8.97	7.18		
50	5.60	5.49	5.73	5.62	5.90	5.71	6.05	5.93	6.17	6.05	6.28	6.05	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PFA004Z110 Ⓐ

Model FDE100VSAWPVH Indoor unit FDE50VH (2 units) Outdoor unit FDC100VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.10	11.60	8.14	11.92	8.07	12.55	8.40	13.18	8.21
-10							10.67	7.96	11.23	7.99	11.53	7.92	12.13	8.25	12.73	8.06
-5							10.31	7.81	10.85	7.84	11.35	7.85	12.35	8.33	13.36	8.27
0					8.55	6.79	10.33	7.82	11.22	7.99	11.56	7.93	12.25	8.29	12.93	8.13
5					9.01	6.99	10.41	7.85	11.11	7.95	11.44	7.88	12.09	8.24	12.74	8.07
11					9.41	7.16	10.44	7.86	10.96	7.89	11.36	7.85	12.15	8.26	12.94	8.13
13					9.80	7.34	10.47	7.88	10.81	7.83	11.27	7.82	12.20	8.28	13.13	8.19
15					10.19	7.51	10.50	7.89	10.66	7.77	11.19	7.79	12.26	8.30	13.32	8.25
17					9.83	7.35	10.59	7.92	10.97	7.89	11.40	7.87	12.26	8.30	13.13	8.19
19					10.26	7.54	10.67	7.96	11.27	8.01	11.61	7.95	12.27	8.30	12.94	8.13
21					10.08	7.46	10.56	7.91	11.15	7.96	11.49	7.90	12.15	8.26	12.82	8.09
23					9.90	7.38	10.45	7.87	11.04	7.92	11.37	7.86	12.03	8.22	12.70	8.05
25			9.79	7.79	9.81	7.34	10.40	7.85	10.98	7.89	11.31	7.83	11.97	8.20	12.63	8.03
27			9.62	7.71	9.72	7.30	10.35	7.82	10.92	7.87	11.39	7.86	11.86	8.16		
29			9.42	7.61	9.49	7.20	10.11	7.73	10.69	7.78	11.16	7.78	11.63	8.07		
31			9.21	7.51	9.26	7.10	9.87	7.63	10.46	7.69	10.93	7.69	11.39	7.99		
33	7.82	6.63	8.42	7.14	9.03	7.00	9.64	7.53	10.23	7.60	10.70	7.60	11.16	7.91		
35	7.68	6.56	8.24	7.06	8.80	6.90	9.40	7.44	10.00	7.51	10.46	7.51	10.93	7.83		
37	7.59	6.52	8.11	7.00	8.63	6.83	9.18	7.35	9.72	7.40	10.15	7.39	10.57	7.71		
39	7.50	6.47	7.98	6.94	8.46	6.75	8.95	7.26	9.44	7.29	9.83	7.28	10.22	7.59		
41	7.40	6.43	7.85	6.88	8.29	6.68	8.72	7.17	9.16	7.19	9.51	7.16	9.86	7.47		
43	7.31	6.38	7.72	6.82	8.12	6.61	8.50	7.09	8.88	7.08	9.19	7.05	9.50	7.36		
46	7.17	6.31	7.52	6.73	7.87	6.50	8.16	6.96	8.46	6.93	8.71	6.88	8.97	7.18		
50	5.60	5.49	5.73	5.62	5.90	5.71	6.05	5.93	6.17	6.05	6.28	6.05	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PFA004Z110 Ⓐ

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

Model FDE125VNAWPVH Indoor unit FDE60VH (2 units) Outdoor unit FDC125VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.66	15.78	11.70	16.21	11.60	17.06	12.14	17.92	11.87
-10							14.51	11.47	15.27	11.51	15.68	11.40	16.50	11.94	17.32	11.69
-5							14.03	11.27	14.75	11.31	15.43	11.31	16.80	12.05	18.16	11.95
0					11.63	9.81	14.05	11.28	15.26	11.51	15.73	11.42	16.65	12.00	17.58	11.77
5					12.26	10.07	14.16	11.33	15.11	11.45	15.56	11.36	16.44	11.93	17.33	11.69
11					12.79	10.30	14.20	11.34	14.91	11.37	15.44	11.32	16.52	11.95	17.59	11.77
13					13.33	10.52	14.24	11.36	14.70	11.29	15.33	11.27	16.59	11.98	17.86	11.85
15					13.86	10.75	14.29	11.38	14.50	11.21	15.22	11.23	16.67	12.00	18.12	11.94
17					13.37	10.54	14.40	11.42	14.91	11.37	15.50	11.34	16.68	12.01	17.86	11.85
19					13.95	10.79	14.51	11.47	15.33	11.53	15.78	11.44	16.69	12.01	17.59	11.77
21					13.71	10.69	14.36	11.41	15.17	11.47	15.62	11.38	16.53	11.95	17.43	11.72
23					13.47	10.58	14.22	11.35	15.01	11.41	15.46	11.32	16.36	11.90	17.27	11.67
25			13.32	11.15	13.34	10.53	14.15	11.32	14.93	11.38	15.38	11.29	16.28	11.87	17.18	11.65
27			13.09	11.05	13.22	10.48	14.07	11.29	14.85	11.35	15.49	11.33	16.13	11.82		
29			12.81	10.92	12.91	10.35	13.75	11.16	14.54	11.23	15.18	11.22	15.81	11.71		
31			12.53	10.79	12.60	10.21	13.43	11.04	14.23	11.11	14.86	11.10	15.50	11.61		
33	10.63	9.52	11.45	10.30	12.28	10.08	13.11	10.91	13.91	10.99	14.55	10.99	15.18	11.50		
35	10.45	9.43	11.21	10.19	11.97	9.95	12.79	10.79	13.60	10.87	14.23	10.87	14.86	11.40		
37	10.32	9.37	11.03	10.11	11.74	9.86	12.48	10.67	13.22	10.73	13.80	10.72	14.38	11.24		
39	10.20	9.31	10.85	10.03	11.51	9.76	12.17	10.55	12.84	10.59	13.36	10.57	13.89	11.08		
41	10.07	9.25	10.67	9.95	11.28	9.66	11.87	10.44	12.45	10.45	12.93	10.41	13.41	10.93		
43	9.94	9.19	10.49	9.87	11.04	9.57	11.56	10.32	12.07	10.31	12.50	10.26	12.92	10.77		
46	9.75	9.10	10.22	9.76	10.70	9.43	11.10	10.15	11.50	10.11	11.85	10.04	12.20	10.55		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PFA004Z110 Ⓐ

Model FDE125VSAWPVH Indoor unit FDE60VH (2 units) Outdoor unit FDC125VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.66	15.78	11.70	16.21	11.60	17.06	12.14	17.92	11.87
-10							14.51	11.47	15.27	11.51	15.68	11.40	16.50	11.94	17.32	11.69
-5							14.03	11.27	14.75	11.31	15.43	11.31	16.80	12.05	18.16	11.95
0					11.63	9.81	14.05	11.28	15.26	11.51	15.73	11.42	16.65	12.00	17.58	11.77
5					12.26	10.07	14.16	11.33	15.11	11.45	15.56	11.36	16.44	11.93	17.33	11.69
11					12.79	10.30	14.20	11.34	14.91	11.37	15.44	11.32	16.52	11.95	17.59	11.77
13					13.33	10.52	14.24	11.36	14.70	11.29	15.33	11.27	16.59	11.98	17.86	11.85
15					13.86	10.75	14.29	11.38	14.50	11.21	15.22	11.23	16.67	12.00	18.12	11.94
17					13.37	10.54	14.40	11.42	14.91	11.37	15.50	11.34	16.68	12.01	17.86	11.85
19					13.95	10.79	14.51	11.47	15.33	11.53	15.78	11.44	16.69	12.01	17.59	11.77
21					13.71	10.69	14.36	11.41	15.17	11.47	15.62	11.38	16.53	11.95	17.43	11.72
23					13.47	10.58	14.22	11.35	15.01	11.41	15.46	11.32	16.36	11.90	17.27	11.67
25			13.32	11.15	13.34	10.53	14.15	11.32	14.93	11.38	15.38	11.29	16.28	11.87	17.18	11.65
27			13.09	11.05	13.22	10.48	14.07	11.29	14.85	11.35	15.49	11.33	16.13	11.82		
29			12.81	10.92	12.91	10.35	13.75	11.16	14.54	11.23	15.18	11.22	15.81	11.71		
31			12.53	10.79	12.60	10.21	13.43	11.04	14.23	11.11	14.86	11.10	15.50	11.61		
33	10.63	9.52	11.45	10.30	12.28	10.08	13.11	10.91	13.91	10.99	14.55	10.99	15.18	11.50		
35	10.45	9.43	11.21	10.19	11.97	9.95	12.79	10.79	13.60	10.87	14.23	10.87	14.86	11.40		
37	10.32	9.37	11.03	10.11	11.74	9.86	12.48	10.67	13.22	10.73	13.80	10.72	14.38	11.24		
39	10.20	9.31	10.85	10.03	11.51	9.76	12.17	10.55	12.84	10.59	13.36	10.57	13.89	11.08		
41	10.07	9.25	10.67	9.95	11.28	9.66	11.87	10.44	12.45	10.45	12.93	10.41	13.41	10.93		
43	9.94	9.19	10.49	9.87	11.04	9.57	11.56	10.32	12.07	10.31	12.50	10.26	12.92	10.77		
46	9.75	9.10	10.22	9.76	10.70	9.43	11.10	10.15	11.50	10.11	11.85	10.04	12.20	10.55		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PFA004Z110 Ⓐ

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

Model FDE140VNAWPVH Indoor unit FDE71VH (2 units) Outdoor unit FDC140VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.66	15.78	11.70	16.21	11.60	17.06	12.14	17.92	11.87
-10							14.51	11.47	15.27	11.51	15.68	11.40	16.50	11.94	17.32	11.69
-5							14.03	11.27	14.75	11.31	15.43	11.31	16.80	12.05	18.16	11.95
0					11.63	9.81	14.05	11.28	15.26	11.51	15.73	11.42	16.65	12.00	17.58	11.77
5					12.26	10.07	14.16	11.33	15.11	11.45	15.56	11.36	16.44	11.93	17.33	11.69
11					12.79	10.30	14.20	11.34	14.91	11.37	15.44	11.32	16.52	11.95	17.59	11.77
13					13.33	10.52	14.24	11.36	14.70	11.29	15.33	11.27	16.59	11.98	17.86	11.85
15					13.86	10.75	14.29	11.38	14.50	11.21	15.22	11.23	16.67	12.00	18.12	11.94
17					13.37	10.54	14.40	11.42	14.91	11.37	15.50	11.34	16.68	12.01	17.86	11.85
19					13.95	10.79	14.51	11.47	15.33	11.53	15.78	11.44	16.69	12.01	17.59	11.77
21					13.71	10.69	14.36	11.41	15.17	11.47	15.62	11.38	16.53	11.95	17.43	11.72
23					13.47	10.58	14.22	11.35	15.01	11.41	15.46	11.32	16.36	11.90	17.27	11.67
25			13.32	11.15	13.34	10.53	14.15	11.32	14.93	11.38	15.38	11.29	16.28	11.87	17.18	11.65
27			13.09	11.05	13.22	10.48	14.07	11.29	14.85	11.35	15.49	11.33	16.13	11.82		
29			12.81	10.92	12.91	10.35	13.75	11.16	14.54	11.23	15.18	11.22	15.81	11.71		
31			12.53	10.79	12.60	10.21	13.43	11.04	14.23	11.11	14.86	11.10	15.50	11.61		
33	10.63	9.52	11.45	10.30	12.28	10.08	13.11	10.91	13.91	10.99	14.55	10.99	15.18	11.50		
35	10.45	9.43	11.21	10.19	11.97	9.95	12.79	10.79	13.60	10.87	14.23	10.87	14.86	11.40		
37	10.32	9.37	11.03	10.11	11.74	9.86	12.48	10.67	13.22	10.73	13.80	10.72	14.38	11.24		
39	10.20	9.31	10.85	10.03	11.51	9.76	12.17	10.55	12.84	10.59	13.36	10.57	13.89	11.08		
41	10.07	9.25	10.67	9.95	11.28	9.66	11.87	10.44	12.45	10.45	12.93	10.41	13.41	10.93		
43	9.94	9.19	10.49	9.87	11.04	9.57	11.56	10.32	12.07	10.31	12.50	10.26	12.92	10.77		
46	9.75	9.10	10.22	9.76	10.70	9.43	11.10	10.15	11.50	10.11	11.85	10.04	12.20	10.55		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PFA004Z110 Ⓐ

Model FDE140VSAWPVH Indoor unit FDE71VH (2 units) Outdoor unit FDC140VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.66	15.78	11.70	16.21	11.60	17.06	12.14	17.92	11.87
-10							14.51	11.47	15.27	11.51	15.68	11.40	16.50	11.94	17.32	11.69
-5							14.03	11.27	14.75	11.31	15.43	11.31	16.80	12.05	18.16	11.95
0					11.63	9.81	14.05	11.28	15.26	11.51	15.73	11.42	16.65	12.00	17.58	11.77
5					12.26	10.07	14.16	11.33	15.11	11.45	15.56	11.36	16.44	11.93	17.33	11.69
11					12.79	10.30	14.20	11.34	14.91	11.37	15.44	11.32	16.52	11.95	17.59	11.77
13					13.33	10.52	14.24	11.36	14.70	11.29	15.33	11.27	16.59	11.98	17.86	11.85
15					13.86	10.75	14.29	11.38	14.50	11.21	15.22	11.23	16.67	12.00	18.12	11.94
17					13.37	10.54	14.40	11.42	14.91	11.37	15.50	11.34	16.68	12.01	17.86	11.85
19					13.95	10.79	14.51	11.47	15.33	11.53	15.78	11.44	16.69	12.01	17.59	11.77
21					13.71	10.69	14.36	11.41	15.17	11.47	15.62	11.38	16.53	11.95	17.43	11.72
23					13.47	10.58	14.22	11.35	15.01	11.41	15.46	11.32	16.36	11.90	17.27	11.67
25			13.32	11.15	13.34	10.53	14.15	11.32	14.93	11.38	15.38	11.29	16.28	11.87	17.18	11.65
27			13.09	11.05	13.22	10.48	14.07	11.29	14.85	11.35	15.49	11.33	16.13	11.82		
29			12.81	10.92	12.91	10.35	13.75	11.16	14.54	11.23	15.18	11.22	15.81	11.71		
31			12.53	10.79	12.60	10.21	13.43	11.04	14.23	11.11	14.86	11.10	15.50	11.61		
33	10.63	9.52	11.45	10.30	12.28	10.08	13.11	10.91	13.91	10.99	14.55	10.99	15.18	11.50		
35	10.45	9.43	11.21	10.19	11.97	9.95	12.79	10.79	13.60	10.87	14.23	10.87	14.86	11.40		
37	10.32	9.37	11.03	10.11	11.74	9.86	12.48	10.67	13.22	10.73	13.80	10.72	14.38	11.24		
39	10.20	9.31	10.85	10.03	11.51	9.76	12.17	10.55	12.84	10.59	13.36	10.57	13.89	11.08		
41	10.07	9.25	10.67	9.95	11.28	9.66	11.87	10.44	12.45	10.45	12.93	10.41	13.41	10.93		
43	9.94	9.19	10.49	9.87	11.04	9.57	11.56	10.32	12.07	10.31	12.50	10.26	12.92	10.77		
46	9.75	9.10	10.22	9.76	10.70	9.43	11.10	10.15	11.50	10.11	11.85	10.04	12.20	10.55		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PFA004Z110 Ⓐ

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

(c) Triple type

Model FDE140VNAWTVH Indoor unit FDE50VH (3 units) Outdoor unit FDC140VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.52	15.78	11.57	16.21	11.46	17.06	11.98	17.92	11.72
-10							14.51	11.32	15.27	11.37	15.68	11.26	16.50	11.79	17.32	11.53
-5							14.03	11.13	14.75	11.17	15.43	11.17	16.80	11.89	18.16	11.79
0					11.63	9.69	14.05	11.14	15.26	11.37	15.73	11.28	16.65	11.84	17.58	11.61
5					12.26	9.95	14.16	11.18	15.11	11.31	15.56	11.22	16.44	11.77	17.33	11.53
11					12.79	10.18	14.20	11.20	14.91	11.23	15.44	11.18	16.52	11.79	17.59	11.61
13					13.33	10.40	14.24	11.22	14.70	11.15	15.33	11.13	16.59	11.82	17.86	11.70
15					13.86	10.64	14.29	11.23	14.50	11.07	15.22	11.09	16.67	11.85	18.12	11.78
17					13.37	10.42	14.40	11.28	14.91	11.23	15.50	11.20	16.68	11.85	17.86	11.70
19					13.95	10.67	14.51	11.32	15.33	11.39	15.78	11.30	16.69	11.85	17.59	11.62
21					13.71	10.57	14.36	11.27	15.17	11.33	15.62	11.24	16.53	11.80	17.43	11.56
23					13.47	10.46	14.22	11.21	15.01	11.27	15.46	11.18	16.36	11.74	17.27	11.51
25			13.32	11.03	13.34	10.41	14.15	11.18	14.93	11.24	15.38	11.15	16.28	11.71	17.18	11.49
27			13.09	10.92	13.22	10.36	14.07	11.15	14.85	11.21	15.49	11.19	16.13	11.66		
29			12.81	10.79	12.91	10.23	13.75	11.02	14.54	11.09	15.18	11.08	15.81	11.55		
31			12.53	10.66	12.60	10.09	13.43	10.89	14.23	10.97	14.86	10.96	15.50	11.45		
33	10.63	9.41	11.45	10.17	12.28	9.96	13.11	10.77	13.91	10.85	14.55	10.85	15.18	11.34		
35	10.45	9.32	11.21	10.06	11.97	9.83	12.79	10.64	13.60	10.73	14.23	10.73	14.86	11.24		
37	10.32	9.26	11.03	9.98	11.74	9.73	12.48	10.52	13.22	10.59	13.80	10.57	14.38	11.08		
39	10.20	9.20	10.85	9.90	11.51	9.63	12.17	10.41	12.84	10.45	13.36	10.42	13.89	10.92		
41	10.07	9.14	10.67	9.82	11.28	9.54	11.87	10.29	12.45	10.30	12.93	10.27	13.41	10.76		
43	9.94	9.08	10.49	9.74	11.04	9.44	11.56	10.17	12.07	10.17	12.50	10.11	12.92	10.61		
46	9.75	8.99	10.22	9.62	10.70	9.30	11.10	10.00	11.50	9.96	11.85	9.89	12.20	10.38		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PFA004Z110 Ⓐ

Model FDE140VSAWTVH Indoor unit FDE50VH (3 units) Outdoor unit FDC140VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.52	15.78	11.57	16.21	11.46	17.06	11.98	17.92	11.72
-10							14.51	11.32	15.27	11.37	15.68	11.26	16.50	11.79	17.32	11.53
-5							14.03	11.13	14.75	11.17	15.43	11.17	16.80	11.89	18.16	11.79
0					11.63	9.69	14.05	11.14	15.26	11.37	15.73	11.28	16.65	11.84	17.58	11.61
5					12.26	9.95	14.16	11.18	15.11	11.31	15.56	11.22	16.44	11.77	17.33	11.53
11					12.79	10.18	14.20	11.20	14.91	11.23	15.44	11.18	16.52	11.79	17.59	11.61
13					13.33	10.40	14.24	11.22	14.70	11.15	15.33	11.13	16.59	11.82	17.86	11.70
15					13.86	10.64	14.29	11.23	14.50	11.07	15.22	11.09	16.67	11.85	18.12	11.78
17					13.37	10.42	14.40	11.28	14.91	11.23	15.50	11.20	16.68	11.85	17.86	11.70
19					13.95	10.67	14.51	11.32	15.33	11.39	15.78	11.30	16.69	11.85	17.59	11.62
21					13.71	10.57	14.36	11.27	15.17	11.33	15.62	11.24	16.53	11.80	17.43	11.56
23					13.47	10.46	14.22	11.21	15.01	11.27	15.46	11.18	16.36	11.74	17.27	11.51
25			13.32	11.03	13.34	10.41	14.15	11.18	14.93	11.24	15.38	11.15	16.28	11.71	17.18	11.49
27			13.09	10.92	13.22	10.36	14.07	11.15	14.85	11.21	15.49	11.19	16.13	11.66		
29			12.81	10.79	12.91	10.23	13.75	11.02	14.54	11.09	15.18	11.08	15.81	11.55		
31			12.53	10.66	12.60	10.09	13.43	10.89	14.23	10.97	14.86	10.96	15.50	11.45		
33	10.63	9.41	11.45	10.17	12.28	9.96	13.11	10.77	13.91	10.85	14.55	10.85	15.18	11.34		
35	10.45	9.32	11.21	10.06	11.97	9.83	12.79	10.64	13.60	10.73	14.23	10.73	14.86	11.24		
37	10.32	9.26	11.03	9.98	11.74	9.73	12.48	10.52	13.22	10.59	13.80	10.57	14.38	11.08		
39	10.20	9.20	10.85	9.90	11.51	9.63	12.17	10.41	12.84	10.45	13.36	10.42	13.89	10.92		
41	10.07	9.14	10.67	9.82	11.28	9.54	11.87	10.29	12.45	10.30	12.93	10.27	13.41	10.76		
43	9.94	9.08	10.49	9.74	11.04	9.44	11.56	10.17	12.07	10.17	12.50	10.11	12.92	10.61		
46	9.75	8.99	10.22	9.62	10.70	9.30	11.10	10.00	11.50	9.96	11.85	9.89	12.20	10.38		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PFA004Z110 Ⓐ

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

(6) Wall mounted type (SRK)

(a) Single type

Model SRK100VNAWZR Indoor unit SRK100ZR-W Outdoor unit FDC100VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.14	11.60	8.06	11.92	7.90	12.55	8.26	13.18	7.90
-10							10.67	8.04	11.23	7.97	11.53	7.81	12.13	8.18	12.73	7.82
-5							10.31	7.95	10.85	7.87	11.35	7.77	12.35	8.22	13.36	7.93
0					8.55	7.00	10.33	7.95	11.22	7.96	11.56	7.82	12.25	8.20	12.93	7.85
5					9.01	7.14	10.41	7.97	11.11	7.93	11.44	7.79	12.09	8.17	12.74	7.82
11					9.41	7.26	10.44	7.98	10.96	7.90	11.36	7.77	12.15	8.18	12.94	7.86
13					9.80	7.38	10.47	7.99	10.81	7.86	11.27	7.75	12.20	8.19	13.13	7.89
15					10.19	7.50	10.50	8.00	10.66	7.82	11.19	7.73	12.26	8.20	13.32	7.92
17					9.83	7.38	10.59	8.02	10.97	7.90	11.40	7.78	12.26	8.20	13.13	7.89
19					10.26	7.52	10.67	8.04	11.27	7.98	11.61	7.83	12.27	8.20	12.94	7.86
21					10.08	7.46	10.56	8.01	11.15	7.95	11.49	7.80	12.15	8.18	12.82	7.84
23					9.90	7.41	10.45	7.98	11.04	7.92	11.37	7.77	12.03	8.16	12.70	7.82
25			9.79	7.94	9.81	7.38	10.40	7.97	10.98	7.90	11.31	7.76	11.97	8.14	12.63	7.81
27			9.62	7.88	9.72	7.35	10.35	7.96	10.92	7.89	11.39	7.78	11.86	8.12		
29			9.42	7.81	9.49	7.28	10.11	7.89	10.69	7.83	11.16	7.72	11.63	8.08		
31			9.21	7.74	9.26	7.21	9.87	7.83	10.46	7.77	10.93	7.67	11.39	8.03		
33	7.82	6.89	8.42	7.47	9.03	7.14	9.64	7.77	10.23	7.71	10.70	7.61	11.16	7.99		
35	7.68	6.84	8.24	7.41	8.80	7.08	9.40	7.71	10.00	7.66	10.46	7.56	10.93	7.94		
37	7.59	6.81	8.11	7.36	8.63	7.03	9.18	7.65	9.72	7.59	10.15	7.49	10.57	7.88		
39	7.50	6.77	7.98	7.32	8.46	6.98	8.95	7.59	9.44	7.52	9.83	7.42	10.22	7.81		
41	7.40	6.74	7.85	7.28	8.29	6.93	8.72	7.54	9.16	7.46	9.51	7.35	9.86	7.75		
43	7.31	6.70	7.72	7.23	8.12	6.88	8.50	7.48	8.88	7.39	9.19	7.28	9.50	7.68		
46	7.17	6.65	7.52	7.17	7.87	6.81	8.16	7.40	8.46	7.30	8.71	7.18	8.97	7.59		
50	5.60	5.49	5.73	5.62	5.90	5.78	6.05	5.93	6.17	6.05	6.28	6.15	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PCA001Z877

Model SRK100VSAWZR Indoor unit SRK100ZR-W Outdoor unit FDC100VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.01	11.60	8.07	11.92	8.00	12.55	8.32	13.18	8.14
-10							10.67	7.86	11.23	7.91	11.53	7.84	12.13	8.16	12.73	7.99
-5							10.31	7.71	10.85	7.75	11.35	7.77	12.35	8.24	13.36	8.20
0					8.55	6.70	10.33	7.72	11.22	7.91	11.56	7.86	12.25	8.20	12.93	8.05
5					9.01	6.90	10.41	7.75	11.11	7.86	11.44	7.80	12.09	8.15	12.74	7.99
11					9.41	7.08	10.44	7.77	10.96	7.80	11.36	7.77	12.15	8.17	12.94	8.05
13					9.80	7.26	10.47	7.78	10.81	7.74	11.27	7.74	12.20	8.19	13.13	8.12
15					10.19	7.44	10.50	7.79	10.66	7.68	11.19	7.71	12.26	8.21	13.32	8.19
17					9.83	7.27	10.59	7.83	10.97	7.80	11.40	7.79	12.26	8.21	13.13	8.12
19					10.26	7.47	10.67	7.86	11.27	7.93	11.61	7.87	12.27	8.21	12.94	8.05
21					10.08	7.39	10.56	7.82	11.15	7.88	11.49	7.82	12.15	8.17	12.82	8.01
23					9.90	7.31	10.45	7.77	11.04	7.83	11.37	7.78	12.03	8.12	12.70	7.97
25			9.79	7.71	9.81	7.27	10.40	7.75	10.98	7.81	11.31	7.75	11.97	8.10	12.63	7.95
27			9.62	7.62	9.72	7.22	10.35	7.72	10.92	7.78	11.39	7.79	11.86	8.06		
29			9.42	7.52	9.49	7.12	10.11	7.62	10.69	7.69	11.16	7.69	11.63	7.98		
31			9.21	7.42	9.26	7.01	9.87	7.52	10.46	7.59	10.93	7.60	11.39	7.89		
33	7.82	6.54	8.42	7.03	9.03	6.91	9.64	7.42	10.23	7.50	10.70	7.51	11.16	7.81		
35	7.68	6.47	8.24	6.95	8.80	6.81	9.40	7.33	10.00	7.41	10.46	7.42	10.93	7.72		
37	7.59	6.43	8.11	6.89	8.63	6.73	9.18	7.23	9.72	7.29	10.15	7.30	10.57	7.60		
39	7.50	6.38	7.98	6.82	8.46	6.66	8.95	7.14	9.44	7.18	9.83	7.17	10.22	7.47		
41	7.40	6.33	7.85	6.76	8.29	6.58	8.72	7.05	9.16	7.07	9.51	7.05	9.86	7.35		
43	7.31	6.28	7.72	6.70	8.12	6.51	8.50	6.96	8.88	6.96	9.19	6.93	9.50	7.22		
46	7.17	6.21	7.52	6.61	7.87	6.40	8.16	6.82	8.46	6.80	8.71	6.76	8.97	7.04		
50	5.60	5.45	5.73	5.62	5.90	5.58	6.05	5.93	6.17	5.95	6.28	5.89	6.38	6.20		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PCA001Z877

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

(b) Twin type

Model SRK100VNAWPZSX Indoor unit SRK50ZSX-W (2 units) Outdoor unit FDC100VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.30	11.60	8.35	11.92	8.28	12.55	8.63	13.18	8.45
-10							10.67	8.16	11.23	8.20	11.53	8.13	12.13	8.49	12.73	8.30
-5							10.31	8.01	10.85	8.05	11.35	8.06	12.35	8.56	13.36	8.51
0					8.55	6.97	10.33	8.02	11.22	8.20	11.56	8.14	12.25	8.53	12.93	8.37
5					9.01	7.16	10.41	8.05	11.11	8.15	11.44	8.09	12.09	8.47	12.74	8.31
11					9.41	7.34	10.44	8.06	10.96	8.09	11.36	8.06	12.15	8.49	12.94	8.37
13					9.80	7.51	10.47	8.08	10.81	8.03	11.27	8.03	12.20	8.51	13.13	8.43
15					10.19	7.68	10.50	8.09	10.66	7.97	11.19	8.00	12.26	8.53	13.32	8.50
17					9.83	7.52	10.59	8.12	10.97	8.09	11.40	8.07	12.26	8.53	13.13	8.43
19					10.26	7.71	10.67	8.16	11.27	8.22	11.61	8.15	12.27	8.54	12.94	8.37
21					10.08	7.63	10.56	8.11	11.15	8.17	11.49	8.11	12.15	8.49	12.82	8.33
23					9.90	7.55	10.45	8.07	11.04	8.12	11.37	8.06	12.03	8.45	12.70	8.29
25			9.79	7.96	9.81	7.51	10.40	8.05	10.98	8.10	11.31	8.04	11.97	8.43	12.63	8.27
27			9.62	7.88	9.72	7.48	10.35	8.02	10.92	8.07	11.39	8.07	11.86	8.39		
29			9.42	7.78	9.49	7.37	10.11	7.93	10.69	7.98	11.16	7.98	11.63	8.31		
31			9.21	7.68	9.26	7.27	9.87	7.83	10.46	7.89	10.93	7.89	11.39	8.23		
33	7.82	6.78	8.42	7.31	9.03	7.17	9.64	7.74	10.23	7.80	10.70	7.81	11.16	8.15		
35	7.68	6.71	8.24	7.23	8.80	7.07	9.40	7.64	10.00	7.71	10.46	7.72	10.93	8.07		
37	7.59	6.67	8.11	7.17	8.63	7.00	9.18	7.55	9.72	7.60	10.15	7.60	10.57	7.94		
39	7.50	6.62	7.98	7.11	8.46	6.93	8.95	7.46	9.44	7.50	9.83	7.48	10.22	7.82		
41	7.40	6.58	7.85	7.05	8.29	6.85	8.72	7.37	9.16	7.39	9.51	7.37	9.86	7.71		
43	7.31	6.53	7.72	6.99	8.12	6.78	8.50	7.29	8.88	7.29	9.19	7.25	9.50	7.59		
46	7.17	6.46	7.52	6.90	7.87	6.68	8.16	7.16	8.46	7.13	8.71	7.08	8.97	7.41		
50	5.60	5.49	5.73	5.62	5.90	5.78	6.05	5.93	6.17	6.05	6.28	6.15	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature ℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PCA001Z877

Model SRK100VSAWPZSX Indoor unit SRK50ZSX-W (2 units) Outdoor unit FDC100VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							11.02	8.30	11.60	8.35	11.92	8.28	12.55	8.63	13.18	8.45
-10							10.67	8.16	11.23	8.20	11.53	8.13	12.13	8.49	12.73	8.30
-5							10.31	8.01	10.85	8.05	11.35	8.06	12.35	8.56	13.36	8.51
0					8.55	6.97	10.33	8.02	11.22	8.20	11.56	8.14	12.25	8.53	12.93	8.37
5					9.01	7.16	10.41	8.05	11.11	8.15	11.44	8.09	12.09	8.47	12.74	8.31
11					9.41	7.34	10.44	8.06	10.96	8.09	11.36	8.06	12.15	8.49	12.94	8.37
13					9.80	7.51	10.47	8.08	10.81	8.03	11.27	8.03	12.20	8.51	13.13	8.43
15					10.19	7.68	10.50	8.09	10.66	7.97	11.19	8.00	12.26	8.53	13.32	8.50
17					9.83	7.52	10.59	8.12	10.97	8.09	11.40	8.07	12.26	8.53	13.13	8.43
19					10.26	7.71	10.67	8.16	11.27	8.22	11.61	8.15	12.27	8.54	12.94	8.37
21					10.08	7.63	10.56	8.11	11.15	8.17	11.49	8.11	12.15	8.49	12.82	8.33
23					9.90	7.55	10.45	8.07	11.04	8.12	11.37	8.06	12.03	8.45	12.70	8.29
25			9.79	7.96	9.81	7.51	10.40	8.05	10.98	8.10	11.31	8.04	11.97	8.43	12.63	8.27
27			9.62	7.88	9.72	7.48	10.35	8.02	10.92	8.07	11.39	8.07	11.86	8.39		
29			9.42	7.78	9.49	7.37	10.11	7.93	10.69	7.98	11.16	7.98	11.63	8.31		
31			9.21	7.68	9.26	7.27	9.87	7.83	10.46	7.89	10.93	7.89	11.39	8.23		
33	7.82	6.78	8.42	7.31	9.03	7.17	9.64	7.74	10.23	7.80	10.70	7.81	11.16	8.15		
35	7.68	6.71	8.24	7.23	8.80	7.07	9.40	7.64	10.00	7.71	10.46	7.72	10.93	8.07		
37	7.59	6.67	8.11	7.17	8.63	7.00	9.18	7.55	9.72	7.60	10.15	7.60	10.57	7.94		
39	7.50	6.62	7.98	7.11	8.46	6.93	8.95	7.46	9.44	7.50	9.83	7.48	10.22	7.82		
41	7.40	6.58	7.85	7.05	8.29	6.85	8.72	7.37	9.16	7.39	9.51	7.37	9.86	7.71		
43	7.31	6.53	7.72	6.99	8.12	6.78	8.50	7.29	8.88	7.29	9.19	7.25	9.50	7.59		
46	7.17	6.46	7.52	6.90	7.87	6.68	8.16	7.16	8.46	7.13	8.71	7.08	8.97	7.41		
50	5.60	5.49	5.73	5.62	5.90	5.78	6.05	5.93	6.17	6.05	6.28	6.15	6.38	6.26		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature ℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	6.47	6.40	6.32	6.24	6.16
-17.7	-18	6.52	6.46	6.40	6.30	6.20
-15.7	-16	7.37	7.29	7.20	7.11	7.02
-13.5	-14	7.66	7.57	7.47	7.38	7.30
-11.5	-12	8.23	8.12	8.01	7.93	7.85
-9.5	-10	8.80	8.67	8.54	8.47	8.40
-7.5	-8	9.38	9.23	9.08	9.02	8.95
-5.5	-6	9.56	9.41	9.26	9.20	9.14
-3.0	-4	9.74	9.59	9.45	9.38	9.32
-1.0	-2	9.92	9.77	9.63	9.57	9.50
1.0	0	10.10	9.96	9.81	9.75	9.68
2.0	1	10.19	10.05	9.91	9.84	9.77
3.0	2	10.45	10.31	10.17	10.10	10.03
5.0	4	10.96	10.82	10.68	10.62	10.55
7.0	6	11.48	11.34	11.20	11.13	11.07
9.0	8	11.79	11.65	11.51	11.45	11.39
11.5	10	12.09	11.96	11.82	11.77	11.71
13.5	12	12.72	12.57	12.41	12.35	12.29
15.5	14	13.35	13.18	13.01	12.94	12.88
16.5	16	13.67	13.49	13.31	13.24	13.17

PCA001Z877

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃CDB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

Model SRK125VNAWPZSX Indoor unit SRK60ZSX-W (2 units) Outdoor unit FDC125VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	10.01	15.78	10.07	16.21	9.95	17.06	10.26	17.92	9.97
-10							14.51	9.80	15.27	9.85	15.68	9.74	16.50	10.04	17.32	9.76
-5							14.03	9.59	14.75	9.63	15.43	9.64	16.80	10.16	18.16	10.05
0					11.63	8.34	14.05	9.60	15.26	9.85	15.73	9.76	16.65	10.10	17.58	9.85
5					12.26	8.62	14.16	9.65	15.11	9.78	15.56	9.68	16.44	10.02	17.33	9.76
11					12.79	8.86	14.20	9.66	14.91	9.70	15.44	9.64	16.52	10.05	17.59	9.85
13					13.33	9.11	14.24	9.68	14.70	9.61	15.33	9.59	16.59	10.08	17.86	9.94
15					13.86	9.36	14.29	9.70	14.50	9.52	15.22	9.55	16.67	10.11	18.12	10.03
17					13.37	9.13	14.40	9.75	14.91	9.70	15.50	9.66	16.68	10.11	17.86	9.94
19					13.95	9.40	14.51	9.80	15.33	9.88	15.78	9.78	16.69	10.11	17.59	9.85
21					13.71	9.29	14.36	9.74	15.17	9.81	15.62	9.71	16.53	10.05	17.43	9.80
23					13.47	9.17	14.22	9.67	15.01	9.74	15.46	9.65	16.36	9.99	17.27	9.74
25			13.32	9.74	13.34	9.12	14.15	9.64	14.93	9.71	15.38	9.61	16.28	9.96	17.18	9.71
27			13.09	9.62	13.22	9.06	14.07	9.61	14.85	9.67	15.49	9.66	16.13	9.91		
29			12.81	9.48	12.91	8.91	13.75	9.47	14.54	9.54	15.18	9.53	15.81	9.79		
31			12.53	9.34	12.60	8.77	13.43	9.33	14.23	9.41	14.86	9.40	15.50	9.67		
33	10.63	8.24	11.45	8.80	12.28	8.63	13.11	9.20	13.91	9.28	14.55	9.28	15.18	9.56		
35	10.45	8.15	11.21	8.69	11.97	8.49	12.79	9.06	13.60	9.15	14.23	9.16	14.86	9.44		
37	10.32	8.08	11.03	8.60	11.74	8.38	12.48	8.93	13.22	9.00	13.80	8.99	14.38	9.27		
39	10.20	8.02	10.85	8.52	11.51	8.28	12.17	8.81	12.84	8.85	13.36	8.82	13.89	9.11		
41	10.07	7.95	10.67	8.43	11.28	8.18	11.87	8.68	12.45	8.70	12.93	8.66	13.41	8.94		
43	9.94	7.89	10.49	8.35	11.04	8.08	11.56	8.56	12.07	8.55	12.50	8.50	12.92	8.78		
46	9.75	7.79	10.22	8.22	10.70	7.93	11.10	8.38	11.50	8.33	11.85	8.26	12.20	8.54		
50	7.61	6.76	7.79	7.13	8.02	6.82	8.23	7.30	8.40	7.21	8.54	7.12	8.68	7.44		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PCA001Z877

Model SRK125VSAWPZSX Indoor unit SRK60ZSX-W (2 units) Outdoor unit FDC125VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	10.01	15.78	10.07	16.21	9.95	17.06	10.26	17.92	9.97
-10							14.51	9.80	15.27	9.85	15.68	9.74	16.50	10.04	17.32	9.76
-5							14.03	9.59	14.75	9.63	15.43	9.64	16.80	10.16	18.16	10.05
0					11.63	8.34	14.05	9.60	15.26	9.85	15.73	9.76	16.65	10.10	17.58	9.85
5					12.26	8.62	14.16	9.65	15.11	9.78	15.56	9.68	16.44	10.02	17.33	9.76
11					12.79	8.86	14.20	9.66	14.91	9.70	15.44	9.64	16.52	10.05	17.59	9.85
13					13.33	9.11	14.24	9.68	14.70	9.61	15.33	9.59	16.59	10.08	17.86	9.94
15					13.86	9.36	14.29	9.70	14.50	9.52	15.22	9.55	16.67	10.11	18.12	10.03
17					13.37	9.13	14.40	9.75	14.91	9.70	15.50	9.66	16.68	10.11	17.86	9.94
19					13.95	9.40	14.51	9.80	15.33	9.88	15.78	9.78	16.69	10.11	17.59	9.85
21					13.71	9.29	14.36	9.74	15.17	9.81	15.62	9.71	16.53	10.05	17.43	9.80
23					13.47	9.17	14.22	9.67	15.01	9.74	15.46	9.65	16.36	9.99	17.27	9.74
25			13.32	9.74	13.34	9.12	14.15	9.64	14.93	9.71	15.38	9.61	16.28	9.96	17.18	9.71
27			13.09	9.62	13.22	9.06	14.07	9.61	14.85	9.67	15.49	9.66	16.13	9.91		
29			12.81	9.48	12.91	8.91	13.75	9.47	14.54	9.54	15.18	9.53	15.81	9.79		
31			12.53	9.34	12.60	8.77	13.43	9.33	14.23	9.41	14.86	9.40	15.50	9.67		
33	10.63	8.24	11.45	8.80	12.28	8.63	13.11	9.20	13.91	9.28	14.55	9.28	15.18	9.56		
35	10.45	8.15	11.21	8.69	11.97	8.49	12.79	9.06	13.60	9.15	14.23	9.16	14.86	9.44		
37	10.32	8.08	11.03	8.60	11.74	8.38	12.48	8.93	13.22	9.00	13.80	8.99	14.38	9.27		
39	10.20	8.02	10.85	8.52	11.51	8.28	12.17	8.81	12.84	8.85	13.36	8.82	13.89	9.11		
41	10.07	7.95	10.67	8.43	11.28	8.18	11.87	8.68	12.45	8.70	12.93	8.66	13.41	8.94		
43	9.94	7.89	10.49	8.35	11.04	8.08	11.56	8.56	12.07	8.55	12.50	8.50	12.92	8.78		
46	9.75	7.79	10.22	8.22	10.70	7.93	11.10	8.38	11.50	8.33	11.85	8.26	12.20	8.54		
50	7.61	6.76	7.79	7.13	8.02	6.82	8.23	7.30	8.40	7.21	8.54	7.12	8.68	7.44		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	7.60	7.51	7.42	7.33	7.24
-17.7	-18	7.80	7.73	7.66	7.54	7.42
-15.7	-16	8.66	8.56	8.46	8.36	8.25
-13.5	-14	8.95	8.84	8.73	8.63	8.53
-11.5	-12	9.52	9.39	9.26	9.17	9.08
-9.5	-10	10.10	9.95	9.80	9.72	9.64
-7.5	-8	10.67	10.50	10.34	10.26	10.19
-5.5	-6	11.13	10.96	10.79	10.72	10.64
-3.0	-4	11.59	11.42	11.25	11.17	11.09
-1.0	-2	12.05	11.87	11.70	11.62	11.54
1.0	0	12.50	12.33	12.16	12.07	11.99
2.0	1	12.73	12.56	12.38	12.30	12.22
3.0	2	13.06	12.88	12.71	12.62	12.54
5.0	4	13.70	13.53	13.35	13.27	13.19
7.0	6	14.35	14.18	14.00	13.92	13.84
9.0	8	14.73	14.56	14.39	14.31	14.24
11.5	10	15.11	14.94	14.78	14.71	14.64
13.5	12	15.90	15.71	15.52	15.44	15.37
15.5	14	16.69	16.48	16.26	16.18	16.09
16.5	16	17.09	16.86	16.63	16.54	16.46

PCA001Z877

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

Model SRK140VNAWPZR Indoor unit SRK71ZR-W (2 units) Outdoor unit FDC140VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.51	15.78	11.53	16.21	11.41	17.06	11.93	17.92	11.64
-10							14.51	11.33	15.27	11.35	15.68	11.23	16.50	11.75	17.32	11.46
-5							14.03	11.14	14.75	11.16	15.43	11.14	16.80	11.85	18.16	11.71
0					11.63	9.72	14.05	11.15	15.26	11.35	15.73	11.24	16.65	11.80	17.58	11.54
5					12.26	9.97	14.16	11.20	15.11	11.29	15.56	11.18	16.44	11.74	17.33	11.46
11					12.79	10.18	14.20	11.21	14.91	11.21	15.44	11.14	16.52	11.76	17.59	11.54
13					13.33	10.40	14.24	11.23	14.70	11.14	15.33	11.10	16.59	11.78	17.86	11.62
15					13.86	10.62	14.29	11.24	14.50	11.07	15.22	11.07	16.67	11.81	18.12	11.69
17					13.37	10.42	14.40	11.28	14.91	11.22	15.50	11.16	16.68	11.81	17.86	11.62
19					13.95	10.66	14.51	11.33	15.33	11.37	15.78	11.26	16.69	11.81	17.59	11.54
21					13.71	10.56	14.36	11.27	15.17	11.31	15.62	11.21	16.53	11.76	17.43	11.49
23					13.47	10.46	14.22	11.22	15.01	11.25	15.46	11.15	16.36	11.71	17.27	11.45
25			13.32	11.05	13.34	10.41	14.15	11.19	14.93	11.22	15.38	11.12	16.28	11.68	17.18	11.42
27			13.09	10.95	13.22	10.36	14.07	11.16	14.85	11.19	15.49	11.16	16.13	11.64		
29			12.81	10.82	12.91	10.23	13.75	11.04	14.54	11.08	15.18	11.05	15.81	11.54		
31			12.53	10.70	12.60	10.10	13.43	10.92	14.23	10.97	14.86	10.94	15.50	11.44		
33	10.63	9.45	11.45	10.22	12.28	9.98	13.11	10.80	13.91	10.86	14.55	10.83	15.18	11.34		
35	10.45	9.37	11.21	10.12	11.97	9.85	12.79	10.68	13.60	10.75	14.23	10.73	14.86	11.24		
37	10.32	9.31	11.03	10.05	11.74	9.76	12.48	10.57	13.22	10.61	13.80	10.58	14.38	11.09		
39	10.20	9.25	10.85	9.97	11.51	9.67	12.17	10.46	12.84	10.48	13.36	10.43	13.89	10.95		
41	10.07	9.20	10.67	9.89	11.28	9.58	11.87	10.35	12.45	10.35	12.93	10.29	13.41	10.80		
43	9.94	9.14	10.49	9.82	11.04	9.49	11.56	10.24	12.07	10.21	12.50	10.15	12.92	10.66		
46	9.75	9.05	10.22	9.70	10.70	9.35	11.10	10.08	11.50	10.02	11.85	9.94	12.20	10.45		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature ℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PCA001Z877

Model SRK140VSAWPZR Indoor unit SRK71ZR-W (2 units) Outdoor unit FDC140VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃DB		21 ℃DB		23 ℃DB		26 ℃DB		27 ℃DB		28 ℃DB		31 ℃DB		33 ℃DB	
	12 ℃WB		14 ℃WB		16 ℃WB		18 ℃WB		19 ℃WB		20 ℃WB		22 ℃WB		24 ℃WB	
℃DB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.51	15.78	11.53	16.21	11.41	17.06	11.93	17.92	11.64
-10							14.51	11.33	15.27	11.35	15.68	11.23	16.50	11.75	17.32	11.46
-5							14.03	11.14	14.75	11.16	15.43	11.14	16.80	11.85	18.16	11.71
0					11.63	9.72	14.05	11.15	15.26	11.35	15.73	11.24	16.65	11.80	17.58	11.54
5					12.26	9.97	14.16	11.20	15.11	11.29	15.56	11.18	16.44	11.74	17.33	11.46
11					12.79	10.18	14.20	11.21	14.91	11.21	15.44	11.14	16.52	11.76	17.59	11.54
13					13.33	10.40	14.24	11.23	14.70	11.14	15.33	11.10	16.59	11.78	17.86	11.62
15					13.86	10.62	14.29	11.24	14.50	11.07	15.22	11.07	16.67	11.81	18.12	11.69
17					13.37	10.42	14.40	11.28	14.91	11.22	15.50	11.16	16.68	11.81	17.86	11.62
19					13.95	10.66	14.51	11.33	15.33	11.37	15.78	11.26	16.69	11.81	17.59	11.54
21					13.71	10.56	14.36	11.27	15.17	11.31	15.62	11.21	16.53	11.76	17.43	11.49
23					13.47	10.46	14.22	11.22	15.01	11.25	15.46	11.15	16.36	11.71	17.27	11.45
25			13.32	11.05	13.34	10.41	14.15	11.19	14.93	11.22	15.38	11.12	16.28	11.68	17.18	11.42
27			13.09	10.95	13.22	10.36	14.07	11.16	14.85	11.19	15.49	11.16	16.13	11.64		
29			12.81	10.82	12.91	10.23	13.75	11.04	14.54	11.08	15.18	11.05	15.81	11.54		
31			12.53	10.70	12.60	10.10	13.43	10.92	14.23	10.97	14.86	10.94	15.50	11.44		
33	10.63	9.45	11.45	10.22	12.28	9.98	13.11	10.80	13.91	10.86	14.55	10.83	15.18	11.34		
35	10.45	9.37	11.21	10.12	11.97	9.85	12.79	10.68	13.60	10.75	14.23	10.73	14.86	11.24		
37	10.32	9.31	11.03	10.05	11.74	9.76	12.48	10.57	13.22	10.61	13.80	10.58	14.38	11.09		
39	10.20	9.25	10.85	9.97	11.51	9.67	12.17	10.46	12.84	10.48	13.36	10.43	13.89	10.95		
41	10.07	9.20	10.67	9.89	11.28	9.58	11.87	10.35	12.45	10.35	12.93	10.29	13.41	10.80		
43	9.94	9.14	10.49	9.82	11.04	9.49	11.56	10.24	12.07	10.21	12.50	10.15	12.92	10.66		
46	9.75	9.05	10.22	9.70	10.70	9.35	11.10	10.08	11.50	10.02	11.85	9.94	12.20	10.45		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature ℃DB				
℃DB	℃WB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PCA001Z877

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

(c) Triple type

Model SRK140VNAWTZSX Indoor unit SRK50ZSX-W (3 units) Outdoor unit FDC140VNA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.82	15.78	11.87	16.21	11.77	17.06	12.33	17.92	12.08
-10							14.51	11.63	15.27	11.68	15.68	11.58	16.50	12.14	17.32	11.89
-5							14.03	11.43	14.75	11.47	15.43	11.48	16.80	12.24	18.16	12.16
0					11.63	9.94	14.05	11.44	15.26	11.67	15.73	11.59	16.65	12.19	17.58	11.97
5					12.26	10.21	14.16	11.49	15.11	11.61	15.56	11.53	16.44	12.12	17.33	11.89
11					12.79	10.43	14.20	11.50	14.91	11.53	15.44	11.49	16.52	12.14	17.59	11.98
13					13.33	10.66	14.24	11.52	14.70	11.45	15.33	11.45	16.59	12.17	17.86	12.06
15					13.86	10.89	14.29	11.54	14.50	11.38	15.22	11.40	16.67	12.20	18.12	12.14
17					13.37	10.68	14.40	11.58	14.91	11.54	15.50	11.51	16.68	12.20	17.86	12.06
19					13.95	10.93	14.51	11.63	15.33	11.70	15.78	11.61	16.69	12.20	17.59	11.98
21					13.71	10.83	14.36	11.57	15.17	11.64	15.62	11.55	16.53	12.15	17.43	11.92
23					13.47	10.72	14.22	11.51	15.01	11.57	15.46	11.49	16.36	12.09	17.27	11.87
25			13.32	11.29	13.34	10.67	14.15	11.48	14.93	11.54	15.38	11.46	16.28	12.06	17.18	11.85
27			13.09	11.18	13.22	10.62	14.07	11.45	14.85	11.51	15.49	11.50	16.13	12.01		
29			12.81	11.05	12.91	10.48	13.75	11.32	14.54	11.39	15.18	11.39	15.81	11.90		
31			12.53	10.92	12.60	10.35	13.43	11.20	14.23	11.27	14.86	11.27	15.50	11.80		
33	10.63	9.63	11.45	10.43	12.28	10.22	13.11	11.07	13.91	11.15	14.55	11.16	15.18	11.69		
35	10.45	9.55	11.21	10.32	11.97	10.09	12.79	10.94	13.60	11.03	14.23	11.04	14.86	11.58		
37	10.32	9.48	11.03	10.24	11.74	9.99	12.48	10.82	13.22	10.89	13.80	10.88	14.38	11.42		
39	10.20	9.42	10.85	10.16	11.51	9.89	12.17	10.71	12.84	10.75	13.36	10.73	13.89	11.26		
41	10.07	9.36	10.67	10.08	11.28	9.80	11.87	10.59	12.45	10.61	12.93	10.57	13.41	11.11		
43	9.94	9.30	10.49	10.00	11.04	9.70	11.56	10.47	12.07	10.47	12.50	10.42	12.92	10.95		
46	9.75	9.21	10.22	9.88	10.70	9.56	11.10	10.30	11.50	10.26	11.85	10.19	12.20	10.72		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PCA001Z877

Model SRK140VSAWTZSX Indoor unit SRK50ZSX-W (3 units) Outdoor unit FDC140VSA-W

Cooling Mode (kW)

Outdoor air temp.	Indoor air temperature															
	18 ℃CDB		21 ℃CDB		23 ℃CDB		26 ℃CDB		27 ℃CDB		28 ℃CDB		31 ℃CDB		33 ℃CDB	
	12 ℃CWB		14 ℃CWB		16 ℃CWB		18 ℃CWB		19 ℃CWB		20 ℃CWB		22 ℃CWB		24 ℃CWB	
℃CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
-15							14.99	11.82	15.78	11.87	16.21	11.77	17.06	12.33	17.92	12.08
-10							14.51	11.63	15.27	11.68	15.68	11.58	16.50	12.14	17.32	11.89
-5							14.03	11.43	14.75	11.47	15.43	11.48	16.80	12.24	18.16	12.16
0					11.63	9.94	14.05	11.44	15.26	11.67	15.73	11.59	16.65	12.19	17.58	11.97
5					12.26	10.21	14.16	11.49	15.11	11.61	15.56	11.53	16.44	12.12	17.33	11.89
11					12.79	10.43	14.20	11.50	14.91	11.53	15.44	11.49	16.52	12.14	17.59	11.98
13					13.33	10.66	14.24	11.52	14.70	11.45	15.33	11.45	16.59	12.17	17.86	12.06
15					13.86	10.89	14.29	11.54	14.50	11.38	15.22	11.40	16.67	12.20	18.12	12.14
17					13.37	10.68	14.40	11.58	14.91	11.54	15.50	11.51	16.68	12.20	17.86	12.06
19					13.95	10.93	14.51	11.63	15.33	11.70	15.78	11.61	16.69	12.20	17.59	11.98
21					13.71	10.83	14.36	11.57	15.17	11.64	15.62	11.55	16.53	12.15	17.43	11.92
23					13.47	10.72	14.22	11.51	15.01	11.57	15.46	11.49	16.36	12.09	17.27	11.87
25			13.32	11.29	13.34	10.67	14.15	11.48	14.93	11.54	15.38	11.46	16.28	12.06	17.18	11.85
27			13.09	11.18	13.22	10.62	14.07	11.45	14.85	11.51	15.49	11.50	16.13	12.01		
29			12.81	11.05	12.91	10.48	13.75	11.32	14.54	11.39	15.18	11.39	15.81	11.90		
31			12.53	10.92	12.60	10.35	13.43	11.20	14.23	11.27	14.86	11.27	15.50	11.80		
33	10.63	9.63	11.45	10.43	12.28	10.22	13.11	11.07	13.91	11.15	14.55	11.16	15.18	11.69		
35	10.45	9.55	11.21	10.32	11.97	10.09	12.79	10.94	13.60	11.03	14.23	11.04	14.86	11.58		
37	10.32	9.48	11.03	10.24	11.74	9.99	12.48	10.82	13.22	10.89	13.80	10.88	14.38	11.42		
39	10.20	9.42	10.85	10.16	11.51	9.89	12.17	10.71	12.84	10.75	13.36	10.73	13.89	11.26		
41	10.07	9.36	10.67	10.08	11.28	9.80	11.87	10.59	12.45	10.61	12.93	10.57	13.41	11.11		
43	9.94	9.30	10.49	10.00	11.04	9.70	11.56	10.47	12.07	10.47	12.50	10.42	12.92	10.95		
46	9.75	9.21	10.22	9.88	10.70	9.56	11.10	10.30	11.50	10.26	11.85	10.19	12.20	10.72		
50	7.61	7.46	7.79	7.64	8.02	7.86	8.23	8.07	8.40	8.23	8.54	8.37	8.68	8.51		

Heating Mode:HC (kW)

Outdoor air temp.		Indoor air temperature				
		℃CDB				
℃CDB	℃CWB	16	18	20	22	24
-19.8	-20	8.07	7.97	7.88	7.78	7.68
-17.7	-18	8.20	8.13	8.05	7.93	7.80
-15.7	-16	9.19	9.09	8.98	8.87	8.76
-13.5	-14	9.52	9.40	9.29	9.18	9.07
-11.5	-12	10.18	10.04	9.90	9.81	9.71
-9.5	-10	10.84	10.68	10.52	10.43	10.35
-7.5	-8	11.50	11.32	11.14	11.06	10.98
-5.5	-6	12.08	11.89	11.71	11.63	11.55
-3.0	-4	12.65	12.47	12.28	12.20	12.11
-1.0	-2	13.23	13.04	12.85	12.77	12.68
1.0	0	13.81	13.62	13.42	13.33	13.24
2.0	1	14.10	13.90	13.71	13.62	13.53
3.0	2	14.46	14.26	14.07	13.98	13.89
5.0	4	15.17	14.98	14.78	14.69	14.60
7.0	6	15.89	15.69	15.50	15.41	15.32
9.0	8	16.31	16.12	15.93	15.85	15.77
11.5	10	16.73	16.55	16.36	16.28	16.21
13.5	12	17.61	17.39	17.18	17.10	17.01
15.5	14	18.48	18.24	18.00	17.91	17.82
16.5	16	18.92	18.67	18.41	18.32	18.22

PCA001Z877

Notes(1) These data show average status.
Depending on the system control, there may be ranges where the operation is not conducted continuously.
These data show the case where the operation frequency of a compressor is fixed. (Cooling only)
In the heating mode in which the outside air temperature is 0℃DB or less, the compressor operates at maximum frequency.
(2) Capacities are based on the following conditions.
Corresponding refrigerant piping length :7.5m
Level difference of Zero.
(3) Symbols are as follows
TC :Total cooling capacity (kW)
SHC :Sensible heat capacity (kW)
HC :Heating capacity (kW)

[References data]

Capacity variation against outdoor and indoor temperature at rated capacity condition.

(I) **Models FDC100, 125, 140VNA-W, 100, 125, 140VSA-W**

① **Cooling**



② **Heating**



1.9.2 Correction of cooling and heating capacity in relation to air flow rate control (Fan speed)

Fan speed	P-Hi or Hi	Me	Lo
Coefficient	1.00	0.97	0.95

1.9.3 Correction of cooling and heating capacity in relation to one way length of refrigerant piping

It is necessary to correct the cooling and heating capacity in relation to the one way equivalent piping length between the indoor and outdoor units.

Models 100 - 140

Equivalent piping length (1)(m)			7.5	10	15	20	25	30	35	40	45	50	55
Heating			1	1	1	1	1	0.998	0.998	0.993	0.993	0.988	0.988
Cooling	100 model	ϕ15.88	1	0.991	0.978	0.964	0.951	0.937	0.924	0.910	0.897	0.883	0.870
	125 model		1	0.986	0.968	0.950	0.932	0.914	0.896	0.878	0.860	0.842	0.824
	140 model		1	0.985	0.966	0.946	0.927	0.907	0.888	0.868	0.849	0.829	0.810
	100 model	ϕ19.05	1.016	1.013	1.007	1.002	0.996	0.991	0.985	0.980	0.974	0.969	0.963
	125 model		1.022	1.018	1.009	1.001	0.992	0.984	0.975	0.967	0.958	0.950	0.941
	140 model		1.026	1.021	1.011	1.002	0.992	0.983	0.973	0.964	0.954	0.945	0.935

Note (1) Calculate the equivalent length using the following formula.
However, install the piping so that the piping length is within +5 m of the limit length (actual length) for the respective types.

• Equivalent length =Actual length + (Equivalent bend length x number of bends in the piping.)
Equivalent length per bend.

Gas pipe diameter (mm)	ϕ12.7	ϕ15.88	ϕ19.05	ϕ22.22	ϕ25.4	ϕ28.58
Equivalent bend length	0.20	0.25	0.30	0.35	0.40	0.45

1.9.4 Height difference between the indoor unit and outdoor unit

When the outdoor unit is located below indoor units in cooling mode, or when the outdoor unit is located above indoor units in heating mode, the correction coefficient mentioned in the below table should be subtracted from the value in the above table.

Height difference between the indoor unit and outdoor unit in the vertical height difference	5m	10m	15m	20m	25m	30m
Adjustment coefficient	0.99	0.98	0.97	0.96	0.95	0.94

Piping length limitations

Item \ Model	100, 125, 140
Max. one way piping length	50m
Max. vertical height difference	Outdoor unit is higher 50m Outdoor unit is lower 15m

Note (1) Values in the table indicate the one way piping length between the indoor and outdoor units.

How to obtain the cooling and heating capacity

Example : The net cooling capacity of the model FDUM100VNAWVH with the air flow "P-High", the piping length of 15m, the outdoor unit located 5m lower than the indoor unit, indoor wet-bulb temperature at 19.0℃ and outdoor dry-bulb temperature 35℃ is

Net cooling capacity = 10.0 × 1.00 × 0.978 × 0.99 ≒ 9.7kW

- 10.0: Net cooling total capacity of FDUM100VNAWVH (Outdoor temp. : 35℃DB Indoor temp. : 19℃WB) shown in table 1.9.1
- 1.00: Air flow : P-Hi shown in table 1.9.2
- 0.978: Piping length :15m (Gas pipe size is ϕ15.88) shown in table 1.9.3
- 0.99: Height diff. :5m (Outdoor unit : below) shown in table 1.9.4

1.10 APPLICATION DATA

1.10.1 Installation of indoor unit

(1) Ceiling cassette-4 way type(FDT)

PJF012D051 A

This manual is for the installation of the indoor unit.
For electrical wiring work (Indoor unit), refer to page 195. For remote control installation, refer to page 199. For wireless kit installation, refer to page 354. For electrical wiring work (Outdoor unit) and refrigerant pipe work installation for outdoor unit, refer to page 211. For motion sensor kit installation, refer to page 386. This unit must always be used with the panel.

SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, ⚠WARNING and ⚠CAUTION .
  ⚠WARNING : Wrong installation would cause serious consequences such as injuries or death.
  ⚠CAUTION : Wrong installation might cause serious consequences depending on circumstances.
  Both mentions the important items to protect your health and safety so strictly follow them by any means.
- The meanings of "Marks" used here are as shown on the right:
  ⃠ Never do it under any circumstances. | ❗ Always do it according to the instruction.
- After completing the installation, do commissioning to confirm there are no abnormalities, and explain to the customers about "SAFETY PRECAUTIONS", correct operation method and maintenance method (air filter cleaning, operation method and temperature setting method) with user's manual of this unit.
  Ask your customers to keep this installation manual together with the user's manual. Also, ask them to hand over the user's manual to the new user when the owner is changed.

⚠WARNING

- **Installation should be performed by the specialist.**
  If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Install the system correctly according to these installation manuals.**
  Improper installation may cause explosion, injury, water leakage, electric shock, and fire.
- **Check the density refered by the foumula (accordance with ISO5149).**
  If the density exceeds the limit density, please consult the dealer and installate the ventilation system.
- **Use the genuine accessories and the specified parts for installation.**
  If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Ventilate the working area well in case the refrigerant leaks during installation.**
  If the refrigerant contacts the fire, toxic gas is produced.
  In case of R32, the refrigerant could be ignited because of its flammability.
- **Install the unit in a location that can hold heavy weight.**
  Improper installation may cause the unit to fall leading to accidents.
- **Install the unit properly in order to be able to withstand strong winds such as typhoons, and earthquakes.**
  Improper installation may cause the unit to fall leading to accidents.
- **Do not mix air in to the cooling cycle on installation or removal of the air-conditioner.**
  If air is mixed in, the pressure in the cooling cycle will rise abnormally and may cause explosion and injuries.
- **Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.**
  Power source with insufficient capacity and improper work can cause electric shock and fire.
- **Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in order not to apply unexpected stress on the terminal.**
  Loose connections or hold could result in abnormal heat generation or fire.
- **Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services panel property.**
  Improper fitting may cause abnormal heat and fire.
- **Check for refrigerant gas leakage after installation is completed.**
  If the refrigerant gas leaks into the house and comes in contact with a fan heater, a stove, or an oven, toxic gas is produced.
- **Use the specified pipe, flare nut, and tools for R32 or R410A.**
  Using existing parts (R22) could cause the unit failure and serious accident due to explosion of the cooling cycle.
- **Tighten the flare nut according to the specified method by with torque wrench.**
  If the flare nut were tightened with excess torque, it could cause burst and refrigerant leakage after a long period.
- **Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulfide gas can occur.**
  Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.
- **Connect the pipes for refrigeration circuit securely in installation work before compressor is operated.**
  If the compressor is operated when the service valve is open without connecting the pipe, it could cause explosion and injuries due to abnormal high pressure in the system.
- **Stop the compressor before removing the pipe after shutting the service valve on pump down work.**
  If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.
- **Only use prescribed option parts. The installation must be carried out by the qualified installer.**
  If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.
- **Do not repair by yourself. And consult with the dealer about repair.**
  Improper repair may cause water leakage, electric shock or fire.
- **Consult the dealer or a specialist about removal of the air-conditioner.**
  Improper installation may cause water leakage, electric shock or fire.
- **Turn off the power source during servicing or inspection work.**
  If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.
- **Do not run the unit when the panel or protection guard are taken off.**
  Touching the rotating equipment, hot surface, or high voltage section could cause an injury to be caught in the machine, to get burned, or electric shock.
- **Shut off the power before electrical wiring work.**
  It could cause electric shock, unit failure and improper running.

⚠ CAUTION

- **Perform earth wiring surely.**
  Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Improper earth could cause unit failure and electric shock due to a short-circuit.
- **Earth leakage breaker must be installed.**
  If the earth leakage breaker is not installed, it can cause electric shocks.
- **Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.**
  Using the incorrect one could cause the system failure and fire.
- **Do not use any materials other than a fuse of correct capacity where a fuse should be used.**
  Connecting the circuit by wire or copper wire could cause unit failure and fire.
- **Do not install the indoor unit near the location where there is possibility of flammable gas leakages.**
  If the gas leaks and gathers around the unit, it could cause fire.
- **Do not install and use the unit where corrosive gas (such as sulfurous acid gas etc.) or flammable gas (such as thinner, petroleum etc.) may be generated or accumulated, or volatile flammable substances are handled.**
  It could cause the corrosion of heat exchanger, breakage of plastic parts etc. And inflammable gas could cause fire.
- **Secure a space for installation, inspection and maintenance specified in the manual.**
  Insufficient space can result in accident such as personal injury due to falling from the installation place.
- **Do not use the indoor unit at the place where water splashes such as laundry.**
  Indoor unit is not waterproof. It could cause electric shock and fire.
- **Do not use the indoor unit for a special purpose such as food storage, cooling for precision instrument, preservation of animals, plants, and a work of art.**
  It could cause the damage of the items.
- **Do not install nor use the system near equipments which generate electromagnetic wave or high harmonics.**
  Equipments like inverter equipment, private power generator, high-frequency medical equipment, or telecommunication equipment might influence the air-conditioner and cause a malfunction and breakdown. Or the air conditioner might influence medical equipments or telecommunication equipments, and obstruct their medical activity or cause jamming.
- **Do not install the remote control at the direct sunlight.**
  It could cause breakdown or deformation of the remote control.
- **Do not install the indoor unit at the place listed below.**
  · Places where flammable gas could leak.
  · Places where carbon fiber, metal powder or any powder is floated.
  · Place where the substances which affect the air conditioner are generated such as sulfide gas, chloride gas, acid, alkali or ammonic atmospheres.
  · Places exposed to oil mist or steam directly.
  · On vehicles and ships
  · Places where machinery which generates high harmonics is used.
  · Places where cosmetics or special sprays are frequently used.
  · Highly salted area such as beach.
  · Heavy snow area
  · Places where the system is affected by smoke from a chimney.
  · Altitude over 1000m
- **Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation)**
  · Locations with any obstacles which can prevent inlet and outlet air of the unit
  · Locations where vibration can be amplified due to insufficient strength of structure.
  · Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam. (in case of the infrared specification unit)
  · Locations where an equipment affected by high harmonics is placed. (TV set or radio receiver is placed within 5m)
  · Locations where drainage cannot run off safely.
  It can affect performance or function and etc..
  Do not install the motion sensor mounting panel at following places. It could cause detection error, incapacity of detection, or characteristic degradation.
  • Place where vibration is applied to it for a long period of time.
  • Place where static electricity or electromagnetic wave generates.
  • Place where it is exposed to high temperature or humidity for a long period of time.
  • Dusty place or where the lens face could be fouled or damaged.
- **Do not put any valuables which will break down by getting wet under the air-conditioner.**
  Condensation could drop when the relative humidity is higher than 80% or drain pipe is clogged, and it damages user's belongings.
- **Do not use the base frame for the outdoor unit which is corroded or damaged after a long period of use.**
  It could cause the unit falling down and injury.
- **Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit.**
  If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit.
- **Install the drain pipe to drain the water surely according to the installation manual.**
  Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.
- **Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.**
  If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents.
- **For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding.**
  Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance.
- **Ensure the insulation on the pipes for refrigeration circuit so as not to condense water.**
  Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables.
- **Do not install the outdoor unit where is likely to be a nest for insects and small animals.**
  Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean.
- **Pay extra attention, carrying the unit by hand.**
  Carry the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective gloves in order to avoid injury by the aluminum fin.
- **Make sure to dispose of the packaging material.**
  Leaving the materials may cause injury as metals like nail and woods are used in the package.
- **Do not operate the system without the air filter.**
  It may cause the breakdown of the system due to clogging of the heat exchanger.
- **Do not touch any button with wet hands.**
  It could cause electric shock.
- **Do not touch the refrigerant piping with bare hands when in operation.**
  The pipe during operation would become very hot or cold according to the operating condition, and it could cause a burn or frostbite.
- **Do not clean up the air-conditioner with water.**
  It could cause electric shock.
- **Do not turn off the power source immediately after stopping the operation.**
  Be sure to wait for more than 5 minutes. Otherwise it could cause water leakage or breakdown.
- **Do not control the operation with the circuit breaker.**
  It could cause fire or water leakage. In addition, the fan may start operation unexpectedly and it may cause injury.

①Before installation

- Install correctly according to the installation manual.
- Confirm the following points:
  - ○Unit type/Power source specification
  - ○Pipes/Wires/Small parts ○Accessory items

When moving the indoor unit, hold only the hanging hardware (4 places) only, with care not to apply forces to any other parts of the unit (particularly the refrigerant pipe, drain pipe, and resin parts).

Accessory item

For unit hanging		For refrigerant pipe			For drain pipe			
Flat washer (M10)	Level gauge	Pipe cover(big)	Pipe cover (small)	Strap	Pipe cover(big)	Pipe cover(small)	Drain hose	Hose clamp
8	1	1	1	4	1	1	1	1
For unit hanging	For unit hight position adjustment and hanging support	For heat insulation of gas pipe	For heat insulation of liquid tube	For pipe cover fixing	For heat insulation of drain socket	For heat insulation of drain socket	For drain pipe connecting	For drain hose mounting

②Selection of installation location for the indoor unit

① Select the suitable areas to install the unit under approval of the user.

- Areas where the indoor unit can deliver hot and cold wind sufficiently. Suggest to the user to use a circulator if the ceiling height is over 3m to avoid warm air being accumulated on the ceiling.
- In case of the panel having the motion sensor, the installation height must be no higher than 4 m. It could reduce the sensitivity of motion sensor, disabling the detection.
- Areas where there is enough space to install and service.
- Areas where it can be drained properly. Areas where drain pipe descending slope can be taken.
- Areas where there is no obstruction of air flow on both air return grille and air supply port.
- Areas where fire alarm will not be accidentally activated by the air-conditioner.
- Areas where the supply air does not short-circuit.
- Areas where it is not influenced by draft air.
- Areas not exposed to direct sunlight.
- Areas where dew point is lower than around 28°C and relative humidity is lower than 80%.
  This indoor unit is tested under the condition of JIS (Japan Industrial Standard) high humidity condition and confirmed there is no problem. However, there is some risk of condensation drop if the air conditioner is operated under the severer condition than mentioned above.
  If there is a possibility to use it under such a condition, attach additional insulation of 10 to 20mm thick for entire surface of indoor unit, refrigeration pipe and drain pipe.
- Areas where TV and radio stays away more than 1m. (It could cause jamming and noise.)
- Areas where any items which will be damaged by getting wet are not placed such as food, table wares, server, or medical equipment under the unit.
- Areas where there is no influence by the heat which cookware generates.
- Areas where not exposed to oil mist, powder and/or steam directly such as above fryer.
- Areas where lighting device such as fluorescent light or incandescent light doesn't affect the operation.
  (A beam from lighting device sometimes affects the infrared receiver for the wireless remote control and the air-conditioner might not work properly.)

②Check if the place where the air-conditioner is installed can hold the weight of the unit. If it is not able to hold, reinforce the structure with boards and beams strong enough to hold it. If the strength is not enough, it could cause injury due to unit falling.

③If there are 2 units of wireless type, keep them away for more than 6m to avoid malfunction due to cross communication.

④When plural indoor units are installed nearby, keep them away for more than 4 to 5m.

Space for installation and service

- When it is not possible to keep enough space between indoor unit and wall or between indoor units, close the air supply port where it is not possible to keep space and confirm there is no short-circuit of air flow.
- Install the indoor unit at a height of more than 2.5m above the floor.



Where there are pipe joints on the way of embedded piping, provide adequate openings for inspection of the joints.

Set blow-out pattern

- Select the most proper number of blow-out air supply port direction from 4 way, 3 way or 2 way according to the shape of the room and installation position. (1 way is not available.)
- If it is necessary to change the number of air supply port, prepare the covering materials. (sold as accessory)
- Instruct the user not to use low fan speed when 2 way or 3 way air supply is used.
- Do not use 2 way air supply port under high temperature and humidity environment. (Otherwise it could cause condensation and leakage of water.)
- It is possible to set the air flow direction port by port independently. Refer to the user's manual for details.

③Preparation before installation

- If suspension bolt becomes longer, do reinforcement of earthquake resistant.
  - ○For grid ceiling
    When suspension bolt length is over 500mm, or the gap between the ceiling and roof is over 700mm, apply earthquake resistant brace to the bolt.
  - ○In case the unit is hanged directly from the slab and is installed on the ceiling plane which has enough strength.
    When suspension bolt length is over 1000mm, apply the earthquake resistant brace to the bolt.
- Prepare four (4) sets of suspension bolt, nut and spring washer (M10 or M8) on site.

Ceiling opening, Suspension bolts pitch, Pipe position

※It is possible the suspension bolts pitch to adjust accoding to the this table.

Type \ Mark	P1	P2
1	770	725-770
2	770-800	725

(mm)

Series	Type	a	d	f	g	h
Single Split (PAC) series	40 to 71 type	236	37	105	88	67
	100 to 140 type	298	99	167	140	129
VRF (KX) series	28 to 71 type	236	37	105	88	67
	90 to 160 type	298	99	167	140	129

Symbol	
A	Gas piping
B	Liquid piping
C	Drain piping
D	Hole for wiring
F	Suspension bolts
G	Outside air opening for ducting
H1 H2	Air outlet opening for ducting



④Installation of indoor unit

Work procedure

1. Set the suspension bolt length to about 50 mm from the ceiling.
2. Temporarily locate the lower nuts of the suspension bolts (4 places) at a position approximately 150 mm from the ceiling.
3. Temporarily locate the upper nuts of the suspension bolts (4 places) at positions sufficiently distance from the lower nuts so that they do not interfere with the suspension of the indoor unit and with its height adjustment.
4. Set the upper nuts of the suspension bolts and upper washers (4 places) at positions sufficiently distance from the lower nuts. Then, push and insert the temporary fixing carton of washers (*1) onto suspension bolts. Make sure that the upper washers do not slide down.
5. Suspend the indoor unit.
6. After suspending the indoor unit, mount the level gauge (*2) to the air outlet of the indoor unit, and adjust the suspension height of the indoor unit. Loosen the upper nuts (4 places), and adjust the suspension height using the lower nuts (4 places). Confirm there is no slack between the lower nuts and flat washers of the indoor unit hanger plate (4 places).
7. Remove the temporary fixing carton of washers (from all 4 places).
8. Make sure that the indoor unit is installed horizontally. Confirm the levelness of the indoor unit using a level gauge or transparent hose filled with water.
   (Keep the height difference at both ends of the indoor unit within 3 mm.)
9. Tighten the upper nuts of the suspension bolts (4 places).



④Installation of indoor unit (continued)

Protection of the indoor unit

- If it is not possible to install the panel for a while or if attaching the ceiling board after installing the indoor unit, protect the indoor unit by using upper carton.





Caution

- Do not adjust the unit height by adjusting the upper nuts. Doing so will cause unexpected stress on the indoor unit and cause the unit to become deformed, prevent the panel from being installed, and be generated fan interference noise.
- Make sure that the indoor unit is installed horizontally and set the appropriate gap between the underside of the unit and the ceiling plane. Improper installation may cause air leakage, dew condensation, water leakage and noise.
- Even after the panel has been installed, the unit height can still be finely adjusted. Refer to the panel installation manual for details.
- Make sure there is no gap between the panel and the ceiling surface, and between the panel and the indoor unit. Any gap may cause air and/or water to leak, or condensation to form.

⑤Refrigerant pipe

Caution

- Be sure to use new pipes for the refrigerant pipes. Use the flare nut attached to the product.
  Regarding whether existing pipes can be reused or not, and the washing method, refer to the instruction manual of the outdoor unit, catalogue or technical data.
  1) In case of reuse: Do not use old flare nut, but use the nut attached to the unit.
  2) In case of reuse: Flare the end of pipe replaced partially for R32 or R410A.

⚠WARNING : When flared joints are reused indoors, the flare part shall be re-fabricated. (only for R32)



Pipe dia. d mm	Min. pipe wall thickness mm	Protruding dimension for flare, mm		Flare O.D. D mm	Flare nut tightening torque N·m
		Rigid (Clutch type)			
		For R32 For R410A	Conventional tool		
6.35	0.8	0 – 0.5	0.7 – 1.3	8.9 – 9.1	14 – 18
9.52	0.8			12.8 – 13.2	34 – 42
12.7	0.8			16.2 – 16.6	49 – 61
15.88	1			19.3 – 19.7	68 – 82
19.05	1.2			23.6 – 24.0	100 – 120

- Use phosphorus deoxidized copper alloy seamless pipe (C1220T) for refrigeration pipe installation. In addition, make sure there is no damage both inside and outside of the pipe, and no harmful substances such as sulfur, oxide, dust or a contaminant stuck on the pipes.
- Do not use any refrigerant other than the designated refrigerant.
  Using other refrigerant except the designated refrigerant, may degrade inside refrigeration oil. And air getting into refrigeration circuit may cause over-pressure and resultant it may result in bursting, etc.
- Store the copper pipes indoors and seal the both end of them until they are brazed in order to avoid any dust, dirt or water getting into pipe. Otherwise it will cause degradation of refrigeration oil and compressor breakdown, etc.
- Use special tools for R32 or R410A refrigerant.

Work procedure

1. Remove the flare nut and blind flanges on the pipe of the indoor unit.
   ※ Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them. (Gas may come out at this time, but it is not abnormal.)
   - Pay attention whether the flare nut pops out. (as the indoor unit is sometimes pressured.)
2. Make a flare on liquid pipe and gas pipe, and connect the refrigeration pipes on the indoor unit.
   ※Bend radius of pipe must be 4D or larger. Once a pipe is bent, do not readjust the bending. Do not twist a pipe or collapse to 2/3D or smaller.
   - Make sure to use flare nuts assembled on the unions. Usage of other flare nuts could cause refrigerant leakage.

   ※Do a flare connection as follows:
   - Make sure to hold the nut on indoor unit pipe side using double spanner method as indicated when fastening / loosening flare nuts in order to prevent unintentional twisting of the copper pipe.
   - When fastening the flare nut, align the refrigeration pipe with the center of flare nut, screw the nut for 3-4 times by hand and then tighten it by spanner with the specified torque mentioned in the table above.



3. Cover the flare connection part of the indoor unit with attached insulation material after a gas leakage inspection, and tighten both ends with attached straps.
   - Make sure to insulate both gas pipes and liquid pipes completely.
     ※Incomplete insulation may cause dew condensation or water dropping.
   - Use heat-resistant (120 °C or more) insulations on the gas side pipes.
   - In case of using at high humidity condition, reinforce insulation of refrigerant pipes. Surface of insulation may cause dew condition or water dropping, if insulations are not reinforced.
4. Refrigerant is charged in the outdoor unit.
   As for the additional refrigerant charge for the indoor unit and piping, refer to the installation manual attached to the outdoor unit.

⑤Refrigerant pipe (continued)

Caution:
Refrigerating machine oil should not be applied to the threads of union or external surface of flare. It is because, even if the same tightening torque is applied, the oil is likely to decrease the slide friction force on the threads and increase, in turn, the axial component force so that it could crack the flare by the stress corrosion.
Refrigerating machine oil may be applied to the internal surface of flare only.

<The case of using thicness of insulation is 10mm>



<The case of using reinfoced insulation>



⑥Drain pipe

Caution

- Install the drain pipe according to the installation manual in order to drain properly.
  Imperfection in draining may cause flood indoors and wetting the household goods, etc.
- Do not put the drain pipe directly into the ditch where toxic gas such as sulfur, the other harmful and inflammable gas is generated. Toxic gas would flow into the room and it would cause serious damage to user's health and safety (some poisoning or deficiency of oxygen). In addition, it may cause corrosion of heat exchanger and bad smell.
- Connect the pipe securely to avoid water leakage from the joint.
- Insulate the pipe properly to avoid condensation drop.
- Check if the water can flow out properly from both the drain outlet on the indoor unit and the end of the drain pipe after installation.
- Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway. In addition, do not put air vent on the drain pipe. Check if water is drained out properly from the pipe during commissioning. Also, keep sufficient space for inspection and maintenance.

Work procedure

1. Make sure that the drain hose (the soft PVC side) is inserted into the end of the step part of the drain socket.
   Fix the hose clamp so that its bolt is located on the outside of the indoor unit, and the bolt are fastened in a vertical orientation.
   - Do not apply adhesives on this end.
2. Position the hose clamp so that it touches the insulation of the drain hose, and then tighten the bolt.
3. Turn the bolt several times until it is securely tightened, but do not tighten it excessively.







4. Prepare a joint for connecting VP25 pipe, adhere and connect the joint to the drain hose (the rigid PVC side), and adhere and connect VP25 pipe (prepare on site).
   ※As for drain pipe, apply VP25 made of rigid PVC which is on the market.
   - Make sure that the adhesive will not get into the supplied drain hose.
     It may cause the flexible part broken after the adhesive is dried up and gets rigid.
   - The flexible drain hose is intended to absorb a small difference at installation of the unit or drain pipes. Intentional bending, expanding may cause the flexible hose broken and water leakage.



   - As for drain pipe, apply VP25 (OD32).
     If apply PVC25 (OD25), connect the expanded connector to the drain hose, with adhesive.
     (Multi unit only)



5. Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway.
   - Pay attention not to give stress on the pipe on the indoor unit side, and support and fix the pipe as close place to the unit as possible when connecting the drain pipe.
   - Do nt set up air vent.



⑥Drain pipe (continued)

●When sharing a drain pipe for more than 1 unit, lay the main pipe 100mm below the drain outlet of the unit. In addition, select VP30 or bigger size for main drain pipe.



6. Insulate the drain pipe.
   ● Be sure to insulate the drain socket and rigid PVC pipe installed indoors otherwise it may cause dew condensation and water leakage.
   ※After drainage test implementation, cover the drain socket part with pipe cover (small size), then use the pipe cover (big size) to cover the pipe cover (small size), clamps and part of the drain hose, and fix and wrap it with tapes to wrap and make joint part gapless.

Drain up

● The position for drain pipe outlet can be raised up to 850mm above the ceiling. Use elbows for installation to avoid obstacles inside ceiling. If the horizontal drain pipe is too long before vertical pipe, the backflow of water will increase when the unit is stopped, and it may cause overflow of water from the drain pan on the indoor unit. In order to avoid overflow, keep the horizontal pipe length and offset of the pipe within the limit shown in the figure below.



Drain test

● After installing the drain pipe, make sure that drain system works correctly and that no water leaks from the joint and drain pan. Check whether the motor sound of the drain pump is normal.
● Conduct a drain test when installing, even during the heating season.
● In the case of new buildings, be sure to complete the test before fixing the ceiling.

1. Pour about 1,000 cc of test water into the drain pan of the indoor unit. Exercise care not to allow electrical equipment such as the drain pump and other components to become wet while filling water.
   Pour test water through the pouring port of the pipe lid using a feed water pump or a similar device, or through the refrigerant pipe joint.

●In case of pouring water from the air outlet



●In case of pouring water from the pouring port of the pipe lid



2. Make sure that water drains out completely and that no water leaks from any joints of the drain pipe during the test.
   Test to confirm that the water drains out correctly while listening to the drain pump motor operating sound.
   At the drain socket (transparent), it is possible to check whether the water drains out correctly.
3. Unplug the rubber plug on the indoor unit so that the remaining water drains from the drain pan after the draining test.
   After checking the water drainage, fix the rubber plug correctly. Installation work for the drain pipe must be performed for the entire drain pipe up to the indoor unit.
   If the pipe lid has been removed in order to pour water, mount the pipe lid again.

Drain pump operation

●In case electrical wiring work completed
Drain pump can be operated by the wired remote control.
For the operation method, refer to Operation for drain pump in the installation manual for wiring work.
●In case electrical wiring work not completed
Drain pump will run continuously when the dip switch"SW7-1" on the indoor unit PCB is turned ON, the connector CnB is disconnected, and then the power source (230VAC on the terminal block ① and ②) is turned ON.
Make sure to turn OFF "SW7-1" and reconnect the connector CnB after the test.

⑦Wiring-out position and wiring connection

● Electrical installation work must be performed according to the installation manual by an electrical installation service provider qualified by a power provider of the country, and be executed according to the technical standards and other regulations applicable to electrical installation in the country.
Be sure to use an exclusive circuit.
● Use specified cord, fasten the wiring to the terminal securely, and hold the cord securely in order not to apply unexpected stress on the terminal.
● Do not put both power source line and signal line on the same route. It may cause miscommunication and malfunction.
● Be sure to do D type earth work.
● For the details of electrical wiring work, see attached instruction manual for electrical wiring work.

1. Loosen the 2 screws of the lid of the control box, and slide the lid in the direction of the arrow shown in the figure. It will then be possible to open the lid.
2. Unhook the lid from the control box, and remove the lid.
3. Remove the 2 screws from the wiring cover, and remove the wiring cover.
4. Hold each wire inside the unit, and securely fasten them to the terminal block.
5. Fix the wiring using clamps.
6. Install the wiring cover and the lid of the control box.

When opening the lid of the control box



When closing the lid of the control box



Main fuse specification

Specification	Part No.
T3.15A L250V	SSA564A149AF

⑦Wiring-out position and wiring connection (continued)

Single Split (PAC) series



VRF (KX) series



⑧Panel installation

●Install the panel on the indoor unit after electrical wiring work.
●Refer to the attached manual for panel installation for details.

⑨Check list after installation

●Check the following items after all installation work completed.

Check if;	Expected trouble	Check
The indoor and outdoor units are fixed securely?	Falling, vibration, noise	
Inspection for leakage is done?	Insufficient capacity	
Insulation work is properly done?	Water leakage	
Water is drained properly?	Water leakage	
Power source voltage is same as mentioned in the model name plate?	PCB burnt out, not working at all	
There is mis-wiring or mis-connection of piping?	PCB burnt out, not working at all	
Earth wiring is connected properly?	Electric shock	
Cable size comply with specified size?	PCB burnt out, not working at all	
Any obstacle blocks airflow on air inlet and outlet?	Insufficient capacity	

⑩How to check the dirt of drain pan and cleanimg the inlet of the drain pump. (Maintenance)

The method of checking the dirt of drain pan

●It is possible to check dirt on the drain pan and drain pump inlet without removing the panel.
1. Open the inlet grille and remove the corner lid on the drain pan side.
2. Remove the drain cap cover (1 screw) from the panel corner.
3. Check the dirt on the drain pan from the drain cap, and check the drain pump inlet. If the drain pan is very dirty, remove the drain pan and clean it.
4. After checking, refix the drain cap cover securely.
   If the cover is not refixed correctly, it may cause condensation to form and/or water to leak.



Cleaning of drain pump inlet

●It is possible to clean the drain pump inlet and surrounding area by removing the drain cap only; it is not necessary to remove the panel and drain pan.
●Before removing the drain cap, remove the rubber plug and drain water from the drain pan.
1. Remove the drain cap cover as described above.
2. Insert the nose of the pliers into the concave portions (2 places) of the drain cap, and rotate the pliers about 1 turn in the CCW direction. The drain cap is removed.
3. When cleaning the drain pump inlet, use a soft plastic tool. If a metallic tool is used, the drain cap mounting portion may be scratched and water may leak.
4. Before mounting the drain cap, rinse it and **remove any foreign material from the inside of the cap.** If the drain cap is installed with foreign material inside it, it may cause water to leak.
5. Insert the nose of the pliers into the concave portions of the drain cap and rotate the pliers to install the drain cap. Rotate the drain cap about 1 turn in the CW direction until it stops rotating. If the drain cap is not rotated for 1 or more turns, the cap will not have been installed correctly.
   Remove the drain cap, and then install it again correctly.
6. After tightening the drain cap, make sure the triangle (△) mark of the drain cap comes close to the triangle mark on the panel. If these triangle marks are not close to each other, tighten the drain cap further.
7. Refix the drain cap cover and rubber plug securely. If the cover is not refixed correctly, it may cause condensation to form and/or water to leak.



Notes for removing the drain pan

●Before removing the drain pan, drain water from the drain pan. Remove the rubber plug and drain water.
●The drain pan is installed by the temporary installation plate. Remove the 2 drain pan fixing screws, and loosen the 2 screws of the temporary installation plate.
Slide the temporary installation plate to the outside of the drain pan. And then,it is possible to remove the drain pan.
●When reinstalling the drain pan, slide the temporary installation plate to the inside and temporarily fix the drain pan. Then, tighten the 2 drain pan fixing screws and the 2 screws of the temporary installation plate. Also, refix the rubber plug securely.



PJF012D037 B

• Panel installation

Read this manual together with the indoor unit's installation manual.

⚠ WARNING

- **Fasten the wiring to the terminal securely and hold the cable securely so as not to apply unexpected stress on the terminal. Loose connection or hold will cause abnormal heat generation or fire.**
- **Make sure the power source is turned off when electric wiring work. Otherwise, electric shock, malfunction and improper running may occur.**

Function

The Anti draft panel has the anti draft mechanism. If the Anti draft panel is installed and the anti draft function is set, the anti draft function will be oprerated and reduce the draft feeling. (Refer to ⑩ Panel setting for details.)

- Standard panel : without the anti draft mechanism
- Anti draft panel : with the anti draft mechanism

① Before installation

- Follow installation manual carefully, and install the panel properly.
- Check the following items.

○ Accessories

Accessories

Bolt		4 pieces	For panel installation
Strap		4 pieces	For avoiding the corner panel from falling
Screw		4 pieces	For fixing the corner panel

Note: Accessories are laid in the position removing the corner lid.



Accessories holding position

② Checking the indoor unit installation position

- Read this manual together with the air-conditioner installation manual carefully.
- Check if the opening size for the indoor unit is correct with the level gauge supplied in the indoor unit.
- Check if the gap between the plane and the indoor unit is correct by inserting the level gauge into the air outlet port of the indoor unit. (See below drawing)
- Adjust the installation elevation if necessary.
- Remove the level gauge before installing the panel.

Caution

If there is a height difference beyond the design limit between the installation level of the indoor unit and the panel, the panel may be subject to excessive stress during installation and it may cause distortion and damage.



- The installation level of the indoor unit can be adjusted finely from the opening provided on the corner, even after panel is Installed. (Refer to ⑥ Installing the panel for details.)

③ Removing the inlet grille

1. Hold the stoppers on the inlet grille (2 places) toward OPEN direction, open the inlet grille.
2. Remove the hooks of the inlet grille from the panel while it is in the open position.



④ Removing the corner lid

- Pull the corner lid toward the direction indicated by the arrow and remove it. (Same way for all 4 corner lids)



⑤ Orientation of the panel installation

Take note that there is an orientation to install the panel.

- Install the panel with the orientation shown on the right.
- Align the "PIPE SIDE" mark (on the panel) with the refrigerant pipes on the indoor unit.
- Align the "DRAIN" mark (on the panel) with the drain pipe on the indoor unit.

CAUTION

In case the orientation of the panel is not correct, it will lead to air leakage and also it is not possible to connect the flap motor wiring.



⑥ Installing the panel

1. Temporary hanging
   - Lift up the hanger (2 places) on the panel for temporary support.
   - Hang the panel on the hook on the indoor unit.





The Anti draft panel moves the parts of the anti draft mechanism (shaded area,4 places).Note that they may break if they are moved forcibly by hand. Although the parts (shaded area) of the Standard panel are separate parts from the body, they do not move.

Caution

- The parts (shaded area), of the anti draft mechanism around the air outlet, are separate parts. Handle the panel with care. Especialy, the shaded area of the Anti draft panel move. Note that they may break if they are moved forcibly by hand.

2. Fix the panel on the indoor unit
   - Fasten the panel on the indoor unit with the 4 bolts supplied with the panel.

Caution

- Improperly tightened fixing bolts cause the problems listed below, so make sure that bolts are securely tightened.
- If there is a gap between the ceiling and the panel even after the fixing bolts are tightened, adjust the installation level of the indoor unit again.





- It is possible to adjust the installation height of the indoor unit with the panel installed as long as there is no influence on the drain pipe inclination and/or the indoor unit levelness.



To adjust finely, please turn a nut fastening the indoor unit using a spanner or similar tool from the opening on the corner.

Bolt for installing the panel

Caution

Do not give any stress on the panel when adjusting the height of the indoor unit to avoid unexpected distortion. It may cause the distortion of panel or failing to close the inlet grille, and the parts of the anti draft mechanism.

⑦ Electrical wiring

The wiring work varies depending on the panel type. Select the wiring work appropriate for the panel type.
The connection positions of the indoor unit are as shown below irrespective of the panel type.



<For the Standard panel>
1. Loosen 2 screws on the control box lid of the indoor unit, and remove the lid by sliding it.
2. Pass the flap motor wiring (20-wire) through the hook of the control box, and connect to CnJ1 (20P, white).
3. Fix the control box lid of the indoor unit, and tighten 2 screws.

For the Standard panel



<For the Anti draft panel>
1. Loosen 2 screws on the control box lid of the indoor unit, and remove the lid by sliding it.
2. Pass the flap motor cable (20-wire) through the hook of the control box, and connect to CnJ1 (20P, white).
3. Pass the anti draft motor cable (20-wire) through the hook of the control box, and connect to CnJ2 (20P, white).
4. Fix the control box lid of the indoor unit, and tighten the 2 screws.

For the Anti draft panel



⑧ Installing a corner lid

1. To avoid unexpected falling of the corner lid, put the strap onto the corner lid's pin with turning the strap up.
2. Then hang the strap of a corner lid onto the panel's pin.
3. First insert the part "a" of a corner lid into the part "A" of the panel, and then engage 2 hooks.
4. Fix with screw.



⑨ Installing the inlet grille

To attach the inlet grille, follow the procedure described in ⑤ Removing the inlet grille in the reverse order.
1. Hang the hooks of the inlet grille in the hole of the panel. (The hooks of the grille can be hanged in 4 side of the panel as following.)
2. After the grille is hanged, close the grille while the stoppers(2 places) on the grille are kept pressed to "OPEN" direction. When the grille comes to the original position, release the stoppers to hold the grille. Make sure to hear the sound of "CLICK" in both stoppers.

<Installation>



Caution

- Installing the inlet grille from the hinge side.
- Be careful in the inlet grille Installing, unstable installing may cause grille falling.
- Repair or replace the distorted, broken stopper at once, or the grille falling may occur.

⑩ Panel setting

<Flap swing range setting (Individual flap cotrol setting)>

It is possible to change the swing range of the flap by the wired remote control. Once the upper and lower limit positions are set, the flap will swing within the set range.It is also possible to set the different range to each flap.

<Anti draft setting>

The anti draft function will not be operated if the anti draft panel is installed and its wirings are only connected. To operate the anti draft function, enable the anti draft setting by using the wired or wireless remote control.

Note: It is not possible to set by the following remote control models or older.
Wired:RC-EX1A, RC-E5, RCH-E3
Wireless: RCN-E1R

Once you have enabled the settings in this mode, the anti draft function is operated when the air-conditioner is started, and the parts of the anti draft mechanism are always open when the air-conditioner is operating. When the air-conditioner is stopped, they are closed. It is possible to enabled or disabled the anti draft function for each air outlet.

For the setting details, refer to the user's manual supplied with the remote control.

PJF012D509 A

(2) Ceiling cassette-4 way compact type(FDTC)

This manual is for the installation of the indoor unit.
For electrical wiring work (Indoor unit), refer to page 195. For remote control installation, refer to page 199. For wireless kit installation, refer to page 362. For electrical wiring work (Outdoor unit) and refrigerant pipe work installation for outdoor unit, refer to page 211. For motion sensor kit installation, refer to page 390.
This unit must always be used with the panel.

SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, ⚠WARNING and ⚠CAUTION .
  ⚠WARNING : Wrong installation would cause serious consequences such as injuries or death.
  ⚠CAUTION : Wrong installation might cause serious consequences depending on circumstances.
  Both mentions the important items to protect your health and safety so strictly follow them by any means.
- The meanings of "Marks" used here are as shown on the right:
  ⃠ Never do it under any circumstances. | ❗ Always do it according to the instruction.
- After completing the installation, do commissioning to confirm there are no abnormalities, and explain to the customers about "SAFETY PRECAUTIONS", correct operation method and maintenance method (air filter cleaning, operation method and temperature setting method) with user's manual of this unit.
  Ask your customers to keep this installation manual together with the user's manual. Also, ask them to hand over the user's manual to the new user when the owner is changed.

⚠WARNING

- **Installation should be performed by the specialist.**
  If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Install the system correctly according to these installation manuals.**
  Improper installation may cause explosion, injury, water leakage, electric shock, and fire.
- **Check the density refered by the foumula (accordance with ISO5149).**
  If the density exceeds the limit density, please consult the dealer and installate the ventilation system.
- **Use the genuine accessories and the specified parts for installation.**
  If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Ventilate the working area well in case the refrigerant leaks during installation.**
  If the refrigerant contacts the fire, toxic gas is produced.
  In case of R32, the refrigerant could be ignited because of its flammability.
- **Install the unit in a location that can hold heavy weight.**
  Improper installation may cause the unit to fall leading to accidents.
- **Install the unit properly in order to be able to withstand strong winds such as typhoons, and earthquakes.**
  Improper installation may cause the unit to fall leading to accidents.
- **Do not mix air in to the cooling cycle on installation or removal of the air-conditioner.**
  If air is mixed in, the pressure in the cooling cycle will rise abnormally and may cause explosion and injuries.
- **Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.**
  Power source with insufficient capacity and improper work can cause electric shock and fire.
- **Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in order not to apply unexpected stress on the terminal.**
  Loose connections or hold could result in abnormal heat generation or fire.
- **Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services panel property.**
  Improper fitting may cause abnormal heat and fire.
- **Check for refrigerant gas leakage after installation is completed.**
  If the refrigerant gas leaks into the house and comes in contact with a fan heater, a stove, or an oven, toxic gas is produced.
- **Use the specified pipe, flare nut, and tools for R32 or R410A.**
  Using existing parts (R22) could cause the unit failure and serious accident due to explosion of the cooling cycle.
- **Tighten the flare nut according to the specified method by with torque wrench.**
  If the flare nut were tightened with excess torque, it could cause burst and refrigerant leakage after a long period.
- **Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulfide gas can occur.**
  Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.
- **Connect the pipes for refrigeration circuit securely in installation work before compressor is operated.**
  If the compressor is operated when the service valve is open without connecting the pipe, it could cause explosion and injuries due to abnormal high pressure in the system.
- **Stop the compressor before removing the pipe after shutting the service valve on pump down work.**
  If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.
- **Only use prescribed option parts. The installation must be carried out by the qualified installer.**
  If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.
- **Do not repair by yourself. And consult with the dealer about repair.**
  Improper repair may cause water leakage, electric shock or fire.
- **Consult the dealer or a specialist about removal of the air-conditioner.**
  Improper installation may cause water leakage, electric shock or fire.
- **Turn off the power source during servicing or inspection work.**
  If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.
- **Do not run the unit when the panel or protection guard are taken off.**
  Touching the rotating equipment, hot surface, or high voltage section could cause an injury to be caught in the machine, to get burned, or electric shock.
- **Shut off the power before electrical wiring work.**
  It could cause electric shock, unit failure and improper running.

⚠ CAUTION

- **Perform earth wiring surely.**
  Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Improper earth could cause unit failure and electric shock due to a short-circuit.
- **Earth leakage breaker must be installed.**
  If the earth leakage breaker is not installed, it can cause electric shocks.
- **Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.**
  Using the incorrect one could cause the system failure and fire.
- **Do not use any materials other than a fuse of correct capacity where a fuse should be used.**
  Connecting the circuit by wire or copper wire could cause unit failure and fire.
- **Do not install the indoor unit near the location where there is possibility of flammable gas leakages.**
  If the gas leaks and gathers around the unit, it could cause fire.
- **Do not install and use the unit where corrosive gas (such as sulfurous acid gas etc.) or flammable gas (such as thinner, petroleum etc.) may be generated or accumulated, or volatile flammable substances are handled.**
  It could cause the corrosion of heat exchanger, breakage of plastic parts etc. And inflammable gas could cause fire.
- **Secure a space for installation, inspection and maintenance specified in the manual.**
  Insufficient space can result in accident such as personal injury due to falling from the installation place.
- **Do not use the indoor unit at the place where water splashes such as laundry.**
  Indoor unit is not waterproof. It could cause electric shock and fire.
- **Do not use the indoor unit for a special purpose such as food storage, cooling for precision instrument, preservation of animals, plants, and a work of art.**
  It could cause the damage of the items.
- **Do not install nor use the system near equipments which generate electromagnetic wave or high harmonics.**
  Equipments like inverter equipment, private power generator, high-frequency medical equipment, or telecommunication equipment might influence the air-conditioner and cause a malfunction and breakdown. Or the air-conditioner might influence medical equipments or telecommunication equipments, and obstruct their medical activity or cause jamming.
- **Do not install the remote control at the direct sunlight.**
  It could cause breakdown or deformation of the remote control.
- **Do not install the indoor unit at the place listed below.**
  · Places where flammable gas could leak.
  · Places where carbon fiber, metal powder or any powder is floated.
  · Place where the substances which affect the air conditioner are generated such as sulfide gas, chloride gas, acid, alkali or ammonic atmospheres.
  · Places exposed to oil mist or steam directly.
  · On vehicles and ships
  · Places where machinery which generates high harmonics is used.
  · Places where cosmetics or special sprays are frequently used.
  · Highly salted area such as beach.
  · Heavy snow area
  · Places where the system is affected by smoke from a chimney.
  · Altitude over 1000m
- **Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation)**
  · Locations with any obstacles which can prevent inlet and outlet air of the unit
  · Locations where vibration can be amplified due to insufficient strength of structure.
  · Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam. (in case of the infrared specification unit)
  · Locations where an equipment affected by high harmonics is placed. (TV set or radio receiver is placed within 5m)
  · Locations where drainage cannot run off safely.
  It can affect performance or function and etc..
  Do not install the motion sensor mounting panel at following places. It could cause detection error, incapacity of detection, or characteristic degradation.
  • Place where vibration is applied to it for a long period of time.
  • Place where static electricity or electromagnetic wave generates.
  • Place where it is exposed to high temperature or humidity for a long period of time.
  • Dusty place or where the lens face could be fouled or damaged.
- **Do not put any valuables which will break down by getting wet under the air-conditioner.**
  Condensation could drop when the relative humidity is higher than 80% or drain pipe is clogged, and it damages user's belongings.
- **Do not use the base frame for the outdoor unit which is corroded or damaged after a long period of use.**
  It could cause the unit falling down and injury.
- **Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit.**
  If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit.
- **Install the drain pipe to drain the water surely according to the installation manual.**
  Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.
- **Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.**
  If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents.
- **For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding.**
  Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance.
- **Ensure the insulation on the pipes for refrigeration circuit so as not to condense water.**
  Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables.
- **Do not install the outdoor unit where is likely to be a nest for insects and small animals.**
  Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean.
- **Pay extra attention, carrying the unit by hand.**
  Carry the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective gloves in order to avoid injury by the aluminum fin.
- **Make sure to dispose of the packaging material.**
  Leaving the materials may cause injury as metals like nail and woods are used in the package.
- **Do not operate the system without the air filter.**
  It may cause the breakdown of the system due to clogging of the heat exchanger.
- **Do not touch any button with wet hands.**
  It could cause electric shock.
- **Do not touch the refrigerant piping with bare hands when in operation.**
  The pipe during operation would become very hot or cold according to the operating condition, and it could cause a burn or frostbite.
- **Do not clean up the air-conditioner with water.**
  It could cause electric shock.
- **Do not turn off the power source immediately after stopping the operation.**
  Be sure to wait for more than 5 minutes. Otherwise it could cause water leakage or breakdown.
- **Do not control the operation with the circuit breaker.**
  It could cause fire or water leakage. In addition, the fan may start operation unexpectedly and it may cause injury.

①Before installation

- Install correctly according to the installation manual.
- Confirm the following points:
  - ○Unit type/Power source specification
  - ○Pipes/Wires/Small parts ○Accessory items

When moving the indoor unit, hold only the hanging hardware (4 places) only, with care not to apply forces to any other parts of the unit (particularly the refrigerant pipe, drain pipe, and resin parts).

Accessory item

For unit hanging		For refrigerant pipe			For drain pipe			
Flat washer (M10)	Level gauge	Pipe cover(big)	Pipe cover (small)	Strap	Pipe cover(big)	Pipe cover(small)	Drain hose	Hose clamp
8	1	1	1	4	1	1	1	1
For unit hanging	For unit height position adjustment and hanging support	For heat insulation of gas pipe	For heat insulation of liquid tube	For pipe cover fixing	For heat insulation of drain socket	For heat insulation of drain socket	For drain pipe connecting	For drain hose mounting

②Selection of installation location for the indoor unit

① Select the suitable areas to install the unit under approval of the user.

- Areas where the indoor unit can deliver hot and cold wind sufficiently. Suggest to the user to use a circulator if the ceiling height is over 3m to avoid warm air being accumulated on the ceiling.
- In case of the panel having the motion sensor, the installation height must be no higher than 4 m. It could reduce the sensitivity of motion sensor, disabling the detection.
- Areas where there is enough space to install and service.
- Areas where it can be drained properly. Areas where drain pipe descending slope can be taken.
- Areas where there is no obstruction of air flow on both air return grille and air supply port.
- Areas where fire alarm will not be accidentally activated by the air-conditioner.
- Areas where the supply air does not short-circuit.
- Areas where it is not influenced by draft air.
- Areas not exposed to direct sunlight.
- Areas where dew point is lower than around 28°C and relative humidity is lower than 80%. This indoor unit is tested under the condition of JIS (Japan Industrial Standard) high humidity condition and confirmed there is no problem. However, there is some risk of condensation drop if the air-conditioner is operated under the severer condition than mentioned above. If there is a possibility to use it under such a condition, attach additional insulation of 10 to 20mm thick for entire surface of indoor unit, refrigeration pipe and drain pipe.
- Areas where TV and radio stays away more than 1m. (It could cause jamming and noise.)
- Areas where any items which will be damaged by getting wet are not placed such as food, table wares, server, or medical equipment under the unit.
- Areas where there is no influence by the heat which cookware generates.
- Areas where not exposed to oil mist, powder and/or steam directly such as above fryer.
- Areas where lighting device such as fluorescent light or incandescent light doesn't affect the operation. (A beam from lighting device sometimes affects the infrared receiver for the wireless remote control and the air-conditioner might not work properly.)

②Check if the place where the air-conditioner is installed can hold the weight of the unit. If it is not able to hold, reinforce the structure with boards and beams strong enough to hold it. If the strength is not enough, it could cause injury due to unit falling.

③If there are 2 units of wireless type, keep them away for more than 6m to avoid malfunction due to cross communication.

④When plural indoor units are installed nearby, keep them away for more than 4m.

Space for installation and service

- When it is not possible to keep enough space between indoor unit and wall or between indoor units, close the air supply port where it is not possible to keep space and confirm there is no short-circuit of air flow.
- Install the indoor unit at a height of more than 2.5m above the floor.



Where there are pipe joints on the way of embedded piping, provide adequate openings for inspection of the joints.

Set blow-out pattern

- Select the most proper number of blow-out air supply port direction from 4 way, 3 way or 2 way according to the shape of the room and installation position. (1 way is not available.)
- If it is necessary to change the number of air supply port, prepare the covering materials. (sold as accessory)
- Instruct the user not to use low fan speed when 2way or 3way air supply is used.
- Do not use 2way air supply port under high temperature and humidity environment. (Otherwise it could cause condensation and leakage of water.)
- It is possible to set the air flow direction port by port independently. Refer to tne user's manual for details.

③Preparation before installation

- If suspension bolt becomes longer, do reinforcement of earthquake resistant.
  - ○For grid ceiling
    When suspension bolt length is over 500mm, or the gap between the ceiling and roof is over 700mm, apply earthquake resistant brace to the bolt.
  - ○In case the unit is hanged directly from the slab and is installed on the ceiling plane which has enough strength.
    When suspension bolt length is over 1000mm, apply the earthquake resistant brace to the bolt.
- Prepare four (4) sets of suspension bolt, nut and spring washer (M10 or M8) on site.

Ceiling opening, Suspension bolts pitch, Pipe position

Symbol	Content
A	Gas piping
B	Liquid piping
C	Drain piping
D_1	Power source connection
D_2	Remote control code and signal wiring connection
F	Suspension bolts
G	Outside air opening for ducting
H	Air outlet opening for ducting
J	Inspection opening

Inspection opening



* In case of other than the system ceiling,install an inspection opening at the control box side.



④Installation of indoor unit

Work procedure

1. This unit is designed to install on a system ceiling.
   If necessary, remove T bars temporarily before installing the unit.
   When it is installed on a ceiling other than the system ceiling, install an inspection port at the control box side.
2. Determine the position of suspension bolts (530 mm × 530 mm).
3. Use 4 suspension bolts, and fix them such that each bolt can withstand a pull-out load of 500 N.
4. Set the suspension bolt length to about 50 mm from the ceiling.
5. Temporarily locate the lower nuts of the suspension bolts (4 places) at a position approximately 130 mm from the ceiling.
6. Temporarily locate the upper nuts of the suspension bolts (4 places) at positions sufficiently distance from the lower nuts so that they do not interfere with the suspension of the indoor unit and with its height adjustment.
7. Set the upper nuts of the suspension bolts and upper washers (4 places) at positions sufficiently distance from the lower nuts. Then, push and insert the temporary fixing carton of washers (*1) onto suspension bolts. Make sure that the upper washers do not slide down.
8. Suspend the indoor unit.
9. After suspending the indoor unit, mount the level gauge (*2) to the air outlet of the indoor unit, and adjust the suspension height of the indoor unit. Loosen the upper nuts (4 places), and adjust the suspension height using the lower nuts (4 places). Confirm there is no slack between the lower nuts and flat washers of the indoor unit hanger plate (4 places).
10. Remove the temporary fixing carton of washers (from all 4 places).
11. Make sure that the indoor unit is installed horizontally. Confirm the levelness of the indoor unit using a level gauge or transparent hose filled with water. (Keep the height difference at both ends of the indoor unit within 3 mm.)
12. Tighten the upper nuts of the suspension bolts (4 places).



<In case of other than the system ceiling>



<In case of the system ceiling:>



④Installation of indoor unit (continued)

Protection of the indoor unit

● If it is not possible to install the panel for a while or if attaching the ceiling board after installing the indoor unit, protect the indoor unit by using upper carton.



Caution

● Do not adjust the unit height by adjusting the upper nuts. Doing so will cause unexpected stress on the indoor unit and cause the unit to become deformed, prevent the panel from being installed, and be generated fan interference noise.
● Make sure that the indoor unit is installed horizontally and set the appropriate gap between the underside of the unit and the ceiling plane. Improper installation may cause air leakage, dew condensation, water leakage and noise.
● Make sure there is no gap between the panel and the ceiling surface, and between the panel and the indoor unit. Any gap may cause air and/or water to leak, or condensation to form.

⑤Refrigerant pipe

Caution

●Be sure to use new pipes for the refrigerant pipes. Use the flare nut attached to the product.
Regarding whether existing pipes can be reused or not, and the washing method, refer to the instruction manual of the outdoor unit, catalogue or technical data.
1) In case of reuse: Do not use old flare nut, but use the nut attached to the unit.
2) In case of reuse: Flare the end of pipe replaced partially for R32 or R410A.
⚠WARNING : When flared joints are reused indoors, the flare part shall be re-fabricated. (only for R32)



Pipe dia. d mm	Min. pipe wall thickness mm	Protruding dimension for flare, mm		Flare O.D. D mm	Flare nut tightening torque N·m
		Rigid (Clutch type)			
		For R32 For R410A	Conventional tool		
6.35	0.8	0 – 0.5	0.7 – 1.3	8.9 – 9.1	14 – 18
9.52	0.8			12.8 – 13.2	34 – 42
12.7	0.8			16.2 – 16.6	49 – 61
15.88	1			19.3 – 19.7	68 – 82
19.05	1.2			23.6 – 24.0	100 – 120

●Use phosphorus deoxidized copper alloy seamless pipe (C1220T) for refrigeration pipe installation. In addition, make sure there is no damage both inside and outside of the pipe, and no harmful substances such as sulfur, oxide, dust or a contaminant stuck on the pipes.
●Do not use any refrigerant other than the designated refrigerant.
Using other refrigerant except the designated refrigerant, may degrade inside refrigeration oil. And air getting into refrigeration circuit may cause over-pressure and resultant it may result in bursting, etc.
●Store the copper pipes indoors and seal the both end of them until they are brazed in order to avoid any dust, dirt or water getting into pipe. Otherwise it will cause degradation of refrigeration oil and compressor breakdown, etc.
●Use special tools for R32 or R410A refrigerant.

Work procedure

1. Remove the flare nut and blind flanges on the pipe of the indoor unit.
※ Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them. (Gas may come out at this time, but it is not abnormal.)
●Pay attention whether the flare nut pops out. (as the indoor unit is sometimes pressured.)
2. Make a flare on liquid pipe and gas pipe, and connect the refrigeration pipes on the indoor unit.
※Bend radius of pipe must be 4D or larger. Once a pipe is bent, do not readjust the bending. Do not twist a pipe or collapse to 2/3D or smaller.
● Make sure to use flare nuts assembled on the unions. Usage of other flare nuts could cause refrigerant leakage.
※Do a flare connection as follows:
●Make sure to hold the nut on indoor unit pipe side using double spanner method as indicated when fastening / loosening flare nuts in order to prevent unintentional twisting of the copper pipe.
● When fastening the flare nut, align the refrigeration pipe with the center of flare nut, screw the nut for 3-4 times by hand and then tighten it by spanner with the specified torque mentioned in the table above.



3. Cover the flare connection part of the indoor unit with attached insulation material after a gas leakage inspection, and tighten both ends with attached straps.
● Make sure to insulate both gas pipes and liquid pipes completely.
※ Incomplete insulation may cause dew condensation or water dropping.
● Use heat-resistant (120 °C or more) insulations on the gas side pipes.
● In case of using at high humidity condition, reinforce insulation of refrigerant pipes. Surface of insulation may cause dew condition or water dropping, if insulations are not reinfoced.
4. Refrigerant is charged in the outdoor unit.
As for the additional refrigerant charge for the indoor unit and piping, refer to the installation manual attached to the outdoor unit.

⑤Refrigerant pipe (continued)

Caution:
Refrigerating machine oil should not be applied to the threads of union or external surface of flare. It is because, even if the same tightening torque is applied, the oil is likely to decrease the slide friction force on the threads and increase, in turn, the axial component force so that it could crack the flare by the stress corrosion.
Refrigerating machine oil may be applied to the internal surface of flare only.

<The case of using thicness of insulation is 10mm>



<The case of using reinfoced insulation>



⑥Drain pipe

Caution

● Install the drain pipe according to the installation manual in order to drain properly.
Imperfection in draining may cause flood indoors and wetting the household goods,etc.
● Do not put the drain pipe directly into the ditch where toxic gas such as sulfur, the other harmful and inflammable gas is generated. Toxic gas would flow into the room and it would cause serious damage to user's health and safety (some poisoning or deficiency of oxygen). In addition, it may cause corrosion of heat exchanger and bad smell.
● Connect the pipe securely to avoid water leakage from the joint.
● Insulate the pipe properly to avoid condensation drop.
● Check if the water can flow out properly from both the drain outlet on the indoor unit and the end of the drain pipe after installation.
● Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway. In addition, do not put air vent on the drain pipe. Check if water is drained out properly from the pipe during commissioning. Also, keep sufficient space for inspection and maintenance.

Work procedure

1. Make sure that the drain hose (the soft PVC side) is inserted into the end of the step part of the drain socket.
Fix the hose clamp so that its bolt is located on the outside of the indoor unit, and the bolt are fastened in a vertical orientation.
●Do not apply adhesives on this end.
2. Position the hose clamp so that it touches the insulation of the drain hose, and then tighten the bolt.
3. Turn the bolt several times until it is securely tightened, but do not tighten it excessively.



4. Prepare a joint for connecting VP25 pipe, adhere and connect the joint to the drain hose (the rigid PVC side), and adhere and connect VP25 pipe (prepare on site).
※As for drain pipe, apply VP25 made of rigid PVC which is on the market.
● Make sure that the adhesive will not get into the supplied drain hose.
It may cause the flexible part broken after the adhesive is dried up and gets rigid.
● The flexible drain hose is intended to absorb a small difference at installation of the unit or drain pipes. Intentional bending, expanding may cause the flexible hose broken and water leakage.



● As for drain pipe, apply VP25 (OD32).
If apply PVC25 (OD25), connect the expanded connector to the drain hose, with adhesive. (Multi unit only)



5. Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway.
● Pay attention not to give stress on the pipe on the indoor unit side, and support and fix the pipe as close place to the unit as possible when connecting the drain pipe.
● Do nt set up air vent.



⑥Drain pipe (continued)

● When sharing a drain pipe for more than 1 unit, lay the main pipe 100mm below the drain outlet of the unit. In addition, select VP30 or bigger size for main drain pipe.



6. Insulate the drain pipe.
● Be sure to insulate the drain socket and rigid PVC pipe installed indoors otherwise it may cause dew condensation and water leakage.
※ After drainage test implementation, cover the drain socket part with pipe cover (small size), then use the pipe cover (big size) to cover the pipe cover (small size), clamps and part of the drain hose, and fix and wrap it with tapes to wrap and make joint part gapless.

Drain up

● The position for drain pipe outlet can be raised up to 850mm above the ceiling. Use elbows for installation to avoid obstacles inside ceiling. If the horizontal drain pipe is too long before vertical pipe, the backflow of water will increase when the unit is stopped, and it may cause overflow of water from the drain pan on the indoor unit. In order to avoid overflow, keep the horizontal pipe length and offset of the pipe within the limit shown in the figure below.



Drain test

● After installing the drain pipe, make sure that drain system works correctly and that no water leaks from the joint and drain pan. Check whether the motor sound of the drain pump is normal.
● Conduct a drain test when installing, even during the heating season.
● In the case of new buildings, be sure to complete the test before fixing the ceiling.

1. Pour about 1,000 cc of test water into the drain pan of the indoor unit. Exercise care not to allow electrical equipment such as the drain pump and other components to become wet while filling water.
Pour test water through the pipe lid using a feed water pump or a similar device, or through the refrigerant pipe joint.

● In case of pouring water from the air outlet



● In case of pouring water from the pipe lid
(1) Remove screws at 2 places.
(2) Release the claws, and remove the lid.



2. Make sure that water drains out completely and that no water leaks from any joints of the drain pipe during the test.
Test to confirm that the water drains out correctly while listening to the drain pump motor operating sound. At the drain socket (transparent), it is possible to check whether the water drains out correctly.
3. Unplug the rubber plug on the indoor unit so that the remaining water drains from the drain pan after the draining test.
After checking the water drainage, fix the rubber plug correctly. Installation work for the drain pipe must be performed for the entire drain pipe up to the indoor unit.
If the pipe lid has been removed in order to pour water, mount the pipe lid again.

Drain pump operation

● In case electrical wiring work completed
Drain pump can be operated by the wired remote control.
For the operation method, refer to Operation for drain pump in the installation manual for wiring work.
● In case electrical wiring work not completed
Drain pump will run continuously when the dip switch"SW7-1" on the indoor unit PCB is turned ON, the connector CnB is disconnected, and then the power source (230VAC on the terminal block ① and ②) is turned ON.
Make sure to turn OFF "SW7-1" and reconnect the connector CnB after the test.

⑦Wiring-out position and wiring connection

● Electrical installation work must be performed according to the installation manual by an electrical installation service provider qualified by a power provider of the country, and be executed according to the technical standards and other regulations applicable to electrical installation in the country.
Be sure to use an exclusive circuit.
● Use specified cord, fasten the wiring to the terminal securely, and hold the cord securely in order not to apply unexpected stress on the terminal.
● Do not put both power source line and signal line on the same route. It may cause miscommunication and malfunction.
● Be sure to do D type earth work.
● For the details of electrical wiring work, see attached instruction manual for electrical wiring work.

1. Loosen screws (2 pcs.) on the control box of the unit.
2. Remove the control lid by sliding it in the arrow direction in the figure.
3. Introduce the wiring in the control box, and connect it securely to the terminal block.
4. Fix the wiring with bands as shown below.
5. Install the control lid, with care not to pinch the wiring, and fix the lid with screws (2 pcs.).



Main fuse specification

Specification	Part No.
T3.15A L250V	SSA564A149AF

⑧Panel installation

● Install the panel on the indoor unit after electrical wiring work.
● Refer to the attached manual for panel installation for details.

⑨Check list after installation

● Check the following items after all installation work completed.

Check if;	Expected trouble	Check
The indoor and outdoor units are fixed securely?	Falling, vibration, noise	
Inspection for leakage is done?	Insufficient capacity	
Insulation work is properly done?	Water leakage	
Water is drained properly?	Water leakage	
Power source voltage is same as mentioned in the model name plate?	PCB burnt out, not working at all	
There is mis-wiring or mis-connection of piping?	PCB burnt out, not working at all	
Earth wiring is connected properly?	Electric shock	
Cable size comply with specified size?	PCB burnt out, not working at all	
Any obstacle blocks airflow on air inlet and outlet?	Insufficient capacity	

⑩How to check the dirt of drain pan and cleanimg the inlet of the drain pump. (Maintenance)

The method of checking the dirt of drain pan

1. Remove the panel according to the installation manual of the panel.
2. Check the dirt on the drain pan from the drain cap, and check the drain pump inlet. If the drain pan is very dirty, remove the drain pan and clean it.



Cleaning of drain pump inlet

● It is possible to clean the drain pump inlet and surrounding area by removing the drain cap only; it is not necessary to remove the drain pan.
● Before removing the drain cap, remove the rubber plug and drain water from the drain pan.

1. Insert the nose of the pliers into the concave portions (2 places) of the drain cap, and rotate the pliers about 1 turn in the CCW direction. The drain cap is removed.
2. When cleaning the drain pump inlet, use a soft plastic tool. If a metallic tool is used, the drain cap mounting portion may be scratched and water may leak.
3. Before mounting the drain cap, rinse it and **remove any foreign material from the inside of the cap.** If the drain cap is installed with foreign material inside it, it may cause water to leak.
4. Insert the nose of the pliers into the concave portions of the drain cap and rotate the pliers to install the drain cap. Rotate the drain cap about 1 turn in the CW direction until it stops rotating. If the drain cap is not rotated for 1 or more turns, the cap will not have been installed correctly. Remove the drain cap, and then install it again correctly.
5. After tightening the drain cap, make sure the triangle ( ) mark of the drain cap comes close to the triangle mark on the drain pan. If these triangle marks are not close to each other, tighten the drain cap further.
6. Refix the rubber plug securely. If the cover is not refixed correctly, it may cause condensation to form and/or water to leak.



Notes for removing the drain pan

● Before removing the drain pan, drain water from the drain pan. Remove the rubber plug and drain water.
● The drain pan is installed by the temporary installation plate. Remove the 2 drain pan fixing screws, and loosen the 2 screws of the temporary installation plate.
Slide the temporary installation plate to the outside of the drain pan. And then,it is possible to remove the drain pan.
● When reinstalling the drain pan, slide the temporary installation plate to the inside and temporarily fix the drain pan. Then, tighten the 2 drain pan fixing screws and the 2 screws of the temporary installation plate. Also, refix the rubber plug securely.



• Panel installation

PJF012D503 A

Read this manual together with the indoor unit's installation manual.

* Caution before use

①Be careful the installation height when installing the indoor unit.
Also note that the installation height of this indoor unit is different from that of current (old) unit.

Installation height from the ceiling surface to the indoor unit.
・Old unit: 30 mm ⇒ This unit: 35 +4 0 mm



* Unless the indoor unit is installed at the height as specified above, moisture may frost or condensate, staining the ceiling surface.

②Do not attempt to move forcibly the louver and the air flex.



⚠ WARNING

- **Fasten the wiring to the terminal securely and hold the cable securely so as not to apply unexpected stress on the terminal. Loose connection or hold will cause abnormal heat generation or fire.**
- **Make sure the power source is turned off when electric wiring work. Otherwise, electric shock, malfunction and improper running may occur.**

Function

The draft prevention panel has the draft prevention mechanism. If the draft prevention panel is installed and the draft prevention function is set, the draft prevention function will be operated and reduce the draft feeling. (Refer to ⑪ Panel setting for details.)
・Standard panel : without the draft prevention mechanism
・Draft prevention panel : with the draft prevention mechanism

① Before installation

・Follow installation manual carefully, and install the panel properly.
・Check the following items.
○ Accessories

Accessories

Bolt		4 pieces	For panel installation
Strap		4 pieces	For avoiding the corner panel from falling
Grille hook		1 piece	For avoiding the grille from falling
Screw		4 pieces	For fixing the corner panel

Note: Accessories are laid in the position removing the corner lid.



② Checking the indoor unit installation height

・Read this manual together with the air-conditioner installation manual carefully.
・Check if the opening size for the indoor unit is correct with the level gauge supplied in the indoor unit.
・Check if the gap between the plane and the indoor unit is correct by inserting the level gauge into the air outlet port of the indoor unit. (See below drawing)
・Adjust the installation elevation if necessary.
・Remove the level gauge before installing the panel.

Caution
If there is a height difference beyond the design limit between the installation level of the indoor unit and the panel, the panel may be subject to excessive stress during installation and it may cause distortion and damage.

<In case of other than the system ceiling>



<In case of the system ceiling>



③ Removing the inlet grille

1. While placing a finger behind the stopper (2 places) and pressing it in the direction of arrow ①, pull the grille downward to open the grille.
2. Release the hooks of the inlet grille from the panel while it is in the open position.



④ Removing the corner lid

・Pull the corner lid toward the direction indicated by the arrow and remove it. (Same way for all 4 corner lids)



⑤ Before installing the panel <Only Draft prevention panel>

① Loosen screws (2 pcs.) on the control lid of the unit.
② Slide the control lid in the arrow direction in the figure, and remove it.
③ Loosen screws on the wiring cover (2 places).
④ Slide the wiring cover (2 places) in the arrow direction in the figure, and remove it.
⑤ Disconnect the relay connector of the air flex motor wiring attached to the panel.
⑥ Connect the air flex motor wiring to CNJ2 (20 P, gray) on PCB in the control box of the unit.
⑦ Pass the air flex motor wiring as shown in the figure.
⑧ Install the wiring cover (1 place) with care not to pinch wiring, and fix it with a screw.
⑨ Fix the air flex motor wiring with a band as shown in the figure.
⑩ Install the control lid with care not to pinch wiring, and fix with screws (2 places,).



⑥ Orientation of the panel installation

Take note that there is an orientation to install the panel.
- Install the panel with the orientation shown on the right.
- Align the "PIPE SIDE" mark (on the panel) with the refrigerant pipes on the indoor unit.
- Align the "DRAIN" mark (on the panel) with the drain pipe on the indoor unit.



CAUTION
In case the orientation of the panel is not correct, it will lead to air leakage and also it is not possible to connect the motor wiring.

⑦ Installing the panel

1. Temporary hanging
   - Lift up the hanger (2 places) on the panel for temporary support.
   - Hang the panel on the hook on the indoor unit.



2. Fix the panel on the indoor unit
   - Fasten the panel on the indoor unit with the 4 bolts supplied with the panel.

Caution
Be careful not to pinch the motion sensor wiring.

Caution
- Improperly tightened fixing bolts cause the problems listed below, so make sure that bolts are securely tightened.



- If there is a gap between the ceiling and the panel even after the fixing bolts are tightened, adjust the installation level of the indoor unit again.





Caution
Do not give any stress on the panel when adjusting the height of the indoor unit to avoid unexpected distortion. It may cause the distortion of panel or failing to close the inlet grille, and the parts of the draft prevention mechanism.

⑧ Electrical wiring

The wiring work varies depending on the panel type. Select the wiring work appropriate for the panel type.

<For the standard panel>
① Connect the connector of the louver motor wiring (Wiring color: Red, Black) at the panel side to the connector CnJ3 (20 P, White) of the louver motor wiring (Wiring color: Red, Black) at the unit side.

For the Standard panel





<For the draft prevention panel>
① Connect the connector of the louver motor wiring (Wiring color: Red, Black) at the panel side to the connector CnJ3 (20 P, White) of the louver motor wiring (Wiring color: Red, Black) at the unit side.
② Connect the connector of the air flex motor wiring (Wiring color: Blue, White) at the panel side to the connector CnJ4 (20 P, White) of the air flex motor wiring (Wiring color: Blue, White) at the unit side.

For the Draft prevention panel





Motor wiring connection – Detail view

Install the wiring cover with care not to pinch wiring, and fix it with screws.



*** If the wiring cover is hung at the hook on panel, it will become easier to work.**

⑨ Installing a corner lid

1. To avoid unexpected falling of the corner lid, put the strap onto the corner lid's pin with turning the strap up.
2. Then hang the strap of a corner lid onto the panel's pin.
3. Hook the corner lid claws at 3 places, and fix the corner lid with attached screws.



⑩ Installing the inlet grille

The panel and the inlet grille have no directional limitation to install. (Hinges of the inlet grille can be hooked at any side.)
Install the inlet grille in the reverse order of the steps described at ⑬ Removing the inlet grille .
① Attach the fall grille hook to the panel.
② Insert the hinges of inlet grille in the insert holes on the panel.
Close then the inlet grille while pressing the stoppers (2 places).
Confirm that both stoppers are inserted securely in the panel.

<① Installation of the grille hook>



<② Grille installation>

Caution
- Install the grille hook securely at the panel.
- The inlet grille must be installed starting from the hinge side.
- Install the inlet grille securely. It may drop if it is installed insecurely.
- When the stoppers have been deformed or damaged, repair them immediately, Unless they are repaired properly, the inlet grille may drop off.

⑪ Panel setting

<Louver swing range setting (Individual louver control setting)>

It is possible to change the swing range of the louver by the wired remote control. Once the upper and lower limit positions are set, the louver will swing within the set range.It is also possible to set the different range to each louver.

<Draft prevention setting>

The draft prevention function will not be operated if the draft prevention panel is installed and its wirings are only connected. To operate the draft prevention function, enable the draft prevention setting by using the wired or wireless remote control.

Note: It is not possible to set by the following remote control models or older.
Wired:RC-EX3, RC-E5, RCH-E3
Wireless: RCN-E1R

Once you have enabled the settings in this mode, the draft prevention function is operated when the air-conditioner is started, and the parts of the draft prevention mechanism are always open when the air-conditioner is operating. When the air-conditioner is stopped, they are closed. It is possible to enabled or disabled the draft prevention function for each air outlet.

For the setting details, refer to the user's manual supplied with the remote control.

FRESH AIR INTAKE (Location for installation) FOR FDTC

At the time of installation use the duct hole (cut out) located at the positions shown in follwing diagram, as and when required.

(1) Temperature conditions for OA spacer (1)

- Adjust the temperature conditions of mixed air with outdoor air and indoor air within the usage range of suction air temperature for the air-conditioner.
- The usage temperature conditions of intake outdoor air and indoor air around the ducts are shown in the following table.
- If the temperature conditions of intake outdoor air do not meet, process the outdoor air before intaking.

Operation mode	Usage temperature conditions	
	Intake outdoor air	Indoor air around the ducts
In heating	5ºC DB or higher	18.5ºC WB or lower and 60% RH or lower
In cooling	29ºC DB or lower and 80% RH or lower	20ºC DB or higher

Note(1) : For the OA spacer, refer to page 412.



Detail drawing of fresh air intake



Detail of cut out

■Fresh air intake amount & static pressure characteristics

FDTC50, 60VH



CHARACTERISTICS OF AIR FLOW IN DIVIDED DUCT FOR FDTC

Models FDTC50, 60VH





■Divided duct connection method

1. Open some one during 4 knock out holes, and please connect a divided duct.
   It isn't possible to use more than one hole at the same time.
2. Please make the wind shielding a blowout vent or the side where a divided duct was connected.
3. The shotage of the external static pressure by pressure loss for a connected divided duct and blowout unit is made up by a booster fan.
   example : When 2.5m³/min of ventilation by divided duct is needed in model FDTC60VH (In case of connection duct ϕ 125 x 5m)
   ①Duct resistance : Pressure loss by a flexible duct =35Pa (7Pa/m x 5m)
   ②Blowout unit : Pressure loss by a blowout unit =10Pa
   ③External static pressure when being 2.5m³/min =17Pa (See upper table.)
   ⇒Correspondence by a booster fan =①+②-③ =28Pa

(3) Duct connected-High static pressure type (FDU)

PJG012D022

(a) Indoor unit

・This munual is for instaration of an indoor unit and an outdoor air processing unit (FDU-F).
・This manual is for the installation of an indoor unit.
For electrical wiring work (Indoor), refer to page 195. For remote control installation, refer to page 199. For wireless kit installation, refer to page 370. For electrical wiring work (Outdoor) and refrigerant pipe work installation for outdoor unit, refer to page 211.

The case of FDU-F
- The total connection capacity of the other air conditioning units and the outdoor air processing units must be from 50% to 100% (the total includes the outdoor air processing unit).
  The connection capacity of the outdoor air processing unit must not exceed 30% of the capacity of the outdoor unit.
- Single outdoor air processing unit can be used alone. The connection capacity of the outdoor air processing unit must be from 50% to 100% of the total capacity of the outdoor unit.
  Maximum number of outdoor air processing units that can be connected to the outdoor unit is 2units.
- Capacities of the suction air processing units can be calculated with the forllowing formulas.
  FDU650FKXZE1 = 90, FDU1100FKXZE1 = 140

SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, ⚠WARNING and ⚠CAUTION .
  ⚠WARNING : Wrong installation would cause serious consequences such as injuries or death.
  ⚠CAUTION : Wrong installation might cause serious consequences depending on circumstances.
  Both mentions the important items to protect your health and safety so strictly follow them by any means.
- The meanings of "Marks" used here are as shown on the right:
  ⃠ Never do it under any circumstances. | ❗ Always do it according to the instruction.
- After completing the installation, do commissioning to confirm there are no abnormalities, and explain to the customers about "SAFETY PRECAUTIONS", correct operation method and maintenance method (air filter cleaning, operation method and temperature setting method) with user's manual of this unit.
  Ask your customers to keep this installation manual together with the user's manual. Also, ask them to hand over the user's manual to the new user when the owner is changed.

⚠WARNING

- **Installation should be performed by the specialist.**
  If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Install the system correctly according to these installation manuals.**
  Improper installation may cause explosion, injury, water leakage, electric shock, and fire.
- **Check the density refered by the foumula (accordance with ISO5149).**
  If the density exceeds the limit density, please consult the dealer and installate the ventilation system.
- **Use the genuine accessories and the specified parts for installation.**
  If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Ventilate the working area well in case the refrigerant leaks during installation.**
  If the refrigerant contacts the fire, toxic gas is produced. In case of R32, the refrigerant could be ignited because of its flammability.
- **Install the unit in a location that can hold heavy weight.**
  Improper installation may cause the unit to fall leading to accidents.
- **Install the unit properly in order to be able to withstand strong winds such as typhoons, and earthquakes.**
  Improper installation may cause the unit to fall leading to accidents.
- **Do not mix air in to the cooling cycle on installation or removal of the air-conditioner.**
  If air is mixed in, the pressure in the cooling cycle will rise abnormally and may cause explosion and injuries.
- **Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.**
  Power source with insufficient capacity and improper work can cause electric shock and fire.
- **Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in order not to apply unexpected stress on the terminal.**
  Loose connections or hold could result in abnormal heat generation or fire.
- **Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services panel property.**
  Improper fitting may cause abnormal heat and fire.
- **Check for refrigerant gas leakage after installation is completed.**
  If the refrigerant gas leaks into the house and comes in contact with a fan heater, a stove, or an oven, toxic gas is produced.
- **Use the specified pipe, flare nut, and tools for R32 or R410A.**
  Using existing parts (R22) could cause the unit failure and serious accident due to explosion of the cooling cycle.
- **Tighten the flare nut according to the specified method by with torque wrench.**
  If the flare nut were tightened with excess torque, it could cause burst and refrigerant leakage after a long period.
- **Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulfide gas can occur.**
  Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.
- **Connect the pipes for refrigeration circuit securely in installation work before compressor is operated.**
  If the compressor is operated when the service valve is open without connecting the pipe, it could cause explosion and injuries due to abnormal high pressure in the system.
- **Stop the compressor before removing the pipe after shutting the service valve on pump down work.**
  If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.
- **Only use prescribed option parts. The installation must be carried out by the qualified installer.**
  If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.
- **Do not repair by yourself. And consult with the dealer about repair.**
  Improper repair may cause water leakage, electric shock or fire.
- **Consult the dealer or a specialist about removal of the air-conditioner.**
  Improper installation may cause water leakage, electric shock or fire.
- **Turn off the power source during servicing or inspection work.**
  If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.
- **Do not run the unit when the panel or protection guard are taken off.**
  Touching the rotating equipment, hot surface, or high voltage section could cause an injury to be caught in the machine, to get burned, or electric shock.
- **Shut off the power before electrical wiring work.**
  It could cause electric shock, unit failure and improper running.

⚠CAUTION

- **Perform earth wiring surely.**
  Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Improper earth could cause unit failure and electric shock or fire due to a short circuit.
- **Earth leakage breaker must be installed.**
  If the earth leakage breaker is not installed, it could cause electric shocks or fire.
- **Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.**
  Using the incorrect one could cause the system failure and fire.
- **Do not use any materials other than a fuse of correct capacity where a fuse should be used.**
  Connecting the circuit by wire or copper wire could cause unit failure and fire.
- **Do not install the indoor unit near the location where there is possibility of flammable gas leakages.**
  If the gas leaks and gathers around the unit, it could cause fire.
- **Do not install and use the unit where corrosive gas (such as sulfurous acid gas etc.) or flammable gas (such as thinner, petroleum etc.) may be generated or accumulated, or volatile flammable substances are handled.**
  It could cause the corrosion of heat exchanger, breakage of plastic parts etc. And inflammable gas could cause fire.
- **Secure a space for installation, inspection and maintenance specified in the manual.**
  Insufficient space can result in accident such as personal injury due to falling from the installation place.
- **Do not use the indoor unit at the place where water splashes such as laundry.**
  Indoor unit is not waterproof. It could cause electric shock and fire.
- **Do not use the indoor unit for a special purpose such as food storage, cooling for precision instrument, preservation of animals, plants, and a work of art.**
  It could cause the damage of the items.
- **Do not install nor use the system near equipments which generate electromagnetic wave or high harmonics.**
  Equipments like inverter equipment, private power generator, high-frequency medical equipment, or telecommunication equipment might influence the air-conditioner and cause a malfunction and breakdown. Or the air-conditioner might influence medical equipments or telecommunication equipments, and obstruct their medical activity or cause jamming.
- **Do not install the remote control at the direct sunlight.**
  It could cause breakdown or deformation of the remote control.
- **Do not install the indoor unit at the place listed below.**
  · Places where flammable gas could leak.
  · Places where carbon fiber, metal powder or any powder is floated.
  · Place where the substances which affect the air-onditioner are generated such as sulfide gas, chloride gas, acid, alkali or ammonic atmospheres.
  · Places exposed to oil mist or steam directly.
  · On vehicles and ships
  · Places where machinery which generates high harmonics is used.
  · Places where cosmetics or special sprays are frequently used.
  · Highly salted area such as beach.
  · Heavy snow area
  · Places where the system is affected by smoke from a chimney.
  · Altitude over 1000m
- **Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation)**
  · Locations with any obstacles which can prevent inlet and outlet air of the unit
  · Locations where vibration can be amplified due to insufficient strength of structure.
  · Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam. (in case of the infrared specification unit)
  · Locations where an equipment affected by high harmonics is placed. (TV set or radio receiver is placed within 5m)
  · Locations where drainage cannot run off safely.
  It can affect performance or function and etc..
  Do not install the motion sensor at following places. It could cause detection error, incapacity of detection, or characteristic degradation.
  · Place where vibration is applied to it for a long period of time.
  · Place where static electricity or electromagnetic wave generates.
  · Place where it is exposed to high temperature or humidity for a long period of time.
  · Dusty place or where the lens face could be fouled or damaged.
- **Do not put any valuables which will break down by getting wet under the air-conditioner.**
  Condensation could drop when the relative humidity is higher than 80% or drain pipe is clogged, and it damages user's belongings.
- **Do not use the base frame for the outdoor unit which is corroded or damaged after a long period of use.**
  It could cause the unit falling down and injury.
- **Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit.**
  If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit.
- **Install the drain pipe to drain the water surely according to the installation manual.**
  Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.
- **Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit.**
  Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety.
- **Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.**
  If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents.
- **For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding.**
  Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance.
- **Ensure the insulation on the pipes for refrigeration circuit so as not to condense water.**
  Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables.
- **Do not install the outdoor unit where is likely to be a nest for insects and small animals.**
  Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean.
- **Pay extra attention, carrying the unit by hand.**
  Carry the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective gloves in order to avoid injury by the aluminum fin.
- **Make sure to dispose of the packaging material.**
  Leaving the materials may cause injury as metals like nail and woods are used in the package.
- **Do not operate the system without the air filter.**
  It may cause the breakdown of the system due to clogging of the heat exchanger.
- **Do not touch any button with wet hands.**
  It could cause electric shock.
- **Do not touch the refrigerant piping with bare hands when in operation.**
  The pipe during operation would become very hot or cold according to the operating condition, and it could cause a burn or frostbite.
- **Do not clean up the air-conditioner with water.**
  It could cause electric shock.
- **Do not turn off the power source immediately after stopping the operation.**
  Be sure to wait for more than 5 minutes. Otherwise it could cause water leakage or breakdown.
- **Do not control the operation with the circuit breaker.**
  It could cause fire or water leakage. In addition, the fan may start operation unexpectedly and it may cause injury.

○This model is high static ducted type air-conditioning unit. Therefore, do not use this model for direct blow type air-conditioning unit.

①Before installation

●Install correctly according to the installation manual.

●Confirm the following points:

○Unit type/Power source specification ○Pipes/Wires/Small parts ○Accessory items

Accessory item

For hanging	For refrigerant pipe			For drain pipe					
Flat washer (M10)	Pipe cover (big)	Pipe cover (small)	Strap	Pipe cover (big)	Pipe cover (small)	Drain hose	Hose clamp	Elbow (Multi only)	
8	1	1	4	1	1	1	1	1	
For unit hanging	For heat insulation of gas pipe	For heat insulation of liquid tube	For pipe cover fixing	For heat insulation of drain socket	For heat insulation of drain socket	For drain pipe connecting	For drain hose mounting	For drain pipe connecting	



Accessory parts are stored inside this suction side.

②Selection of installation location for the indoor unit

① Select the suitable areas to install the unit under approval of the user.

- ·Areas where the indoor unit can deliver hot and cold wind sufficiently. Suggest to the user to use a circulator if the ceiling height is over 3m to avoid warm air being accumulated on the ceiling.
- ·Areas where there is enough space to install and service.
- ·Areas where it can be drained properly. Areas where drain pipe descending slope can be taken.
- ·Areas where there is no obstruction of air flow on both air return grille and air supply port.
- ·Areas where fire alarm will not be accidentally activated by the air-conditioner.
- ·Areas where the supply air does not short-circuit.
- ·Areas where it is not influenced by draft air.
- ·Areas not exposed to direct sunlight.
- ·Areas where dew point is lower than around 28°C and relative humidity is lower than 80%.

This indoor unit is tested under the condition of JIS (Japan Industrial Standard) high humidity condition and confirmed there is no problem. However, there is some risk of condensation drop if the air-conditioner is operated under the severer condition than mentioned above. If there is a possibility to use it under such a condition, attach additional insulation of 10 to 20mm thick for entire surface of indoor unit, refrigeration pipe and drain pipe.

- ·Areas where TV and radio stays away more than 1m. (It could cause jamming and noise.)
- ·Areas where any items which will be damaged by getting wet are not placed such as food, table wares, server, or medical equipment under the unit.
- ·Areas where there is no influence by the heat which cookware generates.
- ·Areas where not exposed to oil mist, powder and/or steam directly such as above fryer.
- ·Areas where lighting device such as fluorescent light or incandescent light doesn't affect the operation.

(A beam from lighting device sometimes affects the infrared receiver for the wireless remote control and the air-conditioner might not work properly.)

- ·When operating the suction air processing unit independently, it operates in the outdoor air processing mode.

Blowout temperatures are not same at the standard unit operation and the outdoor air processing mode operations.

Since the temperatures become higher during cooling or lower during heating, take care of the direction of blowout outlet.

Avoid directing the blowout outlet to the space where people are present.

② Check if the place where the air-conditioner is installed can hold the weight of the unit. If it is not able to hold, reinforce the structure with boards and beams strong enough to hold it. If the strength is not enough, it could cause injury due to unit falling.

Space for installation and service

●Make installation altitude over 2.5m.

(Indoor Unit)

Select either of two cases to keep space for installation and services.

(Case 1) From side of unit UNIT: mm



Notes (a) There must not be obstacle to draw out fan motor. (marked area)

(b) Install refrigerant pipe, drain pipe, and wiring so as not to cross marked area.

(Case 2) From bottom of unit UNIT: mm



(Size of inspection hole) UNIT: mm

Single type	–	71	100-140
Multi type	45, 56	71, 90	112-160
FDU-F	–	650	1100
A	1100	1300	1720
B	620		725

③Cautions for the handling and installation place of outdoor air processing unit

①This unit monitors the outdoor air temperature at the position of sensor A in the figure, and controls the start and stop with the thermostat based on the value of sensor A and the setting temperature by the remote control.



Remote control's setting temperature indicates the outdoor air temperature that controls the start and stop of operation by the thermostat.

When the thermostat is turned off, the operation is changed to the fan mode so that the outdoor air is blown out directly into the room. For example if the remote control is set to 22°C in cooling operation, and if the outdoor air temperature is 22°C or lower at that time, the unit will go into fan operation.

②When there is a difference between the air-conditioning temperature in the room during cooling operation and the temperature of air blown out from the outdoor air processing unit, dewing water may drip from the unit. To prevent the dewing, provide a sufficient heat insulation means at the air blow outlet.

③Since the air blow outlet on the outdoor air processing unit may blow out the outdoor air directly, orient the outlet in such a way that it will not blow air directly to persons in the room.

④Since the unit controls the thermostat start and stop by monitoring the outdoor air temperature, it is prohibited to monitor the room temperature by means of the room temperature monitoring by changing the thermostat setting at the remote control side and the option remote temperature sensor. Otherwise, dewing water may drip from the unit at lower outdoor air temperatures during cooling operation.

⑤Install the remote control of the outdoor air processing unit at a place closer to the administrator to avoid the end user from using the remote control.

When handing over the unit to the end user, make sure to explain sufficiently about the foregoing cautions, the installation place of the remote control for the outdoor air processing unit and the position of air blow outlet.

④Preparation before installation

●If suspension bolt becomes longer, do reinforcement of earthquake resistant.

○For grid ceiling

When the suspension bolt length is over 500mm, or the gap between the ceiling and roof is over 700mm, apply earthquake resistant brace to the bolt.

○In case the unit is hanged directly from the slab and is installed on the ceiling plane which has enough strength.

When suspension bolt length is over 1000mm, apply the earthquake resistant brace to the bolt.

●Prepare four (4) sets of suspension bolt, nut and spring washer (M10) on site.

Suspension Bolt Location





UNIT: mm

Single type	—	71	100-140
Multi type	45, 56	71, 90	112-160
FDU-F	—	650	1100
A	786	986	1720
B	472	472	725
C	135	135	180

Pipe locations UNIT: mm

Single type	71
Multi type	45-90
FDU-F	650



Single type	100-140
Multi type	112-160
FDU-F	1100



⑤Installation of indoor unit

Work procedure

1. Prepare a hole of specified size on the ceiling.
2. Install suspension bolts at specified positions.
3. Make sure to use four suspension bolts.
4. Adjust the indoor unit position in order to fit with it.
5. Make sure to install the indoor unit horizontally. Confirm the levelness of the indoor unit with a level gauge or transparent hose filled with water. Keep the height difference at both ends of the indoor unit within 3mm.
6. Tighten four upper nuts and fix the unit after height and levelness adjustment.

Installation

[Hanging]

Hang the unit up.



If the measurements between the unit and the ceiling hole do not match upon installation, it may be adjusted with the long holed installation tool.

Adjustment for horizontality

○Either use a level vial, or adjust the level according to the method below.

●Adjust so the bottom side of the unit will be leveled with the water surface as illustrated below.



Let the pipe side be slightly sloped.

○If the unit is not leveled, it may cause malfunctions or inoperation of the float switch.

⑥Duct Work

①A corrugated board (for preventing sputtering) is attached to the main body of the air-conditioner (on the outlet port). Do not remove it until connecting the duct.

●An air filter can be provided on the main body of the air-conditioner (on the inlet port). Remove it when connecting the duct on the inlet port.

②Blowout duct

●Use rectangular duct to connect with unit.

●Duct size for each unit is as shown below.

UNIT: mm

Single type	—	71	100-140
Multi type	45, 56	71, 90	112-160
FDU-F	—	650	1100
A	682	882	1202
B	172	172	172



●Duct should be at their minimum length.

●We recommend to use sound and heat insulated duct to prevent it from condensation.

●Connect duct to unit before ceiling attachment.

③Inlet port

●When connecting the duct to the inlet port, remove the air filter if it is fitted to the inlet port.

●Inlet port size for each unit is as shown below.

UNIT: mm

Single type	-	71	100-140
Multi Type	45, 56	71, 90	112-160
FDU-F	-	650	1100
A	582	742	1282
B	202	202	237



●Make sure to insulate the duct to prevent dewing on it.

④Install the specific blowout duct in a location where the air will circulate to the entire room.

●Conduct the installation of the specific blowout hole and the connection of the duct before attaching them to the ceiling.

●Insulate the area where the duct is secured by a band for dew condensation prevention.



⑤Make sure provide an inspection hole on the ceiling. It is indispensable to service electric equipment, motor, functional components and cleaning of heat exchanger.

⑥Duct Work (continued)

⑥Make sure to insulate ducts, in order to prevent dewing on them.

⑦Connect the duct with care not to touch the blower (fan motor) with fingers. Or, when inhaling air directly from the suction side, install an air filter at the air suction inlet.

FDU



FDU-F



Bad example of duct work

①If a duct is not provided at the suction side but it is substituted with the space over the ceiling, humidity in the space will increase by the influence of capacity of ventilation fan, strength of wind blowing against the out door air louver, weather (rainy day) and others.

a)Moisture in air is likely to condense over the external plates of the unit and to drip on the ceiling. Unit should be operated under the conditions as listed in the above table and within the limitation of wind volume. When the building is a concrete structure, especially immediately after the construction, humidity tends to rise even if the space over the ceiling is not substituted in place of a duct. In such occasion, it is necessary to insulate the entire unit with glass wool (25mm). (Use a wire net or equivalent to hold the glass wool in place.)

b)It may run out the allowable limit of unit operation（Example, the case of FDU: When outdoor air temperature is 35°CDB, suction air temperature is 27°CWB) and it could result in such troubles as compressor overload, etc..

c)There is a possibility that the blow air volume may exceed the allowable range of operation due to the capacity of ventilation fan or strength of wind blowing against external air louver so that drainage from be heat exchanger may fall to reach the drain pan but leak outside (Example: drip on to the ceiling) with consequential water leakage in the room.

②If vibration damping is not conducted between the unit and the duct, and between the unit and the slab, vibration will be transmitted to the duct and vibration noise may occur. Also, vibration may be transmitted from the unit to the slab. Vibration damping must be performed.



Connecting the air intake/vent ducts the case of FDU

①Fresh Air Intake

[for air intake duct only]

○Use the side fresh air intake hole, or supply through a part of the suction duct.



[for simultaneous air intake/vent]

○Intake air through the suction duct.
(the side cannot be used)



②Air Vent

○Use the side air vent hole.
(always use together with the air intake)



○Insulate the duct to protect it from dew condensation.

⑦Refrigerant pipe

Caution

●Be sure to use new pipes for the refrigerant pipes. Use the flare nut attached to the product.
Regarding whether existing pipes can be reused or not, and the washing method, refer to the instruction manual of the outdoor unit, catalogue or technical data.
1) In case of reuse: Do not use old flare nut, but use the one attached to the unit.
2) In case of reuse: Flare the end of pipe replaced partially for R32 or R410A.

⚠WARNING : When flared joints are reused indoors, the flare part shall be re-fabricated. (only for R32)



Pipe dia. d mm	Min. pipe wall thickness mm	Protruding dimension for flare, mm		Flare O.D. D mm	Flare nut tightening torque N·m
		Rigid (Clutch type)			
		For R32 For R410A	Conventional tool		
6.35	0.8	0 – 0.5	0.7 – 1.3	8.9 – 9.1	14 – 18
9.52	0.8			12.8 – 13.2	34 – 42
12.7	0.8			16.2 – 16.6	49 – 61
15.88	1			19.3 – 19.7	68 – 82
19.05	1.2			23.6 – 24.0	100 – 120

●Use phosphorus deoxidized copper alloy seamless pipe (C1220T) for refrigeration pipe installation. In addition, make sure there is no damage both inside and outside of the pipe, and no harmful substances such as sulfur, oxide, dust or a contaminant stuck on the pipes.
●Do not use any refrigerant other than R32 or R410A.
Using other refrigerant except R32 or R410A (R22 etc.) may degrade inside refrigeration oil. And air getting into refrigeration circuit may cause over-pressure and resultant it may result in bursting, etc.
●Store the copper pipes indoors and seal the both end of them until they are brazed in order to avoid any dust, dirt or water getting into pipe. Otherwise it will cause degradation of refrigeration oil and compressor breakdown, etc.
●Use special tools for R32 or R410A refrigerant.

Piping work



When conducting piping work, make sure to allow the pipes to be aligned in a straight line for at least 250 mm, as shown in the left illustration. (This is necessary for the drain pump to function)

Work procedure

1. Remove the flare nut and blind flanges on the pipe of the indoor unit.
※ Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them. (Gas may come out at this time, but it is not abnormal.)
● Pay attention whether the flare nut pops out. (as the indoor unit is sometimes pressured.)
2. Make a flare on liquid pipe and gas pipe, and connect the refrigeration pipes on the indoor unit.
※Bend radius of pipe must be 4D or larger. Once a pipe is bent, do not readjust the bending. Do not twist a pipe or collapse to 2/3D or smaller.
● Make sure to use flare nuts assembled on the unions. Usage of other flare nuts could cause refrigerant leakage.
※Do a flare connection as follows:
● Make sure to hold the nut on indoor unit pipe side using double spanner method as indicated when fastening / loosening flare nuts in order to prevent unintentional twisting of the copper pipe.
● When fastening the flare nut, align the refrigeration pipe with the center of flare nut, screw the nut for 3-4 times by hand and then tighten it by spanner with the specified torque mentioned in the table above.



3. Cover the flare connection part of the indoor unit with attached insulation material after a gas leakage inspection, and tighten both ends with attached straps.
● Make sure to insulate both gas pipes and liquid pipes completely.
※ Incomplete insulation may cause dew condensation or water dropping.
● Use heat-resistant (120 °C or more) insulations on the gas side pipes.
● In case of using at high humidity condition, reinforce insulation of refrigerant pipes. Surface of insulation may cause dew condition or water dropping, if insulations are not reinfoced.
4. Refrigerant is charged in the outdoor unit.
As for the additional refrigerant charge for the indoor unit and piping, refer to the installation manual attached to the outdoor unit.

Caution:
Refrigerating machine oil should not be applied to the threads of union or external surface of flare. It is because, even if the same tightening torque is applied, the oil is likely to decrease the slide friction force on the threads and increase, in turn, the axial component force so that it could crack the flare by the stress corrosion.
Refrigerating machine oil may be applied to the internal surface of flare only.

〈The case of using thicness of insulation is 10mm〉



〈The case of using reinfoced insulation〉



⑧Drain pipe

Caution

● Install the drain pipe according to the installation manual in order to drain properly.
Imperfection in draining may cause flood indoors and wetting the household goods, etc.
● Do not put the drain pipe directly into the ditch where toxic gas such as sulfur, the other harmful and inflammable gas is generated. Toxic gas would flow into the room and it would cause serious damage to user's health and safety (some poisoning or deficiency of oxygen).
In addition, it may cause corrosion of heat exchanger and bad smell.
● Connect the pipe securely to avoid water leakage from the joint.
● Insulate the pipe properly to avoid condensation drop.
● Check if the water can flow out properly from both the drain outlet on the indoor unit and the end of the drain pipe after installation.
● Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway. In addition, do not put air vent on the drain pipe. Check if water is drained out properly from the pipe during commissioning. Also, keep sufficient space for inspection and maintenance.

Work procedure

1. Make sure to insert the drain hose (the end mode of soft PVC) to the end of the step part of drain socket.
Attach the hose clamp to the drain hose around 10mm from the end, and fasten the screw about 5mm left to the nut.
●Do not apply adhesives on this end.
●Do not use acetone-based adhesives to connect to the drain socket.







2. Prepare a joint for connecting VP25 pipe, adhere and connect the joint to the drain hose (the end made of rigid PVC), and adhere and connect VP25 pipe (prepare on site).
※As for drain pipe, apply VP25 made of rigid PVC which is on the market.
●Make sure that the adhesive will not get into the supplied drain hose.
It may cause the flexible part broken after the adhesive is dried up and gets rigid.
●The flexible drain hose is intended to absorb a small difference at installation of the unit or drain pipes. Intentional bending, expanding may cause the flexible hose broken and water leakage.



●As for drain pipe, apply VP25 (OD32).
If apply PVC25 (OD25), connect the expanded connector to the drain hose, with adhesive. (Multi unit only)



3. Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway.
●Pay attention not to give stress on the pipe on the indoor unit side, and support and fix the pipe as close place to the unit as possible when connecting the drain pipe.
●Do not set up air vent.



●When sharing a drain pipe for more than one unit, lay the main pipe 100mm below the drain outlet of the unit. In addition, select VP30 or bigger size for main drain pipe.



⑧Drain pipe (continued)

4. Insulate the drain pipe.
   - ●Be sure to insulate the drain socket and rigid PVC pipe installed indoors otherwise it may cause dew condensation and water leakage.
     ※After drainage test implementation, cover the drain socket part with pipe cover (small size), then use the pipe cover (big size) to cover the pipe cover (small size), clamps and part of the drain hose, and fix and wrap it with tapes to wrap and make joint part gapless.

Drain up

- ● The position for drain pipe outlet can be raised up to 600mm above the ceiling. Use elbows for installation to avoid obstacles inside ceiling. If the horizontal drain pipe is too long before vertical pipe, the backflow of water will increase when the unit is stopped, and it may cause overflow of water from the drain pan on the indoor unit. In order to avoid overflow, keep the horizontal pipe length and offset of the pipe within the limit shown in the figure below.



Otherwise, the construction point makes it same as drain pipe construction.

Drain test

1. Conduct a drain test after completion of the electrical work.
2. During the trail, make sure that drain flows properly through the piping and that no water leaks from connections.
3. In case of a new building, conduct the test before it is furnished with the ceiling.
4. Be sure to conduct this test even when the unit is installed in the heating season.

Procedures

1. Supply about 2000 cc of water to the unit through the air outlet by using a feed water pump.
2. Check the drain while cooling operation.



Outline of bottom drain piping work

- ● If the bottom drain piping can be done with a descending gradient (1/50-1/100), it is possible to connect the pipes as shown in the drawing below.



Uncoupling the drain motor connector

- ● Uncouple the connector CnR for the drain motor as illustrated in the drawing on the right.

(Note: If the unit is run with the connector coupled, drain water will be discharged from the upper drain pipe joint, causing a water leak.)



⑨Wiring-out position and wiring connection

- ● Electrical installation work must be performed according to the installation manual by an electrical installation service provider qualified by a power provider of the country, and be executed according to the technical standards and other regulations applicable to electrical installation in the country.
  Be sure to use an exclusive circuit.
- ● Use specified cord, fasten the wiring to the terminal securely, and hold the cord securely in order not to apply unexpected stress on the terminal.
- ● Do not put both power source line and signal line on the same route. It may cause miscommunication and malfunction.
- ● Be sure to do D type earth work.
- ● For the details of electrical wiring work, see attached instruction manual for electrical wiring work.

1. Remove a lid of the control box (2 screws).
2. Hold each wiring inside the unit and fasten them to terminal block securely.
3. Fix the wiring with clamps.
4. Install the removed parts back to original place.



Single unit wiring connection

⑨Wiring-out position and wiring connection (continued)



Multi unit wiring connection

* Please fix the wiring in the band not to move even if it pulls.

Main fuse specification

Model		Specification	Part No.
FDU	FDU-F		
45-90	650	T 5A L 250V	SSA564A149AH
112-160	1100	T 6.3A L 250V	SSA564A149AJ

⑩External static pressure setting

You can set External Static Pressure (E.S.P.) by method of MANUAL SETTING on remote control. Indoor unit will control fan-speed to keep rated air flow volume at each fan speed setting (Lo-P-Hi)

You can set required E.S.P. by wired remote control that calculated with the set air flow rate and pressure loss of the duct connected.

- ● How to set E.S.P. by wired remote control
  ① Push "◆" marked button(E.S.P. button).
  ② Select indoor unit No. by using ▲▼ button.
  ③ Select setting No. by using ▲▼ button and set E.S.P. by ⊙ button.
  See detailed procedure in technical manual.

Notice

You can not set E.S.P. by wireless remote control.

With E.S.P. setting, confirm that actual E.S.P. agrees with E.S.P. setting.
When E.S.P. setting is higher than actual E.S.P., the air flow rate becomes excessively higher. This will cause water leakage if water splashes.
When E.S.P. setting is lower than actual E.S.P., the air flow rate becomes excessively lower and the cooling or heating may become ineffective.
In order to reduce the risk above the factory E.S.P. setting is set within the range of 80 – 150 Pa (E.S.P. setting No. 8 – 15). Be sure to use within the range of 80 – 150 Pa in actual operations. If actual E.S.P. is lower than 80 Pa, it may cause water leakage.

Setting No.	8	9	10	11	12	13	14	15
E.S.P (Pa)	80	90	100	110	120	130	140	150

※ If 1 – 7 is selected for the setting No. on the remote control, the setting No. shows No. 8.
If 16 – 20 is selected for the setting No. on the remote control, the setting No. shows No. 15.
Factory default is No. 8.

The Case of FDU-F

Setting No.	1	2	3	4	5	6	7	8	9	10	11	12
E.S.P. (Pa)	10	20	30	40	50	60	70	80	90	100	110	120

※ If 13-20 is selected for the setting No. on the remote control, the setting No. shows No. 12.
※ Factory default is No. 8.





SW8-4:OFF (E.S.P. setting No. 8-15)



SW8-4:ON (E.S.P. setting No. 1-19)

If SW8-4 is turned to "ON", E.S.P. setting range can be changed to 10 – 200 Pa (E.S.P. setting No. 1 – 19). This should not be used when actual E.S.P. cannot be confirmed, because the risk above becomes higher.

Setting No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
E.S.P. (Pa)	10	20	30	40	50	60	70	80	90	100	110	120	130	140	150	160	170	180	200

※ If 20 is selected for the setting No. on the remote control, the setting No. shows No. 19.

⑪Check list after installation

●Check the following items after all installation work completed.

Check if	Expected trouble	Check
The indoor and outdoor units are fixed securely?	Falling, vibration, noise	
Inspection for leakage is done?	Insufficient capacity	
Insulation work is properly done?	Water leakage	
Water is drained properly?	Water leakage	
Power source voltage is same as mentioned in the model name plate?	PCB burnt out, not working at all	
No mis-wiring or mis-connection of piping?	PCB burnt out, not working at all	
Earth wiring is connected properly?	Electric shock	
Cable size comply with specified size?	PCB burnt out, not working at all	
Any obstacle blocks air flow on air inlet and outlet?	Insufficient capacity	
Is setting of E.S.P finished?	Excessive air flow, water drop blow out	

(b) Replacement procedure of the fan unit

Notes(1) The unit is a heavy item. It must be supported securely and handled with care not to drop when it is necessary to replace.
(2) For the maintenance space, refer to page 171.

Models FDU100VH, 125VH, 140VH

(i) Remove the control box and the side panel, and remove the screws marked in the circles (2 places) from the unit located at the near side.



(ii) Take out the fan unit located at the near side in the arrow direction.



(iii) Remove the screws marked in the circles (2 places) from the fan unit located at the far side.



(iv) Take out the fan unit in the arrow direction.



(4) Duct connected-Low/Middle static pressure type (FDUM)

PJG012D021

(a) Indoor unit

This manual is for the installation of an indoor unit.
For electrical wiring work (Indoor), refer to page 195. For remote control installation, refer to page 199. For wireless kit installation, refer to page 370. For electrical wiring work (Outdoor) and refrigerant pipe work installation for outdoor unit, refer to page 211.

SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, ⚠WARNING and ⚠CAUTION .
  ⚠WARNING : Wrong installation would cause serious consequences such as injuries or death.
  ⚠CAUTION : Wrong installation might cause serious consequences depending on circumstances.
  Both mentions the important items to protect your health and safety so strictly follow them by any means.
- The meanings of "Marks" used here are as shown on the right:
  ⃠ Never do it under any circumstances. | ❗ Always do it according to the instruction.
- After completing the installation, do commissioning to confirm there are no abnormalities, and explain to the customers about "SAFETY PRECAUTIONS", correct operation method and maintenance method (air filter cleaning, operation method and temperature setting method) with user's manual of this unit.
  Ask your customers to keep this installation manual together with the user's manual. Also, ask them to hand over the user's manual to the new user when the owner is changed.

⚠ WARNING

- **Installation should be performed by the specialist.**
  If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Install the system correctly according to these installation manuals.**
  Improper installation may cause explosion, injury, water leakage, electric shock, and fire.
- **Check the density refered by the foumula (accordance with ISO5149).**
  If the density exceeds the limit density, please consult the dealer and installate the ventilation system.
- **Use the genuine accessories and the specified parts for installation.**
  If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Ventilate the working area well in case the refrigerant leaks during installation.**
  If the refrigerant contacts the fire, toxic gas is produced.
  In case of R32, the refrigerant could be ignited because of its flammability.
- **Install the unit in a location that can hold heavy weight.**
  Improper installation may cause the unit to fall leading to accidents.
- **Install the unit properly in order to be able to withstand strong winds such as typhoons, and earthquakes.**
  Improper installation may cause the unit to fall leading to accidents.
- **Do not mix air in to the cooling cycle on installation or removal of the air-conditioner.**
  If air is mixed in, the pressure in the cooling cycle will rise abnormally and may cause explosion and injuries.
- **Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.**
  Power source with insufficient capacity and improper work can cause electric shock and fire.
- **Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in order not to apply unexpected stress on the terminal.**
  Loose connections or hold could result in abnormal heat generation or fire.
- **Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services panel property.**
  Improper fitting may cause abnormal heat and fire.
- **Check for refrigerant gas leakage after installation is completed.**
  If the refrigerant gas leaks into the house and comes in contact with a fan heater, a stove, or an oven, toxic gas is produced.
- **Use the specified pipe, flare nut, and tools for R32 or R410A.**
  Using existing parts (R22) could cause the unit failure and serious accident due to explosion of the cooling cycle.
- **Tighten the flare nut according to the specified method by with torque wrench.**
  If the flare nut were tightened with excess torque, it could cause burst and refrigerant leakage after a long period.
- **Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulfide gas can occur.**
  Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.
- **Connect the pipes for refrigeration circuit securely in installation work before compressor is operated.**
  If the compressor is operated when the service valve is open without connecting the pipe, it could cause explosion and injuries due to abnormal high pressure in the system.
- **Stop the compressor before removing the pipe after shutting the service valve on pump down work.**
  If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.
- **Only use prescribed option parts. The installation must be carried out by the qualified installer.**
  If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.
- **Do not repair by yourself. And consult with the dealer about repair.**
  Improper repair may cause water leakage, electric shock or fire.
- **Consult the dealer or a specialist about removal of the air-conditioner.**
  Improper installation may cause water leakage, electric shock or fire.
- **Turn off the power source during servicing or inspection work.**
  If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.
- **Do not run the unit when the panel or protection guard are taken off.**
  Touching the rotating equipment, hot surface, or high voltage section could cause an injury to be caught in the machine, to get burned, or electric shock.
- **Shut off the power before electrical wiring work.**
  It could cause electric shock, unit failure and improper running.

⚠ CAUTION

- **Perform earth wiring surely.**
  Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Improper earth could cause unit failure and electric shock or fire due to a short circuit.
- **Earth leakage breaker must be installed.**
  If the earth leakage breaker is not installed, it could cause electric shocks or fire.
- **Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.**
  Using the incorrect one could cause the system failure and fire.
- **Do not use any materials other than a fuse of correct capacity where a fuse should be used.**
  Connecting the circuit by wire or copper wire could cause unit failure and fire.
- **Do not install the indoor unit near the location where there is possibility of flammable gas leakages.**
  If the gas leaks and gathers around the unit, it could cause fire.
- **Do not install and use the unit where corrosive gas (such as sulfurous acid gas etc.) or flammable gas (such as thinner, petroleum etc.) may be generated or accumulated, or volatile flammable substances are handled.**
  It could cause the corrosion of heat exchanger, breakage of plastic parts etc. And inflammable gas could cause fire.
- **Secure a space for installation, inspection and maintenance specified in the manual.**
  Insufficient space can result in accident such as personal injury due to falling from the installation place.
- **Do not use the indoor unit at the place where water splashes such as laundry.**
  Indoor unit is not waterproof. It could cause electric shock and fire.
- **Do not use the indoor unit for a special purpose such as food storage, cooling for precision instrument, preservation of animals, plants, and a work of art.**
  It could cause the damage of the items.
- **Do not install nor use the system near equipments which generate electromagnetic wave or high harmonics.**
  Equipments like inverter equipment, private power generator, high-frequency medical equipment, or telecommunication equipment might influence the air-conditioner and cause a malfunction and breakdown. Or the air-conditioner might influence medical equipments or telecommunication equipments, and obstruct their medical activity or cause jamming.
- **Do not install the remote control at the direct sunlight.**
  It could cause breakdown or deformation of the remote control.
- **Do not install the indoor unit at the place listed below.**
  - Places where flammable gas could leak.
  - Places where carbon fiber, metal powder or any powder is floated.
  - Place where the substances which affect the air-conditioner are generated such as sulfide gas, chloride gas, acid, alkali or ammonic atmospheres.
  - Places exposed to oil mist or steam directly.
  - On vehicles and ships
  - Places where machinery which generates high harmonics is used.
  - Places where cosmetics or special sprays are frequently used.
  - Highly salted area such as beach.
  - Heavy snow area
  - Places where the system is affected by smoke from a chimney.
  - Altitude over 1000m
- **Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation)**
  - Locations with any obstacles which can prevent inlet and outlet air of the unit
  - Locations where vibration can be amplified due to insufficient strength of structure.
  - Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam. (in case of the infrared specification unit)
  - Locations where an equipment affected by high harmonics is placed. (TV set or radio receiver is placed within 5m)
  - Locations where drainage cannot run off safely.

  It can affect performance or function and etc..

  Do not install the motion sensor at following places. It could cause detection error, incapacity of detection, or characteristic degradation.
  - Place where vibration is applied to it for a long period of time.
  - Place where static electricity or electromagnetic wave generates.
  - Place where it is exposed to high temperature or humidity for a long period of time.
  - Dusty place or where the lens face could be fouled or damaged.
- **Do not put any valuables which will break down by getting wet under the air-conditioner.**
  Condensation could drop when the relative humidity is higher than 80% or drain pipe is clogged, and it damages user's belongings.
- **Do not use the base frame for the outdoor unit which is corroded or damaged after a long period of use.**
  It could cause the unit falling down and injury.
- **Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit.**
  If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit.
- **Install the drain pipe to drain the water surely according to the installation manual.**
  Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.
- **Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit.**
  Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety.
- **Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.**
  If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents.
- **For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding.**
  Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance.
- **Ensure the insulation on the pipes for refrigeration circuit so as not to condense water.**
  Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables.
- **Do not install the outdoor unit where is likely to be a nest for insects and small animals.**
  Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean.
- **Pay extra attention, carrying the unit by hand.**
  Carry the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective gloves in order to avoid injury by the aluminum fin.
- **Make sure to dispose of the packaging material.**
  Leaving the materials may cause injury as metals like nail and woods are used in the package.
- **Do not operate the system without the air filter.**
  It may cause the breakdown of the system due to clogging of the heat exchanger.
- **Do not touch any button with wet hands.**
  It could cause electric shock.
- **Do not touch the refrigerant piping with bare hands when in operation.**
  The pipe during operation would become very hot or cold according to the operating condition, and it could cause a burn or frostbite.
- **Do not clean up the air-conditioner with water.**
  It could cause electric shock.
- **Do not turn off the power source immediately after stopping the operation.**
  Be sure to wait for more than 5 minutes. Otherwise it could cause water leakage or breakdown.
- **Do not control the operation with the circuit breaker.**
  It could cause fire or water leakage. In addition, the fan may start operation unexpectedly and it may cause injury.

○This model is middle static ducted type air conditioning unit. Therefore, do not use this model for direct blow type air conditioning unit.

①Before installation

●Install correctly according to the installation manual.

●Confirm the following points:

○Unit type/Power source specification ○Pipes/Wires/Small parts ○Accessory items

Accessory item

For hanging	For refrigerant pipe			For drain pipe			
Flat washer (M10)	Pipe cover (big)	Pipe cover (small)	Strap	Pipe cover (big)	Pipe cover (small)	Drain hose	Hose clamp
8	1	1	4	1	1	1	1
For unit hanging	For heat insulation of gas pipe	For heat insulation of liquid tube	For pipe cover fixing	For heat insulation of drain socket	For heat insulation of drain socket	For drain pipe connecting	For drain hose mounting



Accessory parts are stored inside this suction side.

②Selection of installation location for the indoor unit

① Select the suitable areas to install the unit under approval of the user.

- Areas where the indoor unit can deliver hot and cold wind sufficiently. Suggest to the user to use a circulator if the ceiling height is over 3m to avoid warm air being accumulated on the ceiling.
- Areas where there is enough space to install and service.
- Areas where it can be drained properly. Areas where drain pipe descending slope can be taken.
- Areas where there is no obstruction of air flow on both air return grille and air supply port.
- Areas where fire alarm will not be accidentally activated by the air-conditioner.
- Areas where the supply air does not short-circuit.
- Areas where it is not influenced by draft air.
- Areas not exposed to direct sunlight.
- Areas where dew point is lower than around 28°C and relative humidity is lower than 80%.
  This indoor unit is tested under the condition of JIS (Japan Industrial Standard) high humidity condition and confirmed there is no problem. However, there is some risk of condensation drop if the air-conditioner is operated under the severer condition than mentioned above. If there is a possibility to use it under such a condition, attach additional insulation of 10 to 20mm thick for entire surface of indoor unit, refrigeration pipe and drain pipe.
- Areas where TV and radio stays away more than 1m. (It could cause jamming and noise.)
- Areas where any items which will be damaged by getting wet are not placed such as food, table wares, server, or medical equipment under the unit.
- Areas where there is no influence by the heat which cookware generates.
- Areas where not exposed to oil mist, powder and/or steam directly such as above fryer.
- Areas where lighting device such as fluorescent light or incandescent light doesn't affect the operation.
  (A beam from lighting device sometimes affects the infrared receiver for the wireless remote control and the air conditioner might not work properly.)

② Check if the place where the air-conditioner is installed can hold the weight of the unit. If it is not able to hold, reinforce the structure with boards and beams strong enough to hold it. If the strength is not enough, it could cause injury due to unit falling.

Space for installation and service

●Make installation altitude over 2.5m.

(Indoor Unit)

Select either of two cases to keep space for installation and services.

(Case 1) From side of unit UNIT: mm



Notes (a) There must not be obstacle to draw out fan motor. (marked area)

(b) Install refrigerant pipe, drain pipe, and wiring so as not to cross marked area.

(Case 2) From bottom of unit UNIT: mm



(Size of inspection hole) UNIT: mm

Single type	40-50	60, 71	100-140
Multi type	22-56	71, 90	112-160
A	1100	1300	1720
B	620		725

③Preparation before installation

●If suspension bolt becomes longer, do reinforcement of earthquake resistant.

○For grid ceiling

When the suspension bolt length is over 500mm, or the gap between the ceiling and roof is over 700mm, apply earthquake resistant brace to the bolt.

○In case the unit is hanged directly from the slab and is installed on the ceiling plane which has enough strength.

When suspension bolt length is over 1000mm, apply the earthquake resistant brace to the bolt.

●Prepare four (4) sets of suspension bolt, nut and spring washer (M10) on site.

Suspension Bolt Location



UNIT: mm

Multi type	22-56	71, 90	112-160
Single type	40-50	60, 71	100-140
A	786	986	1404
B	472	472	530
C	135	135	180

Pipe locations UNIT: mm

Multi type	22-90
Single type	40-71



Multi type	112-160
Single type	100-140



④Installation of indoor unit

Installation

[Hanging]

Hang the unit up.



If the measurements between the unit and the ceiling hole do not match upon installation, it may be adjusted with the long holed installation tool.

Adjustment for horizontality

○Either use a level vial, or adjust the level according to the method below.

●Adjust so the bottom side of the unit will be leveled with the water surface as illustrated below.



Let the pipe side be slightly sloped.

○If the unit is not leveled, it may cause malfunctions or inoperation of the float switch.

⑤Duct Work

①A corrugated board (for preventing sputtering) is attached to the main body of the air-conditioner (on the outlet port). Do not remove it until connecting the duct.

●An air filter can be provided on the main body of the air-conditioner (on the inlet port). Remove it when connecting the duct on the inlet port.

②Blowout duct

●Use rectangular duct to connect with unit.
Duct size for each unit is as shown below.

UNIT: mm

Single type	40-50	60, 71	100-140
Multi type	22-56	71, 90	112-140
A	682	882	1202
B	172	172	172



●Duct should be at their minimum length.

●We recommend to use sound and heat insulated duct to prevent it from condensation.

●Connect duct to unit before ceiling attachment.

③Inlet port

●When shipped the inlet port lies on the back.

●When connecting the duct to the inlet port, remove the air filter if it is fitted to the inlet port.

●When placing the inlet port to carry out suction from the bottom side, use the following procedure to replace the suction duct joint and the bottom plate.



●Remove the screws which fasten the bottom plate and the duct joint on the inlet port side of the unit.



●Replace the removed bottom plate and duct joint.



●Fit the duct join with a screw; fit the bottom plate.

●Make sure to insulate the duct to prevent dewing on it.

④Install the specific blowout duct in a location where the air will circulate to the entire room.

●Conduct the installation of the specific blowout hole and the connection of the duct before attaching them to the ceiling.

●Insulate the area where the duct is secured by a band for dew condensation prevention.



⑤Make sure provide an inspection hole on the ceiling. It is indispensable to service electric equipment, motor, functional components and cleaning of heat exchanger.



Bad example of duct work

①If a duct is not provided at the suction side but it is substituted with the space over the ceiling, humidity in the space will increase by the influence of capacity of ventilation fan, strength of wind blowing against the out door air louver, weather (rainy day) and others.

a)Moisture in air is likely to condense over the external plates of the unit and to drip on the ceiling. Unit should be operated under the conditions as listed in the above table and within the limitation of wind volume. When the building is a concrete structure, especially immediately after the construction, humidity tends to rise even if the space over the ceiling is not substituted in place of a duct. In such occasion, it is necessary to insulate the entire unit with glass wool (25mm). (Use a wire net or equivalent to hold the glass wool in place.)

b)It may run out the allowable limit of unit operation (Example: When outdoor air temperature is 35°C DB, suction air temperature is 27°C WB) and it could result in such troubles as compressor overload, etc..

c)There is a possibility that the blow air volume may exceed the allowable range of operation due to the capacity of ventilation fan or strength of wind blowing against external air louver so that drainage from be heat exchanger may fall to reach the drain pan but leak outside (Example: drip on to the ceiling) with consequential water leakage in the room.

②If vibration damping is not conducted between the unit and the duct, and between the unit and the slab, vibration will be transmitted to the duct and vibration noise may occur. Also, vibration may be transmitted from the unit to the slab. Vibration damping must be performed.



⑤Duct Work (continued)

Connecting the air intake/vent ducts

①Fresh Air Intake

[for air intake duct only]

○Use the side fresh air intake hole, or supply through a part of the suction duct.



[for simultaneous air intake/vent]

○Intake air through the suction duct.
(the side cannot be used)



②Air Vent

○Use the side air vent hole.
(always use together with the air intake)



○Insulate the duct to protect it from dew condensation.

⑥Refrigerant pipe

Caution

●Be sure to use new pipes for the refrigerant pipes. Use the flare nut attached to the product.
Regarding whether existing pipes can be reused or not, and the washing method, refer to the instruction manual of the outdoor unit, catalogue or technical data.
1) In case of reuse: Do not use old flare nut, but use the one attached to the unit.
2) In case of reuse: Flare the end of pipe replaced partially for R32 or R410A.

⚠WARNING : When flared joints are reused indoors, the flare part shall be re-fabricated. (only for R32)



Pipe dia. d mm	Min. pipe wall thickness mm	Protruding dimension for flare, mm		Flare O.D. D mm	Flare nut tightening torque N·m
		Rigid (Clutch type)			
		For R32 For R410A	Conventional tool		
6.35	0.8	0 – 0.5	0.7 – 1.3	8.9 – 9.1	14 – 18
9.52	0.8			12.8 – 13.2	34 – 42
12.7	0.8			16.2 – 16.6	49 – 61
15.88	1			19.3 – 19.7	68 – 82
19.05	1.2			23.6 – 24.0	100 – 120

●Use phosphorus deoxidized copper alloy seamless pipe (C1220T) for refrigeration pipe installation. In addition, make sure there is no damage both inside and outside of the pipe, and no harmful substances such as sulfur, oxide, dust or a contaminant stuck on the pipes.

●Do not use any refrigerant other than R32 or R410A.
Using other refrigerant except R32 or R410A (R22 etc.) may degrade inside refrigeration oil. And air getting into refrigeration circuit may cause over-pressure and resultant it may result in bursting, etc.

●Store the copper pipes indoors and seal the both end of them until they are brazed in order to avoid any dust, dirt or water getting into pipe. Otherwise it will cause degradation of refrigeration oil and compressor breakdown, etc.

●Use special tools for R32 or R410A refrigerant.

Piping work



When conducting piping work, make sure to allow the pipes to be aligned in a straight line for at least 250 mm, as shown in the left illustration. (This is necessary for the drain pump to function)

Work procedure

1. Remove the flare nut and blind flanges on the pipe of the indoor unit.
※ Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them. (Gas may come out at this time, but it is not abnormal.)
● Pay attention whether the flare nut pops out. (as the indoor unit is sometimes pressured.)
2. Make a flare on liquid pipe and gas pipe, and connect the refrigeration pipes on the indoor unit.
※Bend radius of pipe must be 4D or larger. Once a pipe is bent, do not readjust the bending. Do not twist a pipe or collapse to 2/3D or smaller.
● Make sure to use flare nuts assembled on the unions. Usage of other flare nuts could cause refrigerant leakage.
※Do a flare connection as follows:
● Make sure to hold the nut on indoor unit pipe side using double spanner method as indicated when fastening / loosening flare nuts in order to prevent unintentional twisting of the copper pipe.
● When fastening the flare nut, align the refrigeration pipe with the center of flare nut, screw the nut for 3-4 times by hand and then tighten it by spanner with the specified torque mentioned in the table above.



3. Cover the flare connection part of the indoor unit with attached insulation material after a gas leakage inspection, and tighten both ends with attached straps.
● Make sure to insulate both gas pipes and liquid pipes completely.
※ Incomplete insulation may cause dew condensation or water dropping.
● Use heat-resistant (120 °C or more) insulations on the gas side pipes.
● In case of using at high humidity condition, reinforce insulation of refrigerant pipes. Surface of insulation may cause dew condition or water dropping, if insulations are not reinfoced.

⑥Refrigerant pipe (continued)

4. Refrigerant is charged in the outdoor unit.
   As for the additional refrigerant charge for the indoor unit and piping, refer to the installation manual attached to the outdoor unit.

Caution:
Refrigerating machine oil should not be applied to the threads of union or external surface of flare. It is because, even if the same tightening torque is applied, the oil is likely to decrease the slide friction force on the threads and increase, in turn, the axial component force so that it could crack the flare by the stress corrosion.
Refrigerating machine oil may be applied to the internal surface of flare only.

<The case of using thicness of insulation is 10mm>



<The case of using reinfoced insulation>



⑦Drain pipe

Caution

- Install the drain pipe according to the installation manual in order to drain properly. Imperfection in draining may cause flood indoors and wetting the household goods, etc.
- Do not put the drain pipe directly into the ditch where toxic gas such as sulfur, the other harmful and inflammable gas is generated. Toxic gas would flow into the room and it would cause serious damage to user's health and safety (some poisoning or deficiency of oxygen). In addition, it may cause corrosion of heat exchanger and bad smell.
- Connect the pipe securely to avoid water leakage from the joint.
- Insulate the pipe properly to avoid condensation drop.
- Check if the water can flow out properly from both the drain outlet on the indoor unit and the end of the drain pipe after installation.
- Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway. In addition, do not put air vent on the drain pipe. Check if water is drained out properly from the pipe during commissioning. Also, keep sufficient space for inspection and maintenance.

Work procedure

1. Make sure to insert the drain hose (the end mode of soft PVC) to the end of the step part of drain socket.
   Attach the hose clamp to the drain hose around 10mm from the end, and fasten the screw about 5mm left to the nut.
   - ●Do not apply adhesives on this end.
   - ●Do not use acetone-based adhesives to connect to the drain socket.



2. Prepare a joint for connecting VP25 pipe, adhere and connect the joint to the drain hose (the end made of rigid PVC), and adhere and connect VP25 pipe (prepare on site).
   ※As for drain pipe, apply VP25 made of rigid PVC which is on the market.
   - ●Make sure that the adhesive will not get into the supplied drain hose. It may cause the flexible part broken after the adhesive is dried up and gets rigid.
   - ●The flexible drain hose is intended to absorb a small difference at installation of the unit or drain pipes. Intentional bending, expanding may cause the flexible hose broken and water leakage.



   - ●As for drain pipe, apply VP25 (OD32).
     If apply PVC25 (OD25), connect the expanded connector to the drain hose, with adhesive. (Multi unit only)



⑦Drain pipe (continued)

3. Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway.
   - ●Pay attention not to give stress on the pipe on the indoor unit side, and support and fix the pipe as close place to the unit as possible when connecting the drain pipe.
   - ●Do not set up air vent.



   - ●When sharing a drain pipe for more than one unit, lay the main pipe 100mm below the drain outlet of the unit. In addition, select VP30 or bigger size for main drain pipe.



4. Insulate the drain pipe.
   - ● Be sure to insulate the drain socket and rigid PVC pipe installed indoors otherwise it may cause dew condensation and water leakage.
     ※After drainage test implementation, cover the drain socket part with pipe cover (small size), then use the pipe cover (big size) to cover the pipe cover (small size), clamps and part of the drain hose, and fix and wrap it with tapes to wrap and make joint part gapless.

Drain up

- The position for drain pipe outlet can be raised up to 600mm above the ceiling. Use elbows for installation to avoid obstacles inside ceiling. If the horizontal drain pipe is too long before vertical pipe, the backflow of water will increase when the unit is stopped, and it may cause overflow of water from the drain pan on the indoor unit. In order to avoid overflow, keep the horizontal pipe length and offset of the pipe within the limit shown in the figure below.



Otherwise, the construction point makes it same as drain pipe construction.

Drain test

1. Conduct a drain test after completion of the electrical work.
2. During the trail, make sure that drain flows properly through the piping and that no water leaks from connections.
3. In case of a new building, conduct the test before it is furnished with the ceiling.
4. Be sure to conduct this test even when the unit is installed in the heating season.

Procedures

1. Supply about 1000 cc of water to the unit through the air outlet by using a feed water pump.
2. Check the drain while cooling operation.



Outline of bottom drain piping work

- If the bottom drain piping can be done with a descending gradient (1/50-1/100), it is possible to connect the pipes as shown in the drawing below.



Uncoupling the drain motor connector

- Uncouple the connector CnR for the drain motor as illustrated in the drawing on the right.

(Note: If the unit is run with the connector coupled, drain water will be discharged from the upper drain pipe joint, causing a water leak.)



⑧Wiring-out position and wiring connection

- Electrical installation work must be performed according to the installation manual by an electrical installation service provider qualified by a power provider of the country, and be executed according to the technical standards and other regulations applicable to electrical installation in the country.
  Be sure to use an exclusive circuit.
- Use specified cord, fasten the wiring to the terminal securely, and hold the cord securely in order not to apply unexpected stress on the terminal.
- Do not put both power source line and signal line on the same route. It may cause miscommunication and malfunction.
- Be sure to do D type earth work.
- For the details of electrical wiring work, see attached instruction manual for electrical wiring work.

1. Remove a lid of the control box (2 screws).
2. Hold each wiring inside the unit and fasten them to terminal block securely.
3. Fix the wiring with clamps.
4. Install the removed parts back to original place.

Single unit wiring connection



Multi unit wiring connection



* Please fix the wiring in the band not to move even if it pulls.

Main fuse specification

Model	Specification	Part No.
22-56	T3.15A L250V	SSA564A149AF
71-160	T5A L250V	SSA564A149AH

⑨External static pressure setting

You can set External Static Pressure (E.S.P.) by either method of MANUAL SETTING or AUTOMATIC SETTING by remote control.
Indoor unit will control fan-speed to keep rated air flow volume at each fan speed setting (Lo-Uhi)

1. MANUAL SETTING
   You can set required E.S.P. by wired remote control that calculated with the set air flow rate and pressure loss of the duct connected.
   Select No.1-10 (10Pa-100Pa) from following table according to calculation result.
   Refer to technical manual for details of air flow characteristic.

Setting No.	1	2	3	4	5	6	7	8	9	10
External Static Pressure (Pa)	10	20	30	40	50	60	70	80	90	100

※ When you set No.11-19 by remote control, unit will control fan-speed with setting of No.10 Factory default is at No.5.

- How to set E.S.P by wired remote control
  ① Push "◆" marked button(E.S.P button).
  ② Select indoor unit No. by using ⬍ button.
  ③ Select setting No. by using ⬍ button and set E.S.P. by ⟲ button.
  See detailed procedure in technical manual.

Notice
You can not set E.S.P. by wireless remote control.

Caution
Be sure to set E.S.P. according to actual duct connected.
Wrong settings causes excessive air flow volume or water drop blown out.

2. AUTOMATIC SETTING
   Indoor unit will recognize E.S.P. by itself automatically and select appropriate fan speed No.1-10.

⑨External static pressure setting (continued)

- How to start automatic setting
  ①, ②Same setting as MANUAL SETTING.
  ③ Select [AUT] by using ⬍ button and press ⟲ button .
  ② After setting E.S.P. at "AUT", operate unit in FAN mode with certain fan speed (Lo-Uhi).

Indoor unit fan will run automatically and recognize E.S.P. by itself.
The operation for automatic E.S.P. recognition will last about 6 minutes, and it will be stopped after recognition is completed.

Caution
- Be sure to execute AUTOMATIC SETTING by remote control AFTER ducting work is completed. When duct specification is changed after AUTOMATIC SETTING, be sure to execute AUTOMATIC SETTING again after power resetting and turning on again.
- Be sure to execute AUTOMATIC SETTING before trial cooling operation. (See ELECTRICAL WIRING WORK INSTRUCTION about trial cooling operation)
- Before AUTOMATIC SETTING, be sure to check that return air filter in duct is installed and damper is opened.
  Wrong procedure causes excessive air flow or water drop blown out.

Notice
- During operation for automatic recognition (the Auto Operation), fan rotates with certain speeds regardless of set fan speed by remote control.
- When duct is set with low static pressure (around 10-50Pa), even if indoor unit operate with higher air flow volume than rated one, but it is not abnormal.
- When you changed operation mode or stop operation with ON/OFF button during Auto Operation, the Auto operation will be canceled.
- In such case, be sure to execute AUTOMATIC SETTING again according to above procedure.

⑩Check list after installation

●Check the following items after all installation work completed.

Check if	Expected trouble	Check
The indoor and outdoor units are fixed securely?	Falling, vibration, noise	
Inspection for leakage is done?	Insufficient capacity	
Insulation work is properly done?	Water leakage	
Water is drained properly?	Water leakage	
Power source voltage is same as mentioned in the model name plate?	PCB burnt out, not working at all	
No mis-wiring or mis-connection of piping?	PCB burnt out, not working at all	
Earth wiring is connected properly?	Electric shock	
Cable size comply with specified size?	PCB burnt out, not working at all	
Any obstacle blocks air flow on air inlet and outlet?	Insufficient capacity	
Is setting of E.S.P finished?	Excessive air flow, water drop blow out	

(b) Replacement procedure of the fan unit

Notes(1) The unit is a heavy item. It must be supported securely and handled with care not to drop when it is necessary to replace.
(2) For the maintenance space, refer to page 177.

(i) Model FDUM50VH

1) Remove the control box and the side panel, and remove the screws marked in the circles (2 places) in the figure.



2) Take out the fan unit in the arrow direction.



(ii) Models FDUM60VH, 71VH

1) Remove the control box and the side panel, and remove the screws marked in the circles (2 places) in the figure.



2) Take out the fan unit in the arrow direction.



(iii) Models FDUM100VH, 125VH, 140VH

1) Remove the control box and the side panel, and remove the screws marked in the circles (2 places) from the unit located at the near side.



2) Take out the fan unit located at the near side in the arrow direction.



3) Remove the screws marked in the circles (2 places) from the fan unit located at the far side.



4) Take out the fan unit in the arrow direction.



(5) Ceiling suspended type (FDE)

PFA012D636 B

This manual is for the installation of an indoor unit.
For electrical wiring work (Indoor), refer to page 195. For remote control installation, refer to page 199. For wireless kit installation, refer to page 378. For electrical wiring work (Outdoor) and refrigerant pipe work installation for outdoor unit, refer to page 211.

SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, ⚠WARNING and ⚠CAUTION .
  ⚠WARNING : Wrong installation would cause serious consequences such as injuries or death.
  ⚠CAUTION : Wrong installation might cause serious consequences depending on circumstances.
  Both mentions the important items to protect your health and safety so strictly follow them by any means.
- The meanings of "Marks" used here are as shown as follows:
  ⃠ Never do it under any circumstances. ❗ Always do it according to the instruction.
- After completing the installation, do commissioning to confirm there are no abnormalities, and explain to the customers about "SAFETY PRECAUTIONS", correct operation method and maintenance method (air filter cleaning, operation method and temperature setting method) with user's manual of this unit.
  Ask your customers to keep this installation manual together with the user's manual. Also, ask them to hand over the user's manual to the new user when the owner is changed.

⚠WARNING

- **Installation should be performed by the specialist.**
  If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Install the system correctly according to these installation manuals.**
  Improper installation may cause explosion, injury, water leakage, electric shock, and fire.
- **When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149).**
  If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accidents.
- **Use the genuine accessories and the specified parts for installation.**
  If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Ventilate the working area well in case the refrigerant leaks during installation.**
  If the refrigerant contacts the fire, toxic gas is produced.
  In case of R32, the refrigerant could be ignited because of its flammability.
- **Install the unit in a location that can hold heavy weight.**
  Improper installation may cause the unit to fall leading to accidents.
- **Install the unit properly in order to be able to withstand strong winds such as typhoons, and earthquakes.**
  Improper installation may cause the unit to fall leading to accidents.
- **Do not mix air in to the cooling cycle on installation or removal of the air-conditioner.**
  If air is mixed in, the pressure in the cooling cycle will rise abnormally and may cause explosion and injuries.
- **Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.**
  Power source with insufficient capacity and improper work can cause electric shock and fire.
- **Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in order not to apply unexpected stress on the terminal.**
  Loose connections or hold could result in abnormal heat generation or fire.
- **Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services panel property.**
  Improper fitting may cause abnormal heat and fire.
- **Check for refrigerant gas leakage after installation is completed.**
  If the refrigerant gas leaks into the house and comes in contact with a fan heater, a stove, or an oven, toxic gas is produced.
- **Use the specified pipe, flare nut, and tools for R32 or R410A.**
  Using existing parts (R22) could cause the unit failure and serious accident due to explosion of the cooling cycle.
- **Tighten the flare nut according to the specified method by with torque wrench.**
  If the flare nut were tightened with excess torque, it could cause burst and refrigerant leakage after a long period.
- **Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulfide gas can occur.**
  Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.
- **Connect the pipes for refrigeration circuit securely in installation work before compressor is operated.**
  If the compressor is operated when the service valve is open without connecting the pipe, it could cause explosion and injuries due to abnormal high pressure in the system.
- **Stop the compressor before removing the pipe after shutting the service valve on pump down work.**
  If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.
- **Only use prescribed option parts. The installation must be carried out by the qualified installer.**
  If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.
- **Do not repair by yourself. And consult with the dealer about repair.**
  Improper repair may cause water leakage, electric shock or fire.
- **Consult the dealer or a specialist about removal of the air-conditioner.**
  Improper installation may cause water leakage, electric shock or fire.
- **Turn off the power source during servicing or inspection work.**
  If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.
- **Do not run the unit when the panel or protection guard are taken off.**
  Touching the rotating equipment, hot surface, or high voltage section could cause an injury to be caught in the machine, to get burned, or electric shock.
- **Shut off the power before electrical wiring work.**
  It could cause electric shock, unit failure and improper running.

⚠ CAUTION

- **Perform earth wiring surely.**
  Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Improper earth could cause unit failure, electric shock and fire due to a short circuit.
- **Earth leakage breaker must be installed.**
  If the earth leakage breaker is not installed, it can cause fire and electric shocks.
- **Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.**
  Using the incorrect one could cause the system failure and fire.
- **Do not use any materials other than a fuse of correct capacity where a fuse should be used.**
  Connecting the circuit by wire or copper wire could cause unit failure and fire.
- **Do not install the indoor unit near the location where there is possibility of flammable gas leakages.**
  If the gas leaks and gathers around the unit, it could cause fire.
- **Do not install and use the unit where corrosive gas (such as sulfurous acid gas etc.) or flammable gas (such as thinner, petroleum etc.) may be generated or accumulated, or volatile flammable substances are handled.**
  It could cause the corrosion of heat exchanger, breakage of plastic parts etc. And inflammable gas could cause fire.
- **Secure a space for installation, inspection and maintenance specified in the manual.**
  Insufficient space can result in accident such as personal injury due to falling from the installation place.
- **Do not use the indoor unit at the place where water splashes such as laundry.**
  Indoor unit is not waterproof. It could cause electric shock and fire.
- **Do not use the indoor unit for a special purpose such as food storage, cooling for precision instrument, preservation of animals, plants, and a work of art.**
  It could cause the damage of the items.
- **Do not install nor use the system near equipments which generate electromagnetic wave or high harmonics.**
  Equipments like inverter equipment, private power generator, high-frequency medical equipment, or telecommunication equipment might influence the air-conditioner and cause a malfunction and breakdown. Or the air-conditioner might influence medical equipments or telecommunication equipments, and obstruct their medical activity or cause jamming.
- **Do not install the remote control at the direct sunlight.**
  It could cause breakdown or deformation of the remote control.
- **Do not install the indoor unit at the place listed below.**
  · Places where flammable gas could leak.
  · Places where carbon fiber, metal powder or any powder is floated.
  · Place where the substances which affect the air-conditioner are generated such as sulfide gas, chloride gas, acid, alkali or ammonic atmospheres.
  · Places exposed to oil mist or steam directly.
  · On vehicles and ships
  · Places where machinery which generates high harmonics is used.
  · Places where cosmetics or special sprays are frequently used.
  · Highly salted area such as beach.
  · Heavy snow area
  · Places where the system is affected by smoke from a chimney.
  · Altitude over 1000m
- **Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation)**
  · Locations with any obstacles which can prevent inlet and outlet air of the unit
  · Locations where vibration can be amplified due to insufficient strength of structure.
  · Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam. (in case of the infrared specification unit)
  · Locations where an equipment affected by high harmonics is placed. (TV set or radio receiver is placed within 5m)
  · Locations where drainage cannot run off safely.
  It can affect performance or function and etc..
  Do not install the motion sensor at following places. It could cause detection error, incapacity of detection, or characteristic degradation.
  · Place where vibration is applied to it for a long period of time.
  · Place where static electricity or electromagnetic wave generates.
  · Place where it is exposed to high temperature or humidity for a long period of time.
  · Dusty place or where the lens face could be fouled or damaged.
- **Do not put any valuables which will break down by getting wet under the air-conditioner.**
  Condensation could drop when the relative humidity is higher than 80% or drain pipe is clogged, and it damages user's belongings.
- **Do not use the base frame for the outdoor unit which is corroded or damaged after a long period of use.**
  It could cause the unit falling down and injury.
- **Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit.**
  If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit.
- **Install the drain pipe to drain the water surely according to the installation manual.**
  Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.
- **Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit.**
  Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety.
- **Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.**
  If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents.
- **For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding.**
  Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance.
- **Ensure the insulation on the pipes for refrigeration circuit so as not to condense water.**
  Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables.
- **Do not install the outdoor unit where is likely to be a nest for insects and small animals.**
  Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean.
- **Pay extra attention, carrying the unit by hand.**
  Carry the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective gloves in order to avoid injury by the aluminum fin.
- **Make sure to dispose of the packaging material.**
  Leaving the materials may cause injury as metals like nail and woods are used in the package.
- **Do not operate the system without the air filter.**
  It may cause the breakdown of the system due to clogging of the heat exchanger.
- **Do not touch any button with wet hands.**
  It could cause electric shock.
- **Do not touch the refrigerant piping with bare hands when in operation.**
  The pipe during operation would become very hot or cold according to the operating condition, and it could cause a burn or frostbite.
- **Do not clean up the air-conditioner with water.**
  It could cause electric shock.
- **Do not turn off the power source immediately after stopping the operation.**
  Be sure to wait for more than 5 minutes. Otherwise it could cause water leakage or breakdown.
- **Do not control the operation with the circuit breaker.**
  It could cause fire or water leakage. In addition, the fan may start operation unexpectedly and it may cause injury.

①Before installation

- Install correctly according to the installation manual.
- Confirm the following points:
  - ○Unit type/Power source specification
  - ○Pipes/Wires/Small parts ○Accessory items



Accessory item

For unit hanging		For refrigerant pipe			For drain pipe					For air return grille
Flat washer (M10)	Paper pattern	Pipe cover (large)	Pipe cover (small)	Strap	Drain hose (with clamp)	Hose clamp	Fixing bracket	Screw	Heavy insulation	Screw
8	1	1	1	4	1	1	1	2	1	4
For unit hanging	For unit hanging and adjustment	For heat insulation of gas pipe	For heat insulation of liquid pipe	For fixing of pipe cover	For drain pipe connection	For drain hose mounting	For fixing of drain hose	For installing of fixing bracket	For drain hose	For fixing air return grille

②Selection of installation location for the indoor unit

① Select the suitable areas to install the unit under approval of the user.
- Areas where the indoor unit can deliver hot and cold wind sufficiently. Suggest to the user to use a circulator if the ceiling height is over 3m to avoid warm air being accumulated on the ceiling.
- In case of having the motion sensor, the installation height must be no higher than 4 m. It could reduce the sensitivity of motion sensor, disabling the detection.
- Areas where there is enough space to install and service.
- Areas where it can be drained properly. Areas where drain pipe descending slope can be taken.
- Areas where there is no obstruction of air flow on both air return grille and air supply port.
- Areas where fire alarm will not be accidentally activated by the air-conditioner.
- Areas where the supply air does not short-circuit.
- Areas where it is not influenced by draft air.
- Areas not exposed to direct sunlight.
- Areas where dew point is lower than around 28°C and relative humidity is lower than 80%.
  This indoor unit is tested under the condition of JIS (Japan Industrial Standard) high humidity condition and confirmed there is no problem. However, there is some risk of condensation drop if the air-conditioner is operated under the severer condition than mentioned above.
  If there is a possibility to use it under such a condition, attach additional insulation of 10 to 20mm thick for entire surface of indoor unit, refrigeration pipe and drain pipe.
- Areas where TV and radio stays away more than 1m. (It could cause jamming and noise.)
- Areas where any items which will be damaged by getting wet are not placed such as food, table wares, server, or medical equipment under the unit.
- Areas where there is no influence by the heat which cookware generates.
- Areas where not exposed to oil mist, powder and/or steam directly such as above fryer.
- Areas where lighting device such as fluorescent light or incandescent light doesn't affect the operation.
  (A beam from lighting device sometimes affects the infrared receiver for the wireless remote control and the air conditioner might not work properly.)

② Check if the place where the air-conditioner is installed can hold the weight of the unit. If it is not able to hold, reinforce the structure with boards and beams strong enough to hold it. If the strength is not enough, it could cause injury due to unit falling.

③ If there are 2 units of wireless type, keep them away for more than 6m to avoid malfunction due to cross communication.

④ When plural indoor units are installed nearby, it is recommended to separate each other more than 4m.

Space for installation and service



③Preparation before installation

- If suspension bolt becomes longer, do reinforcement of earthquake resistant.
  - ○For grid ceiling
    When suspension bolt length is over 500mm, or the gap between the ceiling and roof is over 700mm, apply earthquake resistant brace to the bolt.
  - ○In case the unit is hanged directly from the slab and is installed on the ceiling plane which has enough strength.
    When suspension bolt length is over 1000mm, apply the earthquake resistant brace to the bolt.
- Prepare four (4) sets of suspension bolt, nut and spring washer (M10) on site.

Pitch of suspension bolts and pipe position

Pitch of suspension bolts (mm)



Location of pipe outlets (mm)



③Preparation before installation (continued)

(mm)

Series	type	A	B
Single split (PAC) series	40 to 50type	1070	1022
	60 to 71type	1320	1272
	100 to 140type	1620	1572
VRF (KX) series	36 to 56type	1070	1022
	71type	1320	1272
	112 to 140type	1620	1572

※Pipes can be taken out in 3 directions (rear, right or top).
- Cut out holes using nippers, etc.
- Cut out holes to take out pipes along the cutoff line on the rear cover.
- Cut out the top face cover aligning to the piping position.
- When taking pipe out to right-hand side, cut out a hole along the groove at the inside of side panel.
- After installing pipes and wires, seal clearances around pipes and wires with putty, etc. to shut off dust.

Make sure to install the covers at rear and top in order to protect the inside of unit from intrusion of dust or protect wires from damages by sharp edges. When taking them out to the right-hand side, remove burrs or sharp edges from the cutout.

Pipe position (mm)



Haulage

- Move the box as close to the installation area as possible packed.
- If it must be unpacked, wrap the unit with a nylon sling, and be careful not to damage the unit.
  ※Do not hold fragile plastic parts, such as the side panel, blow louver, etc.
- If you need to lay the unit on a floor after unpacking, always put it with the intake grille facing upward.

Preparation before instalation

1. Remove the air return grille.
Slide stoppers (4 places) of the catches, then pull out the pins (4 or 6 places).



2. Remove the side panel.
Remove the screw and detach the side panel by sliding it toward the direction indicated by the arrow mark.



3. Remove the hanging plate.
Remove the screw, and then loosen the fixing bolts.



④Installation of indoor unit

⚠ WARNING
Completely seal the hole in the wall with putty. If not sealed properly, dust, insects, small animals, and highly humid air may enter the room from outside, which could result in fire or other hazards.

⚠ CAUTION
Completely seal the hole in the wall with putty.
If not sealed properly, furniture and other fixtures may be damaged by water leakage or condensation.



Work procedure

1. Select the suspension bolt locations and the pipe hole location.
   (1) Use enclosed paper pattern as a reference, and drill the holes for the suspension bolts and pipe.
   ※Decide the locations based on direct measurements.
   (2) Once the locations are properly placed, the paper pattern can be removed.



2. Install the suspension bolts in place.
3. Fix with 4 suspension bolts, which can endure load of 500N.
4. Check the measurements given at the right figure for the length of the suspension bolts.



5. Fasten the hanging plate onto the suspension bolts.



※Please fasten firmly with double nuts.

6. Install the unit to the hanging plate. (See the figure at right.)
   (1) Slide the unit in from front side to get it hanged on the hanging plate with the bolts.
   (2) Fasten the four fixing bolts (M8: 2 each on the left and right sides) firmly.
   (3) Fasten the two screws (M4: 1 each on the left and right sides).



⚠**WARNING** : Hang a side panel on from the panel side to the rear side and then fasten it securely onto the indoor unit with screws.

※To ensure smooth drain flow, install the unit with a descending slope toward the drain outlet.



⚠ **CAUTION** : Do not give the reversed slope, which may cause water leaks.

⑤Refrigerant pipe

Caution

●Be sure to use new pipes for the refrigerant pipes. Use the flare nut attached to the product.
Regarding whether existing pipes can be reused or not, and the washing method, refer to the instruction manual of the outdoor unit, catalogue or technical data.
1) In case of reuse: Do not use old flare nut, but use the one attached to the unit.
2) In case of reuse: Flare the end of pipe replaced partially for R32 or R410A.
⚠WARNING : When flared joints are reused indoors, the flare part shall be re-fabricated. (only for R32)



Pipe dia. d mm	Min. pipe wall thickness mm	Protruding dimension for flare, mm		Flare O.D. D mm	Flare nut tightening torque N·m
		Rigid (Clutch type)			
		For R32 For R410A	Conventional tool		
6.35	0.8	0 – 0.5	0.7 – 1.3	8.9 – 9.1	14 – 18
9.52	0.8			12.8 – 13.2	34 – 42
12.7	0.8			16.2 – 16.6	49 – 61
15.88	1			19.3 – 19.7	68 – 82
19.05	1.2			23.6 – 24.0	100 – 120

●Use phosphorus deoxidized copper alloy seamless pipe (C1220T) for refrigeration pipe installation. In addition, make sure there is no damage both inside and outside of the pipe, and no harmful substances such as sulfur, oxide, dust or a contaminant stuck on the pipes.
●Do not use any refrigerant other than R32 or R410A.
Using other refrigerant except R32 or R410A (R22 etc.) may degrade inside refrigeration oil. And air getting into refrigeration circuit may cause over-pressure and resultant it may result in bursting, etc.
●Store the copper pipes indoors and seal the both end of them until they are brazed in order to avoid any dust, dirt or water getting into pipe. Otherwise it will cause degradation of refrigeration oil and compressor breakdown, etc.
●Use special tools for R32 or R410A refrigerant.

Work procedure

1. Remove the flare nut and blind flanges on the pipe of the indoor unit.
※ Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them. (Gas may come out at this time, but it is not abnormal.)
● Pay attention whether the flare nut pops out. (as the indoor unit is sometimes pressured.)
2. Make a flare on liquid pipe and gas pipe, and connect the refrigeration pipes on the indoor unit.
●When pulling out pipes backward or upward, install them passing through the attached cover together with the electrical cabling.
●Seal the gap with putty, or other, to protect from dust, etc.
※Bend radius of pipe must be 4D or larger. Once a pipe is bent, do not readjust the bending. Do not twist a pipe or collapse to 2/3D or smaller.
● Make sure to use flare nuts assembled on the unions. Usage of other flare nuts could cause refrigerant leakage.
※Do a flare connection as follows:
● Make sure to hold the nut on indoor unit pipe side using double spanner method as indicated when fastening / loosening flare nuts in order to prevent unintentional twisting of the copper pipe.
● When fastening the flare nut, align the refrigeration pipe with the center of flare nut, screw the nut for 3-4 times by hand and then tighten it by spanner with the specified torque mentioned in the table above.



3. Cover the flare connection part of the indoor unit with attached insulation material after a gas leakage inspection, and tighten both ends with attached straps.
● Make sure to insulate both gas pipes and liquid pipes completely.
※Incomplete insulation may cause dew condensation or water dropping.
●Use heat-resistant (120 °C or more) insulations on the gas side pipes.
●In case of using at high humidity condition, reinforce insulation of refrigerant pipes.
Surface of insulation may cause dew condition or water dropping, if insulations are not reinfoced.
4. Refrigerant is charged in the outdoor unit.
As for the additional refrigerant charge for the indoor unit and piping, refer to the installation manual attached to the outdoor unit.

Caution:
Refrigerating machine oil should not be applied to the threads of union or external surface of flare. It is because, even if the same tightening torque is applied, the oil is likely to decrease the slide friction force on the threads and increase, in turn, the axial component force so that it could crack the flare by the stress corrosion.
Refrigerating machine oil may be applied to the internal surface of flare only.

<The case of using thicness of insulation is 10mm>



<The case of using reinfoced insulation>



The pipe can be connected from three different directions. (back, reight, top)
● When the pipe is routed through the back.
If the bracket is removed, piping work will become easy.
※After piping, reinstall the removed bracket.



● When the pipe is routed through the top.
Cut the removed top cover, and install to the rear panel instead of rear cover.



⑥Drain pipe

●The drain pipes may pull out either from back, right or left side.

Caution

- Install the drain pipe according to the installation manual in order to drain properly. Imperfection in draining may cause flood indoors and wetting the household goods, etc.
- Do not put the drain pipe directly into the ditch where toxic gas such as sulfur, the other harmful andinflammable gas is generated. Toxic gas would flow into the room and it would cause serious damage to user's health and safety (some poisoning or deficiency of oxygen). In addition, it may cause corrosion of heat exchanger and bad smell.
- Connect the pipe securely to avoid water leakage from the joint.
- Insulate the pipe properly to avoid condensation drop.
- Check if the water can flow out properly from both the drain outlet on the indoor unit and the end of the drain pipe after installation.
- Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway. In addition, do not put air vent on the drain pipe. Check if water is drained out properly from the pipe during commissioning. Also, keep sufficient space for inspection and maintenance.

Work procedure

1. Insert drain hose completely to the base, and tighten the drain hose clamp securely. (adhesive must not be used.)
※When plumbing on the left side, move the rubber plug and the cylindrical insulating materials by the pipe connecting hole on the left side of the unit to the right side.
⚠ Beware of a possible outflow of water that may occur upon removal of a drain plug.



2. Fix the drain hose at the lowest point with a hose clamp supplied as an accessory.
※Give a drain hose a gradient of 10mm as illustrated in the right drawing by laying it without leaving a slack.





● Take head of electrical cables so that they may not run beneath the drain hose.
⚠ A drain hose must be clamped down with a hose clamp.
There is a possibility that drain water overflows.
3. Connect VP20(prepare on site) to drain hose. (Adhesive must not be used.)
※ Use commercially available rigid PVC general pipe VP20 for drain pipe.
4. Do not to make the up-down bending and trap in the mid-way while assuming that the drain pipes is downhill. (more than 1/100)
● Never set up air vent.
5. Insulate the drain pipe.
● Insulate the drain hose clamp with the heat insulation supplied as accessories.
● When the unit is installed in a humid place, consider precautions against dew condensation such as heat insulation for the drain pipe.

Drain test

●After installation of drain pipe, make sure that drain system work in good condition and no water leakage from joint and drain pan.
●Do drain test even if installation of heating season.

⑦Wiring-out position and wiring connection

- Electrical installation work must be performed according to the installation manual by an electrical installation service provider qualified by a power provider of the country, and be executed according to the technical standards and other regulations applicable to electrical installation in the country. Be sure to use an exclusive circuit.
- Use specified cord, fasten the wiring to the terminal securely, and hold the cord securely in order not to apply unexpected stress on the terminal.
- Do not put both power source line and signal line on the same route. It may cause miscommunication and malfunction.
- Be sure to do D type earth work.
- For the details of electrical wiring work, see attached instruction manual for electrical wiring work.

1. Remove wiring from clips.
2. Remove the control box (Screw ①, 2pcs).
3. Pull out the control box by sliding along the groove on the bracket (Direction Ⓐ→Ⓑ).
4. Remove the lid of control box (Screw ②, 2pcs).
5. Hold each wiring inside the unit and connect to the terminal block surely.
6. Fix the wiring by clamp.
7. Install the lid of control box (Screw ②, 2pcs).
8. Return the control box to the original place by sliding along the groove on the bracket (Direction Ⓑ→Ⓐ).
9. Install the removed parts at their original places.

※1 Wiring for the signal receiving section of wireless kit (Option) and motion sensor kit (Option) are connected at the time of shipping from the factory. It is not necessary to disconnect these wiring when wired remote control is connected. When the wired/wireless kits are used together, it becomes necessary to set the slaves and remote control. For the methods of installing the wireless kit and the motion sensor kit, refer to the attached installation manuals.

NOTICE

When installing the Superlink adapter, remove the band fixed the wiring from receiver.



⑦Wiring-out position and wiring connection (continued)



⑧Control mode switching

● The control content of indoor units can be switched in following way. (▭ is the default setting)

Switch No.	Control Content	
SW8-4	ON	Indoor unit silent mode
	OFF	Normal operation

⑨Attaching the air return grille

● The air return grille must be attached when electrical cabling work is completed.

1. Fix the chains tied to the air return grille onto the indoor unit with screws supplied as accessories (4 pieces).
2. Close the air return grille. This completes the unit installtion work.



⑩Check list after installation

● Check the following items after all installation work completed.

Check if	Expected trouble	Check
The indoor and outdoor units are fixed securely?	Falling, vibration, noise	
Inspection for leakage is done?	Insufficient capacity	
Insulation work is properly done?	Water leakage	
Water is drained properly?	Water leakage	
Power source voltage is same as mentioned in the model name plate?	PCB burnt out, not working at all	
There is mis-wiring or mis-connection of piping?	PCB burnt out, not working at all	
Earth wiring is connected properly?	Electric shock	
Cable size comply with specified size?	PCB burnt out, not working at all	
Any obstacle blocks air flow on air inlet and outlet?	Insufficient capacity	

(6) Wall mounted type (SRK)

RLF012A202B△D

(a) Models SRK50, 60ZSX-W

Model SRK20,25,35,50,60ZSX
R32/R410A REFRIGERANT USED

• This installation manual deals with an indoor unit installation only. For an outdoor unit installation, refer to page 211.
• This unit is designed for R32 or R410A. See a label on the outdoor unit to check refrigerant information.

SAFETY PRECAUTIONS

• Before installation, read the "SAFETY PRECAUTIONS" carefully and strictly follow it during the installation work in order to protect yourself.
• The precautionary items mentioned below are distinguished into two levels, ⚠WARNING and ⚠CAUTION .

⚠WARNING Indicates a potentially hazardous situation which, if not avoided, can result in serious consequences such as death or severe injury.

⚠CAUTION Indicates a potentially hazardous situation which, if not avoided, can result in personal injury or property damage.

Both mention the important items to protect your health and safety. Therefore, strictly follow them by any means.

• Be sure to confirm no operation problem on the equipment after completing the installation. If unusual noise can be heard during the test run, consult the dealer.
• Be sure to explain the operating methods as well as the maintenance methods of this equipment to the user according to the user's manual.
• Be sure to keep the installation manual together with user's manual at a place where it is easily accessible to the user any time. Moreover, ask the user to hand the manuals to a new user, whenever required.

⚠ WARNING

- **Be sure to use only for residential purpose.**
  If this unit is installed in inferior environment such as machine shop, vehicle (like ship), warehouse, etc., it can malfunction.
- **Installation must be carried out by the qualified installer completely in accordance with the installation manual.**
  Installation by non qualified person or incorrect installation can cause serious troubles such as water leak, electric shock, fire and personal injury.
- **Be sure to wear protective goggles and gloves while performing installation work.**
  Improper safety measures can result in personal injury.
- **Use the original accessories and the specified components for the installation.**
  Using parts other than those prescribed may cause water leak, electric shock, fire and personal injury.
- **Do not install the unit near the location where leakage of flammable gases can occur.**
  If leaked gases accumulate around the unit, it can cause fire resulting in property damage and personal injury.
- **When installing the unit in small rooms, make sure that refrigerant density does not exceed the limit (Reference: ISO5149) in the event of leakage.**
  If refrigerant density exceeds the limit, consult the dealer and install the ventilation system.
  Otherwise lack of oxygen can occur resulting in serious accident.
- **Install the unit in a location where unit will remain stable, horizontal and free of any vibration transmission.**
  Unsuitable installation location can cause the unit to fall resulting in material damage and personal injury.
- **Do not run the unit with removed panels or protections.**
  Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shock.
- **This unit is designed specifically for R32 or R410A.**
  Using any other refrigerant can cause unit failure and personal injury.
- **Do not vent R32 or R410A into atmosphere.**
  R32 is a fluorinated greenhouse gas with a Global Warming Potential(GWP)=675.
  R410A is a fluorinated greenhouse gas with a Global Warming Potential(GWP)=2088.
- **Make sure that no air enters the refrigerant circuit when the unit is installed and removed.**
  If air enters the refrigerant circuit, the pressure in the refrigerant circuit will become too high, which can cause burst and personal injury.
- **Be sure to use the prescribed pipes, flare nuts and tools for R32 or R410A.**
  Using existing parts (for R22 or R407C) can cause refrigerant circuit burst resulting in unit failure and personal injury.
- **Be sure to connect both liquid and gas connecting pipes properly before operating the compressor.**
  Do not open the liquid and gas service valves before completing piping work, and evacuation.
  If the compressor is operated when connecting pipes are not connected and service valves are open, air can be sucked into the refrigerant circuit which can cause anomalous high pressure resulting in burst or personal injury.
- **Be sure to tighten the flare nuts to specified torque using the torque wrench.**
  Tightening flare nuts with excess torque can cause burst and refrigerant leakage after a long period.
- **During pump down work, be sure to stop the compressor before closing service valves and removing connecting pipes.**
  If the connecting pipes are removed when the compressor is in operation and service valves are open, air can be sucked into the refrigerant circuit which can cause anomalous high pressure resulting in burst or personal injury.
- **In the event of refrigerant leakage during installation, be sure to ventilate the working area properly.**
  If the refrigerant comes into contact with naked flames, poisonous gases will be produced.
- **Electrical work must be carried out by the qualified electrician, strictly in accordance with national or regional electricity regulations.**
  Incorrect installation can cause electric shock, fire or personal injury.
- **Make sure that earth leakage breaker and circuit breaker of appropriate capacities are installed.**
  Circuit breaker should be able to disconnect all poles under over current. Absence of appropriate breakers can cause electric shock, personal injury or property damage.
- **Be sure to switch off the power source in the event of installation, maintenance or service.**
  If the power source is not switched off, there is a risk of electric shock, unit failure or personal injury.
- **Be sure to tighten the cables securely in terminal block and relieve the cables properly to prevent overloading the terminal blocks.**
  Loose connections or cable mountings can cause anomalous heat production or fire.
- **Do not process, splice or modify the power cable, or share the socket with other power plugs.**
  Improper power cable or power plug can cause fire or electric shock due to poor connection, insufficient insulation or over-current.
- **Do not perform any change in protective device or its setup condition yourself.**
  Changing protective device specifications can cause electric shock, fire or burst.
- **Be sure to clamp the cables properly so that they do not touch any internal component of the unit.**
  If cables touch any internal component, it can cause overheating and fire.
- **Be sure to install service cover properly.**
  Improper installation can cause electric shock or fire due to intrusion of dust or water.
- **Be sure to use the prescribed power and connecting cables for electrical work.**
  Using improper cables can cause electric leak or fire.
- **This appliance must be connected to main power source by means of a circuit breaker or switch with a contact separation of at least 3mm.**
  Improper electrical work can cause unit failure or personal injury.
- **When plugging this unit, a plug conforming to the standard IEC60884-1 must be used.**
  Using improper plug can cause electric shock or fire.
- **Be sure to connect the power source cable with power source properly.**
  Improper connection can cause intrusion of dust or water resulting in electric shock or fire.

⚠ CAUTION

- **Take care when carrying the unit by hand.**
  If the unit weight is more than 20kg, it must be carried by two or more persons.
  Do not carry the unit by the plastic straps. Always use the carry handle.
- **Do not install the outdoor unit in a location where insects and small animals can inhabit.**
  Insects and small animals can enter the electrical parts and cause damage resulting in fire or personal injury. Instruct the user to keep the surroundings clean.
- **If the outdoor unit is installed at height, make sure that there is enough space for installation, maintenance and service.**
  Insufficient space can result in personal injury due to falling from the height.
- **Do not install the unit near the location where neighbours are bothered by noise or air generating from the unit.**
  It can affect surrounding environment and cause a claim.
- **Do not install in the locations where unit is directly exposed to corrosive gases (like sulphide gas, chloride gas), sea breeze or salty atmosphere.**
  It can cause corrosion of heat exchanger and damage to plastic parts.
- **Do not install the unit close to the equipments that generate electromagnetic waves and/or high-harmonic waves.**
  Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns.
  The system can also affect medical equipment and telecommunication equipment, and obstruct its function or cause jamming.
- **Do not install the unit in the locations where:**
  • There are heat sources nearby.
  • Unit is directly exposed to rain or sunlight.
  • There is any obstacle which can prevent smooth air circulation from inlet and outlet side of the unit.
  • Unit is directly exposed to oil mist and steam such as kitchen.
  • Chemical substances like ammonia (organic fertilizer), calcium chloride (snow melting agent) and acid (sulfurous acid etc.), which can harm the unit, will generate or accumulate.
  • Drain water can not be discharged properly.
  • TV set or radio receiver is placed within 1m.
  • Height above sea level is more than 1000m.
  It can cause performance degradation, corrosion and damage of components, unit malfunction and fire.
- **Dispose of all packing materials properly.**
  Packing materials contain nails and wood which can cause personal injury.
  Keep the polybag away from children to avoid the risk of suffocation.
- **Do not put anything on the outdoor unit.**
  Object may fall causing property damage or personal injury.
- **Do not touch the aluminum fin of the outdoor unit.**
  Aluminium fin temperature is high during heating operation. Touching fin can cause burn.
- **Do not touch any refrigerant pipe with your hands when the system is in operation.**
  During operation the refrigerant pipes become extremely hot or extremely cold depending on the operating condition. Touching pipes can cause personal injury like burn (hot/cold).
- **Install isolator or disconnect switch on the power source wiring in accordance with the local codes and regulations.**
  The isolator should be locked in OFF state in accordance with EN60204-1.

1. ACCESSORIES AND TOOLS

Standard accessories (Supplied with indoor unit)

(1)	Installation board	1pc	(5)	Wood screws (for remote control holder ø3.5 X 16mm)		2pcs
(2)	Wireless remote control	1pc	(6)	Batteries [R03 (AAA, Micro) 1.5V]		2pcs
(3)	Remote control holder	1pc	(7)	Air-cleaning filters		2pcs
(4)	Tapping screws (for installation board ø4 X 25mm)	5pcs	(8)	Insulation (#486 50 X 100 t3)		1pc

Locally procured parts

(a)	Sleeve (1pc)
(b)	Sealing plate (1pc)
(c)	Inclination plate (1pc)
(d)	Putty
(e)	Connecting cable
(f)	Drain hose (extension hose)
(g)	Piping cover (for insulation of connection piping)
(h)	Clamp and screw (for finishing work)
(i)	Electrical tape

Tools for installation work

Plus headed driver	Pipe cutter
Knife	Hole core drill (65mm in diameter)
Saw	Wrench key (Hexagon) [4mm]
Tape measure	Flaring tool set*
Torque wrench (14.0-62.0N·m (1.4-6.2kgf·m))	Gas leak detector*
	Pipe bender
Plier	Flare adjustment gauge

* Designed specifically for R32 or R410A

2. SELECTING INSTALLATION LOCATION

After getting customer's approval, select installation location according to following guidelines.

1. Indoor unit

- Where there is no obstruction to the airflow and where the cooled and heated air can be evenly distributed.
- A solid place where the unit or the wall will not vibrate.
- A place where there will be enough space for servicing. (Where space mentioned on the right side can be secured.)
- Where it is easy to conduct wiring and piping work.
- A place where unit is not directly exposed to sunlight or street light.
- A place where it can be easily drained.
- A place separated at least 1m away from the television or the radio. (To prevent interference to images and sounds.)
- A place where this unit is not affected by the high frequency equipment or electric equipment.
- Avoid installing this unit in place where there is much oil mist.
- A place where there is no electric equipment or household.
- Install the indoor unit on the wall where the height from the floor to the bottom of the unit is more than 180 cm.

2. Wireless remote control

- A place where the air-conditioner can receive the signal surely during operating the wireless remote control.
- A place where it is not affected by the TV, radio etc.
- Do not place where it is exposed to direct sunlight or near heat devices such as a stove.





3. INSTALLING INSTALLATION BOARD

- Installation board should be installed on the wall which can support the weight of the indoor unit.
- Adjustment of the installation board in the horizontal direction is to be conducted with 5 screws in a temporary tightened state.
- With the standard hole as a center, adjust the board and level it.



⚠ CAUTION

Improper adjustment of the installation board can cause water leakage.



4. DRILLING HOLE AND FIXTURE OF SLEEVE

When drilling the wall that contains a metal lath, wire lath or metal plate, be sure to use sealing plate, sleeve and inclination plate (Locally procured parts).



(1) Drill a hole with hole core drill.



(2) Cut sleeve to adjust to wall thickness. In case of rear piping draw out, cut off the lower and the right side portions of the sleeve collar.



(3) Fix sealing plate, sleeve and inclination plate.



(4) After piping work, seal the hole in the wall with putty.

⚠ WARNING

Completely seal the hole in the wall with putty. If not sealed properly, dust, insects, small animals, and highly humid air may enter the room from outside, which could result in fire or other hazards.

⚠ CAUTION

Completely seal the hole in the wall with putty. If not sealed properly, furniture and other fixtures may be damaged by water leakage or condensation.

5. ELECTRICAL WIRING WORK

- Before installation, make sure that the power source complies with the air-conditioner's power specification.
- Carry out electrical wiring work according to following guidelines.

1. Preparing cable

(1) Selecting cable
Select the connecting cable in accordance with the specifications mentioned below.
4-core* 1.5mm² conformed with 60245 IEC57
* 1 Earth wire is included (Yellow/Green).

(2) Arrange each wire length as shown below.
Make sure that each wire is stripped 10mm from the end.

<Connecting cable> <Wire end>



(3) Attach round crimp-type terminal to each wire as shown in the below.
Select the size of round crimp-type terminal after considering the specifications of terminal block and wire diameter.



2. Remove bottom panel

(1) Remove the 3 screws (in the cap).
(2) Remove the hooks of left and right side and then bottom panel can be removed.

NOTE

- Open the cap using a fine-tipped tool.
- When opening the cap, exercise care not to damage the design surface.



3. Connecting cable

(1) Remove the terminal cover.
(2) Remove the cable clamp.
(3) Connect the connecting wires to the terminal block.
(4) Fix the connecting cable by cable clamp.
(5) Fix the terminal cover.

NOTE

Take care not to confuse the terminal numbers for indoor and outdoor connections.



⚠ WARNING

Incorrect wiring connection can cause malfunction or fire.

6. FORMING PIPING AND DRAIN HOSE

1. Forming piping

Piping is possible in the right, rear, downward, left, left rear or left downward direction.

NOTE

Sufficient care must be taken not to damage the panels when connecting pipes.



Cut out the panel smoothly along the line in case of side or bottom piping.



Left hand side piping	Right hand side piping
	

Forming of pipings
- Hold the bottom of the piping and fix direction before stretching it and shaping it.



Taping of the exterior
- Tape only the portion that goes through the wall.
- Always tape the wiring with the piping.

2. Drain change procedures

(1) Remove the screw and drain hose.
(2) Remove the drain cap by hand or pliers.
(3) Insert the drain cap which was removed at procedure (2) securely using a hexagonal wrench etc.
(4) Install the drain hose and screw securely.



⚠ CAUTION

Incorrect installation of drain hose and cap can cause water leakage.

7. DRAINAGE WORK

- Arrange the drain hose in a downward angle.
- Avoid the following drain piping.

- Pour water to the drain pan located under the heat exchanger, and ensure that the water is discharged outdoor.
- When extended drain hose is present inside the room, insulate it securely with heat insulator available in the market.

Since this air-conditioner is designed to collect dew drops on the rear surface to the drain pan, do not install the connecting wire above the gutter.

⚠ CAUTION

Incorrect drainage work can cause water leakage.



8. INSTALLING INDOOR UNIT

Installing the indoor unit to installation board

(1) Pass the pipe through the hole in the wall, and hook the upper part of the indoor unit to the installation board.

(2) Gently push the lower part to fix the indoor unit base lower latch to installation board.

(3) Install the latches of the bottom panel (7 locations).
Secure the bottom panel with the 3 screws (in the cap).



Removing the indoor unit from installation board

(1) Remove the bottom panel. (Refer to 5.2)
(2) Pull the indoor unit base latch downward. (both right and left hand sides). (The indoor unit base latch can be removed from the installation board.)
(3) Push up the indoor unit upward so that it can be removed from installation board.



9. CONNECTING PIPING WORK

1. Preparation of connecting pipe

1.1. Selecting connecting pipe

Select connecting pipe according to the following table.

	Model SRK20/25/35	Model SRK50/60
Gas pipe	ø9.52	ø12.7
Liquid pipe	ø6.35	ø6.35

- Pipe wall thickness must be greater than or equal to 0.8 mm.
- Pipe material must be O-type (Phosphorus deoxidized seamless copper pipe ICS 23.040.15, ICS 77.150.30).

1.2. Cutting connecting pipe

(1) Cut the connecting pipe to the required length with pipe cutter.
(2) Hold the pipe downward and remove the burrs. Make sure that no foreign material enters the pipe.
(3) Cover the connecting pipe ends with the tape.

2. Piping work

2.1. Flaring pipe

(1) Take out flare nuts from the service valves of indoor unit and engage them onto connecting pipes.
(2) Flare the pipes according to table and figure shown below.
Flare dimensions for R32 are different from those for conventional refrigerant.
Although it is recommended to use the flaring tools designed specifically for R32 or R410A, conventional flaring tools can also be used by adjusting the measurement of protrusion B with a flare adjustment gauge.

Copper pipe outer diameter	$A^{0}_{-0.4}$
ø6.35	9.1
ø9.52	13.2
ø12.7	16.6



Copper pipe outer diameter	Rigid (clutch) type	
	R32 or R410A	Conventional
ø6.35	0-0.5	1.0-1.5
ø9.52		
ø12.7		

2.2 Connecting pipes

(1) Connect pipes on both liquid and gas sides.
(2) Tighten nuts to specified torque shown in the table below.

Service valve size (mm)	Tightening torque (N·m)
ø6.35 (1/4")	14-18
ø9.52 (3/8")	34-42
ø12.7 (1/2")	49-61



⚠ CAUTION

- Do not apply refrigerating machine oil to the flared surface. It can cause refrigerant leakage.
- Do not apply excess torque to the flared nuts. The flared nuts may crack resulting in refrigerant leakage.

3. Heating and condensation prevention

(1) Dress the connecting pipes (both liquid and gas pipes) with insulation to prevent it from heating and dew condensation.
Use the heat insulating material which can withstand 120°C or higher temperature. Make sure that insulation is wrapped tightly around the pipes and no gap is left between them.
(2) Wrap the refrigerant pipings of indoor unit with indoor unit heat insulation using tape.
(3) Cover the flare-connected joints (indoor side) with the indoor unit heat insulation and wrap it with an insulation pad (standard accessory provided with indoor unit).
(4) Wrap the connecting pipes, connecting cable and drain hose with the tape.



NOTE

Locations where relative humidity exceeds 70%, both liquid and gas pipes need to be dressed with 20mm or thicker heat insulation materials.

⚠ CAUTION

- Improper insulation can cause condensate(water) formation during cooling operation. Condensate can leak or drip causing damage to household property.
- Poor heat insulating capacity can cause pipe outer surface to reach high temperature during heating operation. It can cause cable deterioration and personal injury.

4. Finishing work

(1) Make sure that the exterior portion of connecting pipes, connecting cable and drain hose is wrapped properly with tape. Shape the connecting pipes to match with the contours of the pipe assembly route.
(2) Fix the pipe assembly with the wall using clamps and screws. Pipe assembly should be anchored every 1.5m or less to isolate the vibration.
(3) Install the service cover securely. Water may enter the unit if service cover is not installed properly, resulting in unit malfunction and failure.



⚠ WARNING (only for R32)

- To avoid the risk of fire or explosion, the flared connection must/shall be installed outdoors.
- Reusable mechanical connectors and flared joints are not allowed indoors.



⚠ CAUTION

Make sure that the connecting pipes do not touch the components within the unit. If pipes touch the internal components, it may generate abnormal sounds and/or vibrations.

10. HOW TO OPEN, CLOSE, REMOVE AND INSTALL THE AIR INLET PANEL

1. Open
Pull the air inlet panel at both ends of lower part and release latches, then pull up the panel until you feel resistance.
(The panel stops at approx. 60° open position)

2. Close
Hold the panel at both ends of lower part, lower it downward slowly, then push it slightly until the latch works.

3. Removing
Open the panel by 80° (as shown in the right illustration) and then pull it forward.

4. Installing
Insert the panel arm into the slot on the front panel from the position shown in right illustration, hold the panel at both ends of lower part, lower it downward slowly, then push it slightly until the latch works.



NOTE
- When carrying out maintenance, handle the air inlet panel with care.

11. HOW TO REMOVE AND INSTALL THE SIDE AND FRONT PANEL

1. Side panel (R/L)

1.1. Removing
(1) Remove the 2 screws.
(2) Remove the 3 latches and then side panel can be removed.

1.2. Installing
(1) Cover the unit with the side panel and fix 3 latches.
(2) Secure the side panel with the 2 screws.

2. Front panel

2.1. Removing
(1) Remove the side panel (R/L), the air inlet panel, the air filters and the bottom panel.
(2) Remove the 3 screws.
(3) Remove the 4 upper latches and then front panel can be removed.

2.2. Installing
(1) Cover the unit with the front panel and fix 4 upper latches.
(2) Secure the front panel with the 3 screws.
(3) Install the bottom panel, the side panel (R/L), the air inlet panel and the air filters.

<Top view>





12. INSTALLING WIRELESS REMOTE CONTROL

Mount the batteries
(1) Slide and take out the cover of backside.
(2) Mount the batteries [R03 (AAA, Micro), ×2 pieces] in the body properly.
(Fit he poles with the indication marks + & −)
(3) Set the cover again.

NOTE
- Do not use new and old batteries together.
- In case the unit is not operated for a long time, take out the batteries



Installing remote control holder
(1) Select the place where the unit can receive signals.
(2) Fix the holder to pillar or wall with wood screws.



13. INSTALLING TWO AIR-CONDITIONERS IN THE SAME ROOM

In case two air-conditioners are installed in the same room, apply this setting so that one unit can be operated with only one wireless remote control.

Setting one wireless remote control
(1) Slide and take out the cover and batteries.
(2) Cut the switching line next to the battery with wire cutters.
(3) Set the batteries and cover again.

Setting one indoor unit
(1) Turn off the power source and turn it on after 1 minute.
(2) Send the signal by pressing the ACL switch on the wireless remote control that was set according to the procedure described on the above side.
(3) Check that the reception buzzer sound “Peep” is emitted from the indoor unit. Since the signal is sent about 6 seconds after the ACL switch is pressed, point the wireless remote control to the indoor unit for a while.



NOTE
If no reception buzzer is emitted, restart the setting from the beginning.

14. TERMINAL CONNECTION FOR AN INTERFACE

To install wired remote control, superlink etc., interface kit is needed.

(1) Remove the air inlet panel, bottom panel and side panel (R).
(2) Remove the control cover. (Remove the screw.)
(3) There is a terminal (respectively marked with CNS) for the indoor control board. While connecting an interface, connect to the respective terminal securely with the connection harness supplied with an option “Interface kit SC-BIKN-E and SC-BIKN2-E” and fasten the connection harness onto the indoor control box with the clamp and screw supplied with the kit.
(4) Hook to fix the interface kit to the 2 latches on side panel (L).
For more details, refer to the user’s manual of “Interface kit SC-BIKN-E and SC-BIKN2-E”.

<Right side>





15. PUMP DOWN WORK

For the environmental protection, be sure to pump down when relocating or disposing of the unit. Pump down is the method of recovering refrigerant from the indoor unit to the outdoor unit before the connecting pipes are removed from the unit. When pump down is carried out, forced cooling operation is needed.

Forced cooling operation
(1) Turn off the power source and turn it on again after 1 minute. The air inlet panel and flap open and close.
(2) After the air inlet panel closes, press the ON/OFF button continuously for at least 5 seconds. Then operation will start.

For the detail of pump down, refer to the installation manual of outdoor unit.



16. INSTALLATION CHECK AND TEST RUN

After finishing the installation work, check the following points again before turning on the power. Conduct a test run and ensure that the unit operates properly.
At the same time, explain to the customer how to use the unit and how to take care of the unit following the user’s manual.

Before test run
Before test run, check following points.

Power source voltage complies with the rated voltage of air-conditioner.	
Earth leakage breaker and circuit breaker are installed.	
Power cable and connecting cable are securely fixed to the terminal block.	
Both liquid and gas service valves are fully open.	
No gas leaks from the joints of the service valves.	
Indoor and outdoor side pipe joints have been insulated.	
Hole on the wall is completely sealed with putty.	
Drain hose and cap are installed properly.	
Screw of the terminal cover is tightened securely.	

Test run
Check following points during test run.

Indoor unit receives signal of wireless remote control.	
Air-conditioning operation is normal.	
There is no abnormal noise.	
Water drains out smoothly.	
Display of wireless remote control is normal.	

After test run

Explain the operating and maintenance methods to the user according to the user’s manual.	
Keep this installation manual together with user’s manual.	

NOTE
During restart or change in operation mode, the unit will not start operating for approximately 3 minutes. This is to protect the unit and it is not malfunction.

RLD012A018 A

Model SRK63,71,80,100ZR
R32/R410A REFRIGERANT USED

(b) Models SRK71, 100ZR-W

• This installation manual deals with an indoor unit installation only. For an outdoor unit installation, refer to page 211.
• This unit is designed for R32 or R410A. See a label on the outdoor unit to check refrigerant information.

SAFETY PRECAUTIONS

• Before installation, read the "SAFETY PRECAUTIONS" carefully and strictly follow it during the installation work in order to protect yourself.
• The precautionary items mentioned below are distinguished into two levels, ⚠ WARNING and ⚠ CAUTION .

⚠ WARNING Indicates a potentially hazardous situation which, if not avoided, can result in serious consequences such as death or severe injury.
⚠ CAUTION Indicates a potentially hazardous situation which, if not avoided, can result in personal injury or property damage.

Both mention the important items to protect your health and safety. Therefore, strictly follow them by any means.

• Be sure to confirm no operation problem on the equipment after completing the installation. If unusual noise can be heard during the test run, consult the dealer.
• Be sure to explain the operating methods as well as the maintenance methods of this equipment to the user according to the user's manual.
• Be sure to keep the installation manual together with user's manual at a place where it is easily accessible to the user any time. Moreover, ask the user to hand the manuals to a new user, whenever required.

⚠ WARNING

- **Be sure to use only for residential purpose.**
  If this unit is installed in inferior environment such as machine shop, vehicle (like ship), warehouse, etc., it can malfunction.
- **Installation must be carried out by the qualified installer completely in accordance with the installation manual.**
  Installation by non qualified person or incorrect installation can cause serious troubles such as water leak, electric shock, fire and personal injury.
- **Be sure to wear protective goggles and gloves while performing installation work.**
  Improper safety measures can result in personal injury.
- **Use the original accessories and the specified components for the installation.**
  Using parts other than those prescribed may cause water leak, electric shock, fire and personal injury.
- **Do not install the unit near the location where leakage of flammable gases can occur.**
  If leaked gases accumulate around the unit, it can cause fire resulting in property damage and personal injury.
- **When installing the unit in small rooms, make sure that refrigerant density does not exceed the limit (Reference: ISO5149) in the event of leakage.**
  If refrigerant density exceeds the limit, consult the dealer and install the ventilation system.
  Otherwise lack of oxygen can occur resulting in serious accident.
- **Install the unit in a location where unit will remain stable, horizontal and free of any vibration transmission.**
  Unsuitable installation location can cause the unit to fall resulting in material damage and personal injury.
- **Do not run the unit with removed panels or protections.**
  Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shock.
- **This unit is designed specifically for R32 or R410A.**
  Using any other refrigerant can cause unit failure and personal injury.
- **Do not vent R32 or R410A into atmosphere.**
  R32 is a fluorinated greenhouse gas with a Global Warming Potential(GWP)=675.
  R410A is a fluorinated greenhouse gas with a Global Warming Potential(GWP)=2088.
- **Make sure that no air enters the refrigerant circuit when the unit is installed and removed.**
  If air enters the refrigerant circuit, the pressure in the refrigerant circuit will become too high, which can cause burst and personal injury.
- **Be sure to use the prescribed pipes, flare nuts and tools for R32 or R410A.**
  Using existing parts (for R22 or R407C) can cause refrigerant circuit burst resulting in unit failure and personal injury.
- **Be sure to connect both liquid and gas connecting pipes properly before operating the compressor.**
  Do not open the liquid and gas operation valves before completing piping work, and evacuation.
  If the compressor is operated when connecting pipes are not connected and operation valves are open, air can be sucked into the refrigerant circuit which can cause anomalous high pressure resulting in burst or personal injury.
- **Be sure to tighten the flare nuts to specified torque using the torque wrench.**
  Tightening flare nuts with excess torque can cause burst and refrigerant leakage after a long period.
- **During pump down work, be sure to stop the compressor before closing operation valves and removing connecting pipes.**
  If the connecting pipes are removed when the compressor is in operation and operation valves are open, air can be sucked into the refrigerant circuit which can cause anomalous high pressure resulting in burst or personal injury.
- **In the event of refrigerant leakage during installation, be sure to ventilate the working area properly.**
  If the refrigerant comes into contact with naked flames, poisonous gases will be produced.
- **Electrical work must be carried out by the qualified electrician, strictly in accordance with national or regional electricity regulations.**
  Incorrect installation can cause electric shock, fire or personal injury.
- **Make sure that earth leakage breaker and circuit breaker of appropriate capacities are installed.**
  Circuit breaker should be able to disconnect all poles under over current. Absence of appropriate breakers can cause electric shock, personal injury or property damage.
- **Be sure to switch off the power source in the event of installation, maintenance or service.**
  If the power source is not switched off, there is a risk of electric shock, unit failure or personal injury.
- **Be sure to tighten the cables securely in terminal block and relieve the cables properly to prevent overloading the terminal blocks.**
  Loose connections or cable mountings can cause anomalous heat production or fire.
- **Do not process, splice or modify the power cable, or share the socket with other power plugs.**
  Improper power cable or power plug can cause fire or electric shock due to poor connection, insufficient insulation or over-current.
- **Do not perform any change in protective device or its setup condition yourself.**
  Changing protective device specifications can cause electric shock, fire or burst.
- **Be sure to clamp the cables properly so that they do not touch any internal component of the unit.**
  If cables touch any internal component, it can cause overheating and fire.
- **Be sure to install service cover properly.**
  Improper installation can cause electric shock or fire due to intrusion of dust or water.
- **Be sure to use the prescribed power and connecting cables for electrical work.**
  Using improper cables can cause electric leak or fire.
- **This appliance must be connected to main power source by means of a circuit breaker or switch with a contact separation of at least 3mm.**
  Improper electrical work can cause unit failure or personal injury.
- **When plugging this unit, a plug conforming to the standard IEC60884-1 must be used.**
  Using improper plug can cause electric shock or fire.
- **Be sure to connect the power source cable with power source properly.**
  Improper connection can cause intrusion of dust or water resulting in electric shock or fire.

⚠ CAUTION

- **Take care when carrying the unit by hand.**
  If the unit weight is more than 20kg, it must be carried by two or more persons.
  Do not carry the unit by the plastic straps. Always use the carry handle.
- **Do not install the outdoor unit in a location where insects and small animals can inhabit.**
  Insects and small animals can enter the electrical parts and cause damage resulting in fire or personal injury. Instruct the user to keep the surroundings clean.
- **If the outdoor unit is installed at height, make sure that there is enough space for installation, maintenance and service.**
  Insufficient space can result in personal injury due to falling from the height.
- **Do not install the unit near the location where neighbours are bothered by noise or air generating from the unit.**
  It can affect surrounding environment and cause a claim.
- **Do not install in the locations where unit is directly exposed to corrosive gases (like sulphide gas, chloride gas), sea breeze or salty atmosphere.**
  It can cause corrosion of heat exchanger and damage to plastic parts.
- **Do not install the unit close to the equipments that generate electromagnetic waves and/or high-harmonic waves.**
  Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns.
  The system can also affect medical equipment and telecommunication equipment, and obstruct its function or cause jamming.
- **Do not install the unit in the locations where:**
  • There are heat sources nearby.
  • Unit is directly exposed to rain or sunlight.
  • There is any obstacle which can prevent smooth air circulation from inlet and outlet side of the unit.
  • Unit is directly exposed to oil mist and steam such as kitchen.
  • Chemical substances like ammonia (organic fertilizer), calcium chloride (snow melting agent) and acid (sulfurous acid etc.), which can harm the unit, will generate or accumulate.
  • Drain water can not be discharged properly.
  • TV set or radio receiver is placed within 1m.
  • Height above sea level is more than 1000m.
  It can cause performance degradation, corrosion and damage of components, unit malfunction and fire.
- **Dispose of all packing materials properly.**
  Packing materials contain nails and wood which can cause personal injury.
  Keep the polybag away from children to avoid the risk of suffocation.
- **Do not put anything on the outdoor unit.**
  Object may fall causing property damage or personal injury.
- **Do not touch the aluminum fin of the outdoor unit.**
  Aluminium fin temperature is high during heating operation. Touching fin can cause burn.
- **Do not touch any refrigerant pipe with your hands when the system is in operation.**
  During operation the refrigerant pipes become extremely hot or extremely cold depending on the operating condition. Touching pipes can cause personal injury like burn (hot/cold).
- **Install isolator or disconnect switch on the power source wiring in accordance with the local codes and regulations.**
  The isolator should be locked in OFF state in accordance with EN60204-1.

1. ACCESSORIES AND TOOLS

Standard accessories (supplied with indoor unit)

(1)	Installation board	1pc	(6)	Batteries [R03 (AAA, Micro) 1.5V]		2pcs
(2)	Remote control	1pc	(7)	Air-cleaning filters		2pcs
(3)	Remote control holder	1pc	(8)	Filter holders		2pcs
(4)	Tapping screws (for installation board ø4 X 25mm)	10pcs	(9)	Insulation (#486 50 X 100 t3)		1pc
(5)	Wood screws (for remote control holder ø3.5 X 16mm)	2pcs				

Locally procured parts

(a)	Sleeve (1pc)
(b)	Sealing plate (1pc)
(c)	Inclination plate (1pc)
(d)	Putty
(e)	Connecting cable
(f)	Drain hose (extension hose)
(g)	Piping cover (for insulation of connection piping)
(h)	Clamp and screw (for finishing work)
(i)	Electrical tape

Tools for installation Work

Plus headed driver	Hole core drill (65mm in diameter)
Knife	Wrench key (Hexagon) [4mm]
Saw	Flaring tool set*
Tape measure	Gas leak detector*
Torque wrench (14.0-82.0N·m (1.4-8.2kgf·m))	Pipe bender
Plier	Gauge for projection adjustment (Used when flare is made by using conventional flare tool)
Pipe cutter	

* Designed specifically for R32 or R410A

2. SELECTING INSTALLATION LOCATION

After getting customer's approval, select installation location according to following guidelines.

1. Indoor unit

- Where there is no obstruction to the airflow and where the cooled and heated air can be evenly distributed.
- A solid place where the unit or the wall will not vibrate.
- A place where there will be enough space for servicing. (Where space mentioned on the right side can be secured.)
- Where it is easy to conduct wiring and piping work.
- A place where unit is not directly exposed to sunlight or street light.
- A place where it can be easily drained.
- A place separated at least 1m away from the television or the radio. (To prevent interference to images and sounds.)
- A place where this unit is not affected by the high frequency equipment or electric equipment.
- Avoid installing this unit in place where there is much oil mist.
- A place where there is no electric equipment or household.
- Install the indoor unit on the wall where the height from the floor to the bottom of the unit is more than 180 cm.

2. Remote control

- A place where the air-conditioner can receive the signal surely during operating the remote control.
- A place where it is not affected by the TV, radio etc.
- Do not place where it is exposed to direct sunlight or near heat devices such as a stove.



3. INSTALLING INSTALLATION BOARD

- Installation board should be installed on the wall which can support the weight of the indoor unit.
- Adjustment of the installation board in the horizontal direction is to be conducted with 8 screws in a temporary tightened state.
- With the standard hole as a center, adjust the board and level it.





In case of fixing the unit on concrete wall, use nut anchor.



⚠ CAUTION

Improper adjustment of the installation board can cause water leakage.

4. DRILLING HOLE AND FIXTURE OF SLEEVE

When drilling the wall that contains a metal lath, wire lath or metal plate, be sure to use sealing plate, sleeve and inclination plate (Locally procured parts).



(1) Drill a hole with hole core drill.



(2) Cut sleeve to adjust to wall thickness. In case of rear piping draw out, cut off the lower and the right side portions of the sleeve collar.



(3) Fix sealing plate, sleeve and inclination plate.



(4) After piping work, seal the hole in the wall with putty.

⚠ WARNING

Completely seal the hole in the wall with putty. If not sealed properly, dust, insects, small animals, and highly humid air may enter the room from outside, which could result in fire or other hazards.

⚠ CAUTION

Completely seal the hole in the wall with putty. If not sealed properly, furniture and other fixtures may be damaged by water leakage or condensation.

5. ELECTRICAL WIRING WORK

- Before installation, make sure that the power source complies with the air-conditioner's power specification.
- Carry out electrical wiring work according to following guidelines.

1. Preparing cable

(1) Selecting cable
Select the connecting cable in accordance with the specifications mentioned below.
4-core* 1.5mm² conformed with 60245 IEC57
* 1 Earth wire is included (Yellow/Green).

(2) Arrange each wire length as shown below.
Make sure that each wire is stripped 10mm from the end.

<Connecting cable> <Wire end>



(3) Attach round crimp-type terminal to each wire as shown in the below.
Select the size of round crimp-type terminal after considering the specifications of terminal block and wire diameter.



2. Connecting cable

(1) Open the air inlet panel.
(2) Remove the lid.
(3) Remove the cable clamp.
(4) Connect the connecting wires to the terminal block.
(5) Fix the connecting cable by cable clamp.
(6) Fix the lid.
(7) Close the air inlet panel.

NOTE

Take care not to confuse the terminal numbers for indoor and outdoor connections.



• Earth wire shall be Yellow/Green (Y/G) in color and longer than other AC wires for safety reason.

⚠ WARNING

Incorrect wiring connection can cause malfunction or fire.

6. FORMING PIPING AND DRAIN HOSE

1. Forming piping

Piping is possible in the right, rear, downward, left, left rear or left downward direction.

NOTE

Sufficient care must be taken not to damage the panels when connecting pipes.



Left hand side piping	Right hand side piping
	

Forming of pipings.
- Hold the bottom of the piping and fix direction before stretching it and shaping it.



Taping of the exterior
- Tape only the portion that goes through the wall.
- Always tape the wiring with the piping.

2. Drain change procedures

(1) Remove the screw and drain hose.
(2) Remove the drain cap by hand or pliers.
(3) Insert the drain cap which was removed at procedure (2) securely using a hexagonal wrench etc.
(4) Install the drain hose and screw securely.



⚠ CAUTION

Incorrect installation of drain hose and cap can cause water leakage.

7. DRAINAGE WORK

- Arrange the drain hose in a downward angle.
- Avoid the following drain piping.

- Pour water to the drain pan located under the heat exchanger, and ensure that the water is discharged outdoor.
- When extended drain hose is present inside the room, insulate it securely with heat insulator available in the market.

Since this air-conditioner is designed to collect dew drops on the rear surface to the drain pan, do not install the connecting wire above the gutter.

⚠ CAUTION

Incorrect drainage work can cause water leakage.



8. INSTALLING INDOOR UNIT

Installing the indoor unit to installation board



(1) Pass the pipe through the hole in the wall, and hook the upper part of the indoor unit to the installation board.

(2) Gently push the lower part to fix the indoor unit base lower latch to installation board.

Removing the indoor unit from installation board

(1) Push up at the marked portion of the indoor unit base latch, and slightly pull it toward you (both right and left hand sides). (The indoor unit base latch can be removed from the installation board.)
(2) Push up the indoor unit upward so that it can be removed from installation board.



9. CONNECTING PIPING WORK

1. Preparation of connecting pipe

1.1. Selecting connecting pipe

Select connecting pipe according to the following table.

	Model SRK63	Model SRK71/80	Model SRK100
Gas pipe	ø12.7	ø15.88	ø15.88
Liquid pipe	ø6.35	ø6.35	ø9.52

- Pipe wall thickness must be greater than or equal to 0.8 mm (ø15.88:1.0mm).
- Pipe material must be O-type (Phosphorus deoxidized seamless copper pipe ICS 23.040.15, ICS 77.150.30).

1.2. Cutting connecting pipe

(1) Cut the connecting pipe to the required length with pipe cutter.
(2) Hold the pipe downward and remove the burrs. Make sure that no foreign material enters the pipe.
(3) Cover the connecting pipe ends with the tape.

2. Piping work

2.1. Flaring pipe

(1) Take out flare nuts from the operation valves of indoor unit and engage them onto connecting pipes.
(2) Flare the pipes according to table and figure shown below.
Flare dimensions for R32 are different from those for conventional refrigerant.
Although it is recommended to use the flaring tools designed specifically for R32 or R410A, conventional flaring tools can also be used by adjusting the dimension B with a flare adjustment gauge.

Copper pipe outer diameter	A
ø6.35	9.1
ø9.52	13.2
ø12.7	16.6
ø15.88	19.7



Copper pipe outer diameter	B [Rigid (clutch) type]	
	R32 or R410A	Conventional
ø6.35	0-0.5	1.0-1.5
ø9.52		
ø12.7		
ø15.88		

2.2 Connecting pipes

(1) Connect pipes on both liquid and gas sides.
(2) Tighten nuts to specified torque shown in the table below.

Operation valve size (mm)	Tightening torque (N·m)
ø6.35 (1/4")	14-18
ø9.52 (3/8")	34-42
ø12.7 (1/2")	49-61
ø15.88 (5/8")	68-82



⚠ CAUTION

- Do not apply refrigerating machine oil to the flared surface. It can cause refrigerant leakage.
- Do not apply excess torque to the flared nuts. The flared nuts may crack resulting in refrigerant leakage.

3. Heating and condensation prevention

(1) Dress the connecting pipes (both liquid and gas pipes) with insulation to prevent it from heating and dew condensation.
Use the heat insulating material which can withstand 120°C or higher temperature. Make sure that insulation is wrapped tightly around the pipes and no gap is left between them.
(2) Wrap the refrigerant pipings of indoor unit with indoor unit heat insulation using tape.
(3) Cover the flare-connected joints (indoor side) with the indoor unit heat insulation and wrap it with an insulation pad (standard accessory provided with indoor unit).
(4) Wrap the connecting pipes, connecting cable and drain hose with the tape.

(2)



(3)



(4)



NOTE

Locations where relative humidity exceeds 70%, both liquid and gas pipes need to be dressed with 20mm or thicker heat insulation materials.

⚠ CAUTION

- Improper insulation can cause condensate(water) formation during cooling operation.
Condensate can leak or drip causing damage to household property.
- Poor heat insulating capacity can cause pipe outer surface to reach high temperature during heating operation. It can cause cable deterioration and personal injury.

4. Finishing work

(1) Make sure that the exterior portion of connecting pipes, connecting cable and drain hose is wrapped properly with tape. Shape the connecting pipes to match with the contours of the pipe assembly route.
(2) Fix the pipe assembly with the wall using clamps and screws. Pipe assembly should be anchored every 1.5m or less to isolate the vibration.
(3) Install the service cover securely. Water may enter the unit if service cover is not installed properly, resulting in unit malfunction and failure.



⚠ WARNING (only for R32)

- To avoid the risk of fire or explosion, the flared connection must/shall be installed outdoors.
- Reusable mechanical connectors and flared joints are not allowed indoors.



⚠ CAUTION

Make sure that the connecting pipes do not touch the components within the unit. If pipes touch the internal components, it may generate abnormal sounds and/or vibrations.

10. HOW TO OPEN, CLOSE, REMOVE AND INSTALL THE AIR INLET PANEL

1. Open
Pull the air inlet panel at both ends of lower part and release latches, then pull up the panel until you feel resistance.
(The panel stops at approx. 60° open position)

2. Close
Hold the panel at both ends of lower part, lower it downward slowly, then push it slightly until the latch works.

3. Removing
Open the panel by 80° (as shown in the right illustration) and then pull it forward.

4. Installing
Insert the panel arm into the slot on the front panel from the position shown in right illustration, hold the panel at both ends of lower part, lower it downward slowly, then push it slightly until the latch works.



11. HOW TO REMOVE AND INSTALL FRONT PANEL

1. Removing
(1) Remove the air inlet panel and the air filters.
(2) Remove the 8 screws.
(3) Remove the 5 upper latches and then front panel can be removed.

2. Installing
(1) Cover the unit with the front panel and fix 5 upper latches.
(2) Secure the front panel with the 8 screws.
(3) Install the air inlet panel and the air filters.



12. INSTALLING REMOTE CONTROL

Mount the batteries
(1) Slide and take out the cover of backside.
(2) Mount the batteries [R03 (AAA, Micro), ×2 pieces] in the body properly.
(Fit he poles with the indication marks + & −)
(3) Set the cover again.

NOTE
- Do not use new and old batteries together.
- In case the unit is not operated for a long time, take out the batteries



Installing remote control holder
(1) Select the place where the unit can receive signals.
(2) Fix the holder to pillar or wall with wood screws.



13. TERMINAL CONNECTION FOR AN INTERFACE

To install wired remote control, superlink etc., interface kit is needed.

(1) Remove the air inlet panel and front panel.
(2) Remove the control cover. (Remove the screw.)
(3) There is a terminal (respectively marked with CNS) for the indoor control board. While connecting an interface, connect to the respective terminal securely with the connection harness supplied with an optional “Interface connection kit SC-BIKN-E and SC-BIKN2-E” and fasten the connection harness onto the indoor control box with the clamp and screw supplied with the kit.
For more details, refer to the user’s manual of “Interface connection kit SC-BIKN-E and SC-BIKN2-E”.



14. INSTALLING TWO AIR-CONDITIONERS IN THE SAME ROOM

In case two air-conditioners are installed in the same room, apply this setting so that one unit can be operated with only one remote control.

Setting one remote control
(1) Slide and take out the cover and batteries.
(2) Cut the switching line next to the battery with wire cutters.
(3) Set the batteries and cover again.



Setting one indoor unit
(1) Turn off the power source and turn it on after 1 minute.
(2) Send the signal by pressing the ACL switch on the remote control that was set according to the procedure described on the left side.
(3) Check that the reception buzzer sound “peep” is emitted from the indoor unit. Since the signal is sent about 6 seconds after the ACL switch is pressed, point the remote control to the indoor unit for a while.

NOTE
If no reception buzzer is emitted, restart the setting from the beginning.



15. PUMP DOWN WORK

For the environmental protection, be sure to pump down when relocating or disposing of the unit. Pump down is the method of recovering refrigerant from the indoor unit to the outdoor unit before the connecting pipes are removed from the unit. When pump down is carried out, forced cooling operation is needed.

Forced cooling operation
(1) Turn off the power source and turn it on again after 1 miniute.
(2) Press the ON/OFF button continuously for at least 5 seconds. Then operation will start.

For the detail of pump down, refer to the installation manual of outdoor unit.



16. INSTALLATION CHECK AND TEST RUN

After finishing the installation work, check the following points again before turning on the power. Conduct a test run and ensure that the unit operates properly.
At the same time, explain to the customer how to use the unit and how to take care of the unit following the user’s manual.

Before test run
Before test run, check following points.

Power source voltage complies with the rated voltage of air-conditioner.	
Earth leakage breaker and circuit breaker are installed.	
Power cable and connecting cable are securely fixed to the terminal block.	
Both liquid and gas operation valves are fully open.	
No gas leaks from the joints of the operation valves.	
Indoor and outdoor side pipe joints have been insulated.	
Hole on the wall is completely sealed with putty.	
Drain hose and cap are installed properly.	
Screw of the lid is tightened securely.	

Test run
Check following points during test run.

Indoor unit receives signal of remote control.	
Air-conditioning operation is normal.	
There is no abnormal noise.	
Water drains out smoothly.	
Display of remote control is normal.	

After test run

Explain the operating and maintenance methods to the user according to the user’s manual.	
Keep this installation manual together with user’s manual.	

NOTE
During restart or change in operation mode, the unit will not start operating for approximately 3 minutes. This is to protect the unit and it is not malfunction.

(7) Effective range of cool/hot wind (Reference)

(a) FDT series

Guideline for ceiling height

Fan Speed Setting	Model			
	FDT50VH, 60VH	FDT71VH	FDT100VH	FDT125VH, 140VH
Hi	2.7m	3.0m	3.2m	3.6m
P-Hi	3.5m	3.8m	4.3m	4.5m

Notes (1) If the ceiling height is over 3m, please consider to add circulators.
This table shows reference values in case of four outlet.
If you shut some outlets, they are different.
Fan speed setting can be changed by using a wired remote control.

(b) FDE series

Model	Effective range
FDE50VH	7.5m
FDE60VH, 71VH	8.0m
FDE100VH, 125VH, 140VH	9.0m

[Conditions]
1. Height of unit: 2.4 – 3.0 (m) above floor level
2. Fan speed : Hi
3. Location: Free space without obstacles
4. The effective range means the horizontal distance for wind to reach the floor.
5. Wind speed at the effective range: 0.5 m/s

1.10.2 Electric wiring work installation

PSC012D117Ⓐ

Electrical wiring work must be performed by an electrician qualified by a local power provider according to the electrical installation technical standards and interior wiring regulations applicable to the installation site.

Security instructions

- **Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.**
- **The precautionary items mentioned below are distinguished into two levels, ⚠WARNING and ⚠CAUTION .**
  ⚠WARNING : Wrong installation would cause serious consequences such as injuries or death.
  ⚠CAUTION : Wrong installation might cause serious consequences depending on circumstances.
  Both mentions the important items to protect your health and safety so strictly follow them by any means.
- **The meanings of "Marks" used here are as shown on the right:**
  ⃠ Never do it under any circumstances. ❗ Always do it according to the instruction.
- **Accord with following items. Otherwise, there will be the risks of electric shock and fire caused by overheating or short-circuit.**

⚠WARNING

- **Be sure to have the electric wiring work done by qualified electrical installer, and use exclusive circuit.**
  Power source with insufficient capacity and improper work can cause electric shock and fire.
- **Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in order not to apply unexpected stress on the terminal.**
  Loose connections or hold could result in abnormal heat generation or fire.
- **Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services panel property.**
  Improper fitting may cause abnormal heat and fire.
- **Use the genuine option parts. And installation should be performed by a specialist.**
  If you install the unit by yourself, it could cause water leakage, electric shock and fire.
- **Do not repair by yourself. And consult with the dealer about repair.**
  Improper repair may cause water leakage, electric shock or fire.
- **Consult the dealer or a specialist about removal of the air-conditioner.**
  Improper installation may cause water leakage, electric shock or fire.
- **Turn off the power source during servicing or inspection work.**
  If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.
- **Shut off the power before electrical wiring work.**
  It could cause electric shock, unit failure and improper running.

⚠CAUTION

- **Perform earth wiring surely.**
  Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Improper earth could cause unit failure and electric shock due to a short-circuit.
- **Earth leakage breaker must be installed.**
  If the earth leakage breaker is not installed, it can cause electric shocks.
- **Make sure to install earth leakage breaker on power source line. (countermeasure thing to high harmonics.)**
  Absence of breaker could cause electric shock.
- **Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.**
  Using the incorrect one could cause the system failure and fire.
- **Do not use any materials other than a fuse of correct capacity where a fuse should be used.**
  Connecting the circuit by wire or copper wire could cause unit failure and fire.
- **Use power source line of correct capacity.**
  Using incorrect capacity one could cause electric leak, abnormal heat generation and fire.
- **Do not mingle solid cord and stranded cord on power source and signal side terminal block.**
  In addition, do not mingle difference capacity solid or stranded cord.
  Inappropriate cord setting could cause loosing screw on terminal block, bad electrical contact, smoke and fire.
- **Do not turn off the power source immediately after stopping the operation.**
  Be sure to wait for more than 5 minutes. Otherwise it could cause water leakage or breakdown.
- **Do not control the operation with the circuit breaker.**
  It could cause fire or water leakage. In addition, the fan may start operation unexpectedly and it may cause injury.

Control mode switching

- The control content of indoor units can be switched in following way. (☐ is the default setting)

Switch No.		Control Content
SW2		Indoor unit address (0-Fh)
SW5-1		Master/Slave Switching (plural /Slave unit Setting)
SW5-2		
SW6-1～4		Model capacity setting
SW7－1	ON	Operation check, Drain motor test run
	OFF	Normal operation

①Electrical wiring connection

- Electrical wiring work must be performed by an electlician an qualified by a local power provider. These wiring specifications are determined on the assumption that the following instructions are observed:
  ① Do not use cords other than copper ones.
  Do not use any source line lighter than one specified in parentheses for each type below.
  –braided cord (code designation 60245 IEC 51), if allowed in the relevant part 2;
  –ordinary tough rubber sheathed cord (code designation 60245 IEC 53);
  –flat twin tinsel cord (code designation 60227 IEC 41);
  –ordinary polyvinyl chloride sheathed cord (code designation 60227 IEC 53);
  ② Connect the power source to the outdoor unit.
  ③ Pay extra attention so as not to confuse signal line and power source line connection, because an error in their connection can be burn all the boards at once.
- Connect ground wires before connecting wires between the indoor and outdoor units and between indoor units. The ground wires need to be longer than the wires between the indoor and outdoor units, and protected from undue stress.
- Do not turn on the power source before completing the work.
- The ground wires must be connected by the Class D grounding connection.
- Use the round crimp terminals for connections to the terminal block.



- Use dedicated branch circuits, avoiding combination with other devices. Otherwise, it could trip the power source breaker, resulting in secondary accidents.
- Install the overcurrent and earth leakage breakers (sensitivity current: 30 mA) specified to respective models.
- Do not connect indoor and outdoor signal cables to extension cables on the way. If the joint is wetted with intruding water, it could cause a ground insulation failure or poor connection, resulting in communication errors. (If it is inevitable to connect cables on the way, make sure to prevent the water intrusion completely.)
- When running wires (wires for power source, remote controller, connecting between indoor and outdoor units, or other) behind the ceiling, protect them using copper or other pipes against assault by rat, or other.
- It is up to 3.5 mm^2 the size of power supply cables connected to indoor units. When using cables of 5.5 mm^2 or larger, provide a dedicated pull box for branching connection to indoor units.
- If signal and power source cables are connected mistakenly, it could burn down all PCBs.
  ① Even if the power source of 220/240/380/415 V is connected mistakenly to A-B signal cable, it is protected at initial occasion only.
  ② If the remote control fails to detect the unit No. (address) at 15 minutes after turning the power on, check and repair all signal cables for misconnection.
  ③ Cut the jumper wire J10SL1 of burnt PCB, and reconnect connectors CnK (yellow) and CnK1 (white) to CnK2 (black).
  ④ If any anomaly is found on wires between the A-B terminal block and the PCB, replace them.
- At the outside of indoor and outdoor units, take care to avoid direct contacts between remote control and power source cables.
- In no event connect the power source of 220/240/380/415 V to the remote control terminal block. It could cause failures.
- Connections of wiring between units, ground wire and remote control cable
  ① When connecting wires between units, ground wire or remote control wire, connect them according to the number of terminals on the power source terminal block or signal terminal block in the control box. Connect the ground wire to the ground terminal on the power source terminal block.
  ② Make sure to install an earth leakage breaker for the power source. Select a breaker for inverter circuit.
  ③ When the earth leakage breaker is exclusive for the earth leakage protection, it is necessary to connect also an isolating switch (Switch + Class B fuse) or wiring circuit breaker in series to the earth leakage breaker.
  ④ Install the isolating switch close to the unit.
- Connect wires securing by tightening screws firmly. Confirm also no connector or wire (from terminal) is disconnected in the control box.
- When installing an auxiliary electric heater, consult the electric heater manual or technical data.

Cable connection for single unit installation

①As for connecting method of power source, select from following connecting patterns. In principle, do not directly connect power souce line to inside unit.
※As for exceptional connecting method of power source, discuss with the power provider of the country with referring to technical documents, and follow its instruction.
②For cable size and circuit breaker selection, refer to the outdoor unit installation manual.



Cable connection for a V multi configuration installation

①Connect the same pairs number of terminal block "①, ②, and ③"and " ⓧ and ⓨ" between master and slave indoor units.
②Do the same address setting of all inside units belong to same refrigerant system by rotary switch SW2 on indoor unit's PCB (Printed circuit board).
③Set slave indoor unit as "slave 1" through "slave 3" by address switch SW5-1, 5-2 on PCB.
④When the AIR CON NO. button on the remote control unit is pressed after turning on the power, an indoor unit's address number will be displayed. Do not fail to confirm that the connected indoor unit's numbers are displayed on the remote control unit by pressing the ▲ or ▼ button.



Method of setting Master/Slave of indoor unit

(Factory setting: "Master")

Indoor Unit		Master	Slave 1	Slave 2	Slave 3
PCB SW	SW5-1	OFF	OFF	ON	ON
	SW5-2	OFF	ON	OFF	ON

②Remote control, wiring and functions

●Do not install it on the following places
①Places exposed to direct sunlight
②Places near heat devices
③High humidity places
④Hot surface or cold surface enough to generate condensation
⑤Places exposed to oil mist or steam directly.
⑥Uneven surface

Installation and wiring of remote control

①Install remote control referring to the attached installation manual.
②Wiring of remote control should use 0.3mm² ×2 core wires or cables.
The insulation thickness is 1mm or more. (on-site configuration)
③Maximum prolongation of remote control wiring is 600 m.
If the prolongation is over 100m, change to the size below.
But, wiring in the remote control case should be under 0.5mm² . Change the wire size outside of the case according to wire connecting. Waterproof treatment is necessary at the wire connecting section. Be careful about contact failure.
100 - 200m ..... 0.5mm² × 2 cores
Under 300m ..... 0.75mm² × 2 cores
Under 400m ..... 1.25mm² × 2 cores
Under 600m ..... 2.0mm² × 2 cores
④Avoid using multi-core cables to prevent malfunction.
⑤Keep remote control line away from earth (frame or any metal of building).
⑥Make sure to connect remote control line to the remote control and terminal block of indoor unit. (No polarity)

Control plural indoor units by a single remote control

①A remote control can control plural indoor units (Up to 16).
In above setting, all plural indoor units will operate under same mode and temperature setting.
②Connect all indoor units with 2 core remote control line.
③Set unique remote control communication address from "0" to "F" to each inside unit by the rotary switch SW2 on the indoor unit's PCB.



Master/ slave setting when more than one remote control unit are used

A maximum of two remote control units can be connected to one indoor unit (or one group of indoor units.)
The air-conditioner operation follows the last operation of the remote control regardless of the master/slave setting of it.
Acceptable combination is "two (2) wired remote controls", "one (1) wired remote control and one (1) wireless kit" or "two (2) wireless kits".
Set one to "Master" and the other to "Slave".
Note:The setting "Remote control unit sensor enabled" is only selectable with the master remote control unit in the position where you want to check room temperature.



③Operation and confirmation from remote control

No.	Item	Operation from the eco touch remote control (RC-EX series)	Operation from the standard remote control (RC-E series)
1	Check the number of units connected in the multi remote control system.	[Menu] ⇒ [Service setting] ⇒ [Service & Maintenance] ⇒ [Service password] ⇒ [IU address]	① Press the AIR CON NO button to display the IU address. ② Press the ▲ or ▼ button and check addresses of connected indoor units one by one.
2	Check if each unit is connected properly in the remote control system.	[Menu] ⇒ [Service setting] ⇒ [Service & Maintenance] ⇒ [Service password] ⇒ [IU address] ⇒ [Check run mode]	① Press the AIR CON NO button to display the IU address. ② Press the ▲ or ▼ button and select one of IU addresses. ③ Press the (MODE) button. The unit starts to blow air.
3	Setting main/sub remote controls	[Menu] ⇒ [Service setting] ⇒ [R/C function settings] ⇒ [Service password] ⇒ [Main/Sub of R/C]	Set SW1 to "Sub" for the sub remote control unit.
4	Checking operation data	[Menu] ⇒ [Service setting] ⇒ [Service & Maintenance] ⇒ [Service password] ⇒ [Operation data]	Press the CHECK button. ⇒ "OPER DATA ▼" is displayed. ⇒ Press the (SET) button. ⇒ "DATA LOADING" is displayed. ⇒ Select one of addresses for connected indoor units by pressing the ▲ or ▼ button. ⇒ Press the (SET) button. ⇒ "DATA LOADING" is displayed. ⇒ Select data by pressing the ▲ or ▼ button.
5	Checking inspection display	[Menu] ⇒ [Service setting] ⇒ [Service & Maintenance] ⇒ [Service password] ⇒ [Error display]	Press the CHECK button. ⇒ "OPER DATA ▼" is displayed. ⇒ Press the ▼ button. ⇒ "ERROR DATA ▲" is displayed. ⇒ Press the (SET) button. ⇒ "DATA LOADING" is displayed. ⇒ Data is displayed.
6	Cooling test run from remote control	[Menu] ⇒ [Service setting] ⇒ [Installation settings] ⇒ [Service password] ⇒ [Test run] ⇒ [Cooling test run] ⇒ [Start]	① Start the system by pressing the ON/OFF button. ② Select "❄ (Cool)" with the (MODE) button. ③ Press the TEST button for 3 seconds or longer. The screen display will switch to "❄ TEST RUN ▼". ④ Pressing the (SET) button, while the "❄ TEST RUN ▼" is displayed, starts the cooling test run. The screen display will switch to "❄ TEST RUN".
7	Trial operation of drain pump from remote control	[Menu] ⇒ [Service setting] ⇒ [Installation settings] ⇒ [Service password] ⇒ [Test run] ⇒ [Drain pump test run] ⇒ [Run]	① Start the system by pressing the ON/OFF button. The display will change to "❄ TEST RUN ▼". ② Press the ▼ button once to display "DRAIN PUMP ▲▼". ③ Pressing the (SET) button starts the drain pump operation. The display will show "TO STOP".

The menu configuration may vary depending on models of the remote control. If the model of your remote control is different, refer to the installation manual attached to the remote control.

④ Function of CNT connector of indoor printed circuit board



Note (1) To be no longer than 2 m.

●XR1-4 are DC 12 V relays. (Equivalent to Omron's LY2F)
●XR5 is a DC 12 V, 24 V or 100 V, 200 V relay. (Equivalent to Omron's MY2F)
●Maker and model of CnT connector (Site side)
Connector : Molex 5264-06
Terminal : Molex 5263T
●CnTA connector is used on FDT, or other. <Check with the specifications.> (Site side) Maker and model
Connector : J.S.T. Mfg. XAP02V-1-E
Terminal : J.S.T. Mfg. SXA-01T-P0.6
●Output 1 – 4 and input1/2 can be selected/set as required from following items.
Factory default is set as shown below.

Output

①	RUN output	⑧	Fan ON output 3
②	Heating output	⑨	Defrost/oil return output
③	Compressor ON output	⑩	Ventilation output
④	Inspection (error) output	⑪	Heater output
⑤	Cooling output	⑫	Free cleaning output
⑥	Fan ON output 1	⑬	Indoor overload error output
⑦	Fan ON output 2		

Input

①	RUN/STOP	⑤	Setting temp. shift
②	RUN permit prohibition	⑥	Compulsory thermostat OFF
③	Emergency stop	⑦	Temporary stop
④	Cooling/Heating	⑧	Silent mode

Factory default setting

CnT-2	Output 1	RUN output	CnT-5	Output 4	Inspection (error) output
CnT-3	Output 2	Heating output	CnT-6	Input 1	RUN/STOP
CnT-4	Output 3	Compressor ON output	CnTA	Input 2	RUN/STOP

●For the setting method, refer to the technical data.

⑤ Operation and setting from remote control

A : Refer to the instruction manual for RC-EX series
B : Refer to the installation manual for RC-EX series
C : Loading a utility software vie Internet

○ : Nearly same function setting and operations are possible.
△ : Similar function setting and opperations are possible.

*1: Remote controls before RC-EX1A don't have this function.
*2: Remote controls before RC-EX3 don't have this function.

Setting & display item			Description	RC-EX3A	RC-E5
1.Remote Control network					
1	Control plural indoor units by a single remote control		A remote control can control plural indoor units up to 16 (in one group of remote control network). An address is set to each indoor unit.		○
2	Main/sub setting of remote controls		A pair of remote controls (including option wireless remote control) can be connected within the remote control network. Set one to "Main" and the other to "Sub".	B	○
2.TOP scrren, Switch manipulation					
1	Menu		"Control","State", or "Details" can be selected. (3-8)	A	
2	Operation mode		"Cooling","Heating","Fan","Dry" or "Auto" can be set.	A	○
3	Set temp.		"Set temperature" can be set by 0.5℃ interval.	A	○
4	Air flow direction		"Air flow direction" [Individual flap control] can be set. Select Enable or Disable for the "3D AUTO" (in case of FDK). *1	A	△
5	Fan speed		"Fan speed" can be set.	A	○
6	Timer setting		"Timer operation" can be set.	A	○
7	ON/OFF		"On/Off operation of the system" can be done.	A	○
8	F1 SW	*1	The system operates and is controlled according to the function specified to the F1 switch.	A	
9	F2 SW	*1	The system operates and is controlled according to the function specified to the F2 switch.	A	
10	Select the language	*2	Select the language to display on the remote control. ・ Select from English, German, French, Spanish, Italian, Dutch, Turkish, Portuguese, Russian,Polish, Japanese and Chinese.	A	
3.Useful functions					
1	Individual flap control		The moving range (the positions of upper limit and lower limit) of the flap for individual flap can be set. Set also the left and right limit positions for FDK. *1	A	△
2	Anti draft setting When the panel with the anti-draft function is assembled.	*1	・ Details .....You can set Enable or Disable for anti draft motion performed at each blow outlet in each operation mode. ・ ON/OFF setting .....You can set ON/OFF (operation/stop) of anti draft function for the enabled blow outlet set in Details. *2	A	
3	Timer settings	Set On timer by hour	The period of time to start operation after stopping can be set. ・ The period of set time can be set within range of 1hour-12houres (1hr interval). ・ The operation mode, set temp-and fan speed at starting operation can be set.	A	△
		Set Off timer by hour	The period of time to stop operation after starting can be set. ・ The period of set time can be set within range of 1hour-12houres (1hr interval).	A	△
		Set On timer by clock	The clock time to start operation can be set. ・ The set clock time can be set by 5-minutes intervals. ・ [Once (one time only)] or [Everyday] operation can be switched. ・ The operation mode, set temp. and fan speed at starting operation can be set.	A	△
		Set Off timer by clock	The clock time to stop operation can be set. ・ The set clock time can be set by 5-minute intervals. ・ [Once (one time only)] or [Everyday] operation can be switched.	A	△
		Confirmation of timer settings	Status of timer settings can be seen.	A	
4	Favorite setting [Administrator password]	*1	Set the operation mode, setting temperature, air flow capacity and air flow direction for the choice setting operations. Set them for the Favorite set 1 and the Favorite set 2 respectively.	A	
5	Weekly timer		On timer and Off timer on weekly basis can be set. ・ 8-operation patterns per day can be set at a maximum. ・ The setting clock time can be set by 5-minute intervals. ・ Holiday setting is available. ・ The operation mode, set temp. and fan speed at starting operation can be set.	A	△
6	Home leave mode [Administrator password]		When leaving home for a long period like a vaction leave, the unit can be operated to maintain the room temperature not to be hotter in summer or not to be colder in winter. ・ The judgment to switch the operation mode (Cooring ⇔ Heating) is done by the both factors of the set temp. and outdoor air temp. ・ The set temp. and fan speed can be set.	A	
7	External Ventilation When the ventilator is combined.		On/Off operation of the external ventilator can be done. It is necessary to set from [Menu] ⇒ [Service setting] ⇒ [R/C function settings] ⇒ [Ventilation setting]. ・ If the "Independent" is selected for the ventilation setting, the ventilator can be operated or stopped.	A	○
8	Select the language		Select the language to display on the remote control. ・ Select from English, German, French, Spanish, Italian, Dutch, Turkish, Portuguese, Russian,Polish, Japanese and Chinese. *1	A	
9	Silent mode control	*2	The period of time to operate the unit by prioritizing the quietness can be set. ・ Start and end can be set for the silent mode	A	
4.Energy-saving setting			Administrator password		
1	Sleep timer		To prevent the timer from keeping ON, set hours to stop operation automatically with this timer. ・ The selectable range of setting time is from 30 to 240 minutes. (10-minute intervals) ・ When setting is "Enable", this timer will activate whenever the ON timer is set.	A	△
2	Peak-cut timer		Power consumption can be reduced by restructing the maximum capacity. Set the [Start time], the [End time] and the capacity limit % (Peak-cut %). ・ 4-operation patterns per day can be set at maximum. ・ The setting time can be changed by 5-minute intervals. ・ The selectable range of capacity limit % (Peak-cut %) is from 0% to 40-80% (20% interval) ・ Holiday setting is available.	A	
3	Automatic temp set back		After the elapse of the set time period, the current set temp. will be set back to the [Set back time.] ・ The setting can be done in cooling and heating mode respectively. ・ Selectable range of the set time is from 20 min. to 120 min. (10 min. interval). ・ Set the [Set back temp.] by 1℃ interval.	A	△
4	Motion sensor control When the panel with the motion sensor is assembled.	*1	When the motion sensor is used, it is necessary to set Enable or Disable for the "Power control" and the "Auto-off".	A	
5.Filter					
1	Filter sign reset	Filter sign reset	The filter sign can be reset.	A	
		Setting next cleaning date	The next cleaning date can be set.	A	
6.User setting					
1	Internal settings	Clock setting	The current date and time can be set or revised. ・ If a power failure continues no longer than 80 hours, the clock continues to tick by the built-in power source.	A	△
		Date and time display	[Display] or [Hide] the date and/or time can be set, and [12H] or [24H] display can be set.	A	
		Summer time	When select [Enable], the +1hour adjustment of current time can be set. When select [Disable], the [Summer time] adjustment can be reset.	A	
		Contrast	The contrast of LCD can be adjusted higher or lower.	A	
		Backlight	Switching on/off a light can be set and period of the lighting time can be set within the range of 5sec-90 sec (5sec interval).	A	
		Control sound	It can set with or without [Control sound (beep sound)] at touch panel.	A	
		Operation lamp luminance	*1 This is used to adjust the luminance of operation lamp.	A	
2	Administrator settings [Administrator password]	Permission/Prohibition setting	・ Permission/Prohibition setting of operation can be set. [On/Off] [Change set temp] [Change operation mode] [Change flap direction] [Change fan speed] [High power operation] [Energy-saving operation] [Timer] Request for administrator can be set. [Individual flap control] [Weekly timer] [Select the language] [Anti draft setting] *1	A	△
		Outdoor unit silent mode timer	The period of time to operate the outdoor unit by prioritizing the quiteness can be set. ・ The [Start time] and the [End time] for operating outdoor unit in silent mode can be set. ・ The period of the operation time can be set once aday by 5-minute interals.	A	△
		Setting temp. range	The upper/lower limit of temp. setting range can be set. ・ The limitation of indoor temp. setting range can be set for each operation mode in cooling and heating.	A	△

⑤ Operation and setting from remote control (continued)

Setting & display item				Description	RC-EX3A	RC-E5
2	Administrator settings	Temp increment setting		The temp increment setting can be changed by 0.5˚C or 1.0˚C.	A	
		Set temp display		Ways of displaying setting temperatures can be selected.	A	
	[Administrator password]	R/C display setting		Register [Room name] [Name of I/U] Display [Indoor temp display] or not. Display [Error code display] or not. Display [Heating stand-by display] [Defrost operation display] [Auto cooling/heating display] [Display temp of R/C, Room, Outdoor] or not	A	△
		Change administrator password		The administrator password can be changed. (Default setting is "0000")	A	
				The administrator password can be reset.	B	
		F1/F2 function setting	*1	Functions can be set for F1 and F2. Selectable functions: [Anti draft ON/OFF] *2 [High power operation], [Energy-saving operation], [Silent mode cont.], [Home leave mode], [Favorite set 1], [Favorite set 2] and [Filter sign reset].	A	
7.Service setting						
1	Installer settings	Installation date		The [Installation date] can be registed. ・ When registering the [Instaration date], the [Next service date] is displayed automatically. (For changing the [Next service date], please refer the item of [Service & Maintenance])	B	
	[Service password]	Company information		The [Company information] can be registed and can be displayed on the R/C. ・ The [Company] can be registered within 26 characters. ・ The [Phone No.] can be registed within 13 digits.	B	
		Test run		On/Off operation of the test run can be done.	B	○
			Cooling test run	The [Cooling test run] can be done at 5˚C of set temp. for 30 minutes.		
			Drain pump test run	Only drain pump can be operated.		
		Staric pressure adjustment		In case of combination with only the ducted indoor unit which has a function of static pressure adjustment, the static pressure is adjustable. ・ It can be set for each indoor unit individually.	B	
		Change auto-address		The set address of each indoor unit decided by auto-address setting method can be changed to any other address. (For multiple KX units only)	B	△
		Address setting of main IU		Main indoor unit address can be set. ・ Only the Main indoor unit can change operation mode and the Sub indoor units dominated by the Main indoor shall follow. ・ The Main indoor unit can domain 10 indoor units at a maximum.	B	△
		IU back-up function		When a pair of indoor units (2 groups) is connected to one unit of remote control, it can be set Enable or Disable for the [IU rotation], [IU capacity back-up] and [IU fault back-up]	B	
		Motion sensor setting When the panel with the motion sensor is assembled.	*1	Set Enable or Disable for the infrared sensor detectors of indoor units connected to the remote control. If Disable is selected, it cannot be control the motion sensor control for the energy-saving setting.	B	
2	R/C function setting	Main/Sub R/C		The R/C setting of [Main/Sub] can be changed.	B	○
	[Service password]	Return air temp		When two or more indoor units are connected to one unit of remote control, suction sensors, which are used for the judgement by thermostat, can be selected. ・ It can be selected from [Individual], [Master IU] and [Average temp].	B	
		R/C sensor		It can be set the mode to switch to the remote control sensor. It can be selected from cooling and heating.	B	△
		R/C sensor adjustment		The offset value of [R/C sensor] sensing temp. can be set respectively in heating and cooling.	B	△
		Operation mode		Enable or Disable can be set for each operation mode.	B	△
		ºC / ºF		Set the unit for setting temperatures. ・ °C or °F can be selected.	B	
		Fan speed		Fan speeds can be selected.	B	○
		External input		When two or more indoor units are connected to one unit of remote control, the range to apply CNT inputs can be set.	B	○
		Upper/lower flap control		[Stop at fixed position] or [Stop at any position] can be selected for the upper and lower louvers.	B	○
		Left/right flap control	*1	[Fixed position stop] or [Stop at any position] can be selected for the right and left louvers.	B	
		Ventilation setting		Combination control for ventilator can be set.	B	○
		Auto-restart		The operation control method after recovery of power failure happened during operation can be set.	B	○
		Auto temp setting		[Enable] or [Disable] of [Auto temp setting] can be selected.	B	
		Auto fan speed		[Enable] or [Disable] of [Auto fan speed] can be selected.	B	
3	IU settings	Fan speed setting		The fan speed for indoor units can be set.	B	○
		Filter sign		The setting of filter sign display timer can be done from following patterns.	B	○
	[Service password]	External input 1		The connect of control by external input 1 can be changed.	B	○
		External input 1 signal		The type of external input 1 signal can be changed.	B	○
		External input 2		The connect of control by external input 2 can be changed.	B	
		External input 2 signal		The type of external input 2 signal can be changed.	B	
		Heating thermo-OFF temp adjustment		The judgement temp. of heating themo-off can be adjusted within the range from 0 to +3˚C (1˚C interval)	B	△
		Return temperature adjustment		The sensing temp. of return air temp. sensor built in the indoor unit can be adjusted within the range of ±2˚C.	B	△
		Fan control in cooling thermo-OFF		Fan control, when the cooling thermostat is turned OFF, can be changed.	B	○
		Fan control in heating thermo-OFF		Fan control, when the heating thermostat is turned OFF, can be changed.	B	○
		Anti-frost temp		Judgment temperature for the anti-frost control during cooling can be changed.	B	○
		Anti-frost control		When the anti-frost control of indoor unit in cooling is activated, the fan speed can be changed.	B	○
		Drain pump operation		In any operation mode in addition to cooling and dry mode, the setting of drain pump operation can be done.	B	○
		Keep fan operating after cooling is stopped		The time period residual fan operation after stopping or thermo-off in cooling mode can be set.	B	○
		Keep fan operating after heating is stopped		The time period residual fan operation after stopping or thermo-off in heating mode can be set.	B	○
		Intermittent fan operation in heating		The fan operation rule following the residual fan operation after stopping or themo-off in heating mode can be set.	B	○
		Fan circulator operation		In case that the fan is operated as the circulator, the fan control rule can be set.	B	
		Control pressure adjust		When only the OA processing units are operated, control pressure value can be changed.	B	
		Auto operation mode		The [Auto rule selection] for switching the operation mode automatically can be selected from 3 patterns.	B	
		Thermo. rule setting		When selecting [Outdoor air temp. control], the judgment temp can be offset by outdoor temp..	B	
		Auto fan speed control		Auto switching range for the auto fan speed control can be set.	B	
		IU overload alarm		If the difference between the setting temperature and the suction temperature becomes larger than the temperature difference set for the overload alarm, at 30 minutes after the start of operation, the overload alarm signal is transmitted from the external output (CNT-5).	B	
		External output setting	*1	Functions assigned to the external outputs 1 to 4 can be changed.	B	
4	Service & Maintenance	IU address		Max 16 indoor units can be connected to one remote control, and all address No. of the connected indoor units can be displayed. ・ The indoor unit conforming to the address No. can be identified by selecting the address No. and tapping [Check] to operate the indoor fan.	B	○
	[Service password]	Next service date		The [Next service date] can be registered. ・ The [Next service date] and [Company information] is displayed on the message screen.	A B	○
		Operation data		The [Operation data] for indoor unit and outdoor unit can be displayed.	B	○
		Error display			B	△
			Error history	The error history can be displayed.		
			Display anomaly data	The operation data just before the latest error stop can be displayed.		
			Erase anomaly data	Anomaly operation data can be erased.		
			Reset periodical check	The timer for the periodical check can be reset.		
		Saving IU settings		The I/U settings memorized in the indoor PCB connected to the remote control can be saved in the memory of the remote control.	B	
		Special settings		[Erase IU address] [CPU reset] [Restore of default setting] [Touch panel calibration]	B	△
		Indoor unit capacity display	*1	Address No. and capacities of indoor units connected to the remote control are displayed.	B	
8.Contact company				Shows registered [Contact company] and [Contact phone].		
9.Inspection						
	Confirmation of Inspection			This is displayed when any error occurs.	A	△
10.PC connection						
	USB connection			Weekly timer setting and etc., can be set from PC.	C	

◆ Listed items may not function depending on the specifications of indoor and outdoor units which are combined.

1.10.3 Installation of wired remote control (Option parts)

(1) Model RC-EX3A

1） Safety precautions

●Please read this manual carefully before starting installation work to install the unit properly.
Every one of the followings is important information to be observed strictly.

⚠WARNING	Failure to follow these instructions properly may result in serious consequences such as death, severe injury, etc.
⚠CAUTION	Failure to follow these instructions properly may cause injury or property damage.

It could have serious consequences depending on the circumstances.

●The following pictograms are used in the text.

	Never do.		Always follow the instructions given.

●Keep this manual at a safe place where you can consult with whenever necessary. Show this manual to installers when moving or repairing the unit. When the ownership of the unit is transferred, this manual should be given to a new owner.

⚠WARNING

Consult your dealer or a professional contractor to install the unit.
Improper installation made on your own may cause electric shocks, fire or dropping of the unit.

Installation work should be performed properly according to this installation manual.
Improper installation work may result in electric shocks, fire or break-down.

Be sure to use accessories and specified parts for installation work.
Use of unspecified parts may result in drop, fire or electric shocks.

Install the unit properly to a place with sufficient strength to hold the weight.
If the place is not strong enough, the unit may drop and cause injury.

Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.
Power source with insufficient and improper work can cause electric shock and fire.

Shut OFF the main power source before starting electrical work.
Otherwise, it could result in electric shocks, break-down or malfunction.

Do not modify the unit.
It could cause electric shocks, fire, or break-down.

Be sure to turn OFF the power circuit breaker before repairing/ inspecting the unit.
Repairing/inspecting the unit with the power circuit breaker turned ON could cause electric shocks or injury.

⚠WARNING

Do not install the unit in appropriate environment or where inflammable gas could generate, flow in, accumulate or leak.

If the unit is used at places where air contains dense oil mist, steam, organic solvent vapor, corrosive gas (ammonium, sulfuric compound, acid, etc) or where acidic or alkaline solution, special spray, etc. are used, it could cause electric shocks, break-down, smoke or fire as a result of significant deterioration of its performance or corrosion.

Do not install the unit where water vapor is generated excessively or condensation occurs.

It could cause electric shocks, fire, or break-down.

Do not use the unit in a place where it gets wet, such as laundry room.

It could cause electric shocks, fire, or break-down.

Do not operate the unit with wet hands.

It could cause electric shocks.

Do not wash the unit with water.

It could cause electric shocks, fire, or break-down.

Use the specified cables for wiring, and connect them securely with care to protect electronic parts from external forces.

Improper connections or fixing could cause heat generation, fire, etc.

Seal the inlet hole for remote control cable with putty.

If dew, water, insect, etc. enters through the hole, it could cause electric shocks, fire or break-down.

If dew or water enters the unit, it may cause screen display anomalies.

When installing the unit at a hospital, telecommunication facility, etc., take measures to suppress electric noises.

It could cause malfunction or break-down due to hazardous effects on the inverter, private power generator, high frequency medical equipment, radio communication equipment, etc.

The influences transmitted from the remote control to medical or communication equipment could disrupt medical activities, video broadcasting or cause noise interference.

Do not leave the remote control with its upper case removed.

If dew, water, insect, etc. enters through the hole, it could cause electric shocks, fire or break-down.

⚠CAUTION

Do not install the remote control at following places.

(1) It could cause break-down or deformation of remote control.
- Where it is exposed to direct sunlight
- Where the ambient temperature becomes 0 ˚C or below, or 40 ˚C or above
- Where the surface is not flat
- Where the strength of installation area is insufficient

(2) Moisture may be attached to internal parts of the remote control, resulting in a display failure.
- Place with high humidity where condensation occurs on the remote control
- Where the remote control gets wet

(3) Accurate room temperature may not be detected using the temperature sensor of the remote control.
- Where the average room temperature cannot be detected
- Place near the equipment to generate heat
- Place affected by outside air in opening/closing the door
- Place exposed to direct sunlight or wind from air-conditioner
- Where the difference between wall and room temperature is large

To connect to a personal computer via USB, use the dedicated software.
Do not connect other USB devices and the remote control at the same time.

It could cause malfunction or break-down of the remote control/personal computer.

2） Accessories & Prepare on site

Following parts are provided.

Accessories	R/C main unit, wood screw (ø3.5 x 16) 2 pcs, Quick reference

Following parts are arranged at site. Prepare them according to the respective installation procedures.

Item name	Q'ty	Remark
Switch box For 1 piece or 2 pieces (JIS C 8340 or equivalent)	1	These are not required when installing directly on a wall.
Thin wall steel pipe for electric appliance directly on a wall. (JIS C 8305 or equivalent)	As required	
Lock nut, bushing (JIS C 8330 or equivalent)	As required	
Lacing (JIS C 8425 or equivalent)	As required	Necessary to run R/C cable on the wall.
Putty	Suitably	For sealing gaps
Molly anchor	As required	
R/C cable (0.3 mm^2 x 2 pcs)	As required	See right table when longer than 100 m

When the cable length is longer than 100 m, the max size for wires used in the R/C case is 0.5 mm^2 . Connect them to wires of larger size near the outside of R/C. When wires are connected, take measures to prevent water, etc. from entering inside.

≦ 200 m	0.5 mm^2 x 2 cores
≦ 300m	0.75 mm^2 x 2 cores
≦ 400m	1.25 mm^2 x 2 cores
≦ 600m	2.0 mm^2 x 2 cores

3） Installation place

Secure the installation space shown in the figure.
For the installation method, “embedding wiring” or “exposing wiring” can be selected.
For the wiring direction, “Backward”, “Upper center” or “Upper left” can be selected.
Determine the installation place in consideration of the installation method and wiring direction.

Installation space



Secure minimum spaces for disassembling the case.
Upper left and upper right sides
……30mm or more
Bottom side…120mm or more
If using L-shaped screwdriver, 50mm or more is available.

4) Installation procedure

Perform installation and wiring work for the remote control according to the following procedure.

Dimensions (Viewed from front)



PCB side (Viewed from rear)



To disassemble the R/C case into the upper and lower pieces after assembling them once

· Insert the tip of flat head screwdriver or the like in the recess at the lower part of R/C and twist it lightly to remove. It is recommended that the tip of the screwdriver be wrapped with tape to avoid damaging the case.

Take care to protect the removed upper case from moisture or dust.



In case of embedding wiring

(When the wiring is retrieved "Backward")

① Embed the switch box and the R/C wires beforehand.

Seal the inlet hole for the R/C wiring with putty.



② When wires are passed through the bottom case, fix the bottom case at 2 places on the switch box.

Switch box for 1 pcs



Switch box for 2 pcs



③ Connect wires from X and Y terminals of R/C to X and Y terminals of indoor unit. R/C wires (X, Y) have no polarity. Fix wires such that the wires will run around the terminal screws on the top case of R/C.
④ Install the upper case with care not to pinch wires of R/C.



Cautions for wire connection

Use wires of no larger than 0.5 mm² for wiring running through the remote control case. Take care not to pinch the sheath.
Tighten by hand (0.7 N·m or less) the wire connection. If the wire is connected using an electric driver, it may cause failure or deformation.



In case of exposing wiring

(When the wiring is taken out from the "upper center" or "upper left" of R/C)

① Cut out the thin wall sections on the cases for the size of wire.

When taking the wiring out from the upper center, open a hole before separating the upper and bottom cases. This will reduce risk of damaging the PCB and facilitate subsequent work.
When taking the wiring out from the upper left, take care not to damage the PCB and not to leave any chips of cut thin wall inside.





② Fix the bottom R/C case on a flat surface with two wood screws.
③ In case of the upper center, pass the wiring behind the bottom case. (Hatched section)
④ Connect wires from X and Y terminals of R/C to X and Y terminals of indoor unit. R/C wires (X, Y) have no polarity. Fix wires such that the wires will run around the terminal screws on the top case of R/C.
⑤ Install the top case with care not to pinch wires of R/C.
⑥ Seal the area cut in ① with putty.



5) Main/Sub setting when more than one remote control are used

Up to two units of R/C can be used at the maximum for 1 indoor unit or 1 group.
One is main R/C and the other is sub R/C.
Operating range is different depending on the main or sub R/C.



○ : operable ×: not operable

R/C operations			Main	Sub
Run/Stop, Change set temp., Change flap direction, Auto swing, Change fan speed operations			○	○
High power operation, Energy-saving operation			○	○
Silent mode control			○	×
Useful functions	Individual flap control		○	×
	Anti draft setting		○	×
	Timer		○	○
	Favorite setting		○	○
	Weekly timer		○	×
	Home leave mode		○	×
	External ventilation		○	○
	Select the language		○	○
	Silent mode control		○	×
Energy-saving setting			○	×
Filter	Filter sign reset		○	○
User setting	Initial settings		○	○
	Administrator settings	Permission/ Prohibition setting	○	×
		Outdoor unit silent mode timer	○	×
		Setting temp. range	○	×
		Temp increment setting	○	×
		Set temp. display	○	○
		R/C display setting	○	○
		Change administrator password	○	○
		F1/F2 function setting	○	○

R/C operations				Main	Sub
Service setting	Installation settings	Installation date		○	×
		Company information		○	○
		Test run		○	×
		Static pressure adjustment		○	×
		Change auto-address		○	×
		Address setting of main IU		○	×
		IU back-up function		○	×
		Motion sensor setting		○	×
	R/C function settings	Main/Sub of R/C		○	○
		Return air temp.		○	×
		R/C sensor		○	×
		R/C sensor adjustment		○	×
		Operation mode		○	×
		ºC / ºF		○	×
		Fan speed		○	×
		External input		○	×
		Upper/lower flap control		○	×
		Left/right flap control		○	×
		Ventilation setting		○	×
		Auto-restart		○	×
		Auto temp. setting		○	×
		Auto fan speed		○	×
	IU settings			○	×
	Service & Maintenance	IU address		○	○
		Next service date		○	×
		Operation data		○	×
		Error display	Error history	○	○
			Display/erase anomaly data	○	×
			Reset periodical check	○	○
		Saving IU settings		○	×
		Special settings	Erase IU address	○	×
			CPU reset	○	○
			Restore of default setting	○	×
			Touch panel calibration	○	○
		Indoor unit capacity display		○	×

Advice: Connection to personal computer

It can be set from a personal computer via the USB port (mini-B).
Connect after removing the cover for USB port of upper case.
Replace the cover after use.
Special software is necessary for the connection.
For details, view the web site.



Advice: Initializing of password

Administrator password (for daily setting items) and
service password (for installation, test run and maintenance) are used.

○ The administrator password at factory default is "0000". This setting can be changed (Refer to User's Manual).
If the administrator password is forgotten, it can be initialized by holding down the [F1] and [F2] switches together for five seconds on the administrator password input screen.

○ Service password is "9999", which cannot be changed.
When the administrator password is input, the service password is also accepted.



Advice

When connecting two or more FDT/FDTC to one R/C, unify the panel type either to a panel with anti draft function or a standard panel.

PJA012D730B

(2) Model RC-E5

Read together with indoor unit's installation manual.

⚠WARNING

- Fasten the wiring to the terminal securely and hold the cable securely so as not to apply unexpected stress on the terminal.
  Loose connection or hold will cause abnormal heat generation or fire.
- Make sure the power source is turned off when electric wiring work.
  Otherwise, electric shock, malfunction and improper running may occur.

⚠CAUTION

- Do not install the remote control at the following places in order to avoid malfunction.
  (1) Places exposed to direct sunlight
  (2) Places near heat devices
  (3) High humidity places
  (4) Hot surface or cold surface enough to generate condensation
  (5) Places exposed to oil mist or steam directly
  (6) Uneven surface
- Do not leave the remote control without the upper case.
  In case the upper cace needs to be detached, protect the remote control with a packaging box or bag in order to keep it away from water and dust.

Accessories	Remote control, wood screw (ø3.5×16) 2 pieces
Prepare on site	Remote control cord (2 cores) the insulated thickness in 1mm or more. [In case of embedding cord] Erectrical box, M4 screw (2 pieces) [In case of exposing cord] Cord clamp (if needed)

Installation procedure

① Open the cover of remote control, and remove the screw under the buttons without fail.

② Remove the upper case of remote control.
Insert a flat-blade screwdriver into the dented part of the upper part of the remote control, and wrench slightly.



[In case of embedding cord]

③ Embed the erectrical box and remote control cord beforehand.



④ Prepare two M4 screws (recommended length is 12-16mm) on site, and install the lower case to erectrical box.
Choose either of the following two positions in fixing it with screws.





Tighten the screws after cutting off the thin part of screw mounting part.



⑤ Connect the remote control cord to the terminal block.
Connect the terminal of remote control (X,Y) with the terminal of indoor unit (X,Y). (X and Y are no polarity)

⑥ Install the upper case as before so as not to catch up the remote control cord, and tighten with the screws.

[In case of exposing cord]

③ You can pull out the remote control cord from left upper part or center upper part.
Cut off the upper thin part of remote control lower case with a nipper or knife, and grind burrs with a file etc.



④ Install the lower case to the flat wall with attached two wooden screws.

⑤ Connect the remote control cord to the terminal block.
Connect the terminal of remote control (X,Y) with the terminal of indoor unit (X,Y).
(X and Y are no polarity)
Wiring route is as shown in the right diagram depending on the pulling out direction.



The wiring inside the remote control case should be within 0.3mm^2 (recommended) to 0.5mm^2.
The sheath should be peeled off inside the remote control case.
The peeling-off length of each wire is as below.

Pulling out from upper left	Pulling out from upper center
X wiring : 215mm Y wiring : 195mm	X wiring : 170mm Y wiring : 190mm



⑥ Install the upper case as before so as not to catch up the remote control cord, and tighten with the screws.
⑦ In case of exposing cord, fix the cord on the wall with cord clamp so as not to slack.

Installation and wiring of remote control

① Wiring of remote control should use 0.3mm^2 × 2 cores wires or cables. (on-site configuration)
② Maximum prolongation of remote control wiring is 600 m.
If the prolongation is over 100m, change to the size below.
But, wiring in the remote control case should be under 0.5mm^2 . Change the wire size outside of the case according to wire connecting. Waterproof treatment is necessary at the wire connecting section. Be careful about contact failure.
100 - 200m·····0.5mm^2 × 2 cores
Under 300m·····0.75mm^2 × 2 cores
Under 400m·····1.25mm^2 × 2 cores
Under 500m·····2.0mm^2 × 2 cores

Master/ slave setting when more than one remote controls are used

A maximum of two remote controls can be connected to one indoor unit (or one group of indoor units.)



Switch	Setting	Contents
SW1	M	Master remote control
	S	Slave remote control



Set SW1 to "Slave" for the slave remote control. It was factory set to "Master" for shipment.
Note: The setting "Remote control sensor enabled" is only selectable with the master remote control in the position where you want to check room temperature.
The air-conditioner operation follows the last operation of the remote control regardless of the master/ slave setting of it.

The indication when power source is supplied

When power source is turned on, the following is displayed on the remote control until the communication between the remote control and indoor unit settled.
Master remote control : " WAIT M"
Slave remote control : " WAIT S"

At the same time, a mark or a number will be displayed for two seconds first.
This is the software's administration number of the remote control, not an error cord.



※ The left mark is only an example. Other marks may appear.

When remote control cannot communicate with the indoor unit for half an hour, the below indication will appear.
Check wiring of the indoor unit and the outdoor unit etc.

The range of temperature setting

When shipped, the range of set temperature differs depending on the operation mode as below.

Heating : 16-30˚C (55-86˚F)

Except heating (cooling, fan, dry, automatic) : 18-30˚C (62-86˚F)

●Upper limit and lower limit of set temperature can be changed with remote control.

Upper limit setting: valid during heating operation. Possible to set in the range of 20 to 30˚C (68 to 86˚F).

Lower limit setting: valid except heating (automatic, cooling, fan, dry) Possible to set in the range of 18 to 26˚C (62 to 79˚F).

When you set upper and lower limit by this function, control as below.

1. When ⑫TEMP RANGE SET, remote control function of function setting mode is "INDN CHANGE" (factory setting),
   【If upper limit value is set】
   During heating, you cannot set the value exceeding the upper limit.

   【If lower limit value is set 】
   During operation mode except heating, you cannot set the value below the lower limit.

2. When ⑫TEMP RANGE SET, remote control function of function setting mode is "NO INDN CHANGE"
   【If upper limit value is set】
   During heating, even if the value exceeding the upper limit is set, upper limit value will be sent to the indoor unit. But, the indication is the same as the temperature set.

   【If lower limit value is set 】
   During except heating, even if the value lower than the lower limit is set, lower limit value will be sent to the indoor unit. But, the indication is the same as the temperature set.

●How to set upper and lower limit value

1. Stop the air-conditioner, and press (SET) and (MODE) button at the same time for over three seconds .
   The indication changes to "FUNCTION SET ▼".
2. Press ▼ button once, and change to the "TEMP RANGE ▲ " indication.
3. Press (SET) button, and enter the temperature range setting mode.
4. Select "UPPER LIMIT ▼" or "LOWER LIMIT ▲" by using ▲ ▼ button.
5. Press (SET) button to fix.
6. When "UPPER LIMIT ▼" is selected (valid during heating)
   ① Indication: "☝ ∨ ∧ SET UP" → "UPPER 30˚C ∨"
   ② Select the upper limit value with temperature setting button ▽ △. Indication example: "UPPER 26˚C ∨ ∧" (blinking)
   ③ Press (SET) button to fix. Indication example: "UPPER 26˚C" (Displayed for two seconds)
   After the fixed upper limit value displayed for two seconds, the indication will return to "UPPER LIMIT ▼".
7. When "LOWER LIMIT ▲" is selected (valid during cooling, dry, fan, automatic)
   ① Indication: "☝ ∨ ∧ SET UP" → "LOWER 18˚C ∧"
   ② Select the lower limit value with temperature setting button ▽ △. Indication example: "LOWER 24˚C ∨ ∧" (blinking)
   ③ Press (SET) button to fix. Indication for example: "LOWER 24˚C" (Displayed for two seconds)
   After the fixed lower limit value displayed for two seconds, the indication will return to "LOWER LIMIT ▼".
8. Press ON/OFF button to finish.

- It is possible to finish by pressing ON/OFF button on the way, but unfinished change of setting is unavailable.
- During setting, if you press (RESET) button, you return to the previous screen.



The functional setting

●The initial function setting for typical using is performed automatically by the indoor unit connected, when remote control and indoor unit are connected.
As long as they are used in a typical manner, there will be no need to change the initial settings.
If you would like to change the initial setting marked "○", set your desired setting as for the selected item.
The procedure of functional setting is shown as the following diagram.

[Flow of function setting]

Start : Stop air-conditioner and press "○" (SET) and "▽" (MODE) buttons at the same time for over three seconds.
Finalize : Press "○" (SET) button.
Reset : Press "◇" (RESET) button.
Select : Press ▲ ▼ button.
End : Press ON/OFF button.
It is possible to finish above setting on the way, and unfinished change of setting is unavailable.
"○" : Initial settings
"※" : Automatic criterion

Record and keep the setting

Consult the technical data etc. for each control details

Stop air-conditioner and press ○ (SET) + ▽ (MODE) buttons at the same time for over three seconds.

FUNCTION SET ▼

FUNCTION ▼ (Remote control function)

Function / **setting**

01	ESP SET		
	ESP VALID	○	Validate setting of ESP:External Static Pressure
	ESP INVALID		Invalidate setting of ESP
02	AUTO RUN SET		
	AUTO RUN ON	※	
	AUTO RUN OFF	※	Automatical operation is impossible
03	TEMP SW		
	VALID	○	
	INVALID		Temperature setting button is not working
04	MODE SW		
	VALID	○	
	INVALID		Mode button is not working
05	ON/OFF SW		
	VALID	○	
	INVALID		On/Off button is not working
06	FAN SPEED SW		
	VALID	※	
	INVALID	※	Fan speed button is not working
07	LOUVER SW		
	VALID	※	
	INVALID	※	Louver button is not working
08	TIMER SW		
	VALID	○	
	INVALID		Timer button is not working
09	SENSOR SET		
	SENSOR OFF	○	Remote thermistor is not working.
	SENSOR ON		Remote thermistor is working.
	SENSOR +3.0℃		Remote thermistor is working, and to be set for producing +3.0˚C increase in temperature.
	SENSOR +2.0℃		Remote thermistor is working, and to be set for producing +2.0˚C increase in temperature.
	SENSOR +1.0℃		Remote thermistor is working, and to be set for producing +1.0˚C increase in temperature.
	SENSOR -1.0℃		Remote thermistor is working, and to be set for producing -1.0˚C increase in temperature.
	SENSOR -2.0℃		Remote thermistor is working, and to be set for producing -2.0˚C increase in temperature.
	SENSOR -3.0℃		Remote thermistor is working, and to be set for producing -3.0˚C increase in temperature.
10	AUTO RESTART		
	INVALID	○	
	VALID		
11	VENT LINK SET		
	NO VENT	○	
	VENT LINK		In case of Single split series, by connecting ventilation device to CNT of the indoor printed circuit board (in case of VRF series, by connecting it to CND of the indoor printed circuit board), the operation of ventilation device is linked with the operation of indoor unit.
	NO VENT LINK		In case of Single split series, by connecting ventilation device to CNT of the indoor printed circuit board (in case of VRF series, by connecting it to CND of the indoor printed circuit board), you can operate /stop the ventilation device independently by ◇ (VENT) button.
12	TEMP RANGE SET		
	INDIN CHANGE	○	If you change the range of set temperature, the indication of set temperature will vary following the control.
	NO INDIN CHANGE		If you change the range of set temperature, the indication of set temperature will not vary following the control, and keep the set temperature.
13	I/U FAN		
	HI-MID-LO	※	Air flow of fan becomes the three speed of ※ -※ -※ or ※ -※ -※ -※ .
	HI-LO	※	Air flow of fan becomes the two speed of ※ -※ .
	HI-MID		Air flow of fan becomes the two speed of ※ -※ .
	1 FAN SPEED	※	Air flow of fan is fixed at one speed.
14	POSITION		If you change the remote control function "14 POSITION", you must change the indoor function "04 POSITION" accordingly.
	4POSITION STOP	○	You can select the louver stop position in the four.
	FREE STOP		The louver can stop at any position.
15	MODEL TYPE		
	HEAT PUMP	※	
	COOLING ONLY	※	
16	EXTERNAL CONTROL SET		
	INDIVIDUAL	○	If you input signal into CnT of the indoor printed circuit board from external, the indoor unit will be operated independently according to the input from external. If you input into CNT of the indoor printed circuit board from external, all units which connect to the same remote control are operated according to the input from external.
	FOR ALL UNITS		
17	ROOM TEMP INDICATION SET		
	INDICATION OFF	○	
	INDICATION ON		In normal working indication, indoor unit temperature is indicated instead of air flow. (Only the master remote control can be indicated.)
18	※ INDICATION		
	INDICATION ON	○	
	INDICATION OFF		Heating preparation indication should not be indicated.
19	℃/℉ SET		
	℃	○	Temperature indication is by degree C.
	℉		Temperature indication is by degree F.

I/U FUNCTION ▲ (Indoor unit function)

Indoor unit No. are indicated only when plural indoor units are connected.

I/U000 ▲
I/U001 ≑
I/U002 ≑
I/U003 ≑
I/U004 ≑

To set other indoor unit, press AIR CON No. button, which allows you to go back to the indoor unit selection screen (for example: I/U 000 ▲).

Function / **setting**

02	FAN SPEED SET		
	STANDARD	※	
	HIGH SPEED 1	※	
	HIGH SPEED 2		
03	FILTER SIGN SET		
	INDICATION OFF		
	TYPE 1	○	The filter sign is indicated after running for 180 hours.
	TYPE 2		The filter sign is indicated after running for 600 hours.
	TYPE 3		The filter sign is indicated after running for 1000 hours.
	TYPE 4		The filter sign is indicated after running for 1000 hours, then the indoor unit will be stopped by compulsion after 24 hours.
04	POSITION		If you change the indoor function "04 POSITION", you must change the remote control function "14 POSITION" accordingly.
	4POSITION STOP	○	You can select the louver stop position in the four.
	FREE STOP		The louver can stop at any position.
05	EXTERNAL INPUT		
	LEVEL INPUT	○	
	PULSE INPUT		
06	OPERATION PERMISSION/PROHIBITION		
	INVALID	○	
	VALID		Permission/prohibition control of operation will be valid.
07	EMERGENCY STOP		
	INVALID	○	
	VALID		With the VRF series, it is used to stop all indoor units connected with the same outdoor unit immediately. When stop signal is inputed from remote on-off terminal "CNT-6", all indoor units are stopped immediately.
08	※ SP OFFSET		
	OFFSET +3.0℃		To be reset for producing +3.0˚C increase in temperature during heating.
	OFFSET +2.0℃		To be reset for producing +2.0˚C increase in temperature during heating.
	OFFSET +1.0℃		To be reset for producing +1.0˚C increase in temperature during heating.
	NO OFFSET	○	
09	RETURN AIR TEMP		
	OFFSET +2.0℃		To be reset producing +2.0˚C increase in return air temperature of indoor unit.
	OFFSET +1.5℃		To be reset producing +1.5˚C increase in return air temperature of indoor unit.
	OFFSET +1.0℃		To be reset producing +1.0˚C increase in return air temperature of indoor unit.
	NO OFFSET	○	
	OFFSET -1.0℃		To be reset producing -1.0˚C increase in return air temperature of indoor unit.
	OFFSET -1.5℃		To be reset producing -1.5˚C increase in return air temperature of indoor unit.
	OFFSET -2.0℃		To be reset producing -2.0˚C increase in return air temperature of indoor unit.
10	※ FAN CONTROL		
	LOW FAN SPEED	○	When heating thermostat is OFF, fan speed is low speed.
	SET FAN SPEED		When heating thermostat is OFF, fan speed is set speed.
	INTERMITTENCE		When heating thermostat is OFF, fan speed is operated intermittently.
	FAN OFF		When heating thermostat is OFF, the fan is stopped. When the remote thermistor is working, "FAN OFF" is set automatically. Do not set "FAN OFF" when the indoor unit's thermistor is working.
11	FROST PREVENTION TEMP		Change of indoor heat exchanger temperature to start frost prevention control.
	TEMP HIGH		
	TEMP LOW	○	
12	FROST PREVENTION CONTROL		Working only with the Single split series.
	FAN CONTROL ON	○	To control frost prevention, the indoor fan tap is raised.
	FAN CONTROL OFF		
13	DRAIN PUMP LINK		
	◇	○	Drain pump is run during cooling and dry.
	◇ AND※		Drain pump is run during cooling, dry and heating.
	◇ AND※ AND≋		Drain pump is run during cooling, dry, heating and fan.
	◇ AND≋		Drain pump is run during cooling, dry and fan.
14	FAN REMAINING		
	NO REMAINING	○	After cooling is stopped is OFF, the fan does not perform extra operation.
	0.5 HOUR		After cooling is stopped is OFF, the fan perform extra operation for half an hour.
	1 HOUR		After cooling is stopped is OFF, the fan perform extra operation for an hour.
	6 HOUR		After cooling is stopped is OFF, the fan perform extra operation for six hours.
15	※ FAN REMAINING		
	NO REMAINING	○	After heating is stopped or heating thermostat is OFF, the fan does not perform extra operation.
	0.5 HOUR		After heating is stopped or heating thermostat is OFF,the fan perform extra operation for half an hour.
	2 HOUR		After heating is stopped or heating thermostat is OFF,the fan perform extra operation for two hours.
	6 HOUR		After heating is stopped or heating thermostat is OFF, the fan perform extra operation for six hours.
16	※ FAN INTERMITTENCE		
	NO REMAINING	○	
	2min ON 5min OFF		During heating is stopped or heating thermostat is OFF, the fan perform intermittent operation for five minutes with low fan speed after twenty minutes' OFF.
	5min OFF 5min ON		During heating is stopped or heating thermostat is OFF, the fan perform intermittent operation for five minutes with low fan speed after five minutes' OFF.
17	PRESSURE CONTROL		
	STANDARD	※	
	TYPE1	※	Connected "OA Processing" type indoor unit, and is automatically defined.

ON/OFF button (finished)

Note 1: The initial setting marked "※" is decided by connected indoor and outdoor unit, and is automatically defined as following table.

Function No.	Item	Default	Model
Remote control function02	AUTO RUN SET	AUTO RUN ON	"Auto-RUN" mode selectable indoor unit.
		AUTO RUN OFF	Indoor unit without "Auto-RUN" mode
Remote control function06	FAN SPEED SW	VALID	Indoor unit with two or three step of air flow setting
		INVALID	Indoor unit with only one of air flow setting
Remote control function07	LOUVER SW	VALID	Indoor unit with automatically swing louver
		INVALID	Indoor unit without automatically swing louver
Remote control function13	I/U FAN	HI-MID-LO	Indoor unit with three step of air flow setting
		HI-LO	Indoor unit with two step of air flow setting
		HI-MID	
		1 FAN SPEED	Indoor unit with only one of air flow setting
Remote control function15	MODEL TYPE	HEAT PUMP	Heat pump unit
		COOLING ONLY	Exclusive cooling unit

Note 3: As for plural indoor unit, set indoor functions to each master and slave indoor unit.
But only master indoor unit is received the setting change of indoor unit function "05 EXTERNAL INPUT" and "06 PERMISSION / PROHIBISHION".

Note2: Fan setting of "HIGH SPEED"

Fan tap		Indoor unit air flow setting			
		※ -※ - ※ - ※	※ - ※ - ※	※ - ※	※ - ※
FAN SPEED SET	STANDARD	UH - Hi - Me - Lo	Hi - Me - Lo	Hi - Lo	Hi - Me
	HIGH SPEED1, 2	UH - UH - Hi - Me	UH - Hi - Me	UH - Me	UH - Hi

Initial function setting of some indoor unit is "HIGH SPEED".

How to set function

1. **Stop air-conditioner and press (SET) (MODE) buttons at the same time for over three seconds, and the "FUNCTION SET ▼" will be displayed.**

2. **Press (SET) button.**
3. **Make sure which do you want to set, "FUNCTION ▼" (remote control function) or "I/U FUNCTION ▲" (indoor unit function).**
4. **Press ▲ or ▼ button.**
   Selecct "FUNCTION ▼" (remote control function) or "I/U FUNCTION ▲" (indoor unit function).



5. **Press (SET) button.**



6. **【On the occasion of remote control function selection】**

① "DATA LOADING" (Indication with blinking)
↓
Display is changed to "01 ESP SET".

② Press ▲ or ▼ button.
"No. and function"are indicated by turns on the remote control function table, then you can select from them.
(For example)



③ Press (SET) button.
The current setting of selected function is indicated.
(for example) "AUTO RUN ON" ← If "02 AUTO RUN SET" is selected



④ Press ▲ or ▼ button.
Select the setting.



⑤ Press (SET)
"SET COMPLETE" will be indicated, and the setting will be completed.
Then after "No. and function" indication returns, Set as the same procedure if you want to set continuously ,and if to finish, go to 7.

7. **Press ON/OFF button.**
   Setting is finished.

【On the occasion of indoor unit function selection】

① "DATA LOADING" (Blinking for 2 to 23 seconds to read the data)
↓
Indication is changed to "02 FAN SPEED SET".
Go to ②.

[Note]

(1) If plural indoor units are connected to a remote control, the indication is "I/U 000" (blinking) ← The lowest number of the indoor unit connected is indicated.



(2) Press ▲ or ▼ button.
Select the number of the indoor unit you are to set
If you select "ALL UNIT ▼", you can set the same setting with all unites.

(3) Press (SET) button.

② Press ▲ or ▼ button.
"No. and function" are indicated by turns on the indoor unit function table, then you can select from them.
(For example)



③ Press (SET) button.
The current setting of selected function is indicated.
(For example) "STANDARD" ← If "02 FAN SPEED SET" is selected.



④ Press ▲ or ▼ button.
Select the setting.

⑤ Press (SET) button.
"SET COMPLETE" will be indicated, and the setting will be completed.
Then after "No. and function" indication returns, set as the same procedure if you want to set continuously , and if to finish, go to 7.

※ When plural indoor units are connected to a remote control, press the AIR CON No. button, which allows you to go back to the indoor unit selection screen. (example "I/U 000 ▲")

- It is possible to finish by pressing ON/OFF button on the way, but unfinished change of setting is unavailable.
- During setting, if you press (RESET) button, you return to the previous screen.
- Setting is memorized in the control and it is saved independently of power failure.

【How to check the current setting】

When you select from "No. and funcion" and press set button by the previous operation, the "Setting" displayed first is the current setting.
(But, if you select "ALL UNIT ▼", the setting of the lowest number indoor unit is displayed.)

1.10.4 Installation of outdoor unit
Models FDC100-140VNA-W, 100-140VSA-W

PSC012D120A B

Inverter driven split PAC
100, 125, 140 VNA-W 100, 125, 140 VSA-W
Designed for R32 refrigerant

◎This installation manual deals with outdoor units and general installation specifications only. For indoor units, refer to the respective installation manuals supplied with the units.
◎When install the unit, be sure to check whether the selection of installation place, power source specifications, usage limitation (piping length, height differences between indoor and outdoor units, power source voltage and etc.) and installation spaces

SAFETY PRECAUTIONS

- We recommend you to read this "SAFETY PRECAUTIONS" carefully before the installation work in order to gain full advantage of the functions of the unit and to avoid malfunction due to mishandling.
- The precautions described below are divided into ⚠WARNING and ⚠CAUTION. The matters with possibilities leading to serious consequences such as death or serious personal injury due to erroneous handling are listed in the ⚠WARNING and the matters with possibilities leading to personal injury or damage of the unit due to erroneous handling including probability leading to serious consequences in some cases are listed in ⚠CAUTION. **These are very important precautions for safety. Be sure to observe all of them without fail.**
- The meaning of "Marks" used here are as shown below.

⃠	Never do it under any circumstance.	❗	Always do it according to the instruction

- For 3 phase power source outdoor unit, EN61000-3-2 is not applicable if consent by the utility company or nortification to the utility company is given before usage.
- 3 phase power source unit, both indoor and outdoor, is suitable for installation in a commercial and light industrial environment. If installed as a house-hold appliance it could cause electromagnetic interference.
- 5 and 6 HP units of single phase power source are equipment complying with IEC 61000-3-12.
- Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.
- Keep the installation manual together with owner's manual at a place where any user can read at any time. Moreover if necessary, ask to hand them to a new user

Check before installation work

- Model name and power source
- Refrigerant piping length
- Piping, wiring and miscellaneous small parts
- Indoor unit installation manual

⚠ WARNING

- **Installation must be carried out by the qualified installer.**
  If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction.
- **Install the system in full accordance with the instruction manual.**
  Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire.
- **Use the original accessories and the specified components for installation.**
  If parts other than those prescribed by us are used, It may cause fall of the unit, water leaks, electric shocks, fire, refrigerant leak, substandard performance, control failure and personal injury.
- **When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage accordance with ISO5149.**
  Consult the expert about prevention measures. If the density of refrigerant exceeds the limit in the event of leakage, lack of oxygen can occur, which can cause serious accidents.
- **Ventilate the working area well in the event of refrigerant leakage during installation.**
  If the refrigerant comes into contact with naked flames, poisonous gas is produced.
- **After completed installation, check that no refrigerant leaks from the system.**
  If refrigerant leaks into the room and comes into contact with an oven or other hot surface, poisonous gas is produced.
- **Hang up the unit at the specified points with ropes which can support the weight in lifting for portage. And to avoid jolting out of alignment, be sure to hang up the unit at 4-point support.**
  An improper manner of portage such as 3-point support can cause death or serious personal injury due to falling of the unit
- **Install the unit in a location with good support.**
  Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.
- **Ensure the unit is stable when installed, so that it can withstand earthquakes and strong winds.**
  Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.
- **The electrical installation must be carried out by the qualified electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit.**
  Power source with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire,
- **Be sure to shut off the power before starting electrical work.**
  Failure to shut off the power can cause electric shocks, unit failure or incorrect function of equipment.
- **Be sure to use the cables conformed to safety standard and cable ampacity for power distribution work.**
  Unconformable cables can cause electric leak, anomalous heat production or fire.
- **Use the prescribed cables for electrical connection, tighten the cables securely in terminal block and relieve the cables correctly to prevent overloading the terminal blocks.**
  Loose connections or cable mountings can cause anomalous heat production or fire.
- **Arrange the wiring in the control box so that it cannot be pushed up further into the box. Install the service panel correctly.**
  Incorrect installation may result in overheating and fire.
- **Do not perform brazing work in the airtight room**
  It can cause lack of oxygen.
- **Use the prescribed pipes, flare nuts and tools for R32 and R410A.**
  Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circuit.
- **Tighten the flare nut by using double spanners and torque wrench according to prescribed method. Be sure not to tighten the flare nut too much.**
  Loose flare connection or damage on the flare part by tightening with excess torque can cause burst or refrigerant leaks which may result in lack of oxygen.
- **Do not open the service valves for liquid line and gas line until completed refrigerant piping work, air tightness test and evacuation.**
  If the compressor is operated in state of opening service valves before completed connection of refrigerant piping work, you may incur frost bite or injury from an abrupt refrigerant outflow and air can be sucked into refrigerant circuit, which can cause burst or personal injury due to anomalously high pressure in the refrigerant
- **Only use prescribed option parts. The installation must be carried out by the qualified installer.**
  If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.
- **Do not perform any change of protective device itself or its setup condition**
  The forced operation by short-circuiting protective device of pressure switch and temperature controller or the use of non specified component can cause fire or burst.
- **Be sure to switch off the power source in the event of installation, inspection or servicing.**
  If the power source is not shut off, there is a risk of electric shocks, unit failure or personal injury due to the unexpected start of fan.
- **Consult the dealer or an expert regarding removal of the unit.**
  Incorrect installation can cause water leaks, electric shocks or fire.
- **Stop the compressor before closing valve and disconnecting refrigerant pipes in case of pump down operation.**
  If disconnecting refrigerant pipes in state of opening service valves before compressor stopping, you may incur frost bite or injury from an abrupt refrigerant outflow and air can be sucked, which can cause burst or personal injury due to anomalously high pressure in the refrigerant circuit
- **Be sure to wear protective goggles and gloves while at work.**
- **This unit is designed specifically for R32.**
  Using any other refrigerant can cause unit failure and personal injury.
- **Ensure that no air enters in the refrigerant circuit when the unit is installed and removed.**
  If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury.
- **Do not run the unit with removed panels or protections**
  Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shocks.
- **Be sure to fix up the service panels.**
  Incorrect fixing can cause electric shocks or fire due to intrusion of dust or water.
- **Do not perform any repairs or modifications by yourself. Consult the dealer if the unit requires repair.**
  If you repair or modify the unit, it can cause water leaks, electric shocks or fire.
- **Do not process or splice the power cord, or share the socket with other power plugs.**
  This may cause fire or electric shock due to defecting contact, defecting insulation and over-current etc.
- **Do not bundle or wind or process the power cord. Do not deform the power cord by treading it.**
  This may cause fire or heating.

⚠ CAUTION

- **Carry out the electrical work for ground lead with care**
  Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting. Never connect the grounding wire to a gas pipe because if gas leaks,it could cause explosion or ignition.
- **Use the circuit breaker for all pole with correct capacity.**
  Using the incorrect circuit breaker, it can cause the unit malfunction and fire.
- **Install isolator or disconnect switch on the power source wiring in accordance with the local codes and regulations.**
  The isolator should be locked in accordanced with EN60204-1.
- **Take care when carrying the unit by hand.**
  If the unit weights more than 20kg, it must be carried by two or more persons. Do not carry by the plastic straps, always use the carry handle when carrying the unit by hand. Use gloves to minimize the risk of cuts by the aluminum fins.
- **Dispose of any packing materials correctly.**
  Any remaining packing materials can cause personal injury as it contains nails and wood. And to avoid danger of suffocation, be sure to keep the plastic wrapper away from children and to dispose after tear it up.
- **Pay attention not to damage the drain pan by weld spatter when welding work is done near the indoor unit.**
  If weld spatter entered into the indoor unit during welding work, it can cause pin-hole in drain pan and result in water leakage. To prevent such damage, keep the indoor unit in its packing or cover it.
- **Be sure to insulate the refrigerant pipes so as not to condense the ambient air moisture on them.**
  Insufficient insulation can cause condensation, which can lead to moisture damage on the ceiling, floor, furniture and any other valuables.
- **Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work.**
  If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents.
- **Perform installation work properly according to this installation manual.**
  Improper installation can cause abnormal vibrations or increased noise generation.
- **After maintenance, all wiring, wiring ties and the like, should be returned to their original state and wiring route, and the necessary clearance from all metal parts should be secured.**
- **Earth leakage breaker must be installed**
  If the earth leakage breaker is not installed, it can cause fire or electric shocks.
- **Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used.**
  Connecting the circuit with copper wire or other metal thread can cause unit failure and fire.
- **Do not install the unit near the location where leakage of combustible gases can occur.**
  If leaked gases accumulate around the unit, it can cause fire.
- **Do not install the unit where corrosive gas (such as sulfurous acid gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances are handled.**
  Corrosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas can cause fire.
- **Secure a space for installation, inspection and maintenance specified in the manual.**
  Insufficient space can result in accident such as personal injury due to falling from the installation place.
- **When the outdoor unit is installed on a roof or a high place, provide permanent ladders and handrails along the access route and fences and handrails around the outdoor unit.**
  If safety facilities are not provided, it can cause personal injury due to falling from the installation place.
- **Do not install nor use the system close to the equipment that generates electromagnetic fields or high frequency harmonics**
  Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment, and obstruct its function or cause jamming.
- **Do not install the outdoor unit in a location where insects and small animals can inhabit.**
  Insects and small animals can enter the electric parts and cause damage or fire. Instruct the user to keep the surroundings clean.
- **Do not use the base flame for outdoor unit which is corroded or damaged due to long periods of operation.**
  Using an old and damage base flame can cause the unit falling down and cause personal injury.
- **Do not install the unit in the locations listed below**
  - Locations where carbon fiber, metal powder or any powder is floating.
  - Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur.
  - Vehicles and ships
  - Locations where cosmetic or special sprays are often used.
  - Locations with direct exposure of oil mist and steam such as kitchen and machine plant.
  - Locations where any machines which generate high frequency harmonics are used.
  - Locations with salty atmospheres such as coastlines
  - Locations with heavy snow (If installed, be sure to provide base flame and snow hood mentioned in the manual)
  - Locations where the unit is exposed to chimney smoke
  - Locations at high altitude (more than 1000m high)
  - Locations with ammonic atmospheres (e.g. organic fertilizer).
  - Locations with calcium chloride (e.g. snow melting agent).
  - Locations where heat radiation from other heat source can affect the unit
  - Locations without good air circulation.
  - Locations with any obstacles which can prevent inlet and outlet air of the unit
  - Locations where short circuit of air can occur (in case of multiple units installation)
  - Locations where strong air blows against the air outlet of outdoor unit
  - Locations where something located above the unit could fall.
  - It can cause remarkable decrease in performance, corrosion and damage of components, malfunction and fire.
- **Do not install the outdoor unit in the locations listed below.**
  - Locations where discharged hot air or operating sound of the outdoor unit can bother neighborhood.
  - Locations where outlet air of the outdoor unit blows directly to an animal or plants. The outlet air can affect adversely to the plant etc.
  - Locations where vibration can be amplified and transmitted due to insufficient strength of structure.
  - Locations where vibration and operation sound generated by the outdoor unit can affect seriously, (on the wall or at the place near bed room)
  - Locations where an equipment affected by high harmonics is placed. (TV set or radio receiver is placed within 5m)
  - Locations where drainage cannot run off safely.
  - It can affect surrounding environment and cause a claim
- **Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or art.**
  It can cause the damage of the items.
- **Do not touch any buttons with wet hands**
  It can cause electric shocks
- **Do not touch any refrigerant pipes with your hands when the system is in operation.**
  During operation the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury or frost injury.
- **Do not clean up the unit with water**
  It can cause electric shocks
- **Do not operate the outdoor unit with any article placed on it.**
  You may incur property damage or personal injure from a fall of the article.
- **Do not step onto the outdoor unit.**
  You may incur injury from a drop or fall.
- **Do not touch the suction or aluminum fin on the outdoor unit.**
  This may cause injury.

Notabilia as a unit designed for R32

- Do not use any refrigerant other than R32. R32 will rise to pressure about 1.6 times higher than that of a conventional refrigerant (R22 or R407C).
  A cylinder containing R32 has a light blue indication mark on the top.
- A unit designed for R32 has adopted a different size indoor unit operation valve charge port and a different size check joint provided in the unit to prevent the charging of a wrong refrigerant by mistake. The processed dimension of the flared part of a refrigerant pipe and a flare nut's parallel side measurement have also been altered to raise strength against pressure. Accordingly, you are required to arrange dedicated R32 tools listed in the table on the right before installing or servicing this unit.
- All indoor units must be models designed exclusively for R32. Check connectable indoor unit models in a catalog, etc. (A wrong indoor unit, if connected into the system, will impair proper system operation)

	Dedicated R32 and R410A tools
a)	Gauge manifold
b)	Charge hose
c)	Electronic scale for refrigerant charging
d)	Torque wrench
e)	Flare tool
f)	Protrusion control copper pipe gauge
g)	Vacuum pump adapter
h)	Gas leak detector

1. HAULAGE AND INSTALLATION (Take particular care in carrying in or moving the unit, and always perform such an operation with two or more persons.)

⚠CAUTION When a unit is hoisted with slings for haulage, take into consideration the offset of its gravity center position.
If not properly balanced, the unit can be thrown off-balance and fall.



1) Delivery

- Deliver the unit as close as possible to the installation site before removing it from the packaging.
- When some compelling reason necessitates the unpacking of the unit before it is carried in, use nylon slings or protective wood pieces so as not to damage the unit by ropes lifting it.

2) Portage

- The right hand side of the unit as viewed from the front (diffuser side) is heavier. A person carrying the right hand side must take heed of this fact. A person carrying the left hand side must hold with his right hand the handle provided on the front panel of the unit and with his left hand the corner column section.



3) Selection of installation location for the outdoor unit

Be sure to select a suitable installation place in consideration of following conditions.
○ A place where it is horizontal, stable and can endure the unit weight and will not allow vibration transmittance of the unit.
○ A place where it can be free from possibility of bothering neighbors due to noise or exhaust air from the unit
○ A place where the unit is not exposed to oil splashes.
○ A place where it can be free from danger of flammable gas leakage.
○ A place where drain water can be disposed without any trouble.
○ A place where the unit will not be affected by heat radiation from other heat source.
○ A place where snow will not accumulate.
○ A place where the unit can be kept away 5m or more from TV set and/or radio receiver in order to avoid any radio or TV interference.
○ A place where good air circulation can be secured, and enough service space can be secured for maintenance and service of the unit safely.
○ A place where the unit will not be affected by electromagnetic waves and/or high-harmonic waves generated by other equipment.
○ A place where chemical substances like sulfuric gas, chloric gas, acid and alkali (including ammonia), which can harm the unit, will not be generated and not remain.
○ A place where strong wind will not blow against the outlet air blow of the unit.
○ Do not install the unit in places which exposed to sea breeze (e.g. coastal area) or calcium chloride (e.g. snow melting agent), exposed to ammonia substance (e.g. organic fertilizer).

4) Caution about selection of installation location

(1) If the unit is installed in the area where the snow will accumulate, following measures are required.
The bottom plate of unit and intake, outlet may be blocked by snow.

1.Install the unit on the base so that the bottom is higher than snow cover surface.

2.Provide a snow hood to the outdoor unit on site.
Regarding outline of a snow hood, consult a dealer.

3.Install the unit under eaves or provided the roof on site.

Since drain water generated by defrost control may freeze, following measures are required.
- Don't execute drain piping work by using a drain elbow and drain grommets (option parts). [Refer to DRAIN PIPING WORK.]
- Recommend setting Defrost Control (SW3-1) and Snow Guard Fan Control (SW3-2). [Refer to Setting SW3-1, SW3-2.]
- Attach heater on a base plate on site, if there is possibility to freeze drain water.
  In case that the product has a corrective drainage system, the drainage paths should have suitable measure against freezing but be sure not to melt the material of drainage paths with heat.

(2) If the unit can be affected by strong wind, following measures are required.
Strong wind can cause damage of fan (fan motor), or can cause performance degradation, or can trigger anomalous stop of the unit due to rising of high pressure.

1.Install the outlet air blow side of the unit to face a wall of building, or provide a fence or a windbreak screen.



2.Install the outlet air blow side of the unit in a position perpendicular to the direction of wind.



3.The unit should be installed on the stable and level foundation. If the foundation is not level, tie down the unit with wires.

5) Installation space

- Walls surrounding the unit in the four sides are not acceptable.
- There must be a 1-meter or larger space in the above.
- Where a danger of short-circuiting exists, install guide louvers.
- When more than one unit are installed, provide sufficient intake space consciously so that short-circuiting may not occur.
- Where piling snow can bury the outdoor unit, provide proper snow guards.
- A barrier wall placed in front of the exhaust diffuser must not be higher than the unit.

(mm)

Size \ Example installation	I	II	III
L1	Open	Open	500
L2	300	5	Open
L3	150	300	150
L4	150	150	150



6) Installation



- In installing the unit, fix the unit's legs with bolts specified on the left.
- The protrusion of an anchor bolt on the front side must be kept within 15 mm.
- Securely install the unit so that it does not fall over during earthquakes or strong winds, etc.
- Refer to the left illustrations for information regarding concrete foundations.
- Install the unit in a level area. (With a gradient of 5 mm or less.)
  Improper installation can result in a compressor failure, broken piping within the unit and abnormal noise generation.

7) To run the unit for a cooling operation, when the outdoor temperature is –5°C or lower.

- When the outdoor air temperature is -5°C or lower, provide a snow hood to the outdoor unit on site, so that strong wind will not blow against the outdoor heat exchanger directly. Regarding outline of a snow hood, consult a dealer.

2. REFRIGERANT PIPING WORK

1) Restrictions on unit installation and use

- Check the following points in light of the indoor unit specifications and the installation site.
- Observe the following restrictions on unit installation and use. Improper installation can result in a compressor failure or performance degradation.

Restrictions			Marks appearing in the drawing			
	One-way pipe length difference from the first branching point to the indoor unit				< 3m	≧ 3m
	Model for outdoor units	Dimensional restrictions	Single type	Twin type	Triple type A	Triple type B
One-way pipe length of refrigerant piping	100VNA,125VNA,100VSA,125VSA	≦ 50m	L	L+L1+L2	L+L1+L2+L3	L+L1+L2+L3
	140VNA, 140VSA					
Main pipe length	100VNA, 125VNA,100VSA,125VSA	≦ 50m	—	L	—	—
	140VNA, 140VSA				L	L
One-way pipe length between the first branching point from to the second branching point	140VNA, 140VSA	≦ 5m	—	—	—	La
One-way pipe length after the first branching point	All Models	≦ 30m	—	L1,L2	—	—
	140VNA, 140VSA				L1, L2, L3	L1 (1)
One-way pipe length from the first branching point to indoor units through the second branching point	140VNA, 140VSA	≦ 27m	—	—	—	La+L2, La+L3 (1)
One-way pipe length difference from the first branching point to the indoor unit	All Models	≦ 10m	—	IL1-L2I	—	—
	140VNA, 140VSA	≦ 3m			I L1-L2 I , I L2-L3 I , I L3-L1 I	
		≦ 10m			—	L1-(La+L2),L1-(La+L3) (1)
One way pipe length difference from the second branching point to the indoor unit	140VNA, 140VSA	≦ 10m	—	—	—	I L2-L3 I
Elevation difference between indoor and outdoor units	When the outdoor unit is positioned higher.	≦ 50m (2)	H	H	H	H
	When the outdoor unit is positioned lower.	≦ 15m				
Elevation difference between indoor units		≦ 0.5m	—	h	h1,h2,h3	h1,h2,h3

⚠CAUTION
- The use restrictions appearing in the table above are applicable to the standard pipe size combinations shown in the table below. Where an existing pipe system is utilized, different one-way pipe length restrictions should apply depending on its pipe size. For more information, see " 6. UTILIZATION OF EXISTING PIPING."
- With the triple pipe connection, the way of use is different when the difference of one-way pipe length after the first branching point is 3m to 10m. For details, refer to the above table and right figure.

Note (1) Install the indoor units so that L + L1 becomes the longest one-way pipe.
Keep the pipe length difference between L1 and (La + L2) or (La + L3) within 10m.
(2) When the outdoor unit is installed at a position higher than the indoor unit by 30m or more, set SW5-2 on the control PCB to ON.

< Single type >



< Twin type >



< Triple type A >



< Triple type B >



2) Determination of pipe size

- Determine refrigerant pipe size pursuant to the following guidelines based on the indoor unit specifications.

		Model 100V		Model 125V		Model 140V	
		Gas pipe	Liquid pipe	Gas pipe	Liquid pipe	Gas pipe	Liquid pipe
Outdoor unit connected		ϕ15.88	ϕ9.52	ϕ15.88	ϕ9.52	ϕ15.88	ϕ9.52
		Flare	Flare	Flare	Flare	Flare	Flare
Refrigerant piping (Main pipe L)		ϕ15.88	ϕ9.52	ϕ15.88	ϕ9.52	ϕ15.88	ϕ9.52
In the case of a single type	Indoor unit connected	ϕ15.88	ϕ9.52	ϕ15.88	ϕ9.52	ϕ15.88	ϕ9.52
	Capacity of indoor unit	Model 100V		Model 125V		Model 140V	
In the case of a twin type	Branching pipe set	DIS-WA1G		DIS-WA1G		DIS-WA1G	
	Refrigerant piping (branch pipe L1,L2)	ϕ12.7	ϕ9.52	ϕ12.7	ϕ9.52	ϕ15.88	ϕ9.52
	Indoor unit connected	ϕ12.7	ϕ6.35	ϕ12.7	ϕ6.35	ϕ15.88	ϕ9.52
	Capacity of indoor unit	Model 50V×2		Model 60V×2		Model 71V×2	
In the case of a triple type A	Branching pipe set	—		—		DIS-TA1G	
	Refrigerant piping (branch pipe L1,L2,L3)					ϕ12.7	ϕ9.52
	Indoor unit connected					ϕ12.7	ϕ6.35
	Capacity of indoor unit					Model 50Vx3	
In the case of a triple type B	Branching pipe set	—		—		DIS-WA1G	
	Refrigerant piping (branch pipe La)					ϕ15.88	ϕ9.52
	Refrigerant piping (branch pipe L1)					ϕ12.7	ϕ9.52
	Branching pipe set (After branch pipe La)					DIS-WA1G	
	Refrigerant piping (branch pipe L2,L3)					ϕ12.7	ϕ9.52
	Indoor unit connected					ϕ12.7	ϕ6.35
	Capacity of indoor unit					Model 50V×3	

⚠CAUTION
- When the 50V or 60V model is connected as an indoor unit, always use a ϕ9.52 liquid pipe for the branch (branching pipe – indoor unit) and a different diameter joint supplied with the branching pipe set for connection with the indoor unit (ϕ6.35 on the liquid pipe side).
  If a ϕ6.35 pipe is used for connection with a branching pipe, a refrigerant distribution disorder may occur, causing one of the indoor units to fall short of the rated capacity.
- A riser pipe must be a part of the main. A branching pipe set should be installed horizontally at a point as close to an indoor unit as possible.
  A branching part must be dressed with a heat-insulation material supplied as an accessory.
- For the details of installation work required at and near a branching area, see the installation manual supplied with your branching pipe set.
- In the case of a triple type, branching pipe set shown in this table varies depending on the length difference of one way piping after the first branch. Please check the table above.

About brazing

Brazing must be performed under a nitrogen gas flow.

Without nitrogen gas, a large quantity of foreign matters (oxidized film) are created, causing a critical failure from capillary tube or expansion valve clogging.





3) Refrigerant pipe wall thickness and material

- Select refrigerant pipes of the table shown on the right wall thickness and material as specified for each pipe size.
- This unit uses R32. Always use 1/2H pipes having a 1.0mm or thicker wall for ϕ19.05 or larger pipes, because O-type pipes do not meet the pressure resistance requirement.

Pipe diameter [mm]	6.35	9.52	12.7	15.88	22.22	25.4	28.58
Minimum pipe wall thickness [mm]	0.8	0.8	0.8	1.0	1.0	1.0	1.0
Pipe material*	O-type pipe	O-type pipe	O-type pipe	O-type pipe	1/2H-type pipe	1/2H-type pipe	1/2H-type pipe

*Phosphorus deoxidized seamless copper pipe C1220T, JIS H 3300

NOTE
- Select pipes having a wall thickness larger than the specified minimum pipe thickness.

4) On-site piping work

⚠IMPORTANT
- Take care so that installed pipes may not touch components within a unit. If touching with an internal component, it will generate abnormal sounds and/or vibrations.

How to remove the service panel First remove the five screws (× mark) of the service panel and push it down into the direction of the arrow mark and then remove it by pulling it toward you.







- The pipe can be laid in any of the following directions: side right, front, rear and downward.
- Remove a knock-out plate provided on the pipe penetration to open a minimum necessary area.
  ※Please close the gap of piping connecting part with putty or insulation material (locally procured) after piping connection. Small animals or insects may intrude into the outdoor unit and it will cause electrical short.
- Carry out the on site piping work with the operation valve fully closed.
- Give sufficient protection to a pipe end (compressed and blazed, or with an adhesive tape) so that water or foreign matters may not enter the piping.
- Bend a pipe to a radius as large as practical.(R100–R150) Do not bend a pipe repeatedly to correct its form.
- Flare connection is used between the unit and refrigerant pipe. Flare a pipe after engaging a flare nut onto it. Flare dimensions for R32 are different from those for conventional R22 and R407C. Although we recommend the use of flaring tools designed specifically for R32, conventional flaring tools can also be used by adjusting the measurement of protrusion B with a protrusion control gauge.
  ※Do not reuse existing flare, make new flare.
- The pipe should be anchored every 1.5m or less to isolate the vibration.
- Tighten a flare joint securely with a double spanner.



Flared pipe end: A (mm)

Copper pipe outer diameter	A 0 −0.4
ϕ6.35	9.1
ϕ9.52	13.2
ϕ12.7	16.6
ϕ15.88	19.7



Copper pipe protrusion for flaring: B (mm)

Copper pipe outer diameter	In the case of a rigid (clutch) type	
	With an R32 tool	With a conventional tool
ϕ6.35	0–0.5	0.7–1.3
ϕ9.52		
ϕ12.7		
ϕ15.88		

⚠ CAUTION
- Do not apply force beyond proper fastening torque in tightening the flare nut.
- Fix both liquid and gas service valves at the valve main bodies as illustrated on the right, and then fasten them, applying appropriate fastening torque.
- Do not apply refrigerating machine oil to the flared surface. It can cause refrigerant leakage.

Operation valve size (mm)	Tightening torque (N·m)
ϕ6.35 (1/4")	14–18
ϕ9.52 (3/8")	34–42
ϕ12.7 (1/2")	49–61
ϕ15.88 (5/8")	68–82



5) Air tightness test

① Although outdoor and indoor units themselves have been tested for air tightness at the factory, check the connecting pipes after the installation work for air tightness from the service valve's check joint equipped on the outdoor unit side. While conducting a test, keep the service valve shut all the time.
a) Raise the pressure to 0.5 MPa, and then stop. Leave it for five minutes to see if the pressure drops.
b) Then raise the pressure to 1.5 MPa, and stop. Leave it for five more minutes to see if the pressure drops.
c) Then raise the pressure to the specified level (4.15 MPa), and record the ambient temperature and the pressure.
d) If no pressure drop is observed with an installation pressurized to the specified level and left for about one day, it is acceptable. When the ambient Temperature fall 1℃, the pressure also fall approximately 0.01 MPa. The pressure, if changed, should be compensated for.
e) If a pressure drop is observed in checking a) – d), a leak exists somewhere. Find a leak by applying bubble test liquid to welded parts and flare joints and repair it. After repair, conduct an air-tightness test again.

② In conducting an air-tightness test, use nitrogen gas and pressurize the system with nitrogen gas from the gas side. Do not use a medium other than nitrogen gas under any circumstances.



6) Evacuation

<Work flow> When the system has remaining moisture inside or a leaky point, the vacuum gauge indicator will rise.
Check the system for a leaky point and then draw air to create a vacuum again.

Run the vacuum pump for at least one hour after the vacuum gauge shows -101kPa or lower. (-755mmHg or lower)
Confirm that the vacuum gauge indicator does not rise even if the system is left for one hour or more.

Airtightness test completed
↓
Vacuuming begins
↓
Vacuuming completed
↓
Vacuum gauge check
↓
Fill refrigerant

Pay attention to the following points in addition to the above for the R32 and compatible machines.
- ○To prevent a different oil from entering, assign dedicated tools, etc. to each refrigerant type. Under no circumstances must a gauge manifold and a charge hose in particular be shared with other refrigerant types (R22, R407C, etc.).
- ○Use a counterflow prevention adapter to prevent vacuum pump oil from entering the refrigerant system.

7) Additional refrigerant charge

(1) Calculate a required refrigerant charge volume from the following table.

<Single type>

Item / Capacity	Additional charge volume (kg) per meter of refrigerant piping (liquid pipe)	Refrigerant volume charged for shipment at the factory (kg)	Installation's pipe length (m) covered without additional refrigerant charge
100VNA–140VNA 100VSA–140VSA	0.054	3.3	30

<Twin, triple type>

Item / Capacity	Additional charge volume (kg) per meter of refrigerant piping (liquid pipe)		Refrigerant volume charged for shipment at the factory (kg)	Installation's pipe length (m) covered without additional refrigerant charge
	Main pipe	Branch pipe		
100VNA–140VNA 100VSA–140VSA	0.054		3.3	30

- This unit contains factory charged refrigerant covering 30m of refrigerant piping and additional refrigerant charge on the installation site is not required for an installation with up to 30m refrigerant piping. When refrigerant piping exceeds 30m, additionally charge an amount calculated from the pipe length and the above table for the portion in excess of 30m.
- If an existing pipe system is used, a required refrigerant charge volume will vary depending on the liquid pipe size. For further information, see "6. UTILIZATION OF EXISTING PIPING."

Formula to calculate the volume of additional refrigerant required

Additional charge volume (kg) = { Main pipe length (m) – Length covered without additional charge 30 (m) } x 0.054 (kg/m) + Total length of branch pipes (m) x 0.054 (kg/m)

*When an additional charge volume calculation result is negative, it is not necessary to charge refrigerant additionally.

(2) Charging refrigerant
- Since R32 refrigerant must be charged in the liquid phase, you should charge it, keeping the container cylinder upside down or using a refrigerant cylinder equipped with a siphon tube.
- Charge refrigerant always from the liquid side service port with the service valve shut. When you find it difficult to charge a required amount, fully open the outdoor unit valves on both liquid and gas sides and charge refrigerant from the gas (suction) side service port, while running the unit in the cooling mode. In doing so, care must be taken so that refrigerant may be discharged from the cylinder in the liquid phase all the time. When the cylinder valve is throttled down or a dedicated conversion tool to change liquid-phase refrigerant into mist is used to protect the compressor, however, adjust charge conditions so that refrigerant will gasify upon entering the unit.
- In charging refrigerant, always charge a calculated volume by using a scale to measure the charge volume.
- When refrigerant is charged with the unit being run, complete a charge operation within 30 minutes. Running the unit with an insufficient quantity of refrigerant for a long time can cause a compressor failure.

NOTE Put down the refrigerant volume calculated from the pipe length onto the caution label attached on the back side of the service panel.

8) Heating and condensation prevention

(1) Dress refrigerant pipes (both gas and liquid pipes) for heat insulation and prevention of dew condensation.
(2) Use a heat insulating material that can withstand 120℃ or a higher temperature. Poor heat insulating capacity can cause heat insulation problems or cable deterioration.
- Improper heat insulation/anti-dew dressing can result in a water leak or dripping causing damage to household effects, etc.
- All gas pipes must be securely heat insulated in order to prevent damage from dripping water that comes from the condensation formed on them during a cooling operation or personal injury from burns because their surface can reach quite a high temperature due to discharged gas flowing inside during a heating operation.
- Wrap indoor units' flare joints with heat insulating parts (pipe cover) for heat insulation (both gas and liquid pipes).
- Give heat insulation to both gas and liquid side pipes. Bundle a heat insulating material and a pipe tightly together so that no gaps may be left between them and wrap them together with a connecting cable by a dressing tape.
- Although it is verified in a test that this air-conditioning unit shows satisfactory performance under JIS condensation test conditions, **both gas and liquid pipes need to be dressed with 20 mm or thicker heat insulation materials above the ceiling where relative humidity exceeds 70%.**





3. DRAIN PIPING WORK

- Execute drain piping by using a drain elbow and drain grommets supplied separately as option parts, where water drained from the outdoor unit is a problem.
- Water may drip where there is a larger amount of drain water. Seal around the drain elbow and drain grommets with putty or adequate caulking material.
- Condensed water may flow out from vicinity of service valve or connected pipes.
- Where you are likely to have several days of sub-zero temperatures in a row, do not use a drain elbow and drain grommets. (There is a risk of drain water freezing inside and blocking the drain.)
- Do not use drain elbow and grommet made of plastic for drain piping when base heater for outdoor unit is used. Plastic grommet and elbow will be damaged and burnt in worst case.
- Prepare another drain tray made of metallic material for collecting drain when base heater is used.



- When condensed water needs to be led to a drain, etc., install the unit on a flat base (supplied separately as an option part) or concrete blocks.
  Then, please secure space for the drain elbow and the drain hose.



4. ELECTRICAL WIRING WORK For details of electrical cabling, refer to the indoor unit installation manual.

Electrical installation work must be performed by an electrical installation service provider qualified by a power provider of the country. Electrical installation work must be executed according to the technical standards and other regulations applicable to electrical installations in the country.
- Do not use any supply cord lighter than one specified in parentheses for each type below.
  - braided cord (code designation 60245 IEC 51),
  - ordinary tough rubber sheathed cord (code designation 60245 IEC 53)
  - flat twin tinsel cord (code designation 60227 IEC 41);

  Do not use anything lighter than polychloroprene sheathed flexible cord (code designation 60245 IEC57) for supply cords of parts of appliances for outdoor use.
- Ground the unit. Do not connect the grounding wire to a gas pipe, water pipe, lightning rod or telephone grounding wire. If improperly grounded, an electric shock or malfunction may result.
- A grounding wire must be connected before connecting the power cable. Provide a grounding wire longer than the power cable.
- The installation of an impulse withstanding type earth leakage breaker is necessary. A failure to install an earth leakage breaker can result in an accident such as an electric shock or a fire.



Model 100VNA –140VNA　　Model 100VSA –140VSA

- Do not turn on the power until the electrical work is completeted .
- Do not use a condensive capacitor for power factor improvement under any circumstances. (It dose not improve power factor, while it can cause an abnormal overheat accident)
- For power source cables, use conduits.
- Do not lay electronic control cables (remote control and signaling wires) and other cables together outside the unit. Laying them together can result in the malfunctioning or a failure of the unit due to electric noises.
- Fasten cables so that may not touch the piping, etc.
- When cables are connected, make sure that all electrical components within the electrical component box are free of loose connector coupling or terminal connection and then attach the cover securely. (Improper cover attachment can result in malfunctioning or a failure of the unit, if water penetrates into the box.)
- Always use a three-core cable for an indoor-outdoor connecting cable. Never use a shield cable.
- Connect a pair bearing a common terminal number with an indoor-outdoor connecting wire.
- In cabling, fasten cables securely with cable clamps so that no external force may work on terminal connections.
- Grounding terminals are provided in the control box.



Main fuse specification

Model	Specification	Part No.
100VNA-140VNA	250V 30A	PCA006A092B
100VSA-140VSA	—	—

Power cable, indoor-outdoor connecting wires
- Always perform grounding system installation work with the power cord unplugged.

⚠ CAUTION Always use an earth leakage circuit breaker designed for inverter circuits to prevent a faulty operation.



Model	Power source	Power cable thickness(mm²)	MAX. over current (A)	Cable length (m)	Grounding wire thickness	Indoor-outdoor wire thickness × number
100VNA–140VNA	Single phase 3 wires 220–240V 50Hz 220V 60Hz	5.5	24	22	φ1.6mm	φ1.6mm x 3
100VSA–140VSA	3 phase 4 wires 380–415V 50Hz 380V 60Hz	3.5	15	46		

●The specifications shown in the above table are for units without heaters. For units with heaters, refer to the installation instructions or the construction instructions of the indoor unit.
●Switchgear or circuit breaker capacity which is calculated from MAX. over current should be chosen along the regulations in each country.

※At the connection with the duct type indoor unit.

Model	Power source	Power cable thickness(mm²)	MAX. over current (A)	Cable length (m)	Grounding wire thickness	Indoor-outdoor wire thickness × number
100VNA,125VNA	Single phase 3 wires 220–240V 50Hz 220V 60Hz	5.5	26	20	φ1.6mm	φ1.6mm x 3
140VNA			27			
100VSA,125VSA	3 phase 4 wires 380–415V 50Hz 380V 60Hz	3.5	17	40		
140VSA			18	38		

(a) Power source cable: Use the cable which is conformed with 60245 IEC57. When selecting the power source cable length, make sure that voltage drop is less than 2%. If the wire length gets longer, increase the wire diameter.
(b) Indoor-Outdoor connecting wires: Use the wires which is conformed with 60245 IEC57.

5. TEST RUN

⚠ WARNING
- Before test run, make sure that the service valves are open.
- Before test run, turn ON power source for 6 hours in order to warm up the compressor. Without this operation, refrigerant may accumulate in the compressor and earth leakage breaker may be activated.
- In case of the first operation after turning on power source, even if the unit does not move for 30 minutes, it is not a breakdown.
- After power is turned off, wait 3 minutes or more before power source is turned ON again.
- Removing the service panel will expose high-voltage live parts and high-temperature parts, which are quite dangerous. Take utmost care not to incur an electric shock or burns. Do not leave the unit with the service panel open.

} A failure to observe these instructions can result in a compressor breakdown.

⚠ CAUTION
- When you operate switches (SW3, SW5) for on-site setting, be careful not to touch a live part.
- You cannot check discharge pressure from the liquid operation valve charge port.
- The 4-way valve (20S) is energized during a heating operation.
- When power source is cut off to reset the unit, give 3 or more minutes before you turn on power again after power is cut off. If this procedure is not observed in turning on power again, "Communication error between outdoor and indoor unit" may occur.

1) Test run method

(1) A test run can be initiated from an outdoor unit by using SW3-3 and SW3-4 for on-site setting.
(2) Switching SW3-3 to ON will start the compressor.
(3) The unit will start a cooling operation, when SW3-4 is OFF, or a heating operation, when SW3-4 is ON.
(4) **Do not fail to switch SW3-3 to OFF when a test run is completed.**

SW-3-3	SW-3-4	
ON	OFF	Cooling during a test run
	ON	Heating during a test run
OFF	–	Normal or After the test operation

2) Checking the state of the unit in operation

Use check joints provided on the piping before and after the four-way valve installed inside the outdoor unit for checking discharge pressure and suction pressure.
As indicated in the table shown on the right, pressure detected at each point will vary depending on whether a cooling or heating operation has been selected.

	Check joint of the pipe	Charge port of the gas service valve
Cooling operation	Discharge pressure (High pressure)	Suction pressure (Low pressure)
Heating operation	Suction pressure (Low pressure)	Discharge pressure (High pressure)

3) Setting SW3-1, SW3-2, SW5-2, SW7-3, on-site

(1) Defrost control switching (SW3-1)
・When this switch is turned ON, the unit will run in the defrost mode more frequently.
・Set this switch to ON, when installed in a region where outdoor temperature falls below zero during the season the unit is run for a heating operation.
(2) Snow guard fan control (SW3-2)
・When this switch is turned ON, the outdoor unit fan will run for 10 seconds in every 10 minutes, when outdoor temperature falls to 3℃ or lower and the compressor is not running.
・When the unit is used in a very snowy country, set this switch to ON.
(3) High height difference operation control (SW5-2)
・Set this switch to ON when outdoor unit is installed at a position higher than indoor unit by 30m or more.
(4) Lower noise silent mode (SW7-3)
・Upper limit of compressor speed and fan speed becomes lower in silent mode

4) Failure diagnosis in a test run

Error indicated on the remote control unit	Printed circuit board LED(The cycles of 5 seconds)		Failure event	Action
	Red LED	Green LED		
E34	Blinking once	Blinking continuously	Open phase	Check power cables for loose contact or disconnection
E40	Blinking once	Blinking continuously	63H1 actuation or operation with service valves shut (occurs mainly during a heating operation)	1. Check whether the service valves are open. 2. If an error has been canceled when 3 minutes have elapsed since a compressor stop, you can restart the unit by effecting Check Reset from the remote control unit.
E49	Blinking once	Blinking continuously	Low pressure error or operation with service valves shut (occurs mainly during a cooling operation)	
E57	Blinking once	Blinking continuously	Short of refrigerant error or operation with service valves shut (occurs mainly during a cooling operation)	

● If an error code other than those listed above is indicated, refer to the wiring diagram of the outdoor unit and the indoor unit.

5) The state of the electronic expansion valve.

The following table illustrates the steady states of the electronic expansion valve.

	When power is turned on	When the unit comes to a normal stop		When the unit comes to an abnormal stop	
		During a cooling operation	During a heating operation	During a cooling operation	During a heating operation
Valve for a cooling operation	Complete shut position	Complete shut position	Full open position	Full open position	Full open position
Valve for a heating operation	Full open position	Full open position	Complete shut position	Full open position	Full open position

6) Heed the following on the first operation after turning on the circuit breaker.

This outdoor unit may start in the standby mode (waiting for a compressor startup), which can continue up to 30 minutes, to prevent the oil level in the compressor from lowering on the first operation after turning on the circuit breaker. If that is the case, do not suspect a unit failure.

Items to check before a test run

● When you leave the outdoor unit with power supplied to it, be sure to close the panel.

Item No.used in the installation manual	Item	Check item	Check
2	Refrigerant plumbing	If brazed, was it brazed under a nitrogen gas flow?	
		Were air-tightness test and vacuum extraction surely performed?	
		Are heat insulation materials installed on both liquid and gas pipes?	
		Are service valves surely opened for both liquid and gas systems?	
		Have you recorded the additional refrigerant charge volume and refrigerant pipe length on the panel's label?	
4	Electric wiring	Is the unit free of cabling errors such as uncompleted connection, an absent or reversed phase?	
		Are properly rated electrical equipments used for circuit breakers and cables?	
		Doesn't cabling cross-connect between units, where more than one unit are installed?	
		Aren't indoor-outdoor signal wires connected to remote control wires?	
		Do indoor-outdoor connecting cables connect between the same terminal numbers?	
		Are either VCT cabtyre cables or WF flat cables used for indoor-outdoor connecting cables?	
		Does grounding satisfy the D type grounding (type III grounding) requirements?	
		Is the unit grounded with a dedicated grounding wire not connected to another unit's grounding wire?	
		Are cables free of loose screws at their connection points?	
		Are cables held down with cable clamps so that no external force works onto terminal connections?	
–	Indoor unit	Is indoor unit installation work completed?	
		Where a face cover should be attached onto an indoor unit, is the face cover attached to the indoor unit?	

Test run procedure

● Always carry out a test run and check the following in order as listed.

Turn	The contents of operation	Check
①	Open the gas side service valve fully.	
②	Open the liquid side service valve fully.	
③	Close the panel.	
④	Where a remote control unit is used for unit setup on the installation site, follow instructions for unit setup on the installation site with a remote control unit.	
⑤	SW3-3 ON / SW3-4 OFF: the unit will start a cooling operation.	
	SW3-3 ON / SW3-4 ON: the unit will start a heating operation.	
⑥	When the unit starts operation, press the wind direction button provided on the remote control unit to check its operation.	
⑦	Place your hand before the indoor unit's diffuser to check whether cold (warm) winds come out in a cooling (heating) operation.	
⑧	Make sure that a red LED is not blinking.	
⑨	When you complete the test run, do not forget to turn SW3-3 to the OFF position.	
⑩	Where options are used, check their operation according to the respective instruction manuals.	



Models 100VNA – 140VNA


Models 100VSA – 140VSA

6. UTILIZATION OF EXISTING PIPING

Check whether an existing pipe system is reusable or not by using the following flow chart.



⚠ WARNING <Where the existing unit can be run for a cooling operation.>

Carry out the following steps with the existing unit (in the order of (1), (2), (3) and (4))
(1) Run the unit for 30 minutes for a cooling operation.
(2) Stop the indoor fan and run the unit for 3 minutes for a cooling operation (returning liquid)
(3) Close the liquid side service valve of the outdoor unit and pump down (refrigerant recovery)
(4) Blow with nitrogen gas. ※ If discolored refrigeration oil or any foreign matters is discharged by the blow, wash the pipe system or install a new pipe system.
● For the flare nut, do not use the old one, but use the one supplied with the outdoor unit. Process a flare to the dimensions specified for R32.
● **Turn on-site setting switch SW5-1** to the ON position. (Where the gas pipe size is φ19.05)

<Where the existing unit cannot be run for a cooling operation.>
Wash the pipe system or install a new pipe system.
● If you choose to wash the pipe system, contact our distributor in the area.

<Table of pipe size restrictions>
◎:Standard pipe size ○:Applicable
△:Restricted to shorter pipe length limits ×:Not applicable

Additional charging amount of refrigerant per 1m		0.054kg/m		0.11kg/m	
Pipe size	Liquid pipe	φ9.52	φ9.52	φ12.7	φ12.7
	Gas pipe	φ15.88	φ19.05	φ15.88	φ19.05
100V	Usability	◎	○※1	△	△※1
	Maximum one-way pipe length	50	50	25	25
	Length covered without additional charge	30	30	15	15
125V	Usability	◎	○※1	△	△※1
	Maximum one-way pipe length	50	50	25	25
	Length covered without additional charge	30	30	15	15
140V	Usability	◎	○※1	△	△※1
	Maximum one-way pipe length	50	50	25	25
	Length covered without additional charge	30	30	15	15

<Pipe system after the branching pipe>

			After 1st branch ※4			After 2nd branch		
Additional charging amount of refrigerant per 1m			0.054kg/m			0.054kg/m		
Pipe size	Liquid pipe		φ9.52			φ9.52		
	Gas pipe		φ12.7	φ15.88	φ19.05※1	φ12.7	φ15.88	φ19.05※1
Model	Combination type	Combination of capacity						
100V	Twin	50+50	◎	○	×	–	–	–
125V	Twin	60+60	◎	○	×	–	–	–
	Twin	71+71	×	◎	○	–	–	–
140V	Triple A	50+50+50	○	○	×	–	–	–
	Triple B	50+50+50	×	◎※5	○※5	◎	○	×

※1 Because of its insufficient pressure resistance, **turn the DIP switch SW5-1** provided on the outdoor unit board to the ON position for φ19.05 × t1.0. (In the case of a twin-triple-double-twin model, this also applies to the case where φ19.05 × t1.0 is used in a pipe system after the first branching point.) However, you need not turn the DIP switch SW5-1 to the ON position, if 1/2H pipes or pipes having 1.2 or thicker walls are used.
※2 When the main pipe length exceeds 40m, a significant capacity drop may be experienced due to pressure loss in the liquid pipe system. Use φ12.7 for the liquid main.
※3 Keep the total pipe length, not one-way pipe length, below the specified maximum pipe length.
※4 Piping size after branch should be equal or smaller than main pipe size.
※5 Piping size from first branch to indoor unit should be φ9.52 (Liquid) / φ12.7 (Gas).
● Any combinations of pipe sizes not listed in the table or marked with × in the table are not usable.
● Do not reuse existing flare.

<The model types of existing units of which branching pipes are reusable.>
Models later than Type 8.
● F D C ＊ ＊ ＊ 8 □ □ □
● F D C P ＊ ＊ ＊ 8 □ □ □

The branching pipes used with models other than those listed above are not reusable because of their insufficient pressure resistance. Please use our genuine branching pipes for R32.

● ＊ ＊ ＊ are numbers representing horsepower. □□□ is an alphanumeric letter.

Formula to calculate additional charge volume

Additional charge volume (kg) = {Main pipe length (m) – Length covered without additional charge shown in the table (m)} × Additional charge volume per meter of pipe shown in the table (kg/m) + Total length of branch pipes (m)× Additional charge volume per meter of pipe shown in the table (kg/m)

※ If you obtain a negative figure as a result of calculation, no additional refrigerant needs to be charged.
Example) When an 140V (single installation) is installed in a 20m long existing pipe system (liquid φ12.7, gas φ19.05), the quantity of refrigerant to charge additionally should be (20m-15m) x 0.11kg/m = 0.55 kg.

1.10.5 Instructions for branching pipe set (DIS-WA1, WB1, TA1, TB1)

PSB012D865

⚠ WARNING / CAUTION

- This set is for R410A and R32 refrigerant.
- Select a branching pipe set correctly rated for the combined total capacity of connected indoor units and install it according to this manual. An improperly installed branching pipe set can cause degraded performance or an abnormal unit stop.
- Provide good heat insulation to the pipes by following instructions contained in this manual. Improper heat insulation can result in degraded performance or a water leak accident from condensation.
- Please make sure that only parts supplied as accessories or the manufacturer's approved parts are used in installing the unit, because a leak of refrigerant can result in a lack-of-oxygen accident, if it reaches a concentration beyond the tolerable limit.

This manual explains how to use a branching pipe set that is indispensable in connecting pipes for a twin/triple/double-twin configuration installation (system). For the details of piping work, unit installation work and electrical installation work, please refer to the installation manuals and installation guides supplied with your outdoor and indoor units.

1. Branching pipe set specifications

(1) Please make sure that you have chosen the right branching pipe set and the specifications of the parts contained in it by checking with the table below.
(2) Connect pipes as illustrated in the table below. The pipe from an outdoor unit must be brazed to the pipe connection port "①" and the pipes from indoor units to "②," "③" and "④."

Branching pipe set type	Supported outdoor/indoor unit combinations		Part lists			
	Outdoor unit model	Indoor unit model	Branching pipe set for a liquid pipe	Branching pipe set for a gas pipe	Different diameter pipe joint	Heat insulation material
DIS-WA1 (Two-way branching set)	3HP	1.5HP＋1.5HP	ID9.52 ① ② ③ ID9.52 ID9.52 1 piece	ID15.88 ① ② ③ ID15.88 ID15.88 1 piece	Joint A ID9.52 2 pieces Flare joint (for indoor unit side connection) Joint B OD15.88 2 pieces ID12.7	One each for liquid and gas
	4HP	2HP＋2HP				
		1.5HP＋2.5HP				
	5HP	2.5HP＋2.5HP				
		2HP＋3HP				
	6HP	3HP＋3HP				
		2HP＋4HP				
DIS-WB1 (Two-way branching set)	8HP	4HP＋4HP	ID9.52 ① ② ③ ID12.7 ID9.52 1 piece	ID15.88 ① ② ③ ID25.4 ID15.88 1 piece	Joint C OD12.7 1 piece ID9.52	One each for liquid and gas
		3HP＋5HP				
	10HP	5HP＋5HP				
DIS-TA1 (Three-way branching set)	6HP	2HP＋2HP＋2HP	ID9.52 ① ② ③ ④ ID9.52 1 piece	ID12.7 ① ② ③ ④ ID15.88 1 piece	Joint A ID9.52 3 pieces Flare joint (for indoor unit side connection)	One each for liquid and gas
DIS-TB1 (Three-way branching set)	8HP	3HP＋3HP＋3HP	ID9.52 ① ② ③ ④ ID9.52 1 piece	ID15.88 ① ② ③ ④ ID25.4 1 piece	Joint A ID9.52 2 pieces Flare joint (for indoor unit side connection) Joint B OD15.88 1 piece ID12.7 Joint D ID12.7 1 piece OD9.52	One each for liquid and gas

(3) To connect pipes for a Double Twin installation (involving 4 indoor units), please see 2-7. "Double Twin configuration."
(4) A branching pipe set must always be installed into the posture as illustrated in the drawing below.

ID stands for inner diameter and OD, outer diameter.

＜Posture to install into＞

Two-way branching



Three-way branching



2. Pipe connecting procedure

Braze the different diameter pipe joint found in the set matching the connected outdoor and indoor unit capacities according to the instructions set out below.

⚠ CAUTION

In connecting an indoor unit of which capacity is 1.5HP, 2HP or 2.5HP, always use a ϕ9.52 liquid pipe to connect to the branching pipe (branching pipe – indoor unit).
In connecting to an indoor unit (liquid pipe side: ϕ6.35), use the different diameter pipe joint A supplied with the set and follow the procedure set out below.



2-1 DIS-WA1

Supported combinations		Liquid branching pipe	Gas branching pipe
Outdoor unit model	Indoor unit model		
3HP	1.5HP+1.5HP		
4HP	2HP+2HP		
	1.5HP+2.5HP		
5HP	2.5HP+2.5HP		
	2HP+3HP		
6HP	3HP+3HP		
	2HP+4HP		

Note When connect the indoor unit of an old model that is shown in the model list, use the joint supplied with the branch piping set like ※A

2-2 DIS-WB1

Supported combinations		Liquid branching pipe	Gas branching pipe
Outdoor unit model	Indoor unit model		
8HP	3HP+5HP		
	4HP+4HP		
10HP	5HP+5HP		

2-3 DIS-TA1

Applicable to the difference in length of pipes after the branch being less than 3m
* Connection is not allowed when the difference in length of pipes is larger than 3m.

Supported combinations		Liquid branching pipe	Gas branching pipe
Outdoor unit model	Indoor unit model		
6HP	2HP+2HP+2HP		

2-4 DIS-TB1

Applicable to the difference in length of pipes after the branch being less than 3 m
* Connection is not allowed when the difference in length of pipes is larger than 3 m.

Supported combinations		Liquid branching pipe	Gas branching pipe
Outdoor unit model	Indoor unit model		
8HP	3HP+3HP+3HP		

2-5. Triple type for same model/same capacity or different model/same capacity

When the difference in length of pipes after the branch is longer than 3m and shorter than 10m



Outdoor unit model	Indoor unit model	Branching pipe	Branching pipe set type	Liquid branching pipe	Gas branching pipe
6HP	2HP+2HP+2HP	a	DIS-WA1		
		b			
8HP	3HP+3HP+3HP	a	DIS-WB1		
		b	DIS-WA1		

2-6. Triple type for same model/different capacity or different model/different capacity

Applicable to the difference in length of pipes after the branch being less than 3m

* Connection is not allowed when the difference in length of pipes is larger than 3m.



Connecting position

Outdoor unit model	Indoor unit model	A	B	C
10HP	2.5HP+2.5HP+5HP	5HP	2.5HP	2.5HP
	3HP+3HP+4HP	4HP	3HP	3HP

Outdoor unit model	Indoor unit model	Branching pipe	Branching pipe set type	Liquid branching pipe	Gas branching pipe
10HP	2.5HP+2.5HP+5HP	a	DIS-WB1	ID9.52 ② / ① ID12.7 / ③ ID9.52	ID15.88 ② / ① ID25.4 / ③ ID15.88
		b	DIS-WA1	Flare joint (φ6.35) Joint A / Connecting pipe (φ9.52) / ② ID9.52 ③ ① / ⚠ CAUTION Reference / Joint A Flare joint (φ6.35)	ID12.7 Joint B ② ① ID15.88 ③ Joint B ID12.7 / ※A: ID15.88 ② ① ID15.88 ③ ID15.88
10HP	3HP+3HP+4HP	a	DIS-WB1	ID9.52 ② / ① ID12.7 / ③ ID9.52	ID15.88 ② / ① ID25.4 / ③ ID15.88
		b	DIS-WA1	ID9.52 ② / ① ID9.52 / ③ ID9.52	ID15.88 ② / ① ID15.88 / ③ ID15.88

Note When connect the indoor unit of an old model that is shown in the model list, use the joint supplied with the branch piping set like※ A.

2-7. Double Twin type

Pipes should be connected as follows for a Double Twin installation (4 connected indoor units. The capacity of an outdoor unit available for this configuration is either 8HP or 10HP only):

Outdoor unit capacity	Indoor unit capacity
8HP	2HP×4 units
10HP	2.5HP×4 units



Branching pipe	Branching pipe set type	Outdoor unit model	Liquid branching pipe	Gas branching pipe
a	DIS-WB1	8HP	ID9.52 ② / ① ID9.52 / Joint C / ③ ID9.52	ID15.88 ② / ① ID25.4 / ③ ID15.88
		10HP	ID9.52 ② / ① ID12.7 / ③ ID9.52	
b	DIS-WA1	8HP	Flare joint (φ6.35) Joint A / Connecting pipe (φ9.52) / ② ID9.52 ③ ① / ⚠ CAUTION Reference / Joint A Flare joint (φ6.35)	ID12.7 Joint B ② ① ID15.88 ③ Joint B ID12.7
		10HP		※A: ID15.88 ② ① ID15.88 ③ ID15.88 / ID12.7 Joint B ② ① ID15.88 ③ Joint B ID12.7

Note When connect the indoor unit of an old model that is shown in the model list, use the joint supplied with the branch piping set like※ A.

3. Heat insulation work

(1) Condensation can also occur on liquid pipes with this model. Please provide good heat insulation to both liquid and gas pipes.

(2) For the heat insulation of a branching pipe, always use the heat insulation material supplied with the set and provide heat insulation according to the instructions set out below.



1. It has an adhesive layer on the entire inner face. Remove a separator and wrap it around the branching pipe.



2. Apply a heat insulation material (to be procured locally) to the joint between the branching pipe's heat insulation and the heat insulation material covering the installation's piping as described above and wrap a tape over the gap shown as a hatched (///) area to complete dressing of the piping.

1.10.6 Safety precautions in handling air-conditioners with flammable refrigerants

PSA012B839A B

R32 REFRIGERANT USED

	This equipment uses flammable refrigerants. If the refrigerant is leaked, together with an external ignition source, there is a possibility of ignition.		There is information included in the user's manual and/or installation manual.
	The user's manual should be read carefully.		A service personnel should be handing this equipment with reference to the installation manual.

- This safety precaution sheet is for R32 refrigerant. If you want to know the type of refrigerant in the unit, check the label attached to the outdoor unit.
- The precautionary items mentioned below are distinguished into two levels, ⚠ WARNING and ⚠ CAUTION.

⚠ WARNING : Wrong installation would cause serious consequences such as injuries or death.

⚠ CAUTION : Wrong installation might cause serious consequences depending on circumstances.

⚠ WARNING

- Strict compliance of the domestic laws must be observed when disposing the appliance.
- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater.
- Do not pierce or burn.
- Be aware that refrigerants may not contain an odour.

⚠ CAUTION

1. General
- That the installation of pipe-work shall be kept to a minimum.
- That pipe-work shall be protected from physical damage.
- That compliance with national gas regulations shall be observed.
- That mechanical connections shall be accessible for maintenance purposes.
- Keep any required ventilation openings clear of obstruction.
- Servicing shall be performed only as recommended by the manufacturer.

2. Unventilated areas
- The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.

3. Qualification of workers
- The staff in servicing operations must hold the national qualification or other relevant qualifications.

4. Information on servicing

4.1 Checks to the area
- Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimised.
- For repair to the refrigerating system, 4.3 to 4.7 shall be completed prior to conducting work on the system.

4.2 Work procedure
- Work shall be undertaken under a controlled procedure so as to minimise the risk of a flammable gas or vapour being present while the work is being performed.

4.3 General work area
- All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out.
- Work in confined spaces shall be avoided.
- The area around the workspace shall be sectioned off.
- Ensure that the conditions within the area have been made safe by control of flammable material.

4.4 Checking for presence of refrigerant
- The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres.
- Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe.

4.5 Presence of fire extinguisher
- If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO_2 fire extinguisher adjacent to the charging area.

4.6 No ignition sources
- No person carrying out work in relation to a refrigeration system which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion.
- All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space.
- Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks.
- "No Smoking" signs shall be displayed.

4.7 Ventilated area
- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work.
- A degree of ventilation shall continue during the period that the work is carried out.
- The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

4.8 Checks to the refrigeration equipment
- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification.
- At all times the manufacturer's maintenance and service guidelines shall be followed.
- If in doubt consult the manufacturer's technical department for assistance.
- The following checks shall be applied to installations using flammable refrigerants:
  – the charge size is in accordance with the room size within which the refrigerant containing parts are installed;
  – the ventilation machinery and outlets are operating adequately and are not obstructed;
  – if an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant;
  – marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
  – refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

4.9 Checks to electrical devices
- Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures.
- If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with.
- If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used.
- This shall be reported to the owner of the equipment so all parties are advised.
- Initial safety checks shall include:
  – that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
  – that no live electrical components and wiring are exposed while charging, recovering or purging the system;
  – that there is continuity of earth bonding.

5. Repairs to sealed components
- During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc.
- If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.
- Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected.
  This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.
- Ensure that the apparatus is mounted securely.
- Ensure that seals or sealing materials have not degraded to the point that they no longer serve the purpose of preventing the ingress of flammable atmospheres.
- Replacement parts shall be in accordance with the manufacturer's specifications.

NOTE
The use of silicon sealant can inhibit the effectiveness of some types of leak detection equipment.
Intrinsically safe components do not have to be isolated prior to working on them.

⚠ CAUTION

6. Repair to intrinsically safe components

- Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.
- Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere.
- The test apparatus shall be at the correct rating.
- Replace components only with parts specified by the manufacturer.
- Other parts may result in the ignition of refrigerant in the atmosphere from a leak.

7. Cabling

- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

8. Detection of flammable refrigerants

- Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks.
- A halide torch (or any other detector using a naked flame) shall not be used.

9. Leak detection methods

- Electronic leak detectors may be used to detect refrigerant leaks but, in the case of flammable refrigerants, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.)
- Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used.
- Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed.
- Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.
- If a leak is suspected, all naked flames shall be removed/extinguished.
- If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak.
- For appliances containing flammable refrigerants, oxygen free nitrogen (OFN) shall then be purged through the system both before and during the brazing process.

10. Removal and evacuation

- When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants it is important that best practice is followed since flammability is a consideration.
- The following procedure shall be adhered to:
  – remove refrigerant;
  – purge the circuit with inert gas;
  – evacuate;
  – purge again with inert gas;
  – open the circuit by cutting or brazing.
- The refrigerant charge shall be recovered into the correct recovery cylinders.
- For appliances containing flammable refrigerants, the system shall be “flushed” with OFN to render the unit safe.
  This process may need to be repeated several times.
- Compressed air or oxygen shall not be used for purging refrigerant systems.
- For appliances containing flammable refrigerants, flushing shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be repeated until no refrigerant is within the system.
- When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.
  This operation is absolutely vital if brazing operations on the pipe-work are to take place.
- Ensure that the outlet for the vacuum pump is not close to any ignition sources and that ventilation is available.

11. Charging procedures

- In addition to conventional charging procedures, the following requirements shall be followed.
  – Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimise the amount of refrigerant contained in them.
  – Cylinders shall be kept upright.
  – Ensure that the refrigeration system is earthed prior to charging the system with refrigerant.
  – Label the system when charging is complete (if not already).
  – Extreme care shall be taken not to overfill the refrigeration system.
- Prior to recharging the system, it shall be pressure-tested with the appropriate purging gas.
- The system shall be leak-tested on completion of charging but prior to commissioning.
- A follow up leak test shall be carried out prior to leaving the site.

12. Decommissioning

- Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail.
- It is recommended good practice that all refrigerants are recovered safely.
- Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of reclaimed refrigerant.
- It is essential that electrical power is available before the task is commenced.

a) Become familiar with the equipment and its operation.
b) Isolate system electrically.
c) Before attempting the procedure ensure that:
  – mechanical handling equipment is available, if required, for handling refrigerant cylinders;
  – all personal protective equipment is available and being used correctly;
  – the recovery process is supervised at all times by a competent person;
  – recovery equipment and cylinders conform to the appropriate standards.
d) Pump down refrigerant system, if possible.
e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
f) Make sure that cylinder is situated on the scales before recovery takes place.
g) Start the recovery machine and operate in accordance with manufacturer’s instructions.
h) Do not overfill cylinders. (No more than 80 % volume liquid charge).
i) Do not exceed the maximum working pressure of the cylinder, even temporarily.
j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
k) Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

13. Labelling

- Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed.
- For appliances containing flammable refrigerants, ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

14. Recovery

- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed.
- Ensure that the correct number of cylinders for holding the total system charge are available.
- All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant).
- Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order.
- Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, flammable refrigerants.
- In addition, a set of calibrated weighing scales shall be available and in good working order.
- Hoses shall be complete with leak-free disconnect couplings and in good condition.
- Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release.
  Consult manufacturer if in doubt.
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste Transfer Note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant.
- The evacuation process shall be carried out prior to returning the compressor to the suppliers.
- Only electric heating to the compressor body shall be employed to accelerate this process.
- When oil is drained from a system, it shall be carried out safely.

15. Other safety precautions

- A brazed, welded, or mechanical connection shall be made before opening the valves to permit refrigerant to flow between the refrigerating system parts.
- Flammable refrigerant used, refrigerant tubing protected or enclosed to avoid mechanical damage (IEC/EN 60335-2-40/A1).
- Tubing protected to extent that it will not be handled or used for carrying during moving of product (IEC/EN 60335-2-40/A1).
- Flammable refrigerant used, low temperature solder alloys, such as lead/tin alloys, not acceptable for pipe connections (IEC/EN 60335-2-40/A1).
- Do not use flare nut indoor which is locally procured.

Selection of installation location for the indoor unit

● Minimum installation area for indoor unit

⚠ CAUTION

The indoor unit shall be installed in a room with minimum installation area or more according to the refrigerant charge amount (factory refrigerant charge +additional refrigerant charge).
For factory refrigerant charge, refer to the outdoor unit label model name or installation sheet.
For additional refrigerant charge, refer to the outdoor unit installation sheet.

Ceiling mounted type	FDT,FDE,FDU,FDUM series
Wall mounted type	SRK series

Refrigerant charge amount [kg]		1.30	1.50	1.75	2.00	2.25	2.50	2.75	3.00	3.25	3.50	3.75	4.00	4.25	4.50	4.75
minimum installation area [m²]	Ceiling mounted type	1.1	1.4	2.0	2.6	3.2	4.0	4.8	5.7	6.7	7.8	9.0	10.2	11.5	12.9	14.4
	Wall mounted type	1.6	2.1	2.9	3.8	4.8	6.0	7.2	8.6	10.1	11.7	13.4	15.3	17.2	19.3	21.5

Refrigerant charge amount [kg]		5.0	5.5	6.0	6.5	7.0	7.5	8.0	8.5	9.0	9.5	10.0	10.5	11.0	11.5	12.0
minimum installation area [m²]	Ceiling mounted type	16	19	23	27	31	36	41	46	52	58	64	70	77	84	92
	Wall mounted type	24	29	34	40	47	54	61	69	77	86	95	105	115	126	137



The minimum floor area [m²] is determined based on the installation height of 1.8m for wall mounted type and 2.2m for ceiling mounted type.

● Ceiling opening area

⚠ CAUTION

In case of installing the indoor unit in an enclosed ceiling space, ensure there is a sufficient ventilation opening around the unit.
In the event of refrigerant leakage, this countermeasure would prevent an increased concentration of refrigerant.

1.11 TECHNICAL INFORMATION

(1) Ceiling cassette-4 way type (FDT)

FDT100VNAWVH

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	FDT100VH
Outdoor unit model name	FDC100VNA-W

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Function(indicate if present)		Average(mandatory)	Yes
cooling	Yes	Warmer(if designated)	No
heating	Yes	Colder(if designated)	No

Item	symbol	value	unit
Design load			
cooling	Pdesignc	10.0	kW
heating / Average	Pdesignh	8.50	kW
heating / Warmer	Pdesignh	-	kW
heating / Colder	Pdesignh	-	kW

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	7.13	A++
heating / Average	SCOP/A	4.60	A++
heating / Warmer	SCOP/W	-	-
heating / Colder	SCOP/C	-	-

Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	8.50	kW
heating / Warmer (2℃)	Pdh	-	kW
heating / Colder (-22℃)	Pdh	-	kW

Back up heating capacity at outdoor temperature Tdesignh			unit
heating / Average (-10℃)	elbu	0	kW
heating / Warmer (2℃)	elbu	-	kW
heating / Colder (-22℃)	elbu	-	kW

Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	10.00	kW
Tj=30℃	Pdc	7.37	kW
Tj=25℃	Pdc	4.74	kW
Tj=20℃	Pdc	3.10	kW

Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	3.66	-
Tj=30℃	EERd	5.71	-
Tj=25℃	EERd	9.24	-
Tj=20℃	EERd	11.64	-

Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	7.40	kW
Tj=2℃	Pdh	4.50	kW
Tj=7℃	Pdh	2.90	kW
Tj=12℃	Pdh	2.90	kW
Tj=bivalent temperature	Pdh	8.50	kW
Tj=operating limit	Pdh	6.30	kW

Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	3.26	-
Tj=2℃	COPd	4.43	-
Tj=7℃	COPd	5.78	-
Tj=12℃	COPd	7.19	-
Tj=bivalent temperature	COPd	2.96	-
Tj=operating limit	COPd	2.25	-

Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	-	kW
Tj=7℃	Pdh	-	kW
Tj=12℃	Pdh	-	kW
Tj=bivalent temperature	Pdh	-	kW
Tj=operating limit	Pdh	-	kW

Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	-	-
Tj=7℃	COPd	-	-
Tj=12℃	COPd	-	-
Tj=bivalent temperature	COPd	-	-
Tj=operating limit	COPd	-	-

Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	-	kW
Tj=2℃	Pdh	-	kW
Tj=7℃	Pdh	-	kW
Tj=12℃	Pdh	-	kW
Tj=bivalent temperature	Pdh	-	kW
Tj=operating limit	Pdh	-	kW
Tj=-15℃	Pdh	-	kW

Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	-	-
Tj=2℃	COPd	-	-
Tj=7℃	COPd	-	-
Tj=12℃	COPd	-	-
Tj=bivalent temperature	COPd	-	-
Tj=operating limit	COPd	-	-
Tj=-15℃	COPd	-	-

Bivalent temperature			
heating / Average	Tbiv	-10	℃
heating / Warmer	Tbiv	-	℃
heating / Colder	Tbiv	-	℃

Operating limit temperature			
heating / Average	Tol	-20	℃
heating / Warmer	Tol	-	℃
heating / Colder	Tol	-	℃

Cycling interval capacity			
for cooling	Pcycc	-	kW
for heating	Pcych	-	kW

Cycling interval efficiency			
for cooling	EERcyc	-	-
for heating	COPcyc	-	-

Degradation coefficient			
cooling	Cdc	0.25	-

Degradation coefficient			
heating	Cdh	0.25	-

Electric power input in power modes other than 'active mode'			
off mode	Poff	7	W
standby mode	Psb	7	W
thermostat-off mode	Pto(cooling)	22	W
	Pto(heating)	34	W
crankcase heater mode	Pck	5	W

Annual electricity consumption			
cooling	Qce	491	kWh/a
heating / Average	Qhe	2590	kWh/a
heating / Warmer	Qhe	-	kWh/a
heating / colder	Qhe	-	kWh/a

Capacity control(indicate one of three options)	
fixed	No
staged	No
variable	Yes

Other items			
Sound power level(indoor)	Lwa	62	dB(A)
Sound power level(outdoor)	Lwa	69	dB(A)
Global warming potential	GWP	675	$kgCO_2eq.$
Rated air flow(indoor)	-	2220	m^3/h
Rated air flow(outdoor)	-	4500	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex,UB11 1ET, United kingdom

PJF000Z589 B

FDT100VSAWVH

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	FDT100VH
Outdoor unit model name	FDC100VSA-W

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Function(indicate if present)			
cooling	Yes	Average(mandatory)	Yes
heating	Yes	Warmer(if designated)	No
		Colder(if designated)	No

Item	symbol	value	unit
Design load			
cooling	Pdesignc	10.0	kW
heating / Average	Pdesignh	8.50	kW
heating / Warmer	Pdesignh	-	kW
heating / Colder	Pdesignh	-	kW
Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	8.50	kW
heating / Warmer (2℃)	Pdh	-	kW
heating / Colder (-22℃)	Pdh	-	kW
Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	10.00	kW
Tj=30℃	Pdc	7.37	kW
Tj=25℃	Pdc	4.74	kW
Tj=20℃	Pdc	3.10	kW
Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	7.40	kW
Tj=2℃	Pdh	4.50	kW
Tj=7℃	Pdh	2.90	kW
Tj=12℃	Pdh	2.90	kW
Tj=bivalent temperature	Pdh	8.50	kW
Tj=operating limit	Pdh	6.30	kW
Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	-	kW
Tj=7℃	Pdh	-	kW
Tj=12℃	Pdh	-	kW
Tj=bivalent temperature	Pdh	-	kW
Tj=operating limit	Pdh	-	kW
Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	-	kW
Tj=2℃	Pdh	-	kW
Tj=7℃	Pdh	-	kW
Tj=12℃	Pdh	-	kW
Tj=bivalent temperature	Pdh	-	kW
Tj=operating limit	Pdh	-	kW
Tj=-15℃	Pdh	-	kW
Bivalent temperature			
heating / Average	Tbiv	-10	℃
heating / Warmer	Tbiv	-	℃
heating / Colder	Tbiv	-	℃
Cycling interval capacity			
for cooling	Pcycc	-	kW
for heating	Pcych	-	kW
Degradation coefficient			
cooling	Cdc	0.25	-
Electric power input in power modes other than 'active mode'			
off mode	Poff	7	W
standby mode	Psb	7	W
thermostat-off mode	Pto(cooling)	22	W
	Pto(heating)	34	W
crankcase heater mode	Pck	5	W
Capacity control(indicate one of three options)			
fixed		No	
staged		No	
variable		Yes	

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	7.13	A++
heating / Average	SCOP/A	4.60	A++
heating / Warmer	SCOP/W	-	-
heating / Colder	SCOP/C	-	-

Item	symbol	value	unit
Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	elbu	0	kW
heating / Warmer (2℃)	elbu	-	kW
heating / Colder (-22℃)	elbu	-	kW
Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	3.66	-
Tj=30℃	EERd	5.71	-
Tj=25℃	EERd	9.24	-
Tj=20℃	EERd	11.64	-
Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	3.26	-
Tj=2℃	COPd	4.43	-
Tj=7℃	COPd	5.78	-
Tj=12℃	COPd	7.19	-
Tj=bivalent temperature	COPd	2.96	-
Tj=operating limit	COPd	2.25	-
Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	-	-
Tj=7℃	COPd	-	-
Tj=12℃	COPd	-	-
Tj=bivalent temperature	COPd	-	-
Tj=operating limit	COPd	-	-
Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	-	-
Tj=2℃	COPd	-	-
Tj=7℃	COPd	-	-
Tj=12℃	COPd	-	-
Tj=bivalent temperature	COPd	-	-
Tj=operating limit	COPd	-	-
Tj=-15℃	COPd	-	-
Operating limit temperature			
heating / Average	Tol	-20	℃
heating / Warmer	Tol	-	℃
heating / Colder	Tol	-	℃
Cycling interval efficiency			
for cooling	EERcyc	-	-
for heating	COPcyc	-	-
Degradation coefficient			
heating	Cdh	0.25	-
Annual electricity consumption			
cooling	Qce	491	kWh/a
heating / Average	Qhe	2590	kWh/a
heating / Warmer	Qhe	-	kWh/a
heating / colder	Qhe	-	kWh/a
Other items			
Sound power level(indoor)	Lwa	62	dB(A)
Sound power level(outdoor)	Lwa	69	dB(A)
Global warming potential	GWP	675	$kgCO_2eq.$
Rated air flow(indoor)	-	2220	m^3/h
Rated air flow(outdoor)	-	4500	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex,UB11 1ET, United kingdom

PJF000Z589 B

FDT100VNAWPVH

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	FDT50VH (x2 units)
Outdoor unit model name	FDC100VNA-W

Function(indicate if present)	
cooling	Yes
heating	Yes

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Average(mandatory)	Yes
Warmer(if designated)	No
Colder(if designated)	No

Item	symbol	value	unit
Design load			
cooling	Pdesignc	10.0	kW
heating / Average	Pdesignh	8.50	kW
heating / Warmer	Pdesignh	-	kW
heating / Colder	Pdesignh	-	kW
Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	8.50	kW
heating / Warmer (2℃)	Pdh	-	kW
heating / Colder (-22℃)	Pdh	-	kW
Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	10.00	kW
Tj=30℃	Pdc	7.37	kW
Tj=25℃	Pdc	4.74	kW
Tj=20℃	Pdc	3.49	kW
Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	7.40	kW
Tj=2℃	Pdh	4.50	kW
Tj=7℃	Pdh	2.90	kW
Tj=12℃	Pdh	2.82	kW
Tj=bivalent temperature	Pdh	8.50	kW
Tj=operating limit	Pdh	6.30	kW
Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	-	kW
Tj=7℃	Pdh	-	kW
Tj=12℃	Pdh	-	kW
Tj=bivalent temperature	Pdh	-	kW
Tj=operating limit	Pdh	-	kW
Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	-	kW
Tj=2℃	Pdh	-	kW
Tj=7℃	Pdh	-	kW
Tj=12℃	Pdh	-	kW
Tj=bivalent temperature	Pdh	-	kW
Tj=operating limit	Pdh	-	kW
Tj=-15℃	Pdh	-	kW
Bivalent temperature			
heating / Average	Tbiv	-10	℃
heating / Warmer	Tbiv	-	℃
heating / Colder	Tbiv	-	℃
Cycling interval capacity			
for cooling	Pcycc	-	kW
for heating	Pcych	-	kW
Degradation coefficient			
cooling	Cdc	0.25	-
Electric power input in power modes other than 'active mode'			
off mode	Poff	10	W
standby mode	Psb	10	W
thermostat-off mode	Pto(cooling)	15	W
	Pto(heating)	30	W
crankcase heater mode	Pck	5	W
Capacity control(indicate one of three options)			
fixed		No	
staged		No	
variable		Yes	

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	7.41	A++
heating / Average	SCOP/A	4.47	A+
heating / Warmer	SCOP/W	-	-
heating / Colder	SCOP/C	-	-
			unit
Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	elbu	0	kW
heating / Warmer (2℃)	elbu	-	kW
heating / Colder (-22℃)	elbu	-	kW
Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	3.55	-
Tj=30℃	EERd	5.60	-
Tj=25℃	EERd	9.60	-
Tj=20℃	EERd	15.30	-
Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	3.05	-
Tj=2℃	COPd	4.15	-
Tj=7℃	COPd	6.10	-
Tj=12℃	COPd	7.60	-
Tj=bivalent temperature	COPd	2.70	-
Tj=operating limit	COPd	2.25	-
Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	-	-
Tj=7℃	COPd	-	-
Tj=12℃	COPd	-	-
Tj=bivalent temperature	COPd	-	-
Tj=operating limit	COPd	-	-
Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	-	-
Tj=2℃	COPd	-	-
Tj=7℃	COPd	-	-
Tj=12℃	COPd	-	-
Tj=bivalent temperature	COPd	-	-
Tj=operating limit	COPd	-	-
Tj=-15℃	COPd	-	-
Operating limit temperature			
heating / Average	Tol	-20	℃
heating / Warmer	Tol	-	℃
heating / Colder	Tol	-	℃
Cycling interval efficiency			
for cooling	EERcyc	-	-
for heating	COPcyc	-	-
Degradation coefficient			
heating	Cdh	0.25	-
Annual electricity consumption			
cooling	Qce	473	kWh/a
heating / Average	Qhe	2665	kWh/a
heating / Warmer	Qhe	-	kWh/a
heating / colder	Qhe	-	kWh/a
Other items			
Sound power level(indoor)	Lwa	62	dB(A)
Sound power level(outdoor)	Lwa	69	dB(A)
Global warming potential	GWP	675	$kgCO_2eq.$
Rated air flow(indoor)	-	1200	m^3/h
Rated air flow(outdoor)	-	4500	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex,UB11 1ET, United kingdom

PJF000Z589 B

FDT100VSAWPVH

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	**FDT50VH (x2 units)**
Outdoor unit model name	**FDC100VSA-W**

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Function(indicate if present)	
cooling	**Yes**
heating	**Yes**

Average(mandatory)	**Yes**
Warmer(if designated)	**No**
Colder(if designated)	**No**

Item	symbol	value	unit
Design load			
cooling	Pdesignc	**10.0**	kW
heating / Average	Pdesignh	**8.50**	kW
heating / Warmer	Pdesignh	**-**	kW
heating / Colder	Pdesignh	**-**	kW
Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	**8.50**	kW
heating / Warmer (2℃)	Pdh	**-**	kW
heating / Colder (-22℃)	Pdh	**-**	kW
Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	**10.00**	kW
Tj=30℃	Pdc	**7.37**	kW
Tj=25℃	Pdc	**4.74**	kW
Tj=20℃	Pdc	**3.49**	kW
Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**7.40**	kW
Tj=2℃	Pdh	**4.50**	kW
Tj=7℃	Pdh	**2.90**	kW
Tj=12℃	Pdh	**2.82**	kW
Tj=bivalent temperature	Pdh	**8.50**	kW
Tj=operating limit	Pdh	**6.30**	kW
Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**-**	kW
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Tj=-15℃	Pdh	**-**	kW
Bivalent temperature			
heating / Average	Tbiv	**-10**	℃
heating / Warmer	Tbiv	**-**	℃
heating / Colder	Tbiv	**-**	℃
Cycling interval capacity			
for cooling	Pcycc	**-**	kW
for heating	Pcych	**-**	kW
Degradation coefficient			
cooling	Cdc	**0.25**	-
Electric power input in power modes other than 'active mode'			
off mode	Poff	**10**	W
standby mode	Psb	**10**	W
thermostat-off mode	Pto(cooling)	**15**	W
	Pto(heating)	**30**	W
crankcase heater mode	Pck	**5**	W
Capacity control(indicate one of three options)			
fixed		**No**	
staged		**No**	
variable		**Yes**	

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	**7.41**	A++
heating / Average	SCOP/A	**4.47**	A+
heating / Warmer	SCOP/W	**-**	-
heating / Colder	SCOP/C	**-**	-
			unit
Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	elbu	**0**	kW
heating / Warmer (2℃)	elbu	**-**	kW
heating / Colder (-22℃)	elbu	**-**	kW
Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	**3.55**	-
Tj=30℃	EERd	**5.60**	-
Tj=25℃	EERd	**9.60**	-
Tj=20℃	EERd	**15.30**	-
Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**3.05**	-
Tj=2℃	COPd	**4.15**	-
Tj=7℃	COPd	**6.10**	-
Tj=12℃	COPd	**7.60**	-
Tj=bivalent temperature	COPd	**2.70**	-
Tj=operating limit	COPd	**2.25**	-
Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**-**	-
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Tj=-15℃	COPd	**-**	-
Operating limit temperature			
heating / Average	Tol	**-20**	℃
heating / Warmer	Tol	**-**	℃
heating / Colder	Tol	**-**	℃
Cycling interval efficiency			
for cooling	EERcyc	**-**	-
for heating	COPcyc	**-**	-
Degradation coefficient			
heating	Cdh	**0.25**	-
Annual electricity consumption			
cooling	Qce	**473**	kWh/a
heating / Average	Qhe	**2665**	kWh/a
heating / Warmer	Qhe	**-**	kWh/a
heating / colder	Qhe	**-**	kWh/a
Other items			
Sound power level(indoor)	Lwa	**62**	dB(A)
Sound power level(outdoor)	Lwa	**69**	dB(A)
Global warming potential	GWP	**675**	$kgCO_2eq.$
Rated air flow(indoor)	-	**1200**	m^3/h
Rated air flow(outdoor)	-	**4500**	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex,UB11 1ET, United kingdom

PJF000Z589 B

FDT125VNAWVH

Model(s) :	FDC125VNA-W / FDT125VH						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency	η s,c	**258.0**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**309.0**	%
Tj=+30℃	Pdc	**9.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**486.0**	%
Tj=+25℃	Pdc	**5.8**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**773.0**	%
Tj=+20℃	Pdc	**3.1**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1164.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.007**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.022**	kW	Standby mode	P_{SB}	**0.007**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

Information to identify the model(s) to which the information relates :	FDC125VNA-W / FDT125VH
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**14.0**	kW
Seasonal space heating energy efficiency ηs,h		**172.1**	%

Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj

	Symbol	Value	Unit
T_j=-7℃	Pdh	**8.7**	kW
T_j=+2℃	Pdh	**5.3**	kW
T_j=+7℃	Pdh	**3.4**	kW
T_j=+12℃	Pdh	**2.9**	kW
T_{biv}=bivalent temperature	Pdh	**9.8**	kW
T_{OL}=operation limit	Pdh	**7.4**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-

Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj

		Value	Unit
T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**300.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**425.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**545.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**719.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**220.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	□

Power consumpiton in modes other than 'active mode'

	Symbol	Value	Unit
Off mode	P_{OFF}	**0.007**	kW
Thermostat-off mode	P_{TO}	**0.034**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW

		Value	Unit
Supplementary heater back-up heating capacity	elbu	**-**	kW
Type of energy input Standby mode	P_{SB}	**0.007**	kW

Other items

		Value	Unit
Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**71.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV

		Value	Unit
For air-to-air heat pumps: air flow-rate,outdoor measured		**4380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**-**	m^3/h

GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

FDT125VSAWVH

Model(s) :	FDC125VSA-W / FDT125VH						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency	η s,c	**258.0**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**309.0**	%
Tj=+30℃	Pdc	**9.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**486.0**	%
Tj=+25℃	Pdc	**5.8**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**773.0**	%
Tj=+20℃	Pdc	**3.1**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1164.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.007**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.022**	kW	Standby mode	P_{SB}	**0.007**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

Information to identify the model(s) to which the information relates :	FDC125VSA-W / FDT125VH
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**14.0**	kW
Seasonal space heating energy efficiency ηs,h		**172.1**	%

Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj

	Symbol	Value	Unit
T_j=-7℃	Pdh	**8.7**	kW
T_j=+2℃	Pdh	**5.3**	kW
T_j=+7℃	Pdh	**3.4**	kW
T_j=+12℃	Pdh	**2.9**	kW
T_{biv}=bivalent temperature	Pdh	**9.8**	kW
T_{OL}=operation limit	Pdh	**7.4**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-

Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj

		Value	Unit
T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**300.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**425.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**545.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**719.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**220.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃

Power consumpiton in modes other than 'active mode'

	Symbol	Value	Unit
Off mode	P_{OFF}	**0.007**	kW
Thermostat-off mode	P_{TO}	**0.034**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW

		Value	Unit
Supplementary heater back-up heating capacity	elbu	**-**	kW
Type of energy input Standby mode	P_{SB}	**0.007**	kW

Other items

	Symbol	Value	Unit
Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**71.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV

		Value	Unit
For air-to-air heat pumps: air flow-rate,outdoor measured		**4380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**-**	m^3/h

GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

FDT140VNAWVH

Model(s) :	FDC140VNA-W / FDT140VH						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency	η s,c	**243.6**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**284.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**443.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**717.0**	%
Tj=+20℃	Pdc	**3.1**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1164.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.007**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.022**	kW	Standby mode	P_{SB}	**0.007**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

Information to identify the model(s) to which the information relates :	FDC140VNA-W / FDT140VH
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj			
T_j=-7℃	Pdh	**9.0**	kW
T_j=+2℃	Pdh	**5.6**	kW
T_j=+7℃	Pdh	**3.7**	kW
T_j=+12℃	Pdh	**2.9**	kW
T_{biv}=bivalent temperature	Pdh	**10.5**	kW
T_{OL}=operation limit	Pdh	**7.9**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-
Power consumpiton in modes other than 'active mode'			
Off mode	P_{OFF}	**0.007**	kW
Thermostat-off mode	P_{TO}	**0.034**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW
Other items			
Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**73.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Item	Symbol	Value	Unit
Seasonal space heating energy efficiency ηs,h		**173.9**	%
Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**305.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**430.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**550.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**719.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**250.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**210.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Supplementary heater back-up heating capacity	elbu	**-**	kW
Type of energy input Standby mode	P_{SB}	**0.007**	kW
For air-to-air heat pumps: air flow-rate,outdoor measured		**4380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**-**	m^3/h

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

FDT140VSAWVH

Model(s) :	FDC140VSA-W / FDT140VH						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency	η s,c	**243.6**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**284.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**443.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**717.0**	%
Tj=+20℃	Pdc	**3.1**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1164.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.007**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.022**	kW	Standby mode	P_{SB}	**0.007**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

Information to identify the model(s) to which the information relates :				FDC140VSA-W / FDT140VH			
Outdoor side heat exchanger of heat pump :				air			
Indoor side heat exchanger of heat pump :				air			
Indication if the heater is equipped with a supplementary heater :				No			
if applicable :				electric motor			
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW	Seasonal space heating energy efficiency ηs,h		**173.9**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**9.0**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**305.0**	%
T_j=+2℃	Pdh	**5.6**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**430.0**	%
T_j=+7℃	Pdh	**3.7**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**550.0**	%
T_j=+12℃	Pdh	**2.9**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**719.0**	%
T_{biv}=bivalent temperature	Pdh	**10.5**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**250.0**	%
T_{OL}=operation limit	Pdh	**7.9**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**210.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**-**	kW
Off mode	P_{OFF}	**0.007**	kW				
Thermostat-off mode	P_{TO}	**0.034**	kW	Type of energy input Standby mode	P_{SB}	**0.007**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**73.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water fiow-rate, outdoor side heat exchanger		**-**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

FDT125VNAWPVH

Model(s) :	FDC125VNA-W / FDT60VH (x2 units)						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency ηs,c		**315.5**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**330.0**	%
Tj=+30℃	Pdc	**9.2**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**519.0**	%
Tj=+25℃	Pdc	**5.9**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**950.0**	%
Tj=+20℃	Pdc	**3.6**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1960.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

Information to identify the model(s) to which the information relates :				FDC125VNA-W / FDT60VH (x2 units)			
Outdoor side heat exchanger of heat pump :				air			
Indoor side heat exchanger of heat pump :				air			
Indication if the heater is equipped with a supplementary heater :				No			
if applicable :				electric motor			
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**14.0**	kW	Seasonal space heating energy efficiency ηs,h		**205.1**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**8.7**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**328.0**	%
T_j=+2℃	Pdh	**5.3**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**508.0**	%
T_j=+7℃	Pdh	**3.4**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**662.0**	%
T_j=+12℃	Pdh	**3.0**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**985.0**	%
T_{biv}=bivalent temperature	Pdh	**9.8**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	Pdh	**7.4**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**220.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**-**	kW
Off mode	P_{OFF}	**0.008**	kW				
Thermostat-off mode	P_{TO}	**0.020**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4380**	m3/h
Sound power level, outdoor measured	L_{WA}	**71.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**-**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

FDT125VSAWPVH

Model(s) :	FDC125VSA-W / FDT60VH (x2 units)						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency ηs,c		**315.5**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**330.0**	%
Tj=+30℃	Pdc	**9.2**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**519.0**	%
Tj=+25℃	Pdc	**5.9**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**950.0**	%
Tj=+20℃	Pdc	**3.6**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1960.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

Information to identify the model(s) to which the information relates :	FDC125VSA-W / FDT60VH (x2 units)
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**14.0**	kW
Seasonal space heating energy efficiency ηs,h		**205.1**	%

Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj

	Symbol	Value	Unit
T_j=-7℃	Pdh	**8.7**	kW
T_j=+2℃	Pdh	**5.3**	kW
T_j=+7℃	Pdh	**3.4**	kW
T_j=+12℃	Pdh	**3.0**	kW
T_{biv}=bivalent temperature	Pdh	**9.8**	kW
T_{OL}=operation limit	Pdh	**7.4**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-

Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj

		Value	Unit
T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**328.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**508.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**662.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**985.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**220.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃

Power consumpiton in modes other than 'active mode'

	Symbol	Value	Unit
Off mode	P_{OFF}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.020**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW

		Value	Unit
Supplementary heater back-up heating capacity	elbu	**-**	kW
Type of energy input Standby mode	P_{SB}	**0.008**	kW

Other items

	Symbol	Value	Unit
Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**71.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV

	Value	Unit
For air-to-air heat pumps: air flow-rate,outdoor measured	**4380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger	**-**	m^3/h

GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

FDT140VNAWPVH

Model(s) :	FDC140VNA-W / FDT71VH (x2 units)						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**313.3**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**322.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**530.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**870.0**	%
Tj=+20℃	Pdc	**3.7**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**2200.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

Information to identify the model(s) to which the information relates :				FDC140VNA-W / FDT71VH (x2 units)			
Outdoor side heat exchanger of heat pump :				air			
Indoor side heat exchanger of heat pump :				air			
Indication if the heater is equipped with a supplementary heater :				No			
if applicable :				electric motor			
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW	Seasonal space heating energy efficiency ηs,h		**201.6**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**9.3**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**330.0**	%
T_j=+2℃	Pdh	**5.6**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**500.0**	%
T_j=+7℃	Pdh	**3.6**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**640.0**	%
T_j=+12℃	Pdh	**3.0**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**940.0**	%
T_{biv}=bivalent temperature	Pdh	**10.5**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	Pdh	**7.9**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**220.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**-**	kW
Off mode	P_{OFF}	**0.008**	kW				
Thermostat-off mode	P_{TO}	**0.020**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**73.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**-**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

FDT140VSAWPVH

Model(s) :	FDC140VSA-W / FDT71VH (x2 units)						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**313.3**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**322.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**530.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**870.0**	%
Tj=+20℃	Pdc	**3.7**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**2200.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

Information to identify the model(s) to which the information relates :				FDC140VSA-W / FDT71VH (x2 units)			
Outdoor side heat exchanger of heat pump :				air			
Indoor side heat exchanger of heat pump :				air			
Indication if the heater is equipped with a supplementary heater :				No			
if applicable :				electric motor			
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW	Seasonal space heating energy efficiency ηs,h		**201.6**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**9.3**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**330.0**	%
T_j=+2℃	Pdh	**5.6**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**500.0**	%
T_j=+7℃	Pdh	**3.6**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**640.0**	%
T_j=+12℃	Pdh	**3.0**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**940.0**	%
T_{biv}=bivalent temperature	Pdh	**10.5**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	Pdh	**7.9**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**220.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**-**	kW
Off mode	P_{OFF}	**0.008**	kW				
Thermostat-off mode	P_{TO}	**0.020**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**73.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**-**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

FDT140VNAWTVH

Model(s) : FDC140VNA-W / FDT50VH (x3 units)							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**313.3**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**322.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**530.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**870.0**	%
Tj=+20℃	Pdc	**3.7**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**2200.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

Information to identify the model(s) to which the information relates :				FDC140VNA-W / FDT50VH (x3 units)			
Outdoor side heat exchanger of heat pump :				air			
Indoor side heat exchanger of heat pump :				air			
Indication if the heater is equipped with a supplementary heater :				No			
if applicable :				electric motor			
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW	Seasonal space heating energy efficiency ηs,h		**201.6**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**9.3**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**330.0**	%
T_j=+2℃	Pdh	**5.6**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**500.0**	%
T_j=+7℃	Pdh	**3.6**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**640.0**	%
T_j=+12℃	Pdh	**3.0**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**940.0**	%
T_{biv}=bivalent temperature	Pdh	**10.5**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	Pdh	**7.9**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**220.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**-**	kW
Off mode	P_{OFF}	**0.008**	kW				
Thermostat-off mode	P_{TO}	**0.020**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**73.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water fiow-rate, outdoor side heat exchanger		**-**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

FDT140VSAWTVH

Model(s) :	FDC140VSA-W / FDT50VH (x3 units)						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**313.3**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**322.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**530.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**870.0**	%
Tj=+20℃	Pdc	**3.7**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**2200.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

Information to identify the model(s) to which the information relates :				FDC140VSA-W / FDT50VH (x3 units)			
Outdoor side heat exchanger of heat pump :				air			
Indoor side heat exchanger of heat pump :				air			
Indication if the heater is equipped with a supplementary heater :				No			
if applicable :				electric motor			
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW	Seasonal space heating energy efficiency ηs,h		**201.6**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**9.3**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**330.0**	%
T_j=+2℃	Pdh	**5.6**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**500.0**	%
T_j=+7℃	Pdh	**3.6**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**640.0**	%
T_j=+12℃	Pdh	**3.0**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**940.0**	%
T_{biv}=bivalent temperature	Pdh	**10.5**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	Pdh	**7.9**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**220.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**-**	kW
Off mode	P_{OFF}	**0.008**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.020**	kW				
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items				For air-to-air heat pumps: air flow-rate,outdoor measured		**4380**	m^3/h
Capacity control		**variable**		For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**-**	m^3/h
Sound power level, outdoor measured	L_{WA}	**73.0**	dB				
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z589 B

Models FDT50VH, 60VH, 71VH, 100VH, 125VH, 140VH

Model(s) : FDT50VH

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Cooling capacity (sensible)	$P_{rated,c}$	4.4	kW	Total electric power input	P_{elec}	0.040	kW
Cooling capacity (latent)	$P_{rated,c}$	0.6	kW	Sound power level (per speed setting,if applicable)	L_{WA}	55.0	dB
Heating capacity	$P_{rated,h}$	5.4	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDT60VH

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Cooling capacity (sensible)	$P_{rated,c}$	5.5	kW	Total electric power input	P_{elec}	0.070	kW
Cooling capacity (latent)	$P_{rated,c}$	0.1	kW	Sound power level (per speed setting,if applicable)	L_{WA}	58.0	dB
Heating capacity	$P_{rated,h}$	6.7	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDT71VH

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Cooling capacity (sensible)	$P_{rated,c}$	6.2	kW	Total electric power input	P_{elec}	0.080	kW
Cooling capacity (latent)	$P_{rated,c}$	0.9	kW	Sound power level (per speed setting,if applicable)	L_{WA}	59.0	dB
Heating capacity	$P_{rated,h}$	8.0	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDT100VH

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Cooling capacity (sensible)	$P_{rated,c}$	8.4	kW	Total electric power input	P_{elec}	0.130	kW
Cooling capacity (latent)	$P_{rated,c}$	1.6	kW	Sound power level (per speed setting,if applicable)	L_{WA}	62.0	dB
Heating capacity	$P_{rated,h}$	11.2	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDT125VH

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Cooling capacity (sensible)	$P_{rated,c}$	9.6	kW	Total electric power input	P_{elec}	0.140	kW
Cooling capacity (latent)	$P_{rated,c}$	2.9	kW	Sound power level (per speed setting,if applicable)	L_{WA}	63.0	dB
Heating capacity	$P_{rated,h}$	14.0	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDT140VH

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Cooling capacity (sensible)	$P_{rated,c}$	10.4	kW	Total electric power input	P_{elec}	0.140	kW
Cooling capacity (latent)	$P_{rated,c}$	3.6	kW	Sound power level (per speed setting,if applicable)	L_{WA}	63.0	dB
Heating capacity	$P_{rated,h}$	16.0	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

PJF000Z589 B

(2) Ceiling cassette-4 way compact type (FDTC)

FDTC100VNAWPVH

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	**FDTC50VH (x2 units)**
Outdoor unit model name	**FDC100VNA-W**

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Function(indicate if present)	
cooling	**Yes**
heating	**Yes**

Average(mandatory)	**Yes**
Warmer(if designated)	**No**
Colder(if designated)	**No**

Item	symbol	value	unit
Design load			
cooling	Pdesignc	**10.0**	kW
heating / Average	Pdesignh	**8.5**	kW
heating / Warmer	Pdesignh	**-**	kW
heating / Colder	Pdesignh	**-**	kW

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	**6.17**	**A++**
heating / Average	SCOP/A	**4.38**	**A+**
heating / Warmer	SCOP/W	**-**	-
heating / Colder	SCOP/C	**-**	-

Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	**8.5**	kW
heating / Warmer (2℃)	Pdh	**-**	kW
heating / Colder (-22℃)	Pdh	**-**	kW

Back up heating capacity at outdoor temperature Tdesignh			unit
heating / Average (-10℃)	elbu	**0**	kW
heating / Warmer (2℃)	elbu	**-**	kW
heating / Colder (-22℃)	elbu	**-**	kW

Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	**10.00**	kW
Tj=30℃	Pdc	**7.37**	kW
Tj=25℃	Pdc	**4.74**	kW
Tj=20℃	Pdc	**3.25**	kW

Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	**3.17**	-
Tj=30℃	EERd	**4.80**	-
Tj=25℃	EERd	**7.50**	-
Tj=20℃	EERd	**12.00**	-

Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**7.40**	kW
Tj=2℃	Pdh	**4.50**	kW
Tj=7℃	Pdh	**2.90**	kW
Tj=12℃	Pdh	**2.82**	kW
Tj=bivalent temperature	Pdh	**8.50**	kW
Tj=operating limit	Pdh	**6.20**	kW

Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**3.04**	-
Tj=2℃	COPd	**4.30**	-
Tj=7℃	COPd	**5.50**	-
Tj=12℃	COPd	**6.60**	-
Tj=bivalent temperature	COPd	**2.50**	-
Tj=operating limit	COPd	**2.10**	-

Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW

Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-

Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**-**	kW
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Tj=-15℃	Pdh	**-**	kW

Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**-**	-
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Tj=-15℃	COPd	**-**	-

Bivalent temperature			
heating / Average	Tbiv	**-10**	℃
heating / Warmer	Tbiv	**-**	℃
heating / Colder	Tbiv	**-**	℃

Operating limit temperature			
heating / Average	Tol	**-20**	℃
heating / Warmer	Tol	**-**	℃
heating / Colder	Tol	**-**	℃

Cycling interval capacity			
for cooling	Pcycc	**-**	kW
for heating	Pcych	**-**	kW

Cycling interval efficiency			
for cooling	EERcyc	**-**	-
for heating	COPcyc	**-**	-

Degradation coefficient			
cooling	Cdc	**0.25**	-

Degradation coefficient			
heating	Cdh	**0.25**	-

Electric power input in power modes other than 'active mode'			
off mode	Poff	**10**	W
standby mode	Psb	**10**	W
thermostat-off mode	Pto(cooling)	**15**	W
	Pto(heating)	**30**	W
crankcase heater mode	Pck	**5**	W

Annual electricity consumption			
cooling	Qce	**567**	kWh/a
heating / Average	Qhe	**2715**	kWh/a
heating / Warmer	Qhe	**-**	kWh/a
heating / colder	Qhe	**-**	kWh/a

Capacity control(indicate one of three options)	
fixed	**No**
staged	**No**
variable	**Yes**

Other items			
Sound power level(indoor)	Lwa	**59**	dB(A)
Sound power level(outdoor)	Lwa	**69**	dB(A)
Global warming potential	GWP	**675**	$kgCO_2eq.$
Rated air flow(indoor)	-	**780**	m^3/h
Rated air flow(outdoor)	-	**4500**	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex, UB11 1ET, United Kingdom

PJF000Z517 B

FDTC100VSAWPVH

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	**FDTC50VH (x2 units)**
Outdoor unit model name	**FDC100VSA-W**

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Function(indicate if present)	
cooling	**Yes**
heating	**Yes**

Average(mandatory)	**Yes**
Warmer(if designated)	**No**
Colder(if designated)	**No**

Item	symbol	value	unit
Design load			
cooling	Pdesignc	**10.0**	kW
heating / Average	Pdesignh	**8.5**	kW
heating / Warmer	Pdesignh	**-**	kW
heating / Colder	Pdesignh	**-**	kW

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	**6.17**	**A++**
heating / Average	SCOP/A	**4.38**	**A+**
heating / Warmer	SCOP/W	**-**	-
heating / Colder	SCOP/C	**-**	-

Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	**8.5**	kW
heating / Warmer (2℃)	Pdh	**-**	kW
heating / Colder (-22℃)	Pdh	**-**	kW

Back up heating capacity at outdoor temperature Tdesignh			unit
heating / Average (-10℃)	elbu	**0**	kW
heating / Warmer (2℃)	elbu	**-**	kW
heating / Colder (-22℃)	elbu	**-**	kW

Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	**10.00**	kW
Tj=30℃	Pdc	**7.37**	kW
Tj=25℃	Pdc	**4.74**	kW
Tj=20℃	Pdc	**3.25**	kW

Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	**3.17**	-
Tj=30℃	EERd	**4.80**	-
Tj=25℃	EERd	**7.50**	-
Tj=20℃	EERd	**12.00**	-

Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**7.40**	kW
Tj=2℃	Pdh	**4.50**	kW
Tj=7℃	Pdh	**2.90**	kW
Tj=12℃	Pdh	**2.82**	kW
Tj=bivalent temperature	Pdh	**8.50**	kW
Tj=operating limit	Pdh	**6.20**	kW

Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**3.04**	-
Tj=2℃	COPd	**4.30**	-
Tj=7℃	COPd	**5.50**	-
Tj=12℃	COPd	**6.60**	-
Tj=bivalent temperature	COPd	**2.50**	-
Tj=operating limit	COPd	**2.10**	-

Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW

Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-

Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**-**	kW
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Tj=-15℃	Pdh	**-**	kW

Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**-**	-
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Tj=-15℃	COPd	**-**	-

Bivalent temperature			
heating / Average	Tbiv	**-10**	℃
heating / Warmer	Tbiv	**-**	℃
heating / Colder	Tbiv	**-**	℃

Operating limit temperature			
heating / Average	Tol	**-20**	℃
heating / Warmer	Tol	**-**	℃
heating / Colder	Tol	**-**	℃

Cycling interval capacity			
for cooling	Pcycc	**-**	kW
for heating	Pcych	**-**	kW

Cycling interval efficiency			
for cooling	EERcyc	**-**	-
for heating	COPcyc	**-**	-

Degradation coefficient			
cooling	Cdc	**0.25**	-

Degradation coefficient			
heating	Cdh	**0.25**	-

Electric power input in power modes other than 'active mode'			
off mode	Poff	**10**	W
standby mode	Psb	**10**	W
thermostat-off mode	Pto(cooling)	**15**	W
	Pto(heating)	**30**	W
crankcase heater mode	Pck	**5**	W

Annual electricity consumption			
cooling	Qce	**567**	kWh/a
heating / Average	Qhe	**2715**	kWh/a
heating / Warmer	Qhe	**-**	kWh/a
heating / colder	Qhe	**-**	kWh/a

Capacity control(indicate one of three options)	
fixed	**No**
staged	**No**
variable	**Yes**

Other items			
Sound power level(indoor)	Lwa	**59**	dB(A)
Sound power level(outdoor)	Lwa	**69**	dB(A)
Global warming potential	GWP	**675**	$kgCO_2eq.$
Rated air flow(indoor)	-	**780**	m^3/h
Rated air flow(outdoor)	-	**4500**	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex, UB11 1ET, United Kingdom

PJF000Z517 B

FDTC125VNAWPVH

Model(s) : FDC125VNA-W / FDTC60VH (x2 units)							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency ηs,c		**260.6**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**255.0**	%
Tj=+30℃	Pdc	**9.2**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**450.0**	%
Tj=+25℃	Pdc	**5.9**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**739.0**	%
Tj=+20℃	Pdc	**3.5**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1782.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.010**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.010**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z517 B

Information to identify the model(s) to which the information relates :				FDC125VNA-W / FDTC60VH (x2 units)			
Outdoor side heat exchanger of heat pump :				air			
Indoor side heat exchanger of heat pump :				air			
Indication if the heater is equipped with a supplementary heater :				No			
if applicable :				electric motor			
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	14.0	kW	Seasonal space heating energy efficiency ηs,h		171.3	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	8.7	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,bin	270.0	%
T_j=+2℃	Pdh	5.3	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,bin	420.0	%
T_j=+7℃	Pdh	3.4	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,bin	580.0	%
T_j=+12℃	Pdh	3.0	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,bin	805.0	%
T_{biv}=bivalent temperature	Pdh	9.8	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	230.0	%
T_{OL}=operation limit	Pdh	7.4	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	200.0	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	-	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	-	%
Bivalent temperature	T_{biv}	-10.0	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		-	℃
Degradation coefficient heat pumps**	C_{dh}	0.25	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	-	kW
Off mode	P_{OFF}	0.010	kW	Type of energy input Standby mode	P_{SB}	0.010	kW
Thermostat-off mode	P_{TO}	0.020	kW				
Crankcase heater mode	P_{CK}	0.005	kW				
Other items							
Capacity control		variable		For air-to-air heat pumps: air flow-rate,outdoor measured		4380	m^3/h
Sound power level, outdoor measured	L_{WA}	71.0	dB	For water-/brine-to-air heat pumps : Rated brine or water fiow-rate, outdoor side heat exchanger		-	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	-	mg/kWh fuel input GCV				
GWP of the refrigerant		675	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z517 B

FDTC125VSAWPVH

Model(s) : FDC125VSA-W / FDTC60VH (x2 units)							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency ηs,c		**260.6**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**255.0**	%
Tj=+30℃	Pdc	**9.2**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**450.0**	%
Tj=+25℃	Pdc	**5.9**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**739.0**	%
Tj=+20℃	Pdc	**3.5**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1782.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.010**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.010**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z517 B

Information to identify the model(s) to which the information relates :	FDC125VSA-W / FDTC60VH (x2 units)
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**14.0**	kW
Seasonal space heating energy efficiency ηs,h		**171.3**	%

Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj

T_j=-7℃	Pdh	**8.7**	kW
T_j=+2℃	Pdh	**5.3**	kW
T_j=+7℃	Pdh	**3.4**	kW
T_j=+12℃	Pdh	**3.0**	kW
T_{biv}=bivalent temperature	Pdh	**9.8**	kW
T_{OL}=operation limit	Pdh	**7.4**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-

Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj

T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**420.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**580.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**805.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**230.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**200.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃

Power consumpiton in modes other than 'active mode'

Off mode	P_{OFF}	**0.010**	kW
Thermostat-off mode	P_{TO}	**0.020**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW

Supplementary heater back-up heating capacity	elbu	**-**	kW
Type of energy input Standby mode	P_{SB}	**0.010**	kW

Other items

Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**71.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV

For air-to-air heat pumps: air flow-rate,outdoor measured		**4380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water fiow-rate, outdoor side heat exchanger		**-**	m^3/h

GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z517 B

FDTC140VNAWTVH

Model(s) : FDC140VNA-W / FDTC50VH (x3 units)							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**271.4**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**286.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**442.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**773.0**	%
Tj=+20℃	Pdc	**3.5**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1860.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z517 B

Information to identify the model(s) to which the information relates :	FDC140VNA-W / FDTC50VH (x3 units)
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj			
T_j=-7℃	Pdh	**9.3**	kW
T_j=+2℃	Pdh	**5.6**	kW
T_j=+7℃	Pdh	**3.6**	kW
T_j=+12℃	Pdh	**3.0**	kW
T_{biv}=bivalent temperature	Pdh	**10.5**	kW
T_{OL}=operation limit	Pdh	**7.8**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-
Power consumpiton in modes other than 'active mode'			
Off mode	P_{OFF}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.020**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW
Other items			
Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**73.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Item	Symbol	Value	Unit
Seasonal space heating energy efficiency ηs,h		**196.0**	%
Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**317.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**474.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**660.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**963.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**240.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**200.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Supplementary heater back-up heating capacity	elbu	**-**	kW
Type of energy input Standby mode	P_{SB}	**0.008**	kW
For air-to-air heat pumps: air flow-rate,outdoor measured		**4380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water fiow-rate, outdoor side heat exchanger		**-**	m^3/h

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z517 B

FDTC140VSAWTVH

Model(s) : FDC140VSA-W / FDTC50VH (x3 units)							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**271.4**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**286.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**442.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**773.0**	%
Tj=+20℃	Pdc	**3.5**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1860.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z517 B

Information to identify the model(s) to which the information relates :	FDC140VSA-W / FDTC50VH (x3 units)
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	15.5	kW
Seasonal space heating energy efficiency ηs,h		196.0	%

Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj

	Symbol	Value	Unit
T_j=-7℃	Pdh	9.3	kW
T_j=+2℃	Pdh	5.6	kW
T_j=+7℃	Pdh	3.6	kW
T_j=+12℃	Pdh	3.0	kW
T_{biv}=bivalent temperature	Pdh	10.5	kW
T_{OL}=operation limit	Pdh	7.8	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	-	kW
Bivalent temperature	T_{biv}	-10.0	℃
Degradation coefficient heat pumps**	C_{dh}	0.25	-

Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj

		Value	Unit
T_j=-7℃	COPd or GUEh,bin / AEFh,bin	317.0	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	474.0	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	660.0	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	963.0	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	240.0	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	200.0	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	-	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		-	℃

Power consumpiton in modes other than 'active mode'

	Symbol	Value	Unit
Off mode	P_{OFF}	0.008	kW
Thermostat-off mode	P_{TO}	0.020	kW
Crankcase heater mode	P_{CK}	0.005	kW

		Value	Unit
Supplementary heater back-up heating capacity	elbu	-	kW
Type of energy input Standby mode	P_{SB}	0.008	kW

Other items

		Value	Unit
Capacity control		variable	
Sound power level, outdoor measured	L_{WA}	73.0	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	-	mg/kWh fuel input GCV

	Value	Unit
For air-to-air heat pumps: air flow-rate,outdoor measured	4380	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water fiow-rate, outdoor side heat exchanger	-	m^3/h

	Value	Unit
GWP of the refrigerant	675	$kgCO_2eq.$ (100years)

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJF000Z517 B

Models FDTC50VH, 60VH

Model(s) : FDTC50VH							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	$P_{rated,c}$	3.8	kW	Total electric power input	P_{elec}	0.050	kW
Cooling capacity (latent)	$P_{rated,c}$	1.2	kW	Sound power level (per speed setting,if applicable)	L_{WA}	59.0	dB
Heating capacity	$P_{rated,h}$	5.4	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDTC60VH							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	$P_{rated,c}$	3.9	kW	Total electric power input	P_{elec}	0.060	kW
Cooling capacity (latent)	$P_{rated,c}$	1.7	kW	Sound power level (per speed setting,if applicable)	L_{WA}	60.0	dB
Heating capacity	$P_{rated,h}$	6.7	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

(3) Duct connected-High static pressure type (FDU)

FDU100VNAWVH

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	**FDU100VH**
Outdoor unit model name	**FDC100VNA-W**

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Function(indicate if present)	
cooling	**Yes**
heating	**Yes**

Average(mandatory)	**Yes**
Warmer(if designated)	**No**
Colder(if designated)	**No**

Item	symbol	value	unit
Design load			
cooling	Pdesignc	**10.0**	kW
heating / Average	Pdesignh	**8.5**	kW
heating / Warmer	Pdesignh	**-**	kW
heating / Colder	Pdesignh	**-**	kW

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	**6.11**	**A++**
heating / Average	SCOP/A	**4.19**	**A+**
heating / Warmer	SCOP/W	**-**	-
heating / Colder	SCOP/C	**-**	-

Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	**8.5**	kW
heating / Warmer (2℃)	Pdh	**-**	kW
heating / Colder (-22℃)	Pdh	**-**	kW

Back up heating capacity at outdoor temperature Tdesignh			unit
heating / Average (-10℃)	elbu	**0**	kW
heating / Warmer (2℃)	elbu	**-**	kW
heating / Colder (-22℃)	elbu	**-**	kW

Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	**10.00**	kW
Tj=30℃	Pdc	**7.37**	kW
Tj=25℃	Pdc	**4.74**	kW
Tj=20℃	Pdc	**3.10**	kW

Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	**3.35**	-
Tj=30℃	EERd	**5.00**	-
Tj=25℃	EERd	**8.05**	-
Tj=20℃	EERd	**9.50**	-

Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**7.40**	kW
Tj=2℃	Pdh	**4.50**	kW
Tj=7℃	Pdh	**2.90**	kW
Tj=12℃	Pdh	**2.90**	kW
Tj=bivalent temperature	Pdh	**8.50**	kW
Tj=operating limit	Pdh	**6.30**	kW

Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**3.14**	-
Tj=2℃	COPd	**4.02**	-
Tj=7℃	COPd	**5.24**	-
Tj=12℃	COPd	**6.27**	-
Tj=bivalent temperature	COPd	**2.50**	-
Tj=operating limit	COPd	**2.10**	-

Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW

Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-

Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**-**	kW
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Tj=-15℃	Pdh	**-**	kW

Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**-**	-
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Tj=-15℃	COPd	**-**	-

Bivalent temperature			
heating / Average	Tbiv	**-10**	℃
heating / Warmer	Tbiv	**-**	℃
heating / Colder	Tbiv	**-**	℃

Operating limit temperature			
heating / Average	Tol	**-20**	℃
heating / Warmer	Tol	**-20**	℃
heating / Colder	Tol	**-20**	℃

Cycling interval capacity			
for cooling	Pcycc	**-**	kW
for heating	Pcych	**-**	kW

Cycling interval efficiency			
for cooling	EERcyc	**-**	-
for heating	COPcyc	**-**	-

Degradation coefficient			
cooling	Cdc	**0.25**	-

Degradation coefficient			
heating	Cdh	**0.25**	-

Electric power input in power modes other than 'active mode'			
off mode	Poff	**8**	W
standby mode	Psb	**8**	W
thermostat-off mode	Pto(cooling)	**65**	W
	Pto(heating)	**75**	W
crankcase heater mode	Pck	**5**	W

Annual electricity consumption			
cooling	Qce	**574**	kWh/a
heating / Average	Qhe	**2843**	kWh/a
heating / Warmer	Qhe	**-**	kWh/a
heating / colder	Qhe	**-**	kWh/a

Capacity control(indicate one of three options)	
fixed	**No**
staged	**No**
variable	**Yes**

Other items			
Sound power level(indoor)	Lwa	**65**	dB(A)
Sound power level(outdoor)	Lwa	**69**	dB(A)
Global warming potential	GWP	**675**	$kgCO_2eq.$
Rated air flow(indoor)	-	**2,160**	m^3/h
Rated air flow(outdoor)	-	**4,500**	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex, UB11 1ET, United Kingdom

PJG000Z625A

FDU100VSAWVH

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	**FDU100VH**
Outdoor unit model name	**FDC100VSA-W**

Function(indicate if present)	
cooling	**Yes**
heating	**Yes**

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Average(mandatory)	**Yes**
Warmer(if designated)	**No**
Colder(if designated)	**No**

Item	symbol	value	unit
Design load			
cooling	Pdesignc	**10.0**	kW
heating / Average	Pdesignh	**8.5**	kW
heating / Warmer	Pdesignh	**-**	kW
heating / Colder	Pdesignh	**-**	kW

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	**6.11**	**A++**
heating / Average	SCOP/A	**4.19**	**A+**
heating / Warmer	SCOP/W	**-**	-
heating / Colder	SCOP/C	**-**	-

Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	**8.5**	kW
heating / Warmer (2℃)	Pdh	**-**	kW
heating / Colder (-22℃)	Pdh	**-**	kW

Back up heating capacity at outdoor temperature Tdesignh			unit
heating / Average (-10℃)	elbu	**0**	kW
heating / Warmer (2℃)	elbu	**-**	kW
heating / Colder (-22℃)	elbu	**-**	kW

Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	**10.00**	kW
Tj=30℃	Pdc	**7.37**	kW
Tj=25℃	Pdc	**4.74**	kW
Tj=20℃	Pdc	**3.10**	kW

Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	**3.35**	-
Tj=30℃	EERd	**5.00**	-
Tj=25℃	EERd	**8.05**	-
Tj=20℃	EERd	**9.50**	-

Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**7.40**	kW
Tj=2℃	Pdh	**4.50**	kW
Tj=7℃	Pdh	**2.90**	kW
Tj=12℃	Pdh	**2.90**	kW
Tj=bivalent temperature	Pdh	**8.50**	kW
Tj=operating limit	Pdh	**6.30**	kW

Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**3.14**	-
Tj=2℃	COPd	**4.02**	-
Tj=7℃	COPd	**5.24**	-
Tj=12℃	COPd	**6.27**	-
Tj=bivalent temperature	COPd	**2.50**	-
Tj=operating limit	COPd	**2.10**	-

Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW

Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-

Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**-**	kW
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Tj=-15℃	Pdh	**-**	kW

Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**-**	-
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Tj=-15℃	COPd	**-**	-

Bivalent temperature			
heating / Average	Tbiv	**-10**	℃
heating / Warmer	Tbiv	**-**	℃
heating / Colder	Tbiv	**-**	℃

Operating limit temperature			
heating / Average	Tol	**-20**	℃
heating / Warmer	Tol	**-20**	℃
heating / Colder	Tol	**-20**	℃

Cycling interval capacity			
for cooling	Pcycc	**-**	kW
for heating	Pcych	**-**	kW

Cycling interval efficiency			
for cooling	EERcyc	**-**	-
for heating	COPcyc	**-**	-

Degradation coefficient			
cooling	Cdc	**0.25**	-

Degradation coefficient			
heating	Cdh	**0.25**	-

Electric power input in power modes other than 'active mode'			
off mode	Poff	**8.0**	W
standby mode	Psb	**8.0**	W
thermostat-off mode	Pto(cooling)	**65.0**	W
	Pto(heating)	**75.0**	W
crankcase heater mode	Pck	**5.0**	W

Annual electricity consumption			
cooling	Qce	**574**	kWh/a
heating / Average	Qhe	**2843**	kWh/a
heating / Warmer	Qhe	**-**	kWh/a
heating / colder	Qhe	**-**	kWh/a

Capacity control(indicate one of three options)	
fixed	**No**
staged	**No**
variable	**Yes**

Other items			
Sound power level(indoor)	Lwa	**65**	dB(A)
Sound power level(outdoor)	Lwa	**69**	dB(A)
Global warming potential	GWP	**675**	$kgCO_2eq.$
Rated air flow(indoor)	-	**2,160**	m^3/h
Rated air flow(outdoor)	-	**4,500**	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex, UB11 1ET, United Kingdom

PJG000Z625Ⓐ

FDU125VNAWVH

Model(s) : FDC125VNA-W ／ FDU125VH							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency ηs,c		**219.8**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**287.0**	%
Tj=+30℃	Pdc	**9.2**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**425.0**	%
Tj=+25℃	Pdc	**5.9**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**705.0**	%
Tj=+20℃	Pdc	**3.1**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**920.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.075**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items				For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Capacity control		**variable**					
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z625A

Information to identify the model(s) to which the information relates :		FDC125VNA-W ／ FDU125VH					
Outdoor side heat exchanger of heat pump :		air					
Indoor side heat exchanger of heat pump :		air					
Indication if the heater is equipped with a supplementary heater :		No					
if applicable :		electric motor					
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**14.0**	kW	Seasonal space heating energy efficiency ηs,h		**162.1**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**8.7**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**300.0**	%
T_j=+2℃	Pdh	**5.3**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**399.0**	%
T_j=+7℃	Pdh	**3.4**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**515.0**	%
T_j=+12℃	Pdh	**2.7**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**615.0**	%
T_{biv}=bivalent temperature	Pdh	**9.8**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	Pdh	**7.4**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**210.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**—**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**—**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**—**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**—**	kW
Off mode	P_{OFF}	**0.008**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.090**	kW				
Crankcase heater mode	P_{CK}	**0.008**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**71.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**—**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**—**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z625 A

FDU125VSAWVH

Model(s) : FDC125VSA-W ／ FDU125VH							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency ηs,c		**219.8**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**287.0**	%
Tj=+30℃	Pdc	**9.2**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**425.0**	%
Tj=+25℃	Pdc	**5.9**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**705.0**	%
Tj=+20℃	Pdc	**3.1**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**920.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.075**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items				For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Capacity control		**variable**					
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z625A

Information to identify the model(s) to which the information relates : FDC125VSA-W ／ FDU125VH							
Outdoor side heat exchanger of heat pump : air							
Indoor side heat exchanger of heat pump : air							
Indication if the heater is equipped with a supplementary heater : No							
if applicable : electric motor							
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**14.0**	kW	Seasonal space heating energy efficiency ηs,h		**162.1**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**8.7**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**300.0**	%
T_j=+2℃	Pdh	**5.3**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**399.0**	%
T_j=+7℃	Pdh	**3.4**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**515.0**	%
T_j=+12℃	Pdh	**2.7**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**615.0**	%
T_{biv}=bivalent temperature	Pdh	**9.8**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	Pdh	**7.4**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**210.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**–**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**–**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**–**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**–**	kW
Off mode	P_{OFF}	**0.008**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.090**	kW				
Crankcase heater mode	P_{CK}	**0.008**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**71.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**–**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**–**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z625A

FDU140VNAWVH

Model(s) : FDC140VNA-W ／ FDU140VH							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**208.8**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**265.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**390.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**680.0**	%
Tj=+20℃	Pdc	**3.2**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**900.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.090**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items				For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Capacity control		**variable**					
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z625A

Information to identify the model(s) to which the information relates : FDC140VNA-W ／ FDU140VH							
Outdoor side heat exchanger of heat pump : air							
Indoor side heat exchanger of heat pump : air							
Indication if the heater is equipped with a supplementary heater : No							
if applicable : electric motor							
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW	Seasonal space heating energy efficiency ηs,h		**157.4**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**9.3**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**295.0**	%
T_j=+2℃	Pdh	**5.6**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**385.0**	%
T_j=+7℃	Pdh	**3.6**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**500.0**	%
T_j=+12℃	Pdh	**2.7**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**596.0**	%
T_{biv}=bivalent temperature	Pdh	**10.5**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	Pdh	**7.9**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**220.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**—**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**—**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**—**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**—**	kW
Off mode	P_{OFF}	**0.008**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.100**	kW				
Crankcase heater mode	P_{CK}	**0.008**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**73.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**—**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**—**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z625A

FDU140VSAWVH

Model(s) : FDC140VSA-W ／ FDU140VH							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**208.8**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**265.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**390.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**680.0**	%
Tj=+20℃	Pdc	**3.2**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**900.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.090**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items				For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Capacity control		**variable**					
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z625A

Information to identify the model(s) to which the information relates :				FDC140VSA-W ／ FDU140VH			
Outdoor side heat exchanger of heat pump :				air			
Indoor side heat exchanger of heat pump :				air			
Indication if the heater is equipped with a supplementary heater :				No			
if applicable :				electric motor			
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW	Seasonal space heating energy efficiency ηs,h		**157.4**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**9.3**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**295.0**	%
T_j=+2℃	Pdh	**5.6**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**385.0**	%
T_j=+7℃	Pdh	**3.6**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**500.0**	%
T_j=+12℃	Pdh	**2.7**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**596.0**	%
T_{biv}=bivalent temperature	Pdh	**10.5**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	Pdh	**7.9**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**220.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**—**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**—**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**—**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**—**	kW
Off mode	P_{OFF}	**0.008**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.100**	kW				
Crankcase heater mode	P_{CK}	**0.008**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**73.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**—**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**—**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z625A

Models FDU100VH, 125VH, 140VH

Model(s) : FDU100VH							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	$P_{rated,c}$	7.7	kW	Total electric power input	P_{elec}	0.350	kW
Cooling capacity (latent)	$P_{rated,c}$	2.3	kW	Sound power level (per speed setting,if applicable)	L_{WA}	65.0	dB
Heating capacity	$P_{rated,h}$	11.2	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDU125VH							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	$P_{rated,c}$	10.5	kW	Total electric power input	P_{elec}	0.400	kW
Cooling capacity (latent)	$P_{rated,c}$	2.0	kW	Sound power level (per speed setting,if applicable)	L_{WA}	67.0	dB
Heating capacity	$P_{rated,h}$	14.0	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDU140VH							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	$P_{rated,c}$	11.2	kW	Total electric power input	P_{elec}	0.550	kW
Cooling capacity (latent)	$P_{rated,c}$	2.8	kW	Sound power level (per speed setting,if applicable)	L_{WA}	70.0	dB
Heating capacity	$P_{rated,h}$	16.0	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

(4) Duct connected-Low/Middle static pressure type (FDUM)

FDUM100VNAWVH

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	**FDUM100VH**
Outdoor unit model name	**FDC100VNA-W**

Function(indicate if present)	
cooling	**Yes**
heating	**Yes**

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Average(mandatory)	**Yes**
Warmer(if designated)	**No**
Colder(if designated)	**No**

Item	symbol	value	unit
Design load			
cooling	Pdesignc	**10.0**	kW
heating / Average	Pdesignh	**8.5**	kW
heating / Warmer	Pdesignh	**-**	kW
heating / Colder	Pdesignh	**-**	kW
Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	**8.5**	kW
heating / Warmer (2℃)	Pdh	**-**	kW
heating / Colder (-22℃)	Pdh	**-**	kW
Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	**10.00**	kW
Tj=30℃	Pdc	**7.37**	kW
Tj=25℃	Pdc	**4.74**	kW
Tj=20℃	Pdc	**3.10**	kW
Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**7.40**	kW
Tj=2℃	Pdh	**4.50**	kW
Tj=7℃	Pdh	**2.90**	kW
Tj=12℃	Pdh	**2.90**	kW
Tj=bivalent temperature	Pdh	**8.50**	kW
Tj=operating limit	Pdh	**6.30**	kW
Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**-**	kW
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Tj=-15℃	Pdh	**-**	kW
Bivalent temperature			
heating / Average	Tbiv	**-10**	℃
heating / Warmer	Tbiv	**-**	℃
heating / Colder	Tbiv	**-**	℃
Cycling interval capacity			
for cooling	Pcycc	**-**	kW
for heating	Pcych	**-**	kW
Degradation coefficient			
cooling	Cdc	**0.25**	-
Electric power input in power modes other than 'active mode'			
off mode	Poff	**8**	W
standby mode	Psb	**8**	W
thermostat-off mode	Pto(cooling)	**65**	W
	Pto(heating)	**75**	W
crankcase heater mode	Pck	**5**	W

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	**6.11**	**A++**
heating / Average	SCOP/A	**4.19**	**A+**
heating / Warmer	SCOP/W	**-**	-
heating / Colder	SCOP/C	**-**	-
			unit
Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	elbu	**0**	kW
heating / Warmer (2℃)	elbu	**-**	kW
heating / Colder (-22℃)	elbu	**-**	kW
Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	**3.35**	-
Tj=30℃	EERd	**5.00**	-
Tj=25℃	EERd	**8.05**	-
Tj=20℃	EERd	**9.50**	-
Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**3.14**	-
Tj=2℃	COPd	**4.02**	-
Tj=7℃	COPd	**5.24**	-
Tj=12℃	COPd	**6.27**	-
Tj=bivalent temperature	COPd	**2.50**	-
Tj=operating limit	COPd	**2.10**	-
Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**-**	-
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Tj=-15℃	COPd	**-**	-
Operating limit temperature			
heating / Average	Tol	**-20**	℃
heating / Warmer	Tol	**-20**	℃
heating / Colder	Tol	**-20**	℃
Cycling interval efficiency			
for cooling	EERcyc	**-**	-
for heating	COPcyc	**-**	-
Degradation coefficient			
heating	Cdh	**0.25**	-
Annual electricity consumption			
cooling	Qce	**574**	kWh/a
heating / Average	Qhe	**2843**	kWh/a
heating / Warmer	Qhe	**-**	kWh/a
heating / colder	Qhe	**-**	kWh/a

Capacity control(indicate one of three options)	
fixed	**No**
staged	**No**
variable	**Yes**

Other items			
Sound power level(indoor)	Lwa	**65**	dB(A)
Sound power level(outdoor)	Lwa	**69**	dB(A)
Global warming potential	GWP	**675**	$kgCO_2eq.$
Rated air flow(indoor)	-	**2160**	m^3/h
Rated air flow(outdoor)	-	**4500**	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex, UB11 1ET, United Kingdom

PJG000Z491 B

FDUM100VSAWVH

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	**FDUM100VH**
Outdoor unit model name	**FDC100VSA-W**

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Function(indicate if present)	
cooling	**Yes**
heating	**Yes**

Average(mandatory)	**Yes**
Warmer(if designated)	**No**
Colder(if designated)	**No**

Item	symbol	value	unit
Design load			
cooling	Pdesignc	**10.0**	kW
heating / Average	Pdesignh	**8.5**	kW
heating / Warmer	Pdesignh	**-**	kW
heating / Colder	Pdesignh	**-**	kW

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	**6.11**	**A++**
heating / Average	SCOP/A	**4.19**	**A+**
heating / Warmer	SCOP/W	**-**	-
heating / Colder	SCOP/C	**-**	-

Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	**8.5**	kW
heating / Warmer (2℃)	Pdh	**-**	kW
heating / Colder (-22℃)	Pdh	**-**	kW

Back up heating capacity at outdoor temperature Tdesignh			unit
heating / Average (-10℃)	elbu	**0**	kW
heating / Warmer (2℃)	elbu	**-**	kW
heating / Colder (-22℃)	elbu	**-**	kW

Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	**10.00**	kW
Tj=30℃	Pdc	**7.37**	kW
Tj=25℃	Pdc	**4.74**	kW
Tj=20℃	Pdc	**3.10**	kW

Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	**3.35**	-
Tj=30℃	EERd	**5.00**	-
Tj=25℃	EERd	**8.05**	-
Tj=20℃	EERd	**9.50**	-

Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**7.40**	kW
Tj=2℃	Pdh	**4.50**	kW
Tj=7℃	Pdh	**2.90**	kW
Tj=12℃	Pdh	**2.90**	kW
Tj=bivalent temperature	Pdh	**8.50**	kW
Tj=operating limit	Pdh	**6.30**	kW

Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**3.14**	-
Tj=2℃	COPd	**4.02**	-
Tj=7℃	COPd	**5.24**	-
Tj=12℃	COPd	**6.27**	-
Tj=bivalent temperature	COPd	**2.50**	-
Tj=operating limit	COPd	**2.10**	-

Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW

Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-

Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**-**	kW
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Tj=-15℃	Pdh	**-**	kW

Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**-**	-
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Tj=-15℃	COPd	**-**	-

Bivalent temperature			
heating / Average	Tbiv	**-10**	℃
heating / Warmer	Tbiv	**-**	℃
heating / Colder	Tbiv	**-**	℃

Operating limit temperature			
heating / Average	Tol	**-20**	℃
heating / Warmer	Tol	**-20**	℃
heating / Colder	Tol	**-20**	℃

Cycling interval capacity			
for cooling	Pcycc	**-**	kW
for heating	Pcych	**-**	kW

Cycling interval efficiency			
for cooling	EERcyc	**-**	-
for heating	COPcyc	**-**	-

Degradation coefficient			
cooling	Cdc	**0.25**	-

Degradation coefficient			
heating	Cdh	**0.25**	-

Electric power input in power modes other than 'active mode'			
off mode	Poff	**8**	W
standby mode	Psb	**8**	W
thermostat-off mode	Pto(cooling)	**65**	W
	Pto(heating)	**75**	W
crankcase heater mode	Pck	**5**	W

Annual electricity consumption			
cooling	Qce	**574**	kWh/a
heating / Average	Qhe	**2843**	kWh/a
heating / Warmer	Qhe	**-**	kWh/a
heating / colder	Qhe	**-**	kWh/a

Capacity control(indicate one of three options)	
fixed	**No**
staged	**No**
variable	**Yes**

Other items			
Sound power level(indoor)	Lwa	**65**	dB(A)
Sound power level(outdoor)	Lwa	**69**	dB(A)
Global warming potential	GWP	**675**	$kgCO_2eq.$
Rated air flow(indoor)	-	**2160**	m^3/h
Rated air flow(outdoor)	-	**4500**	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex, UB11 1ET, United Kingdom

PJG000Z491 B

FDUM100VNAWPVH

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	**FDUM50VH x2**
Outdoor unit model name	**FDC100VNA-W**

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Function(indicate if present)	
cooling	**Yes**
heating	**Yes**

Average(mandatory)	**Yes**
Warmer(if designated)	**No**
Colder(if designated)	**No**

Item	symbol	value	unit
Design load			
cooling	Pdesignc	**10.0**	kW
heating / Average	Pdesignh	**8.5**	kW
heating / Warmer	Pdesignh	**-**	kW
heating / Colder	Pdesignh	**-**	kW

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	**5.82**	**A+**
heating / Average	SCOP/A	**4.00**	**A+**
heating / Warmer	SCOP/W	**-**	-
heating / Colder	SCOP/C	**-**	-

Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	**8.5**	kW
heating / Warmer (2℃)	Pdh	**-**	kW
heating / Colder (-22℃)	Pdh	**-**	kW

Back up heating capacity at outdoor temperature Tdesignh			unit
heating / Average (-10℃)	elbu	**0**	kW
heating / Warmer (2℃)	elbu	**-**	kW
heating / Colder (-22℃)	elbu	**-**	kW

Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	**10.00**	kW
Tj=30℃	Pdc	**7.37**	kW
Tj=25℃	Pdc	**4.74**	kW
Tj=20℃	Pdc	**3.45**	kW

Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	**3.08**	-
Tj=30℃	EERd	**5.00**	-
Tj=25℃	EERd	**7.50**	-
Tj=20℃	EERd	**11.30**	-

Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**7.40**	kW
Tj=2℃	Pdh	**4.50**	kW
Tj=7℃	Pdh	**2.90**	kW
Tj=12℃	Pdh	**2.93**	kW
Tj=bivalent temperature	Pdh	**8.50**	kW
Tj=operating limit	Pdh	**6.30**	kW

Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**2.84**	-
Tj=2℃	COPd	**4.03**	-
Tj=7℃	COPd	**4.85**	-
Tj=12℃	COPd	**5.79**	-
Tj=bivalent temperature	COPd	**2.40**	-
Tj=operating limit	COPd	**2.00**	-

Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW

Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-

Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**-**	kW
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Tj=-15℃	Pdh	**-**	kW

Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**-**	-
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Tj=-15℃	COPd	**-**	-

Bivalent temperature			
heating / Average	Tbiv	**-10**	℃
heating / Warmer	Tbiv	**-**	℃
heating / Colder	Tbiv	**-**	℃

Operating limit temperature			
heating / Average	Tol	**-20**	℃
heating / Warmer	Tol	**-**	℃
heating / Colder	Tol	**-**	℃

Cycling interval capacity			
for cooling	Pcycc	**-**	kW
for heating	Pcych	**-**	kW

Cycling interval efficiency			
for cooling	EERcyc	**-**	-
for heating	COPcyc	**-**	-

Degradation coefficient			
cooling	Cdc	**0.25**	-

Degradation coefficient			
heating	Cdh	**0.25**	-

Electric power input in power modes other than 'active mode'			
off mode	Poff	**15**	W
standby mode	Psb	**15**	W
thermostat-off mode	Pto(cooling)	**110**	W
	Pto(heating)	**130**	W
crankcase heater mode	Pck	**5**	W

Annual electricity consumption			
cooling	Qce	**602**	kWh/a
heating / Average	Qhe	**2974**	kWh/a
heating / Warmer	Qhe	**-**	kWh/a
heating / colder	Qhe	**-**	kWh/a

Capacity control(indicate one of three options)	
fixed	**No**
staged	**No**
variable	**Yes**

Other items			
Sound power level(indoor)	Lwa	**60**	dB(A)
Sound power level(outdoor)	Lwa	**69**	dB(A)
Global warming potential	GWP	**675**	$kgCO_2eq.$
Rated air flow(indoor)	-	**780**	m^3/h
Rated air flow(outdoor)	-	**4500**	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex, UB11 1ET, United Kingdom

PJG000Z491 B

FDUM100VSAWPVH

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	**FDUM50VH x2**
Outdoor unit model name	**FDC100VSA-W**

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Function(indicate if present)	
cooling	**Yes**
heating	**Yes**

Average(mandatory)	**Yes**
Warmer(if designated)	**No**
Colder(if designated)	**No**

Item	symbol	value	unit
Design load			
cooling	Pdesignc	**10.0**	kW
heating / Average	Pdesignh	**8.5**	kW
heating / Warmer	Pdesignh	**-**	kW
heating / Colder	Pdesignh	**-**	kW

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	**5.82**	**A+**
heating / Average	SCOP/A	**4.00**	**A+**
heating / Warmer	SCOP/W	**-**	-
heating / Colder	SCOP/C	**-**	-

Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	**8.5**	kW
heating / Warmer (2℃)	Pdh	**-**	kW
heating / Colder (-22℃)	Pdh	**-**	kW

Back up heating capacity at outdoor temperature Tdesignh			unit
heating / Average (-10℃)	elbu	**0**	kW
heating / Warmer (2℃)	elbu	**-**	kW
heating / Colder (-22℃)	elbu	**-**	kW

Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	**10.00**	kW
Tj=30℃	Pdc	**7.37**	kW
Tj=25℃	Pdc	**4.74**	kW
Tj=20℃	Pdc	**3.45**	kW

Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	**3.08**	-
Tj=30℃	EERd	**5.00**	-
Tj=25℃	EERd	**7.50**	-
Tj=20℃	EERd	**11.30**	-

Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**7.40**	kW
Tj=2℃	Pdh	**4.50**	kW
Tj=7℃	Pdh	**2.90**	kW
Tj=12℃	Pdh	**2.93**	kW
Tj=bivalent temperature	Pdh	**8.50**	kW
Tj=operating limit	Pdh	**6.30**	kW

Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**2.84**	-
Tj=2℃	COPd	**4.03**	-
Tj=7℃	COPd	**4.85**	-
Tj=12℃	COPd	**5.79**	-
Tj=bivalent temperature	COPd	**2.40**	-
Tj=operating limit	COPd	**2.00**	-

Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW

Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-

Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**-**	kW
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Tj=-15℃	Pdh	**-**	kW

Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**-**	-
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Tj=-15℃	COPd	**-**	-

Bivalent temperature			
heating / Average	Tbiv	**-10**	℃
heating / Warmer	Tbiv	**-**	℃
heating / Colder	Tbiv	**-**	℃

Operating limit temperature			
heating / Average	Tol	**-20**	℃
heating / Warmer	Tol	**-**	℃
heating / Colder	Tol	**-**	℃

Cycling interval capacity			
for cooling	Pcycc	**-**	kW
for heating	Pcych	**-**	kW

Cycling interval efficiency			
for cooling	EERcyc	**-**	-
for heating	COPcyc	**-**	-

Degradation coefficient			
cooling	Cdc	**0.25**	-

Degradation coefficient			
heating	Cdh	**0.25**	-

Electric power input in power modes other than 'active mode'			
off mode	Poff	**15**	W
standby mode	Psb	**15**	W
thermostat-off mode	Pto(cooling)	**110**	W
	Pto(heating)	**130**	W
crankcase heater mode	Pck	**5**	W

Annual electricity consumption			
cooling	Qce	**602**	kWh/a
heating / Average	Qhe	**2974**	kWh/a
heating / Warmer	Qhe	**-**	kWh/a
heating / colder	Qhe	**-**	kWh/a

Capacity control(indicate one of three options)	
fixed	**No**
staged	**No**
variable	**Yes**

Other items			
Sound power level(indoor)	Lwa	**60**	dB(A)
Sound power level(outdoor)	Lwa	**69**	dB(A)
Global warming potential	GWP	**675**	$kgCO_2eq.$
Rated air flow(indoor)	-	**780**	m^3/h
Rated air flow(outdoor)	-	**4500**	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex, UB11 1ET, United Kingdom

PJG000Z491 B

FDUM125VNAWVH

Model(s) : FDC125VNA-W ／ FDUM125VH							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency ηs,c		**219.8**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**287.0**	%
Tj=+30℃	Pdc	**9.2**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**425.0**	%
Tj=+25℃	Pdc	**5.9**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**705.0**	%
Tj=+20℃	Pdc	**3.1**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**920.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.075**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**–**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

Information to identify the model(s) to which the information relates :	FDC125VNA-W ／ FDUM125VH
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**14.0**	kW
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj			
T_j=-7℃	Pdh	**8.7**	kW
T_j=+2℃	Pdh	**5.3**	kW
T_j=+7℃	Pdh	**3.4**	kW
T_j=+12℃	Pdh	**2.7**	kW
T_{biv}=bivalent temperature	Pdh	**9.8**	kW
T_{OL}=operation limit	Pdh	**7.4**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**—**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-

Item	Symbol	Value	Unit
Seasonal space heating energy efficiency ηs,h		**162.1**	%
Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**300.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**399.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**515.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**615.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**210.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**—**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**—**	℃

Power consumpiton in modes other than 'active mode'			
Off mode	P_{OFF}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.090**	kW
Crankcase heater mode	P_{CK}	**0.008**	kW

Supplementary heater back-up heating capacity	elbu	**—**	kW
Type of energy input Standby mode	P_{SB}	**0.008**	kW

Other items			
Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**71.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**—**	mg/kWh fuel input GCV

For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**—**	m^3/h

GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

FDUM125VSAWVH

Model(s) : FDC125VSA-W ／ FDUM125VH							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency ηs,c		**219.8**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**287.0**	%
Tj=+30℃	Pdc	**9.2**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**425.0**	%
Tj=+25℃	Pdc	**5.9**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**705.0**	%
Tj=+20℃	Pdc	**3.1**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**920.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.075**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items				For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Capacity control		**variable**					
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**–**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

Information to identify the model(s) to which the information relates :	FDC125VSA-W ／ FDUM125VH
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**14.0**	kW
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj			
T_j=-7℃	Pdh	**8.7**	kW
T_j=+2℃	Pdh	**5.3**	kW
T_j=+7℃	Pdh	**3.4**	kW
T_j=+12℃	Pdh	**2.7**	kW
T_{biv}=bivalent temperature	Pdh	**9.8**	kW
T_{OL}=operation limit	Pdh	**7.4**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**—**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-

Item	Symbol	Value	Unit
Seasonal space heating energy efficiency ηs,h		**162.1**	%
Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**300.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**399.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**515.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**615.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**210.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**—**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**—**	℃

Power consumpiton in modes other than 'active mode'			
Off mode	P_{OFF}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.090**	kW
Crankcase heater mode	P_{CK}	**0.008**	kW

Supplementary heater back-up heating capacity	elbu	**—**	kW
Type of energy input Standby mode	P_{SB}	**0.008**	kW

Other items			
Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**71.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**—**	mg/kWh fuel input GCV

For air-to-air heat pumps: air flow-rate,outdoor measured	**4,380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger	**—**	m^3/h

GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

FDUM140VNAWVH

Model(s) : FDC140VNA-W ／ FDUM140VH							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**208.8**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**265.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**390.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**680.0**	%
Tj=+20℃	Pdc	**3.2**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**900.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.090**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items				For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Capacity control		**variable**					
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**–**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

Information to identify the model(s) to which the information relates :	FDC140VNA-W ／ FDUM140VH
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj			
T_j=-7℃	Pdh	**9.3**	kW
T_j=+2℃	Pdh	**5.6**	kW
T_j=+7℃	Pdh	**3.6**	kW
T_j=+12℃	Pdh	**2.7**	kW
T_{biv}=bivalent temperature	Pdh	**10.5**	kW
T_{OL}=operation limit	Pdh	**7.9**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**—**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-

Item	Symbol	Value	Unit
Seasonal space heating energy efficiency ηs,h		**157.4**	%
Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**295.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**385.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**500.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**596.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**220.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**—**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**—**	℃

Power consumpiton in modes other than 'active mode'			
Off mode	P_{OFF}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.100**	kW
Crankcase heater mode	P_{CK}	**0.008**	kW

Supplementary heater back-up heating capacity	elbu	**—**	kW
Type of energy input Standby mode	P_{SB}	**0.008**	kW

Other items			
Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**73.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**—**	mg/kWh fuel input GCV

For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**—**	m^3/h

GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

FDUM140VSAWVH

Model(s) : FDC140VSA-W ／ FDUM140VH							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**208.8**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**265.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**390.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**680.0**	%
Tj=+20℃	Pdc	**3.2**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**900.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.090**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items				For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Capacity control		**variable**					
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**–**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

Information to identify the model(s) to which the information relates :				FDC140VSA-W ／ FDUM140VH			
Outdoor side heat exchanger of heat pump :				air			
Indoor side heat exchanger of heat pump :				air			
Indication if the heater is equipped with a supplementary heater :				No			
if applicable :				electric motor			
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW	Seasonal space heating energy efficiency ηs,h		**157.4**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**9.3**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**295.0**	%
T_j=+2℃	Pdh	**5.6**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**385.0**	%
T_j=+7℃	Pdh	**3.6**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**500.0**	%
T_j=+12℃	Pdh	**2.7**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**596.0**	%
T_{biv}=bivalent temperature	Pdh	**10.5**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	Pdh	**7.9**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**220.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**—**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**—**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**—**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**—**	kW
Off mode	P_{OFF}	**0.008**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.100**	kW				
Crankcase heater mode	P_{CK}	**0.008**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**73.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**—**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**—**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

FDUM125VNAWPVH

Model(s) : FDC125VNA-W ／ FDUM60VH (2 units)							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency ηs,c		**277.3**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**276.0**	%
Tj=+30℃	Pdc	**9.2**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**480.0**	%
Tj=+25℃	Pdc	**5.9**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**810.0**	%
Tj=+20℃	Pdc	**3.6**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1730.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**–**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

Information to identify the model(s) to which the information relates :	FDC125VNA-W ／ FDUM60VH (2 units)
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**14.0**	kW
Seasonal space heating energy efficiency ηs,h		**188.3**	%

Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj

T_j=-7℃	Pdh	**8.7**	kW
T_j=+2℃	Pdh	**5.3**	kW
T_j=+7℃	Pdh	**3.4**	kW
T_j=+12℃	Pdh	**3.0**	kW
T_{biv}=bivalent temperature	Pdh	**9.8**	kW
T_{OL}=operation limit	Pdh	**7.4**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**—**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-

Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj

T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**310.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**470.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**596.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**855.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**250.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**210.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**—**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**—**	℃

Power consumpiton in modes other than 'active mode'

Off mode	P_{OFF}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW

Supplementary heater back-up heating capacity	elbu	**—**	kW
Type of energy input Standby mode	P_{SB}	**0.008**	kW

Other items

Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**71.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**—**	mg/kWh fuel input GCV

For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**—**	m^3/h

GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

FDUM125VSAWPVH

Model(s) : FDC125VSA-W ／ FDUM60VH (2 units)							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency ηs,c		**277.3**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**276.0**	%
Tj=+30℃	Pdc	**9.2**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**480.0**	%
Tj=+25℃	Pdc	**5.9**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**810.0**	%
Tj=+20℃	Pdc	**3.6**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1730.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**–**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

Information to identify the model(s) to which the information relates :	FDC125VSA-W ／ FDUM60VH (2 units)
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**14.0**	kW
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj			
T_j=-7℃	Pdh	**8.7**	kW
T_j=+2℃	Pdh	**5.3**	kW
T_j=+7℃	Pdh	**3.4**	kW
T_j=+12℃	Pdh	**3.0**	kW
T_{biv}=bivalent temperature	Pdh	**9.8**	kW
T_{OL}=operation limit	Pdh	**7.4**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**—**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-
Power consumpiton in modes other than 'active mode'			
Off mode	P_{OFF}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW
Other items			
Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**71.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**—**	mg/kWh fuel input GCV
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Item	Symbol	Value	Unit
Seasonal space heating energy efficiency ηs,h		**188.3**	%
Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**310.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**470.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**596.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**855.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**250.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**210.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**—**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**—**	℃
Supplementary heater back-up heating capacity	elbu	**—**	kW
Type of energy input Standby mode	P_{SB}	**0.008**	kW
For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**—**	m^3/h

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

FDUM140VNAWPVH

Model(s) : FDC140VNA-W ／ FDUM71VH (2 units)							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**288.0**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**285.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**500.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**850.0**	%
Tj=+20℃	Pdc	**3.3**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1680.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**–**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

Information to identify the model(s) to which the information relates :				FDC140VNA-W ／ FDUM71VH (2 units)			
Outdoor side heat exchanger of heat pump :				air			
Indoor side heat exchanger of heat pump :				air			
Indication if the heater is equipped with a supplementary heater :				No			
if applicable :				electric motor			
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW	Seasonal space heating energy efficiency ηs,h		**205.7**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**9.3**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**335.0**	%
T_j=+2℃	Pdh	**5.6**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**506.0**	%
T_j=+7℃	Pdh	**3.6**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**678.0**	%
T_j=+12℃	Pdh	**3.1**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**933.0**	%
T_{biv}=bivalent temperature	Pdh	**10.5**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**250.0**	%
T_{OL}=operation limit	Pdh	**7.9**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**200.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**—**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**—**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**—**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**—**	kW
Off mode	P_{OFF}	**0.008**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW				
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**73.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water fiow-rate, outdoor side heat exchanger		**—**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**—**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

FDUM140VSAWPVH

Model(s) : FDC140VSA-W ／ FDUM71VH (2 units)							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**288.0**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**285.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**500.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**850.0**	%
Tj=+20℃	Pdc	**3.3**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1680.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**–**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

Information to identify the model(s) to which the information relates :				FDC140VSA-W ／ FDUM71VH (2 units)			
Outdoor side heat exchanger of heat pump :				air			
Indoor side heat exchanger of heat pump :				air			
Indication if the heater is equipped with a supplementary heater :				No			
if applicable :				electric motor			
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW	Seasonal space heating energy efficiency ηs,h		**205.7**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**9.3**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**335.0**	%
T_j=+2℃	Pdh	**5.6**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**506.0**	%
T_j=+7℃	Pdh	**3.6**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**678.0**	%
T_j=+12℃	Pdh	**3.1**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**933.0**	%
T_{biv}=bivalent temperature	Pdh	**10.5**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**250.0**	%
T_{OL}=operation limit	Pdh	**7.9**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**200.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**—**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**—**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**—**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**—**	kW
Off mode	P_{OFF}	**0.008**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW				
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**73.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**—**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**—**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

FDUM140VNAWTVH

Model(s) : FDC140VNA-W ／ FDUM50VH (3 units)							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**288.0**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**285.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**500.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**850.0**	%
Tj=+20℃	Pdc	**3.3**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1680.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**–**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

Information to identify the model(s) to which the information relates :				FDC140VNA-W ／ FDUM50VH (3 units)			
Outdoor side heat exchanger of heat pump :				air			
Indoor side heat exchanger of heat pump :				air			
Indication if the heater is equipped with a supplementary heater :				No			
if applicable :				electric motor			
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW	Seasonal space heating energy efficiency ηs,h		**205.7**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**9.3**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**335.0**	%
T_j=+2℃	Pdh	**5.6**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**506.0**	%
T_j=+7℃	Pdh	**3.6**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**678.0**	%
T_j=+12℃	Pdh	**3.1**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**933.0**	%
T_{biv}=bivalent temperature	Pdh	**10.5**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**250.0**	%
T_{OL}=operation limit	Pdh	**7.9**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**200.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**—**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**—**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**—**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**—**	kW
Off mode	P_{OFF}	**0.008**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW				
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**73.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water fiow-rate, outdoor side heat exchanger		**—**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**—**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

FDUM140VSAWTVH

Model(s) : FDC140VSA-W ／ FDUM50VH (3 units)							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**288.0**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**285.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**500.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**850.0**	%
Tj=+20℃	Pdc	**3.3**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1680.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**–**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

Information to identify the model(s) to which the information relates :	FDC140VSA-W ／ FDUM50VH (3 units)
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW
Seasonal space heating energy efficiency ηs,h		**205.7**	%

Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj

T_j=-7℃	Pdh	**9.3**	kW
T_j=+2℃	Pdh	**5.6**	kW
T_j=+7℃	Pdh	**3.6**	kW
T_j=+12℃	Pdh	**3.1**	kW
T_{biv}=bivalent temperature	Pdh	**10.5**	kW
T_{OL}=operation limit	Pdh	**7.9**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**—**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-

Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj

T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**335.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**506.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**678.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**933.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**250.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**200.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**—**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**—**	℃

Power consumpiton in modes other than 'active mode'

Off mode	P_{OFF}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW

Supplementary heater back-up heating capacity	elbu	**—**	kW
Type of energy input Standby mode	P_{SB}	**0.008**	kW

Other items

Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**73.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**—**	mg/kWh fuel input GCV

For air-to-air heat pumps: air flow-rate,outdoor measured	**4,380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger	**—**	m^3/h

GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PJG000Z491 B

Models FDUM50VH, 60VH, 71VH, 100VH, 125VH, 140VH

Model(s) : FDUM50VH							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	Prated,c	3.7	kW	Total electric power input	Pelec	0.100	kW
Cooling capacity (latent)	Prated,c	1.3	kW	Sound power level (per speed setting,if applicable)	LWA	60.0	dB
Heating capacity	Prated,h	5.4	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDUM60VH							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	Prated,c	3.9	kW	Total electric power input	Pelec	0.160	kW
Cooling capacity (latent)	Prated,c	1.7	kW	Sound power level (per speed setting,if applicable)	LWA	60.0	dB
Heating capacity	Prated,h	6.7	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDUM71VH							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	Prated,c	5.8	kW	Total electric power input	Pelec	0.200	kW
Cooling capacity (latent)	Prated,c	1.3	kW	Sound power level (per speed setting,if applicable)	LWA	65.0	dB
Heating capacity	Prated,h	8.0	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDUM100VH							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	Prated,c	7.7	kW	Total electric power input	Pelec	0.290	kW
Cooling capacity (latent)	Prated,c	2.3	kW	Sound power level (per speed setting,if applicable)	LWA	65.0	dB
Heating capacity	Prated,h	11.2	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDUM125VH							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	Prated,c	10.5	kW	Total electric power input	Pelec	0.330	kW
Cooling capacity (latent)	Prated,c	2.0	kW	Sound power level (per speed setting,if applicable)	LWA	67.0	dB
Heating capacity	Prated,h	14.0	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDUM140VH							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	Prated,c	11.2	kW	Total electric power input	Pelec	0.450	kW
Cooling capacity (latent)	Prated,c	2.8	kW	Sound power level (per speed setting,if applicable)	LWA	70.0	dB
Heating capacity	Prated,h	16.0	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

(5) Ceiling suspended type (FDE)

FDE100VNAWVH

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	**FDE100VH**
Outdoor unit model name	**FDC100VNA-W**

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Function(indicate if present)		Average(mandatory)	**Yes**
cooling	**Yes**	Warmer(if designated)	**No**
heating	**Yes**	Colder(if designated)	**No**

Item	symbol	value	unit
Design load			
cooling	Pdesignc	**10.0**	kW
heating / Average	Pdesignh	**8.5**	kW
heating / Warmer	Pdesignh	**-**	kW
heating / Colder	Pdesignh	**-**	kW

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	**6.67**	**A++**
heating / Average	SCOP/A	**4.31**	**A+**
heating / Warmer	SCOP/W	**-**	-
heating / Colder	SCOP/C	**-**	-

Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	**8.5**	kW
heating / Warmer (2℃)	Pdh	**-**	kW
heating / Colder (-22℃)	Pdh	**-**	kW

Back up heating capacity at outdoor temperature Tdesignh			unit
heating / Average (-10℃)	elbu	**0**	kW
heating / Warmer (2℃)	elbu	**-**	kW
heating / Colder (-22℃)	elbu	**-**	kW

Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	**10.00**	kW
Tj=30℃	Pdc	**7.37**	kW
Tj=25℃	Pdc	**4.74**	kW
Tj=20℃	Pdc	**3.10**	kW

Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	**3.51**	-
Tj=30℃	EERd	**5.29**	-
Tj=25℃	EERd	**8.79**	-
Tj=20℃	EERd	**10.60**	-

Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**7.40**	kW
Tj=2℃	Pdh	**4.50**	kW
Tj=7℃	Pdh	**2.90**	kW
Tj=12℃	Pdh	**2.90**	kW
Tj=bivalent temperature	Pdh	**8.50**	kW
Tj=operating limit	Pdh	**6.30**	kW

Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**3.10**	-
Tj=2℃	COPd	**4.16**	-
Tj=7℃	COPd	**5.35**	-
Tj=12℃	COPd	**6.70**	-
Tj=bivalent temperature	COPd	**2.80**	-
Tj=operating limit	COPd	**2.20**	-

Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW

Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-

Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**-**	kW
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Tj=-15℃	Pdh	**-**	kW

Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**-**	-
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Tj=-15℃	COPd	**-**	-

Bivalent temperature			
heating / Average	Tbiv	**-10**	℃
heating / Warmer	Tbiv	**-**	℃
heating / Colder	Tbiv	**-**	℃

Operating limit temperature			
heating / Average	Tol	**-20**	℃
heating / Warmer	Tol	**-**	℃
heating / Colder	Tol	**-**	℃

Cycling interval capacity			
for cooling	Pcycc	**-**	kW
for heating	Pcych	**-**	kW

Cycling interval efficiency			
for cooling	EERcyc	**-**	-
for heating	COPcyc	**-**	-

Degradation coefficient			
cooling	Cdc	**0.25**	-

Degradation coefficient			
heating	Cdh	**0.25**	-

Electric power input in power modes other than 'active mode'			
off mode	Poff	**8**	W
standby mode	Psb	**8**	W
thermostat-off mode	Pto(cooling)	**26**	W
	Pto(heating)	**43**	W
crankcase heater mode	Pck	**5**	W

Annual electricity consumption			
cooling	Qce	**525**	kWh/a
heating / Average	Qhe	**2764**	kWh/a
heating / Warmer	Qhe	**-**	kWh/a
heating / colder	Qhe	**-**	kWh/a

Capacity control(indicate one of three options)	
fixed	**No**
staged	**No**
variable	**Yes**

Other items			
Sound power level(indoor)	Lwa	**62**	dB(A)
Sound power level(outdoor)	Lwa	**69**	dB(A)
Global warming potential	GWP	**675**	$kgCO_2eq.$
Rated air flow(indoor)	-	**1920**	m^3/h
Rated air flow(outdoor)	-	**4500**	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex, UB11 1ET, United Kingdom

PFA004Z088 B

FDE100VSAWVH

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	**FDE100VH**
Outdoor unit model name	**FDC100VSA-W**

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Function(indicate if present)		Average(mandatory)	**Yes**
cooling	**Yes**	Warmer(if designated)	**No**
heating	**Yes**	Colder(if designated)	**No**

Item	symbol	value	unit
Design load			
cooling	Pdesignc	**10.0**	kW
heating / Average	Pdesignh	**8.5**	kW
heating / Warmer	Pdesignh	**-**	kW
heating / Colder	Pdesignh	**-**	kW

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	**6.67**	**A++**
heating / Average	SCOP/A	**4.31**	**A+**
heating / Warmer	SCOP/W	**-**	-
heating / Colder	SCOP/C	**-**	-

Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	**8.5**	kW
heating / Warmer (2℃)	Pdh	**-**	kW
heating / Colder (-22℃)	Pdh	**-**	kW

Back up heating capacity at outdoor temperature Tdesignh			unit
heating / Average (-10℃)	elbu	**0**	kW
heating / Warmer (2℃)	elbu	**-**	kW
heating / Colder (-22℃)	elbu	**-**	kW

Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	**10.00**	kW
Tj=30℃	Pdc	**7.37**	kW
Tj=25℃	Pdc	**4.74**	kW
Tj=20℃	Pdc	**3.10**	kW

Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	**3.51**	-
Tj=30℃	EERd	**5.29**	-
Tj=25℃	EERd	**8.79**	-
Tj=20℃	EERd	**10.60**	-

Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**7.40**	kW
Tj=2℃	Pdh	**4.50**	kW
Tj=7℃	Pdh	**2.90**	kW
Tj=12℃	Pdh	**2.90**	kW
Tj=bivalent temperature	Pdh	**8.50**	kW
Tj=operating limit	Pdh	**6.30**	kW

Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**3.10**	-
Tj=2℃	COPd	**4.16**	-
Tj=7℃	COPd	**5.35**	-
Tj=12℃	COPd	**6.70**	-
Tj=bivalent temperature	COPd	**2.80**	-
Tj=operating limit	COPd	**2.20**	-

Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW

Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-

Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**-**	kW
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Tj=-15℃	Pdh	**-**	kW

Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**-**	-
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Tj=-15℃	COPd	**-**	-

Bivalent temperature			
heating / Average	Tbiv	**-10**	℃
heating / Warmer	Tbiv	**-**	℃
heating / Colder	Tbiv	**-**	℃

Operating limit temperature			
heating / Average	Tol	**-20**	℃
heating / Warmer	Tol	**-**	℃
heating / Colder	Tol	**-**	℃

Cycling interval capacity			
for cooling	Pcycc	**-**	kW
for heating	Pcych	**-**	kW

Cycling interval efficiency			
for cooling	EERcyc	**-**	-
for heating	COPcyc	**-**	-

Degradation coefficient			
cooling	Cdc	**0.25**	-

Degradation coefficient			
heating	Cdh	**0.25**	-

Electric power input in power modes other than 'active mode'			
off mode	Poff	**8**	W
standby mode	Psb	**8**	W
thermostat-off mode	Pto(cooling)	**26**	W
	Pto(heating)	**43**	W
crankcase heater mode	Pck	**5**	W

Annual electricity consumption			
cooling	Qce	**525**	kWh/a
heating / Average	Qhe	**2764**	kWh/a
heating / Warmer	Qhe	**-**	kWh/a
heating / colder	Qhe	**-**	kWh/a

Capacity control(indicate one of three options)	
fixed	**No**
staged	**No**
variable	**Yes**

Other items			
Sound power level(indoor)	Lwa	**62**	dB(A)
Sound power level(outdoor)	Lwa	**69**	dB(A)
Global warming potential	GWP	**675**	$kgCO_2eq.$
Rated air flow(indoor)	-	**1920**	m^3/h
Rated air flow(outdoor)	-	**4500**	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex, UB11 1ET, United Kingdom

PFA004Z088 B

FDE100VNAWPVH

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	FDE50VHx2
Outdoor unit model name	FDC100VNA-W

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Function(indicate if present)	
cooling	Yes
heating	Yes

Average(mandatory)	Yes
Warmer(if designated)	No
Colder(if designated)	No

Item	symbol	value	unit
Design load			
cooling	Pdesignc	10.0	kW
heating / Average	Pdesignh	8.5	kW
heating / Warmer	Pdesignh	-	kW
heating / Colder	Pdesignh	-	kW

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	6.16	A++
heating / Average	SCOP/A	4.10	A+
heating / Warmer	SCOP/W	-	-
heating / Colder	SCOP/C	-	-

Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	8.5	kW
heating / Warmer (2℃)	Pdh	-	kW
heating / Colder (-22℃)	Pdh	-	kW

Back up heating capacity at outdoor temperature Tdesignh			unit
heating / Average (-10℃)	elbu	0	kW
heating / Warmer (2℃)	elbu	-	kW
heating / Colder (-22℃)	elbu	-	kW

Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	10.00	kW
Tj=30℃	Pdc	7.37	kW
Tj=25℃	Pdc	4.74	kW
Tj=20℃	Pdc	3.30	kW

Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	3.21	-
Tj=30℃	EERd	5.20	-
Tj=25℃	EERd	7.40	-
Tj=20℃	EERd	12.40	-

Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	7.40	kW
Tj=2℃	Pdh	4.50	kW
Tj=7℃	Pdh	2.90	kW
Tj=12℃	Pdh	2.87	kW
Tj=bivalent temperature	Pdh	8.50	kW
Tj=operating limit	Pdh	6.30	kW

Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	2.89	-
Tj=2℃	COPd	4.14	-
Tj=7℃	COPd	4.89	-
Tj=12℃	COPd	5.85	-
Tj=bivalent temperature	COPd	2.30	-
Tj=operating limit	COPd	2.25	-

Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	-	kW
Tj=7℃	Pdh	-	kW
Tj=12℃	Pdh	-	kW
Tj=bivalent temperature	Pdh	-	kW
Tj=operating limit	Pdh	-	kW

Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	-	-
Tj=7℃	COPd	-	-
Tj=12℃	COPd	-	-
Tj=bivalent temperature	COPd	-	-
Tj=operating limit	COPd	-	-

Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	-	kW
Tj=2℃	Pdh	-	kW
Tj=7℃	Pdh	-	kW
Tj=12℃	Pdh	-	kW
Tj=bivalent temperature	Pdh	-	kW
Tj=operating limit	Pdh	-	kW
Tj=-15℃	Pdh	-	kW

Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	-	-
Tj=2℃	COPd	-	-
Tj=7℃	COPd	-	-
Tj=12℃	COPd	-	-
Tj=bivalent temperature	COPd	-	-
Tj=operating limit	COPd	-	-
Tj=-15℃	COPd	-	-

Bivalent temperature			
heating / Average	Tbiv	-10	℃
heating / Warmer	Tbiv	-	℃
heating / Colder	Tbiv	-	℃

Operating limit temperature			
heating / Average	Tol	-20	℃
heating / Warmer	Tol	-	℃
heating / Colder	Tol	-	℃

Cycling interval capacity			
for cooling	Pcycc	-	kW
for heating	Pcych	-	kW

Cycling interval efficiency			
for cooling	EERcyc	-	-
for heating	COPcyc	-	-

Degradation coefficient			
cooling	Cdc	0.25	-

Degradation coefficient			
heating	Cdh	0.25	-

Electric power input in power modes other than 'active mode'			
off mode	Poff	15	W
standby mode	Psb	15	W
thermostat-off mode	Pto(cooling)	35	W
	Pto(heating)	55	W
crankcase heater mode	Pck	5	W

Annual electricity consumption			
cooling	Qce	569	kWh/a
heating / Average	Qhe	2906	kWh/a
heating / Warmer	Qhe	-	kWh/a
heating / colder	Qhe	-	kWh/a

Capacity control(indicate one of three options)	
fixed	No
staged	No
variable	Yes

Other items			
Sound power level(indoor)	Lwa	62	dB(A)
Sound power level(outdoor)	Lwa	69	dB(A)
Global warming potential	GWP	675	$kgCO_2eq.$
Rated air flow(indoor)	-	780	m^3/h
Rated air flow(outdoor)	-	4500	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex, UB11 1ET, United Kingdom

PFA004Z088 B

FDE100VSAWPVH

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	FDE50VHx2
Outdoor unit model name	FDC100VSA-W

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Function(indicate if present)	
cooling	Yes
heating	Yes

Average(mandatory)	Yes
Warmer(if designated)	No
Colder(if designated)	No

Item	symbol	value	unit
Design load			
cooling	Pdesignc	10.0	kW
heating / Average	Pdesignh	8.5	kW
heating / Warmer	Pdesignh	-	kW
heating / Colder	Pdesignh	-	kW

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	6.16	A++
heating / Average	SCOP/A	4.10	A+
heating / Warmer	SCOP/W	-	-
heating / Colder	SCOP/C	-	-

Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	8.5	kW
heating / Warmer (2℃)	Pdh	-	kW
heating / Colder (-22℃)	Pdh	-	kW

Back up heating capacity at outdoor temperature Tdesignh			unit
heating / Average (-10℃)	elbu	0	kW
heating / Warmer (2℃)	elbu	-	kW
heating / Colder (-22℃)	elbu	-	kW

Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	10.00	kW
Tj=30℃	Pdc	7.37	kW
Tj=25℃	Pdc	4.74	kW
Tj=20℃	Pdc	3.30	kW

Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	3.21	-
Tj=30℃	EERd	5.20	-
Tj=25℃	EERd	7.40	-
Tj=20℃	EERd	12.40	-

Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	7.40	kW
Tj=2℃	Pdh	4.50	kW
Tj=7℃	Pdh	2.90	kW
Tj=12℃	Pdh	2.87	kW
Tj=bivalent temperature	Pdh	8.50	kW
Tj=operating limit	Pdh	6.30	kW

Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	2.89	-
Tj=2℃	COPd	4.14	-
Tj=7℃	COPd	4.89	-
Tj=12℃	COPd	5.85	-
Tj=bivalent temperature	COPd	2.30	-
Tj=operating limit	COPd	2.25	-

Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	-	kW
Tj=7℃	Pdh	-	kW
Tj=12℃	Pdh	-	kW
Tj=bivalent temperature	Pdh	-	kW
Tj=operating limit	Pdh	-	kW

Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	-	-
Tj=7℃	COPd	-	-
Tj=12℃	COPd	-	-
Tj=bivalent temperature	COPd	-	-
Tj=operating limit	COPd	-	-

Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	-	kW
Tj=2℃	Pdh	-	kW
Tj=7℃	Pdh	-	kW
Tj=12℃	Pdh	-	kW
Tj=bivalent temperature	Pdh	-	kW
Tj=operating limit	Pdh	-	kW
Tj=-15℃	Pdh	-	kW

Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	-	-
Tj=2℃	COPd	-	-
Tj=7℃	COPd	-	-
Tj=12℃	COPd	-	-
Tj=bivalent temperature	COPd	-	-
Tj=operating limit	COPd	-	-
Tj=-15℃	COPd	-	-

Bivalent temperature			
heating / Average	Tbiv	-10	℃
heating / Warmer	Tbiv	-	℃
heating / Colder	Tbiv	-	℃

Operating limit temperature			
heating / Average	Tol	-20	℃
heating / Warmer	Tol	-	℃
heating / Colder	Tol	-	℃

Cycling interval capacity			
for cooling	Pcycc	-	kW
for heating	Pcych	-	kW

Cycling interval efficiency			
for cooling	EERcyc	-	-
for heating	COPcyc	-	-

Degradation coefficient			
cooling	Cdc	0.25	-

Degradation coefficient			
heating	Cdh	0.25	-

Electric power input in power modes other than 'active mode'			
off mode	Poff	15	W
standby mode	Psb	15	W
thermostat-off mode	Pto(cooling)	35	W
	Pto(heating)	55	W
crankcase heater mode	Pck	5	W

Annual electricity consumption			
cooling	Qce	569	kWh/a
heating / Average	Qhe	2906	kWh/a
heating / Warmer	Qhe	-	kWh/a
heating / colder	Qhe	-	kWh/a

Capacity control(indicate one of three options)	
fixed	No
staged	No
variable	Yes

Other items			
Sound power level(indoor)	Lwa	62	dB(A)
Sound power level(outdoor)	Lwa	69	dB(A)
Global warming potential	GWP	675	$kgCO_2eq.$
Rated air flow(indoor)	-	780	m^3/h
Rated air flow(outdoor)	-	4500	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex, UB11 1ET, United Kingdom

PFA004Z088 B

FDE125VNAWVH

Model(s) :	FDC125VNA-W ／ FDE125VH						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency	η s,c	**238.1**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**281.0**	%
Tj=+30℃	Pdc	**9.2**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**449.0**	%
Tj=+25℃	Pdc	**5.9**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**739.0**	%
Tj=+20℃	Pdc	**3.1**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1034.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.030**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

Information to identify the model(s) to which the information relates : FDC125VNA-W ／FDE125VH							
Outdoor side heat exchanger of heat pump : air							
Indoor side heat exchanger of heat pump : air							
Indication if the heater is equipped with a supplementary heater : No							
if applicable : electric motor							
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**14.0**	kW	Seasonal space heating energy efficiency	η s,h	**169.1**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**8.7**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,l	**300.0**	%
T_j=+2℃	Pdh	**5.3**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,l	**415.0**	%
T_j=+7℃	Pdh	**3.4**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,l	**545.0**	%
T_j=+12℃	Pdh	**3.0**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,l	**675.0**	%
T_{biv}=bivalent temperature	Pdh	**9.8**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,l	**270.0**	%
T_{OL}=operation limit	Pdh	**7.4**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,l	**220.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,l	**-**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**-**	kW
Off mode	P_{OFF}	**0.008**	kW				
Thermostat-off mode	P_{TO}	**0.045**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**71.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water fiow-rate, outdoor side heat exchanger		**-**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.
*** from 26 September 2018
Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

FDE125VSAWVH

Model(s) :	FDC125VSA-W ／ FDE125VH						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency	η s,c	**238.1**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**281.0**	%
Tj=+30℃	Pdc	**9.2**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**449.0**	%
Tj=+25℃	Pdc	**5.9**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**739.0**	%
Tj=+20℃	Pdc	**3.1**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1034.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.030**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

Information to identify the model(s) to which the information relates : FDC125VSA-W ／ FDE125VH							
Outdoor side heat exchanger of heat pump : air							
Indoor side heat exchanger of heat pump : air							
Indication if the heater is equipped with a supplementary heater : No							
if applicable : electric motor							
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**14.0**	kW	Seasonal space heating energy efficiency	η s,h	**169.1**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**8.7**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,l	**300.0**	%
T_j=+2℃	Pdh	**5.3**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,l	**415.0**	%
T_j=+7℃	Pdh	**3.4**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,l	**545.0**	%
T_j=+12℃	Pdh	**3.0**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,l	**675.0**	%
T_{biv}=bivalent temperature	Pdh	**9.8**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,l	**270.0**	%
T_{OL}=operation limit	Pdh	**7.4**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,l	**220.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,l	**-**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**-**	kW
Off mode	P_{OFF}	**0.008**	kW				
Thermostat-off mode	P_{TO}	**0.045**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**71.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**-**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.
*** from 26 September 2018
Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

FDE140VNAWVH

Model(s) : FDC140VNA-W ／ FDE140VH							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency	η s,c	**227.6**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**269.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**420.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**682.0**	%
Tj=+20℃	Pdc	**3.1**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1034.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.030**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

Information to identify the model(s) to which the information relates : FDC140VNA-W ／ FDE140VH							
Outdoor side heat exchanger of heat pump : air							
Indoor side heat exchanger of heat pump : air							
Indication if the heater is equipped with a supplementary heater : No							
if applicable : electric motor							
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW	Seasonal space heating energy efficiency	η s,h	**166.6**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**9.2**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,l	**290.0**	%
T_j=+2℃	Pdh	**5.6**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,l	**410.0**	%
T_j=+7℃	Pdh	**3.6**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,l	**540.0**	%
T_j=+12℃	Pdh	**3.0**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,l	**675.0**	%
T_{biv}=bivalent temperature	Pdh	**10.5**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,l	**250.0**	%
T_{OL}=operation limit	Pdh	**7.9**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,l	**210.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,l	**-**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**-**	kW
Off mode	P_{OFF}	**0.008**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.045**	kW				
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**73.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water fiow-rate, outdoor side heat exchanger		**-**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.
*** from 26 September 2018
Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

FDE140VSAWVH

Model(s) :	FDC140VSA-W ／ FDE140VH						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency	η s,c	**227.6**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**269.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**420.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**682.0**	%
Tj=+20℃	Pdc	**3.1**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1034.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.030**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

Information to identify the model(s) to which the information relates : FDC140VSA-W ／ FDE140VH							
Outdoor side heat exchanger of heat pump : air							
Indoor side heat exchanger of heat pump : air							
Indication if the heater is equipped with a supplementary heater : No							
if applicable : electric motor							
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW	Seasonal space heating energy efficiency	η s,h	**166.6**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**9.2**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,l	**290.0**	%
T_j=+2℃	Pdh	**5.6**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,l	**410.0**	%
T_j=+7℃	Pdh	**3.6**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,l	**540.0**	%
T_j=+12℃	Pdh	**3.0**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,l	**675.0**	%
T_{biv}=bivalent temperature	Pdh	**10.5**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,l	**250.0**	%
T_{OL}=operation limit	Pdh	**7.9**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,l	**210.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,l	**-**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**-**	kW
Off mode	P_{OFF}	**0.008**	kW				
Thermostat-off mode	P_{TO}	**0.045**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**73.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**-**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.
*** from 26 September 2018
Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

FDE125VNAWPVH

Model(s) :	FDC125VNA-W ／ FDE60VH (2units)						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency	η s,c	**294.7**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**303.0**	%
Tj=+30℃	Pdc	**9.2**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**487.0**	%
Tj=+25℃	Pdc	**5.9**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**853.0**	%
Tj=+20℃	Pdc	**3.5**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1995.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

Information to identify the model(s) to which the information relates : FDC125VNA-W ／ FDE60VH (2units)							
Outdoor side heat exchanger of heat pump : air							
Indoor side heat exchanger of heat pump : air							
Indication if the heater is equipped with a supplementary heater : No							
if applicable : electric motor							
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**14.0**	kW	Seasonal space heating energy efficiency	η s,h	**198.8**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**8.7**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,l	**324.0**	%
T_j=+2℃	Pdh	**5.3**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,l	**487.0**	%
T_j=+7℃	Pdh	**3.4**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,l	**655.0**	%
T_j=+12℃	Pdh	**3.0**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,l	**905.0**	%
T_{biv}=bivalent temperature	Pdh	**9.8**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,l	**280.0**	%
T_{OL}=operation limit	Pdh	**7.4**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,l	**230.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,l	**-**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**-**	kW
Off mode	P_{OFF}	**0.008**	kW				
Thermostat-off mode	P_{TO}	**0.020**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**71.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water fiow-rate, outdoor side heat exchanger		**-**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.
*** from 26 September 2018
Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

FDE125VSAWPVH

Model(s) :	FDC125VSA-W ／ FDE60VH (2units)						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency	η s,c	**294.7**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**303.0**	%
Tj=+30℃	Pdc	**9.2**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**487.0**	%
Tj=+25℃	Pdc	**5.9**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**853.0**	%
Tj=+20℃	Pdc	**3.5**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**1995.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

Information to identify the model(s) to which the information relates : FDC125VSA-W ／ FDE60VH (2units)							
Outdoor side heat exchanger of heat pump : air							
Indoor side heat exchanger of heat pump : air							
Indication if the heater is equipped with a supplementary heater : No							
if applicable : electric motor							
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**14.0**	kW	Seasonal space heating energy efficiency	η s,h	**198.8**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**8.7**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,b	**324.0**	%
T_j=+2℃	Pdh	**5.3**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,b	**487.0**	%
T_j=+7℃	Pdh	**3.4**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,b	**655.0**	%
T_j=+12℃	Pdh	**3.0**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,b	**905.0**	%
T_{biv}=bivalent temperature	Pdh	**9.8**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,b	**280.0**	%
T_{OL}=operation limit	Pdh	**7.4**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,b	**230.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,b	**-**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**-**	kW
Off mode	P_{OFF}	**0.008**	kW				
Thermostat-off mode	P_{TO}	**0.020**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**71.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**-**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.
*** from 26 September 2018
Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

FDE140VNAWPVH

Model(s) :	FDC140VNA-W ／ FDE71VH (2units)						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency	η s,c	**279.5**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**287.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**456.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**789.0**	%
Tj=+20℃	Pdc	**3.7**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**2026.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

Information to identify the model(s) to which the information relates : FDC140VNA-W ／ FDE71VH (2units)							
Outdoor side heat exchanger of heat pump : air							
Indoor side heat exchanger of heat pump : air							
Indication if the heater is equipped with a supplementary heater : No							
if applicable : electric motor							
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW	Seasonal space heating energy efficiency	η s,h	**188.8**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**9.3**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,l	**296.0**	%
T_j=+2℃	Pdh	**5.6**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,l	**467.0**	%
T_j=+7℃	Pdh	**3.6**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,l	**628.0**	%
T_j=+12℃	Pdh	**3.1**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,l	**867.0**	%
T_{biv}=bivalent temperature	Pdh	**10.5**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,l	**260.0**	%
T_{OL}=operation limit	Pdh	**7.9**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,l	**220.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,l	**-**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**-**	kW
Off mode	P_{OFF}	**0.008**	kW				
Thermostat-off mode	P_{TO}	**0.020**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**73.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water fiow-rate, outdoor side heat exchanger		**-**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.
*** from 26 September 2018
Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

FDE140VSAWPVH

Model(s) :	FDC140VSA-W ／ FDE71VH (2units)						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency	η s,c	**279.5**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**287.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**456.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**789.0**	%
Tj=+20℃	Pdc	**3.7**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**2026.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

Information to identify the model(s) to which the information relates : FDC140VSA-W ／ FDE71VH (2units)							
Outdoor side heat exchanger of heat pump : air							
Indoor side heat exchanger of heat pump : air							
Indication if the heater is equipped with a supplementary heater : No							
if applicable : electric motor							
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW	Seasonal space heating energy efficiency	η s,h	**188.8**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**9.3**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,b	**296.0**	%
T_j=+2℃	Pdh	**5.6**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,b	**467.0**	%
T_j=+7℃	Pdh	**3.6**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,b	**628.0**	%
T_j=+12℃	Pdh	**3.1**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,b	**867.0**	%
T_{biv}=bivalent temperature	Pdh	**10.5**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,b	**260.0**	%
T_{OL}=operation limit	Pdh	**7.9**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,b	**220.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,b	**-**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**-**	kW
Off mode	P_{OFF}	**0.008**	kW				
Thermostat-off mode	P_{TO}	**0.020**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**73.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**-**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.
*** from 26 September 2018
Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

FDE140VNAWTVH

Model(s) :	FDC140VNA-W ／ FDE50VH (3units)						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency	η s,c	**279.5**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**287.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**456.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**789.0**	%
Tj=+20℃	Pdc	**3.7**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**2026.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

Information to identify the model(s) to which the information relates : FDC140VNA-W ／ FDE50VH (3units)							
Outdoor side heat exchanger of heat pump : air							
Indoor side heat exchanger of heat pump : air							
Indication if the heater is equipped with a supplementary heater : No							
if applicable : electric motor							
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW	Seasonal space heating energy efficiency	η s,h	**188.8**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**9.3**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,l	**296.0**	%
T_j=+2℃	Pdh	**5.6**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,l	**467.0**	%
T_j=+7℃	Pdh	**3.6**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,l	**628.0**	%
T_j=+12℃	Pdh	**3.1**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,l	**867.0**	%
T_{biv}=bivalent temperature	Pdh	**10.5**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,l	**260.0**	%
T_{OL}=operation limit	Pdh	**7.9**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,l	**220.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,l	**-**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**-**	kW
Off mode	P_{OFF}	**0.008**	kW				
Thermostat-off mode	P_{TO}	**0.020**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**73.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**-**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.
*** from 26 September 2018
Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

FDE140VSAWTVH

Model(s) : FDC140VSA-W ／ FDE50VH (3units)							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency	η s,c	**279.5**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**287.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**456.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**789.0**	%
Tj=+20℃	Pdc	**3.7**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**2026.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4,500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

Information to identify the model(s) to which the information relates : FDC140VSA-W ／ FDE50VH (3units)							
Outdoor side heat exchanger of heat pump : air							
Indoor side heat exchanger of heat pump : air							
Indication if the heater is equipped with a supplementary heater : No							
if applicable : electric motor							
Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW	Seasonal space heating energy efficiency	η s,h	**188.8**	%
Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj				Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
T_j=-7℃	Pdh	**9.3**	kW	T_j=-7℃	COPd or GUEh,bin / AEFh,b	**296.0**	%
T_j=+2℃	Pdh	**5.6**	kW	T_j=+2℃	COPd or GUEh,bin / AEFh,b	**467.0**	%
T_j=+7℃	Pdh	**3.6**	kW	T_j=+7℃	COPd or GUEh,bin / AEFh,b	**628.0**	%
T_j=+12℃	Pdh	**3.1**	kW	T_j=+12℃	COPd or GUEh,bin / AEFh,b	**867.0**	%
T_{biv}=bivalent temperature	Pdh	**10.5**	kW	T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,b	**260.0**	%
T_{OL}=operation limit	Pdh	**7.9**	kW	T_{OL}=operation limit	COPd or GUEh,bin / AEFh,b	**220.0**	%
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW	For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,b	**-**	%
Bivalent temperature	T_{biv}	**-10.0**	℃	For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-				
Power consumpiton in modes other than 'active mode'				Supplementary heater back-up heating capacity	elbu	**-**	kW
Off mode	P_{OFF}	**0.008**	kW				
Thermostat-off mode	P_{TO}	**0.020**	kW	Type of energy input Standby mode	P_{SB}	**0.008**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW				
Other items							
Capacity control		**variable**		For air-to-air heat pumps: air flow-rate,outdoor measured		**4,380**	m^3/h
Sound power level, outdoor measured	L_{WA}	**73.0**	dB	For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**-**	m^3/h
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.
*** from 26 September 2018
Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PFA004Z088 B

Models FDE50VH, 60VH, 71VH, 100VH, 125VH, 140VH

Model(s) : FDE50VH							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	$P_{rated,c}$	3.8	kW	Total electric power input	P_{elec}	0.050	kW
Cooling capacity (latent)	$P_{rated,c}$	1.2	kW	Sound power level (per speed setting,if applicable)	L_{WA}	60.0	dB
Heating capacity	$P_{rated,h}$	5.4	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDE60VH							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	$P_{rated,c}$	5.0	kW	Total electric power input	P_{elec}	0.080	kW
Cooling capacity (latent)	$P_{rated,c}$	0.6	kW	Sound power level (per speed setting,if applicable)	L_{WA}	60.0	dB
Heating capacity	$P_{rated,h}$	6.7	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDE71VH							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	$P_{rated,c}$	5.6	kW	Total electric power input	P_{elec}	0.080	kW
Cooling capacity (latent)	$P_{rated,c}$	1.5	kW	Sound power level (per speed setting,if applicable)	L_{WA}	60.0	dB
Heating capacity	$P_{rated,h}$	8.0	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDE100VH							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	$P_{rated,c}$	8.4	kW	Total electric power input	P_{elec}	0.130	kW
Cooling capacity (latent)	$P_{rated,c}$	1.6	kW	Sound power level (per speed setting,if applicable)	L_{WA}	64.0	dB
Heating capacity	$P_{rated,h}$	11.2	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDE125VH							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	$P_{rated,c}$	9.3	kW	Total electric power input	P_{elec}	0.130	kW
Cooling capacity (latent)	$P_{rated,c}$	3.2	kW	Sound power level (per speed setting,if applicable)	L_{WA}	64.0	dB
Heating capacity	$P_{rated,h}$	14.0	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : FDE140VH							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	$P_{rated,c}$	10.2	kW	Total electric power input	P_{elec}	0.140	kW
Cooling capacity (latent)	$P_{rated,c}$	3.8	kW	Sound power level (per speed setting,if applicable)	L_{WA}	65.0	dB
Heating capacity	$P_{rated,h}$	16.0	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

PFA004Z088 B

(6) Wall mounted type (SRK)

SRK100VNAWZR

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	**SRK100ZR-W**
Outdoor unit model name	**FDC100VNA-W**

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Function(indicate if present)	
cooling	**Yes**
heating	**Yes**

Average(mandatory)	**Yes**
Warmer(if designated)	**No**
Colder(if designated)	**No**

Item	symbol	value	unit
Design load			
cooling	Pdesignc	**10.0**	kW
heating / Average	Pdesignh	**8.50**	kW
heating / Warmer	Pdesignh	**-**	kW
heating / Colder	Pdesignh	**-**	kW

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	**6.13**	**A++**
heating / Average	SCOP/A	**4.33**	**A+**
heating / Warmer	SCOP/W	**-**	-
heating / Colder	SCOP/C	**-**	-
			unit

Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	**8.50**	kW
heating / Warmer (2℃)	Pdh	**-**	kW
heating / Colder (-22℃)	Pdh	**-**	kW

Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	elbu	**0**	kW
heating / Warmer (2℃)	elbu	**-**	kW
heating / Colder (-22℃)	elbu	**-**	kW

Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	**10.00**	kW
Tj=30℃	Pdc	**7.37**	kW
Tj=25℃	Pdc	**4.74**	kW
Tj=20℃	Pdc	**3.00**	kW

Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	**3.10**	-
Tj=30℃	EERd	**4.95**	-
Tj=25℃	EERd	**7.75**	-
Tj=20℃	EERd	**10.05**	-

Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**7.36**	kW
Tj=2℃	Pdh	**4.47**	kW
Tj=7℃	Pdh	**2.88**	kW
Tj=12℃	Pdh	**2.95**	kW
Tj=bivalent temperature	Pdh	**8.50**	kW
Tj=operating limit	Pdh	**6.30**	kW

Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**2.75**	-
Tj=2℃	COPd	**4.18**	-
Tj=7℃	COPd	**5.74**	-
Tj=12℃	COPd	**7.46**	-
Tj=bivalent temperature	COPd	**2.77**	-
Tj=operating limit	COPd	**2.10**	-

Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW

Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-

Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**-**	kW
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Tj=-15℃	Pdh	**-**	kW

Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**-**	-
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Tj=-15℃	COPd	**-**	-

Bivalent temperature			
heating / Average	Tbiv	**-10**	℃
heating / Warmer	Tbiv	**-**	℃
heating / Colder	Tbiv	**-**	℃

Operating limit temperature			
heating / Average	Tol	**-20**	℃
heating / Warmer	Tol	**-**	℃
heating / Colder	Tol	**-**	℃

Cycling interval capacity			
for cooling	Pcycc	**-**	kW
for heating	Pcych	**-**	kW

Cycling interval efficiency			
for cooling	EERcyc	**-**	-
for heating	COPcyc	**-**	-

Degradation coefficient			
cooling	Cdc	**0.25**	-

Degradation coefficient			
heating	Cdh	**0.25**	-

Electric power input in power modes other than 'active mode'			
off mode	Poff	**7**	W
standby mode	Psb	**7**	W
thermostat-off mode	Pto(cooling)	**30**	W
	Pto(heating)	**30**	W
crankcase heater mode	Pck	**5**	W

Annual electricity consumption			
cooling	Qce	**571**	kWh/a
heating / Average	Qhe	**2746**	kWh/a
heating / Warmer	Qhe	**-**	kWh/a
heating / colder	Qhe	**-**	kWh/a

Capacity control(indicate one of three options)	
fixed	**No**
staged	**No**
variable	**Yes**

Other items			
Sound power level(indoor)	Lwa	**63**	dB(A)
Sound power level(outdoor)	Lwa	**69**	dB(A)
Global warming potential	GWP	**675**	$kgCO_2eq.$
Rated air flow(indoor)	-	**1470**	m^3/h
Rated air flow(outdoor)	-	**4500**	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex,UB11 1ET, United kingdom

PCA001Z857A

SRK100VSAWZR

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	**SRK100ZR-W**
Outdoor unit model name	**FDC100VSA-W**

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Function(indicate if present)	
cooling	**Yes**
heating	**Yes**

Average(mandatory)	**Yes**
Warmer(if designated)	**No**
Colder(if designated)	**No**

Item	symbol	value	unit
Design load			
cooling	Pdesignc	**10.0**	kW
heating / Average	Pdesignh	**8.50**	kW
heating / Warmer	Pdesignh	**-**	kW
heating / Colder	Pdesignh	**-**	kW
Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	**8.50**	kW
heating / Warmer (2℃)	Pdh	**-**	kW
heating / Colder (-22℃)	Pdh	**-**	kW
Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	**10.00**	kW
Tj=30℃	Pdc	**7.37**	kW
Tj=25℃	Pdc	**4.74**	kW
Tj=20℃	Pdc	**3.00**	kW
Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**7.36**	kW
Tj=2℃	Pdh	**4.47**	kW
Tj=7℃	Pdh	**2.88**	kW
Tj=12℃	Pdh	**2.95**	kW
Tj=bivalent temperature	Pdh	**8.50**	kW
Tj=operating limit	Pdh	**6.30**	kW
Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**-**	kW
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Tj=-15℃	Pdh	**-**	kW
Bivalent temperature			
heating / Average	Tbiv	**-10**	℃
heating / Warmer	Tbiv	**-**	℃
heating / Colder	Tbiv	**-**	℃
Cycling interval capacity			
for cooling	Pcycc	**-**	kW
for heating	Pcych	**-**	kW
Degradation coefficient			
cooling	Cdc	**0.25**	-
Electric power input in power modes other than 'active mode'			
off mode	Poff	**7**	W
standby mode	Psb	**7**	W
thermostat-off mode	Pto(cooling)	**30**	W
	Pto(heating)	**30**	W
crankcase heater mode	Pck	**5**	W

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	**6.13**	**A++**
heating / Average	SCOP/A	**4.33**	**A+**
heating / Warmer	SCOP/W	**-**	-
heating / Colder	SCOP/C	**-**	-
			unit
Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	elbu	**0**	kW
heating / Warmer (2℃)	elbu	**-**	kW
heating / Colder (-22℃)	elbu	**-**	kW
Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	**3.10**	-
Tj=30℃	EERd	**4.95**	-
Tj=25℃	EERd	**7.75**	-
Tj=20℃	EERd	**10.05**	-
Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**2.75**	-
Tj=2℃	COPd	**4.18**	-
Tj=7℃	COPd	**5.74**	-
Tj=12℃	COPd	**7.46**	-
Tj=bivalent temperature	COPd	**2.77**	-
Tj=operating limit	COPd	**2.10**	-
Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**-**	-
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Tj=-15℃	COPd	**-**	-
Operating limit temperature			
heating / Average	Tol	**-20**	℃
heating / Warmer	Tol	**-**	℃
heating / Colder	Tol	**-**	℃
Cycling interval efficiency			
for cooling	EERcyc	**-**	-
for heating	COPcyc	**-**	-
Degradation coefficient			
heating	Cdh	**0.25**	-
Annual electricity consumption			
cooling	Qce	**571**	kWh/a
heating / Average	Qhe	**2746**	kWh/a
heating / Warmer	Qhe	**-**	kWh/a
heating / colder	Qhe	**-**	kWh/a

Capacity control(indicate one of three options)	
fixed	**No**
staged	**No**
variable	**Yes**

Other items			
Sound power level(indoor)	Lwa	**63**	dB(A)
Sound power level(outdoor)	Lwa	**69**	dB(A)
Global warming potential	GWP	**675**	$kgCO_2eq.$
Rated air flow(indoor)	-	**1470**	m^3/h
Rated air flow(outdoor)	-	**4500**	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex,UB11 1ET, United kingdom

PCA001Z857A

SRK100VNAWPZSX

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	**SRK50ZSX-W (x2 units)**
Outdoor unit model name	**FDC100VNA-W**

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Function(indicate if present)	
cooling	**Yes**
heating	**Yes**

Average(mandatory)	**Yes**
Warmer(if designated)	**No**
Colder(if designated)	**No**

Item	symbol	value	unit
Design load			
cooling	Pdesignc	**10.0**	kW
heating / Average	Pdesignh	**8.50**	kW
heating / Warmer	Pdesignh	**-**	kW
heating / Colder	Pdesignh	**-**	kW

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	**7.05**	**A++**
heating / Average	SCOP/A	**4.47**	**A+**
heating / Warmer	SCOP/W	**-**	-
heating / Colder	SCOP/C	**-**	-

Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	**8.50**	kW
heating / Warmer (2℃)	Pdh	**-**	kW
heating / Colder (-22℃)	Pdh	**-**	kW

Back up heating capacity at outdoor temperature Tdesignh			unit
heating / Average (-10℃)	elbu	**0**	kW
heating / Warmer (2℃)	elbu	**-**	kW
heating / Colder (-22℃)	elbu	**-**	kW

Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	**10.00**	kW
Tj=30℃	Pdc	**7.37**	kW
Tj=25℃	Pdc	**4.74**	kW
Tj=20℃	Pdc	**3.58**	kW

Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	**3.46**	-
Tj=30℃	EERd	**5.30**	-
Tj=25℃	EERd	**9.20**	-
Tj=20℃	EERd	**15.30**	-

Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**7.40**	kW
Tj=2℃	Pdh	**4.50**	kW
Tj=7℃	Pdh	**2.90**	kW
Tj=12℃	Pdh	**2.93**	kW
Tj=bivalent temperature	Pdh	**8.50**	kW
Tj=operating limit	Pdh	**6.30**	kW

Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**3.06**	-
Tj=2℃	COPd	**4.28**	-
Tj=7℃	COPd	**5.86**	-
Tj=12℃	COPd	**7.55**	-
Tj=bivalent temperature	COPd	**2.40**	-
Tj=operating limit	COPd	**2.00**	-

Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW

Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-

Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**-**	kW
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Tj=-15℃	Pdh	**-**	kW

Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**-**	-
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Tj=-15℃	COPd	**-**	-

Bivalent temperature			
heating / Average	Tbiv	**-10**	℃
heating / Warmer	Tbiv	**-**	℃
heating / Colder	Tbiv	**-**	℃

Operating limit temperature			
heating / Average	Tol	**-20**	℃
heating / Warmer	Tol	**-**	℃
heating / Colder	Tol	**-**	℃

Cycling interval capacity			
for cooling	Pcycc	**-**	kW
for heating	Pcych	**-**	kW

Cycling interval efficiency			
for cooling	EERcyc	**-**	-
for heating	COPcyc	**-**	-

Degradation coefficient			
cooling	Cdc	**0.25**	-

Degradation coefficient			
heating	Cdh	**0.25**	-

Electric power input in power modes other than 'active mode'			
off mode	Poff	**10**	W
standby mode	Psb	**10**	W
thermostat-off mode	Pto(cooling)	**50**	W
	Pto(heating)	**65**	W
crankcase heater mode	Pck	**5**	W

Annual electricity consumption			
cooling	Qce	**497**	kWh/a
heating / Average	Qhe	**2661**	kWh/a
heating / Warmer	Qhe	**-**	kWh/a
heating / colder	Qhe	**-**	kWh/a

Capacity control(indicate one of three options)	
fixed	**No**
staged	**No**
variable	**Yes**

Other items			
Sound power level(indoor)	Lwa	**59**	dB(A)
Sound power level(outdoor)	Lwa	**69**	dB(A)
Global warming potential	GWP	**675**	$kgCO_2eq.$
Rated air flow(indoor)	-	**858**	m^3/h
Rated air flow(outdoor)	-	**4500**	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex,UB11 1ET, United kingdom

PCA001Z857A

SRK100VSAWPZSX

Information to identify the model(s) to which the information relates to:	
Indoor unit model name	**SRK50ZSX-W (x2 units)**
Outdoor unit model name	**FDC100VSA-W**

If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.

Function(indicate if present)	
cooling	**Yes**
heating	**Yes**

Average(mandatory)	**Yes**
Warmer(if designated)	**No**
Colder(if designated)	**No**

Item	symbol	value	unit
Design load			
cooling	Pdesignc	**10.0**	kW
heating / Average	Pdesignh	**8.50**	kW
heating / Warmer	Pdesignh	**-**	kW
heating / Colder	Pdesignh	**-**	kW

Item	symbol	value	class
Seasonal efficiency and energy efficiency class			
cooling	SEER	**7.05**	**A++**
heating / Average	SCOP/A	**4.47**	**A+**
heating / Warmer	SCOP/W	**-**	-
heating / Colder	SCOP/C	**-**	-

Declared capacity at outdoor temperature Tdesignh			
heating / Average (-10℃)	Pdh	**8.50**	kW
heating / Warmer (2℃)	Pdh	**-**	kW
heating / Colder (-22℃)	Pdh	**-**	kW

Back up heating capacity at outdoor temperature Tdesignh			unit
heating / Average (-10℃)	elbu	**0**	kW
heating / Warmer (2℃)	elbu	**-**	kW
heating / Colder (-22℃)	elbu	**-**	kW

Declared capacity for cooling, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	Pdc	**10.00**	kW
Tj=30℃	Pdc	**7.37**	kW
Tj=25℃	Pdc	**4.74**	kW
Tj=20℃	Pdc	**3.58**	kW

Declared energy efficiency ratio, at indoor temperature 27(19)℃ and outdoor temperature Tj			
Tj=35℃	EERd	**3.46**	-
Tj=30℃	EERd	**5.30**	-
Tj=25℃	EERd	**9.20**	-
Tj=20℃	EERd	**15.30**	-

Declared capacity for heating / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**7.40**	kW
Tj=2℃	Pdh	**4.50**	kW
Tj=7℃	Pdh	**2.90**	kW
Tj=12℃	Pdh	**2.93**	kW
Tj=bivalent temperature	Pdh	**8.50**	kW
Tj=operating limit	Pdh	**6.30**	kW

Declared coefficient of performance / Average season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**3.06**	-
Tj=2℃	COPd	**4.28**	-
Tj=7℃	COPd	**5.86**	-
Tj=12℃	COPd	**7.55**	-
Tj=bivalent temperature	COPd	**2.40**	-
Tj=operating limit	COPd	**2.00**	-

Declared capacity for heating / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW

Declared coefficient of performance / Warmer season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-

Declared capacity for heating / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	Pdh	**-**	kW
Tj=2℃	Pdh	**-**	kW
Tj=7℃	Pdh	**-**	kW
Tj=12℃	Pdh	**-**	kW
Tj=bivalent temperature	Pdh	**-**	kW
Tj=operating limit	Pdh	**-**	kW
Tj=-15℃	Pdh	**-**	kW

Declared coefficient of performance / Colder season, at indoor temperature 20℃ and outdoor temperature Tj			
Tj=-7℃	COPd	**-**	-
Tj=2℃	COPd	**-**	-
Tj=7℃	COPd	**-**	-
Tj=12℃	COPd	**-**	-
Tj=bivalent temperature	COPd	**-**	-
Tj=operating limit	COPd	**-**	-
Tj=-15℃	COPd	**-**	-

Bivalent temperature			
heating / Average	Tbiv	**-10**	℃
heating / Warmer	Tbiv	**-**	℃
heating / Colder	Tbiv	**-**	℃

Operating limit temperature			
heating / Average	Tol	**-20**	℃
heating / Warmer	Tol	**-**	℃
heating / Colder	Tol	**-**	℃

Cycling interval capacity			
for cooling	Pcycc	**-**	kW
for heating	Pcych	**-**	kW

Cycling interval efficiency			
for cooling	EERcyc	**-**	-
for heating	COPcyc	**-**	-

Degradation coefficient			
cooling	Cdc	**0.25**	-

Degradation coefficient			
heating	Cdh	**0.25**	-

Electric power input in power modes other than 'active mode'			
off mode	Poff	**10**	W
standby mode	Psb	**10**	W
thermostat-off mode	Pto(cooling)	**50**	W
	Pto(heating)	**65**	W
crankcase heater mode	Pck	**5**	W

Annual electricity consumption			
cooling	Qce	**497**	kWh/a
heating / Average	Qhe	**2661**	kWh/a
heating / Warmer	Qhe	**-**	kWh/a
heating / colder	Qhe	**-**	kWh/a

Capacity control(indicate one of three options)	
fixed	**No**
staged	**No**
variable	**Yes**

Other items			
Sound power level(indoor)	Lwa	**59**	dB(A)
Sound power level(outdoor)	Lwa	**69**	dB(A)
Global warming potential	GWP	**675**	$kgCO_2eq.$
Rated air flow(indoor)	-	**858**	m^3/h
Rated air flow(outdoor)	-	**4500**	m^3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 5 The Square, Stockley Park, Uxbridge, Middlesex,UB11 1ET, United kingdom

PCA001Z857A

SRK125VNAWPZSX

Model(s) :	FDC125VNA-W / SRK60ZSX-W (x2 units)						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency ηs,c		**295.4**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**276.0**	%
Tj=+30℃	Pdc	**9.2**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**480.0**	%
Tj=+25℃	Pdc	**5.9**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**880.0**	%
Tj=+20℃	Pdc	**3.4**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**2130.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items				For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Capacity control		**variable**					
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PCA001Z857A

Information to identify the model(s) to which the information relates :	FDC125VNA-W / SRK60ZSX-W (x2 units)
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**14.0**	kW
Seasonal space heating energy efficiency ηs,h		**192.5**	%

Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj

T_j=-7℃	Pdh	**8.7**	kW
T_j=+2℃	Pdh	**5.3**	kW
T_j=+7℃	Pdh	**3.4**	kW
T_j=+12℃	Pdh	**3.0**	kW
T_{biv}=bivalent temperature	Pdh	**9.8**	kW
T_{OL}=operation limit	Pdh	**7.4**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-

Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj

T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**310.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**458.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**671.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**944.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**210.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃

Power consumpiton in modes other than 'active mode'

Off mode	P_{OFF}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.020**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW

Supplementary heater back-up heating capacity	elbu	**-**	kW
Type of energy input Standby mode	P_{SB}	**0.008**	kW

Other items

Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**71.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV

For air-to-air heat pumps: air flow-rate,outdoor measured		**4380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water fiow-rate, outdoor side heat exchanger		**-**	m^3/h

GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PCA001Z857A

SRK125VSAWPZSX

Model(s) :	FDC125VSA-W / SRK60ZSX-W (x2 units)						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**12.5**	kW	Seasonal space cooling energy efficiency ηs,c		**295.4**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**12.5**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**276.0**	%
Tj=+30℃	Pdc	**9.2**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**480.0**	%
Tj=+25℃	Pdc	**5.9**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**880.0**	%
Tj=+20℃	Pdc	**3.4**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**2130.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.008**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.008**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**71.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PCA001Z857A

Information to identify the model(s) to which the information relates :	FDC125VSA-W / SRK60ZSX-W (x2 units)
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**14.0**	kW
Seasonal space heating energy efficiency ηs,h		**192.5**	%

Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj

T_j=-7℃	Pdh	**8.7**	kW
T_j=+2℃	Pdh	**5.3**	kW
T_j=+7℃	Pdh	**3.4**	kW
T_j=+12℃	Pdh	**3.0**	kW
T_{biv}=bivalent temperature	Pdh	**9.8**	kW
T_{OL}=operation limit	Pdh	**7.4**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-

Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj

T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**310.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**458.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**671.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**944.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**270.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**210.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃

Power consumpiton in modes other than 'active mode'

Off mode	P_{OFF}	**0.008**	kW
Thermostat-off mode	P_{TO}	**0.020**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW

Supplementary heater back-up heating capacity	elbu	**-**	kW
Type of energy input Standby mode	P_{SB}	**0.008**	kW

Other items

Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**71.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV

For air-to-air heat pumps: air flow-rate,outdoor measured		**4380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water fiow-rate, outdoor side heat exchanger		**-**	m^3/h

GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PCA001Z857A

SRK140VNAWPZR

Model(s) : FDC140VNA-W / SRK71ZR-W (x2 units)							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**311.5**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**319.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**540.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**890.0**	%
Tj=+20℃	Pdc	**3.7**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**2270.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.010**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.010**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PCA001Z857A

Information to identify the model(s) to which the information relates :	FDC140VNA-W / SRK71ZR-W (x2 units)
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW
Seasonal space heating energy efficiency ηs,h		**209.5**	%

Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj

T_j=-7℃	Pdh	**9.3**	kW
T_j=+2℃	Pdh	**5.6**	kW
T_j=+7℃	Pdh	**3.6**	kW
T_j=+12℃	Pdh	**3.1**	kW
T_{biv}=bivalent temperature	Pdh	**10.5**	kW
T_{OL}=operation limit	Pdh	**7.9**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-

Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj

T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**320.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**504.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**736.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**1090.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**250.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**200.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃

Power consumpiton in modes other than 'active mode'

Off mode	P_{OFF}	**0.010**	kW
Thermostat-off mode	P_{TO}	**0.020**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW

Supplementary heater back-up heating capacity	elbu	**-**	kW
Type of energy input Standby mode	P_{SB}	**0.010**	kW

Other items

Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**73.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV

For air-to-air heat pumps: air flow-rate,outdoor measured	**4380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger	**-**	m^3/h

GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PCA001Z857Ⓐ

SRK140VSAWPZR

Model(s) : FDC140VSA-W / SRK71ZR-W (x2 units)							
Outdoor side heat exchanger of air conditioner : air							
Indoor side heat exchanger of air conditioner : air							
Type : vapour compression							
if applicable : electric motor							
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**311.5**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**319.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**540.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**890.0**	%
Tj=+20℃	Pdc	**3.7**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**2270.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.010**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.010**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PCA001Z857A

Information to identify the model(s) to which the information relates :	FDC140VSA-W / SRK71ZR-W (x2 units)
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW
Seasonal space heating energy efficiency ηs,h		**219.6**	%

Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj

T_j=-7℃	Pdh	**9.3**	kW
T_j=+2℃	Pdh	**5.6**	kW
T_j=+7℃	Pdh	**3.6**	kW
T_j=+12℃	Pdh	**3.1**	kW
T_{biv}=bivalent temperature	Pdh	**10.5**	kW
T_{OL}=operation limit	Pdh	**7.9**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-

Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj

T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**349.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**529.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**750.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**1120.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**250.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**200.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃

Power consumpiton in modes other than 'active mode'

Off mode	P_{OFF}	**0.010**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW

Supplementary heater back-up heating capacity	elbu	**-**	kW
Type of energy input Standby mode	P_{SB}	**0.010**	kW

Other items

Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**73.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV

For air-to-air heat pumps: air flow-rate,outdoor measured		**4380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger		**-**	m^3/h

GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PCA001Z857A

SRK140VNAWTZSX

Model(s) :	FDC140VNA-W / SRK50ZSX-W (x3 units)						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**311.5**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**319.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**540.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**890.0**	%
Tj=+20℃	Pdc	**3.7**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**2270.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.010**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.010**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PCA001Z857A

Information to identify the model(s) to which the information relates :	FDC140VNA-W / SRK50ZSX-W (x3 units)
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW
Seasonal space heating energy efficiency ηs,h		**219.6**	%

Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj

T_j=-7℃	Pdh	**9.3**	kW
T_j=+2℃	Pdh	**5.6**	kW
T_j=+7℃	Pdh	**3.6**	kW
T_j=+12℃	Pdh	**3.1**	kW
T_{biv}=bivalent temperature	Pdh	**10.5**	kW
T_{OL}=operation limit	Pdh	**7.9**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-

Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj

T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**349.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**529.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**750.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**1120.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**250.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**200.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃

Power consumpiton in modes other than 'active mode'

Off mode	P_{OFF}	**0.010**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW

Supplementary heater back-up heating capacity	elbu	**-**	kW
Type of energy input Standby mode	P_{SB}	**0.010**	kW

Other items

Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**73.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV

For air-to-air heat pumps: air flow-rate,outdoor measured	**4380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water flow-rate, outdoor side heat exchanger	**-**	m^3/h

GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PCA001Z857A

SRK140VSAWTZSX

Model(s) :	FDC140VSA-W / SRK50ZSX-W (x3 units)						
Outdoor side heat exchanger of air conditioner :	air						
Indoor side heat exchanger of air conditioner :	air						
Type :	vapour compression						
if applicable :	electric motor						
Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated cooling capacity	Prated,c	**13.6**	kW	Seasonal space cooling energy efficiency ηs,c		**311.5**	%
Declared cooling capacity for part load at given outdoor temperatures Tj and indoor 27℃/19℃(dry/wet bulb)				Declared energy efficiency ratio or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj			
Tj=+35℃	Pdc	**13.6**	kW	Tj=+35℃	EERd or GUEc,bin / AEFc,bin	**319.0**	%
Tj=+30℃	Pdc	**10.0**	kW	Tj=+30℃	EERd or GUEc,bin / AEFc,bin	**540.0**	%
Tj=+25℃	Pdc	**6.4**	kW	Tj=+25℃	EERd or GUEc,bin / AEFc,bin	**890.0**	%
Tj=+20℃	Pdc	**3.7**	kW	Tj=+20℃	EERd or GUEc,bin / AEFc,bin	**2270.0**	%
Degradation coefficient for air conditioners**	Cdc	**0.25**	-				
Power consumpiton in other than 'active mode'							
Off mode	P_{OFF}	**0.010**	kW	Crankcase heater mode	P_{CK}	**0.005**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW	Standby mode	P_{SB}	**0.010**	kW
Other items							
Capacity control		**variable**		For air-to-air air conditioner: air flow-rate,outdoor measured		**4500**	m^3/h
Sound power level, outdoor	L_{WA}	**72.0**	dB				
If engine driven: Emissions of nitrogen oxides	NOx ***	**-**	mg/kWh fuel input GCV				
GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

** If Cdc is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PCA001Z857A

Information to identify the model(s) to which the information relates :	FDC140VSA-W / SRK50ZSX-W (x3 units)
Outdoor side heat exchanger of heat pump :	air
Indoor side heat exchanger of heat pump :	air
Indication if the heater is equipped with a supplementary heater :	No
if applicable :	electric motor

Parameters shall be declared for the average heating season , parameters for the warmer and colder heating seasons are optional.

Item	Symbol	Value	Unit
Rated heating capacity	Prated,h	**15.5**	kW
Seasonal space heating energy efficiency ηs,h		**219.6**	%

Declared heating capacity for part load at indoor temperature 20℃ and outdoor temperature Tj

T_j=-7℃	Pdh	**9.3**	kW
T_j=+2℃	Pdh	**5.6**	kW
T_j=+7℃	Pdh	**3.6**	kW
T_j=+12℃	Pdh	**3.1**	kW
T_{biv}=bivalent temperature	Pdh	**10.5**	kW
T_{OL}=operation limit	Pdh	**7.9**	kW
For air-to-water heat pumps : T_j=-15℃ (if T_{OL}＜-20℃)	Pdh	**-**	kW
Bivalent temperature	T_{biv}	**-10.0**	℃
Degradation coefficient heat pumps**	C_{dh}	**0.25**	-

Declared coefficient of performance or gas utilization efficiency / auxiliary energy factor for part load at given outdoor temperatures Tj

T_j=-7℃	COPd or GUEh,bin / AEFh,bin	**349.0**	%
T_j=+2℃	COPd or GUEh,bin / AEFh,bin	**529.0**	%
T_j=+7℃	COPd or GUEh,bin / AEFh,bin	**750.0**	%
T_j=+12℃	COPd or GUEh,bin / AEFh,bin	**1120.0**	%
T_{biv}=bivalent temperature	COPd or GUEh,bin / AEFh,bin	**250.0**	%
T_{OL}=operation limit	COPd or GUEh,bin / AEFh,bin	**200.0**	%
For air-to-water heat pumps:T_j=-15℃ (if T_{OL}＜-20℃)	COPd or GUEh,bin / AEFh,bin	**-**	%
For water-to-air heat pumps:Operation limit T_{ol} temperature		**-**	℃

Power consumpiton in modes other than 'active mode'

Off mode	P_{OFF}	**0.010**	kW
Thermostat-off mode	P_{TO}	**0.000**	kW
Crankcase heater mode	P_{CK}	**0.005**	kW

Supplementary heater back-up heating capacity	elbu	**-**	kW
Type of energy input Standby mode	P_{SB}	**0.010**	kW

Other items

Capacity control		**variable**	
Sound power level, outdoor measured	L_{WA}	**73.0**	dB
Emissions of nitrogen oxides(if applicable)	NOx ***	**-**	mg/kWh fuel input GCV

For air-to-air heat pumps: air flow-rate,outdoor measured		**4380**	m^3/h
For water-/brine-to-air heat pumps : Rated brine or water fiow-rate, outdoor side heat exchanger		**-**	m^3/h

GWP of the refrigerant		**675**	$kgCO_2eq.$ (100years)

Contact details	Mitsubishi heavy industries thermal systems,LTD

** If Cdh is not determined by measurement then the default degradation coefficient air conditioners shall be 0,25.

*** from 26 September 2018

Where information relates to multi-spilt air conditioners,the test result and performance data be obtained on the basis of the performance of the outdoor unit, with a combination of indoor unit(s) recommended by the manufacturer or importer.

PCA001Z857 A

Models SRK50ZSX-W, 60ZSX-W, 71ZR-W, 100ZR-W

Model(s) : SRK50ZSX-W							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	$P_{rated,c}$	4.0	kW	Total electric power input	P_{elec}	0.030	kW
Cooling capacity (latent)	$P_{rated,c}$	1.0	kW	Sound power level (per speed setting,if applicable)	L_{WA}	59.0	dB
Heating capacity	$P_{rated,h}$	6.0	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : SRK60ZSX-W							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	$P_{rated,c}$	4.7	kW	Total electric power input	P_{elec}	0.040	kW
Cooling capacity (latent)	$P_{rated,c}$	1.4	kW	Sound power level (per speed setting,if applicable)	L_{WA}	62.0	dB
Heating capacity	$P_{rated,h}$	6.8	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : SRK71ZR-W							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	$P_{rated,c}$	5.2	kW	Total electric power input	P_{elec}	0.056	kW
Cooling capacity (latent)	$P_{rated,c}$	1.9	kW	Sound power level (per speed setting,if applicable)	L_{WA}	60.0	dB
Heating capacity	$P_{rated,h}$	7.1	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

Model(s) : SRK100ZR-W							
Item	**Symbol**	**Vaiue**	**Unit**	**Item**	**Symbol**	**Vaiue**	**Unit**
Cooling capacity (sensible)	$P_{rated,c}$	7.4	kW	Total electric power input	P_{elec}	0.060	kW
Cooling capacity (latent)	$P_{rated,c}$	2.6	kW	Sound power level (per speed setting,if applicable)	L_{WA}	63.0	dB
Heating capacity	$P_{rated,h}$	11.2	kW				
Contact details	Mitsubishi heavy industries thermal systems,LTD						

2. V MULTI SYSTEM

CONTENTS

2.1 GENERAL INFORMATION 336
2.1.1 How to read the model name 336
2.1.2 Table of models 336
2.1.3 Table of system combinations 336
2.2 SPECIFICATIONS 337
(1) Indoor units 337
(a) Ceiling cassette-4 way type (FDT) 337
(b) Ceiling suspended type (FDE) 340
(2) Outdoor units 343
(3) Operation chart 349
2.3 EXTERIOR DIMENSIONS 352
2.4 ELECTRICAL WIRING 352
2.5 NOISE LEVEL 352
2.6 TEMPERATURE AND VELOCITY DISTRIBUTION 352
2.7 PIPING SYSTEM 352
2.8 RANGE OF USAGE & LIMITATIONS 352
2.9 SELECTION CHART 352
2.10 APPLICATION DATA 352
2.11 TECHNICAL INFORMATION 352

2.1 GENERAL INFORMATION

2.1.1 How to read the model name



2.1.2 Table of models

Model \ Capacity	50	60	71
Ceiling cassette-4 way type (FDT)	○	○	○
Ceiling suspended type (FDE)	○	○	○
Outdoor unit to be combined (FDC)	FDC100VNA-W FDC100VSA-W (4 HP)	FDC125VNA-W FDC125VSA-W (5 HP)	FDC140VNA-W FDC140VSA-W (6 HP)

2.1.3 Table of system combinations

Outdoor unit	Type	Indoor unit assembly capacity	Branch pipe set (Option)
FDC100VNA-W FDC100VSA-W	Twin	50+50	DIS-WA1G
FDC125VNA-W FDC125VSA-W		60+60 50+71	
FDC140VNA-W FDC140VSA-W	Twin	71+71	
	Triple	50+50+50	DIS-TA1G or DIS-WA1G × 2 sets

Notes(1) Always use the branch piping set (option) at branches in the refrigerant piping.
(2) If wireless specifications are used, use 1 wireless indoor unit in combination with wired indoor units.
(3) The combinations except the above table forbids.

2.2 SPECIFICATIONS

(1) Indoor units

(a) Ceiling cassette -4 way type (FDT)

Item \ Model				FDT50VH
Power source				1 Phase 220-240V 50Hz / 220V 60Hz
Operation data	Sound power level	Cooling	dB(A)	55
		Heating		56
	Sound pressure level	Cooling		P-Hi : 41 Hi : 33 Me : 30 Lo : 26
		Heating		P-Hi : 42 Hi : 33 Me : 28 Lo : 20
	Silent mode sound pressure level			—
Exterior dimensions (Height × Width × Depth)			mm	Unit 236 × 840 × 840 Panel 35 × 950 × 950
Exterior appearance (Munsell color)				Plaster white (6.8Y8.9/0.2) near equivalent
Net weight			kg	Unit 19 Panel 5
Heat exchanger				Louver fin & inner grooved tubing
Fan type & Q'ty				Turbo fan ×1
Fan motor (Starting method)			W	50 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi : 22 Hi : 16 Me : 13 Lo : 10
		Heating		
Available external static pressure			Pa	0
Outside air intake				Possible
Air filter, Quality / Quantity				Pocket plastic net ×1 (Washable)
Shock & vibration absorber				Rubber sleeve (for fan motor)
Electric heater			W	—
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-T-5AW-E2
	Room temperature control			Thermostat by electronics
	Operation display			—
Safety equipments				Internal thermostat for fan motor. Frost protection thermostat.
Installation data	Refrigerant piping size (O.D.)		mm	Liquid line: ϕ 6.35 (1/4")
				Gas line: ϕ 12.7 (1/2")
	Connecting method			Flare piping
	Attached length of piping		m	—
	Insulation for piping			Necessary (both Liquid & Gas lines)
	Drain hose			Hose connectable VP25 (O.D.32)
Drain pump, max lift height			mm	Built-in drain pump, 850
IP number				IPX0
Standard accessories				Mounting kit, Drain hose
Option parts				—

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27˚C	19˚C	35˚C	24˚C	ISO5151-T1
Heating	20˚C	—	7˚C	6˚C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

Item			Model	FDT60VH
Power source				1 Phase 220-240V 50Hz / 220V 60Hz
Operation data	Sound power level	Cooling	dB(A)	58
		Heating		59
	Sound pressure level	Cooling		P-Hi : 44 Hi : 34 Me : 30 Lo : 27
		Heating		P-Hi : 44 Hi : 34 Me : 30 Lo : 23
	Silent mode sound pressure level			—
Exterior dimensions (Height × Width × Depth)			mm	Unit 236 × 840 × 840 Panel 35 × 950 × 950
Exterior appearance (Munsell color)				Plaster white (6.8Y8.9/0.2) near equivalent
Net weight			kg	Unit 21 Panel 5
Heat exchanger				Louver fin & inner grooved tubing
Fan type & Q'ty				Turbo fan ×1
Fan motor (Starting method)			W	50 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi : 26 Hi : 17 Me : 14 Lo : 11
		Heating		
Available external static pressure			Pa	0
Outside air intake				Possible
Air filter, Quality / Quantity				Pocket plastic net ×1 (Washable)
Shock & vibration absorber				Rubber sleeve (for fan motor)
Electric heater			W	—
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-T-5AW-E2
	Room temperature control			Thermostat by electronics
	Operation display			—
Safety equipments				Internal thermostat for fan motor. Frost protection thermostat.
Installation data	Refrigerant piping size (O.D.)		mm	Liquid line: ϕ 6.35 (1/4")
				Gas line: ϕ 12.7 (1/2")
	Connecting method			Flare piping
	Attached length of piping		m	—
	Insulation for piping			Necessary (both Liquid & Gas lines)
	Drain hose			Hose connectable VP25 (O.D.32)
Drain pump, max lift height			mm	Built-in drain pump, 850
IP number				IPX0
Standard accessories				Mounting kit, Drain hose
Option parts				—

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27˚C	19˚C	35˚C	24˚C	ISO5151-T1
Heating	20˚C	—	7˚C	6˚C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

PJF000Z589 B

Item \ Model				FDT71VH
Power source				1 Phase 220-240V 50Hz / 220V 60Hz
Operation data	Sound power level	Cooling	dB(A)	59
		Heating		60
	Sound pressure level	Cooling		P-Hi : 46 Hi : 34 Me : 31 Lo : 26
		Heating		P-Hi : 46 Hi : 34 Me : 31 Lo : 26
	Silent mode sound pressure level			—
Exterior dimensions (Height × Width × Depth)			mm	Unit 236 × 840 × 840 Panel 35 × 950 × 950
Exterior appearance (Munsell color)				Plaster white (6.8Y8.9/0.2) near equivalent
Net weight			kg	Unit 21 Panel 5
Heat exchanger				Louver fin & inner grooved tubing
Fan type & Q'ty				Turbo fan ×1
Fan motor (Starting method)			W	50 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi : 28 Hi : 18 Me : 15 Lo : 12
		Heating		
Available external static pressure			Pa	0
Outside air intake				Possible
Air filter, Quality / Quantity				Pocket plastic net ×1 (Washable)
Shock & vibration absorber				Rubber sleeve (for fan motor)
Electric heater			W	—
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-T-5AW-E2
	Room temperature control			Thermostat by electronics
	Operation display			—
Safety equipments				Internal thermostat for fan motor. Frost protection thermostat.
Installation data	Refrigerant piping size (O.D.)		mm	Liquid line: ϕ 9.52 (3/8")
				Gas line: ϕ 15.88 (5/8")
	Connecting method			Flare piping
	Attached length of piping		m	—
	Insulation for piping			Necessary (both Liquid & Gas lines)
	Drain hose			Hose connectable VP25 (O.D.28)
Drain pump, max lift height			mm	Built-in drain pump, 850
IP number				IPX0
Standard accessories				Mounting kit, Drain hose
Option parts				—

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item \ Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27˚C	19˚C	35˚C	24˚C	ISO5151-T1
Heating	20˚C	—	7˚C	6˚C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

PJF000Z589 B

(b) Ceiling suspended type (FDE)

Item \ Model				FDE50VH
Power source				1 Phase 220-240V 50Hz / 220V 60Hz
Operation data	Nominal cooling capacity		kW	5.0
	Nominal heating capacity		kW	5.4
	Sound power level	Cooling	dB(A)	60
		Heating		
	Sound pressure level	Cooling		P-Hi : 46 Hi : 38 Me : 36 Lo : 31
		Heating		
	Silent mode sound pressure level			—
Exterior dimensions (Height x Width x Depth)			mm	210 × 1070 × 690
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent
Net weight			kg	28
Heat exchanger				Louver fin & inner grooved tubing
Fan type & Q'ty				Centrifugal fan ×2
Fan motor (Starting method)			W	30 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi : 13 Hi : 10 Me : 9 Lo : 7
		Heating		
Available external static pressure			Pa	0
Outside air intake				Not possible
Air filter, Quality / Quantity				Pocket plastic net ×2(Washable)
Shock & vibration absorber				Rubber sleeve(for fan motor)
Electric heater			W	—
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-E-E3
	Room temperature control			Thermostat by electronics
	Operation display			—
Safety equipments				Overload protection for fan motor Frost protection thermostat
Installation data	Refrigerant piping size (O.D.)		mm	Liquid line: ϕ 6.35 (1/4")
				Gas line: ϕ 12.7 (1/2")
	Connecting method			Flare piping
	Attached length of piping		m	—
	Insulation for piping			Necessary (both Liquid & Gas lines)
	Drain hose			Hose connectable VP20(O.D.26)
Drain pump, max lift height			mm	—
IP number				IPX0
Standard accessories				Mounting kit, Drain hose
Option parts				Motion sensor : LB-E

Notes (1) The data are measured at the following conditions.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27℃	19℃	35℃	24℃	ISO5151-T1
Heating	20℃	—	7℃	6℃	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

Item \ Model				FDE60VH
Power source				1 Phase 220-240V 50Hz / 220V 60Hz
Operation data	Nominal cooling capacity		kW	5.6
	Nominal heating capacity		kW	6.7
	Sound power level	Cooling	dB(A)	60
		Heating		
	Sound pressure level	Cooling		P-Hi : 47 Hi : 41 Me : 37 Lo : 32
		Heating		
	Silent mode sound pressure level			—
Exterior dimensions (Height x Width x Depth)			mm	210 × 1320 × 690
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent
Net weight			kg	33
Heat exchanger				Louver fin & inner grooved tubing
Fan type & Q'ty				Centrifugal fan ×4
Fan motor (Starting method)			W	50 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi : 20 Hi : 16 Me : 13 Lo : 10
		Heating		
Available external static pressure			Pa	0
Outside air intake				Not possible
Air filter, Quality / Quantity				Pocket plastic net ×2(Washable)
Shock & vibration absorber				Rubber sleeve(for fan motor)
Electric heater			W	—
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-E-E3
	Room temperature control			Thermostat by electronics
	Operation display			—
Safety equipments				Overload protection for fan motor Frost protection thermostat
Installation data	Refrigerant piping size (O.D.)		mm	Liquid line: ϕ 6.35 (1/4")
				Gas line: ϕ 12.7 (1/2")
	Connecting method			Flare piping
	Attached length of piping		m	—
	Drain hose			Hose connectable VP20(O.D.26)
Drain pump, max lift height			mm	—
IP number				IPX0
Standard accessories				Mounting kit, Drain hose
Option parts				Motion sensor : LB-E

Notes (1) The data are measured at the following conditions.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27℃	19℃	35℃	24℃	ISO5151-T1
Heating	20℃	—	7℃	6℃	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

Item \ Model				FDE71VH
Power source				1 Phase 220-240V 50Hz / 220V 60Hz
Operation data	Nominal cooling capacity (range)		kW	7.1
	Nominal heating capacity (range)		kW	8.0
	Sound power level	Cooling	dB(A)	60
		Heating		
	Sound pressure level	Cooling		P-Hi : 47 Hi : 41 Me : 37 Lo : 32
		Heating		
	Silent mode sound pressure level			—
Exterior dimensions (Height x Width x Depth)			mm	210 × 1320 × 690
Exterior appearance (Munsell color) (RAL color)				Plaster white (6.8Y8.9/0.2) near equivalent (RAL 9003) near equivalent
Net weight			kg	33
Heat exchanger				Louver fin & inner grooved tubing
Fan type & Q'ty				Centrifugal fan ×4
Fan motor (Starting method)			W	50 < Direct line start >
Air flow		Cooling	m^3/min	P-Hi : 20 Hi : 16 Me : 13 Lo : 10
		Heating		
Available external static pressure			Pa	0
Outside air intake				Not possible
Air filter, Quality / Quantity				Pocket plastic net ×2(Washable)
Shock & vibration absorber				Rubber sleeve(for fan motor)
Electric heater			W	—
Operation control	Remote control			(Option) Wired : RC-EX3A , RC-E5 , RCH-E3 Wireless : RCN-E-E3
	Room temperature control			Thermostat by electronics
	Operation display			—
Safety equipments				Overload protection for fan motor Frost protection thermostat
Installation data	Refrigerant piping size (O.D.)		mm	Liquid line: ϕ 9.52 (3/8")
				Gas line: ϕ 15.88 (5/8")
	Connecting method			Flare piping
	Attached length of piping		m	—
	Insulation for piping			Necessary (both Liquid & Gas lines)
	Drain hose			Hose connectable VP20(O.D.26)
Drain pump, max lift height			mm	—
IP number				IPX0
Standard accessories				Mounting kit, Drain hose
Option parts				Motion sensor : LB-E

Notes (1) The data are measured at the following conditions.

Item / Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27℃	19℃	35℃	24℃	ISO5151-T1
Heating	20℃	—	7℃	6℃	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

(2) Outdoor units

Item \ Model				FDC100VNA-W
Power source				1 Phase 220-240V 50Hz / 220V 60Hz
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.)-11.2(Max.)]
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.)-12.5(Max.)]
	Sound power level	Cooling	dB(A)	69
		Heating		70
	Sound pressure level	Cooling		54
		Heating		55
	Silent mode sound pressure level			48/44 (Normal/Silent)
Exterior dimensions (Height × Width × Depth)			mm	845×970×370
Exterior appearance (Munsell color) (RAL color)				Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	77
Compressor type & Q'ty				RMT5126SWP3×1
Compressor motor (Starting method)			kW	Direct line start
Refrigerant oil (Amount, type)			L	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)
Heat exchanger				M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve
Fan type & Q'ty				Propeller fan ×1
Fan motor (Starting method)			W	86 < Direct line start >
Air flow		Cooling	m^3/min	75
		Heating		73
Shock & vibration absorber				Rubber sleeve (for fan motor & compressor)
Electric heater			W	20 (Crank case heater)
Safety equipments				Internal thermostat for fan motor Abnormal discharge temperature protection
Installation data	Refrigerant piping size (O.D.)		mm	Liquid line: ϕ9.52 (3/8")
				Gas line: ϕ15.88 (5/8")
	Connecting method			Flare piping
	Attached length of piping		m	—
	Insulation for piping			Necessary (both Liquid & Gas lines)
	Refrigerant line (one way) length		m	Max.50m
	Vertical height diff. between O/U and I/U		m	Max.50m (Outdoor unit is higher) Max.15m (Outdoor unit is lower)
	Drain hose			Hole size ϕ20 × 3 pcs
IP number				IP24
Standard accessories				—
Option parts				—

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27˚C	19˚C	35˚C	24˚C	ISO5151-T1
Heating	20˚C	—	7˚C	6˚C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Slect the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

Item \ Model				FDC100VSA-W
Power source				3 Phase 380-415V 50Hz / 380V 60Hz
Operation data	Nominal cooling capacity (range)		kW	10.0 [4.0(Min.)-11.2(Max.)]
	Nominal heating capacity (range)		kW	11.2 [4.0(Min.)-12.5(Max.)]
	Sound power level	Cooling	dB(A)	69
		Heating		70
	Sound pressure level	Cooling		54
		Heating		55
	Silent mode sound pressure level			48/44 (Normal/Silent)
Exterior dimensions (Height × Width × Depth)			mm	845×970×370
Exterior appearance (Munsell color) (RAL color)				Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	78
Compressor type & Q'ty				RMT5126SWP4×1
Compressor motor (Starting method)			kW	Direct line start
Refrigerant oil (Amount, type)			L	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)
Heat exchanger				M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve
Fan type & Q'ty				Propeller fan ×1
Fan motor (Starting method)			W	86 < Direct line start >
Air flow		Cooling	m^3/min	75
		Heating		73
Shock & vibration absorber				Rubber sleeve (for fan motor & compressor)
Electric heater			W	20 (Crank case heater)
Safety equipments				Internal thermostat for fan motor Abnormal discharge temperature protection
Installation data	Refrigerant piping size (O.D.)		mm	Liquid line: ϕ9.52 (3/8")
				Gas line: ϕ15.88 (5/8")
	Connecting method			Flare piping
	Attached length of piping		m	—
	Insulation for piping			Necessary (both Liquid & Gas lines)
	Refrigerant line (one way) length		m	Max.50m
	Vertical height diff. between O/U and I/U		m	Max.50m (Outdoor unit is higher) Max.15m (Outdoor unit is lower)
	Drain hose			Hole size ϕ20 × 3 pcs
IP number				IP24
Standard accessories				—
Option parts				—

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
Heating	20°C	—	7°C	6°C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Slect the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.

Item \ Model				FDC125VNA-W
Power source				1 Phase 220-240V 50Hz / 220V 60Hz
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.)-14.0(Max.)]
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.)-16.0(Max.)]
	Sound power level	Cooling	dB(A)	71
		Heating		
	Sound pressure level	Cooling		54
		Heating		56
	Silent mode sound pressure level			48/45 (Normal/Silent)
Exterior dimensions (Height × Width × Depth)			mm	845×970×370
Exterior appearance (Munsell color) (RAL color)				Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	77
Compressor type & Q'ty				RMT5126SWP3×1
Compressor motor (Starting method)			kW	Direct line start
Refrigerant oil (Amount, type)			L	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)
Heat exchanger				M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve
Fan type & Q'ty				Propeller fan ×1
Fan motor (Starting method)			W	86 < Direct line start >
Air flow		Cooling	m^3/min	75
		Heating		73
Shock & vibration absorber				Rubber sleeve (for fan motor & compressor)
Electric heater			W	20 (Crank case heater)
Safety equipments				Internal thermostat for fan motor Abnormal discharge temperature protection
Installation data	Refrigerant piping size (O.D.)		mm	Liquid line: ϕ9.52 (3/8")
				Gas line: ϕ15.88 (5/8")
	Connecting method			Flare piping
	Attached length of piping		m	—
	Insulation for piping			Necessary (both Liquid & Gas lines)
	Refrigerant line (one way) length		m	Max.50m
	Vertical height diff. between O/U and I/U		m	Max.50m (Outdoor unit is higher) Max.15m (Outdoor unit is lower)
	Drain hose			Hole size ϕ20 × 3 pcs
IP number				IP24
Standard accessories				—
Option parts				—

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27˚C	19˚C	35˚C	24˚C	ISO5151-T1
Heating	20˚C	—	7˚C	6˚C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Slect the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

Item \ Model				FDC125VSA-W
Power source				3 Phase 380-415V 50Hz / 380V 60Hz
Operation data	Nominal cooling capacity (range)		kW	12.5 [5.0(Min.)-14.0(Max.)]
	Nominal heating capacity (range)		kW	14.0 [4.0(Min.)-16.0(Max.)]
	Sound power level	Cooling	dB(A)	71
		Heating		
	Sound pressure level	Cooling		54
		Heating		56
	Silent mode sound pressure level			48/45 (Normal/Silent)
Exterior dimensions (Height × Width × Depth)			mm	845×970×370
Exterior appearance (Munsell color) (RAL color)				Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	78
Compressor type & Q'ty				RMT5126SWP4×1
Compressor motor (Starting method)			kW	Direct line start
Refrigerant oil (Amount, type)			L	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)
Heat exchanger				M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve
Fan type & Q'ty				Propeller fan ×1
Fan motor (Starting method)			W	86 < Direct line start >
Air flow		Cooling	m^3/min	75
		Heating		73
Shock & vibration absorber				Rubber sleeve (for fan motor & compressor)
Electric heater			W	20 (Crank case heater)
Safety equipments				Internal thermostat for fan motor Abnormal discharge temperature protection
Installation data	Refrigerant piping size (O.D.)		mm	Liquid line: ϕ9.52 (3/8")
				Gas line: ϕ15.88 (5/8")
	Connecting method			Flare piping
	Attached length of piping		m	—
	Insulation for piping			Necessary (both Liquid & Gas lines)
	Refrigerant line (one way) length		m	Max.50m
	Vertical height diff. between O/U and I/U		m	Max.50m (Outdoor unit is higher) Max.15m (Outdoor unit is lower)
	Drain hose			Hole size ϕ20 × 3 pcs
IP number				IP24
Standard accessories				—
Option parts				—

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27˚C	19˚C	35˚C	24˚C	ISO5151-T1
Heating	20˚C	—	7˚C	6˚C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Slect the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.

Item \ Model				FDC140VNA-W
Power source				1 Phase 220-240V 50Hz / 220V 60Hz
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.)-14.5(Max.)]
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.)-16.5(Max.)]
	Sound power level	Cooling	dB(A)	72
		Heating		73
	Sound pressure level	Cooling		56
		Heating		58
	Silent mode sound pressure level			49/45 (Normal/Silent)
Exterior dimensions (Height × Width × Depth)			mm	845×970×370
Exterior appearance (Munsell color) (RAL color)				Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	77
Compressor type & Q'ty				RMT5126SWP3×1
Compressor motor (Starting method)			kW	Direct line start
Refrigerant oil (Amount, type)			L	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)
Heat exchanger				M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve
Fan type & Q'ty				Propeller fan ×1
Fan motor (Starting method)			W	86 < Direct line start >
Air flow		Cooling	m^3/min	75
		Heating		73
Shock & vibration absorber				Rubber sleeve (for fan motor & compressor)
Electric heater			W	20 (Crank case heater)
Safety equipments				Internal thermostat for fan motor Abnormal discharge temperature protection
Installation data	Refrigerant piping size (O.D.)		mm	Liquid line: ϕ9.52 (3/8")
				Gas line: ϕ15.88 (5/8")
	Connecting method			Flare piping
	Attached length of piping		m	—
	Insulation for piping			Necessary (both Liquid & Gas lines)
	Refrigerant line (one way) length		m	Max.50m
	Vertical height diff. between O/U and I/U		m	Max.50m (Outdoor unit is higher) Max.15m (Outdoor unit is lower)
	Drain hose			Hole size ϕ20 × 3 pcs
IP number				IP24
Standard accessories				—
Option parts				—

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item \ Operation	Indoor air temperature		Outdoor air temperature		Standards
	DB	WB	DB	WB	
Cooling	27˚C	19˚C	35˚C	24˚C	ISO5151-T1
Heating	20˚C	—	7˚C	6˚C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Slect the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

PJF000Z589 B

Item \ Model				FDC140VSA-W
Power source				3 Phase 380-415V 50Hz / 380V 60Hz
Operation data	Nominal cooling capacity (range)		kW	13.6 [5.0(Min.)-14.5(Max.)]
	Nominal heating capacity (range)		kW	15.5 [4.0(Min.)-16.5(Max.)]
	Sound power level	Cooling	dB(A)	72
		Heating		73
	Sound pressure level	Cooling		56
		Heating		58
	Silent mode sound pressure level			49/45 (Normal/Silent)
Exterior dimensions (Height × Width × Depth)			mm	845×970×370
Exterior appearance (Munsell color) (RAL color)				Stucco white (4.2Y7.5/1.1) near equivalent (RAL 7044) near equivalent
Net weight			kg	82
Compressor type & Q'ty				RMT5126SWP4×1
Compressor motor (Starting method)			kW	Direct line start
Refrigerant oil (Amount, type)			L	0.9 (M-MB75)
Refrigerant (Type, amount, pre-charge length)			kg	R32 3.3 in outdoor unit (Incl. the amount for the piping of 30m)
Heat exchanger				M shape fin & inner grooved tubing
Refrigerant control				Electronic expansion valve
Fan type & Q'ty				Propeller fan ×1
Fan motor (Starting method)			W	86 < Direct line start >
Air flow		Cooling	m^3/min	75
		Heating		73
Shock & vibration absorber				Rubber sleeve (for fan motor & compressor)
Electric heater			W	20 (Crank case heater)
Safety equipments				Internal thermostat for fan motor Abnormal discharge temperature protection
Installation data	Refrigerant piping size (O.D.)		mm	Liquid line: ϕ9.52 (3/8")
				Gas line: ϕ15.88 (5/8")
	Connecting method			Flare piping
	Attached length of piping		m	—
	Insulation for piping			Necessary (both Liquid & Gas lines)
	Refrigerant line (one way) length		m	Max.50m
	Vertical height diff. between O/U and I/U		m	Max.50m (Outdoor unit is higher) Max.15m (Outdoor unit is lower)
	Drain hose			Hole size ϕ20 × 3 pcs
IP number				IP24
Standard accessories				—
Option parts				—

Notes (1) The data are measured at the following conditions. The pipe length is 7.5m.

Item / Operation	Indoor air temperature DB	Indoor air temperature WB	Outdoor air temperature DB	Outdoor air temperature WB	Standards
Cooling	27˚C	19˚C	35˚C	24˚C	ISO5151-T1
Heating	20˚C	—	7˚C	6˚C	ISO5151-H1

(2) This air-conditioner is manufactured and tested in conformity with the ISO.
(3) Sound level indicates the value in an anechoic chamber. During operation these values are somewhat higher due to ambient conditions.
(4) Slect the breaker size according to the own national standard.
(5) The operation data indicate when the air-conditioner is operated at 400V 50Hz or 380V 60Hz.

PJF000Z589 B

(3) Operation chart

The V Multi is a system that allows for different models and capacities of indoor units to be connected so the individual operating characteristics of the indoor and outdoor are provided. Use the procedure shown in item (c) to calculate the combined operating characteristics.

(a) Operating characteristic of outdoor unit

(220-240V 50Hz/220V 60Hz)

Item \ Model		FDC100VNA-W	FDC125VNA-W	FDC140VNA-W
Cooling power consumption	kW	3.02/3.02	4.00/4.00	4.59/4.59
Heating power consumption		2.89/2.89	3.38/3.38	4.06/4.06
Cooling running current	A	13.6-13.0/13.6	17.6-16.8/17.6	20.3-19.3/20.3
Heating running current		13.0-12.4/13.0	14.8-14.0/14.8	17.8-17.0/17.8
Inrush current (L.R.A) <Max. running current>	A	5 <24>		

(380-415V 50Hz/380V 60Hz)

Item \ Model		FDC100VSA-W	FDC125VSA-W	FDC140VSA-W
Cooling power consumption	kW	3.02/3.02	4.00/4.00	4.59/4.59
Heating power consumption		2.89/2.89	3.38/3.38	4.06/4.06
Cooling running current	A	4.5-4.3/4.5	5.9-5.6/5.9	6.8-6.4/6.8
Heating running current		4.3-4.1/4.3	5.0-4.7/5.0	6.0-5.7/6.0
Inrush current (L.R.A) <Max. running current>	A	5 <15>		

Note(1) This packaged air-conditioner is manufactured and tested in conformity with the following standard.
ISO-T1 "UNITARY AIR-CONDITIONERS"

(b) Operating characteristic of indoor unit

FDT Series

(220-240V 50Hz/220V 60Hz)

Item \ Model		FDT50VH	FDT60VH	FDT71VH
Cooling power consumption	kW	0.04-0.04/0.04	0.07-0.07/0.07	0.08-0.08/0.08
Heating power consumption		0.04-0.04/0.04	0.07-0.07/0.07	0.08-0.08/0.08
Cooling running current	A	0.36-0.33/0.36	0.62-0.57/0.62	0.70-0.64/0.70
Heating running current		0.36-0.33/0.36	0.62-0.57/0.62	0.70-0.64/0.70

FDE Series

(220-240V 50Hz/220V 60Hz)

Item \ Model		FDE50VH	FDE60VH	FDE71VH
Cooling power consumption	kW	0.05-0.05/0.05	0.08-0.08/0.08	0.08-0.08/0.08
Heating power consumption		0.05-0.05/0.05	0.08-0.08/0.08	0.08-0.08/0.08
Cooling running current	A	0.50-0.50/0.50	0.75-0.75/0.75	0.75-0.75/0.75
Heating running current		0.50-0.50/0.50	0.75-0.75/0.75	0.75-0.75/0.75

Notes(1) This packaged air-conditioner is manufactured and tested in conformity with the following standard.
ISO-T1 "UNITARY AIR-CONDITIONERS"
(2) The values shown in the above table are common to both cooling and heating operations.

(c) Calculation of total operation characteristics

Since the operation characteristics of V Multi system depend on combination of indoor unit, calculate the total operation characteristics of the system by using the formulas below according to speciations of each indoor unit or outdoor unit.

(i) 1 Phase models

1) Total power consumption

Total power consumption (kW) = Power consumption of outdoor unit + ∑ (Power consumption of indoor unit)

2) Total running current

Total running current (A) = Running current of outdoor unit + ∑ (Running current of indoor unit)

3) Total power factor

Total power factor (%) = [Total power consumption (W) / Total running current (A) × Power source] × 100

Total operation characteristics = Operation characteristic value of outdoor unit + Operation characteristic value of indoor unit

[Example]

(Conditions) Operation voltage ····· Indoor unit: 220 V, 50 Hz
Outdoor unit: 220 V, 50 Hz
Operation mode ····· Cooling and Heating
Unit····· Outdoor unit: FDC140VNA-W × 1 unit
Indoor unit: FDT71VH × 2 units

Operation characteristics of each unit (Cooling/Heating)

Item \ Model	FDC140VNA-W	FDT71VH
Power consumption (kW)	4.59/4.06	0.08/0.08
Running current (A)	20.3/17.8	0.70/0.70

① Total power consumption (kW)

(Cooling) 4.59 + (0.08 × 2) = 4.75

(Heating) 4.06 + (0.08 × 2) = 4.22

② Total running current (A)

(Cooling) 20.3 + (0.70 × 2) = 21.7

(Heating) 17.8 + (0.70 × 2) = 19.2

③ Total power factor (%)

(Cooling) $\frac{4.75 \times 1000}{21.7 \times 220} \times 100 \fallingdotseq 99\ \%$

(Heating) $\frac{4.22 \times 1000}{19.2 \times 220} \times 100 \fallingdotseq 99\ \%$

(ii) 3 Phase models

1) Total power consumption

Total power consumption (kW) = Power consumption of outdoor unit + ∑ (Power consumption of indoor unit)

2) Total running current

Total running current (A) = Running current of outdoor unit + [∑ (Running current of indoor unit) × 1/3]

3) Total power factor

Total power factor (%) = [Total power consumption (W) / $\sqrt{3}$ × Total running current (A) × Power source] × 100

Total operation characteristics = Operation characteristic value of outdoor unit + Operation characteristic value of indoor unit

[Example]

(Conditions) Operation voltage ····· Indoor unit: 220 V, 50 Hz
Outdoor unit: 380 V, 50 Hz
Operation mode ····· Cooling and Heating
Unit····· Outdoor unit: FDC125VSA-W × 1 unit
Indoor unit: FDT50VH × 1 unit, FDT71VH × 1 unit

Operation characteristics of each unit

(Cooling/Heating)

Item \ Model	FDC125VSA-W	FDT50VH	FDT71VH
Power consumption (kW)	4.00/3.38	0.04/0.04	0.08/0.08
Running current (A)	5.9/5.0	0.36/0.36	0.70/0.70

① Total power consumption (kW)

(Cooling) 4.00 + 0.04 + 0.08 = 4.12 (kW)

(Heating) 3.38 + 0.04 + 0.08 = 3.50 (kW)

② Total running current (A)

(Cooling) $5.9 + \left[(0.36 + 0.70) \times \frac{1}{3})\right] \fallingdotseq 6.3$ (A)

(Heating) $5.0 + \left[(0.36 + 0.70) \times \frac{1}{3})\right] \fallingdotseq 5.4$ (A)

③ Total power factor (%)

(Cooling) $\frac{4.12 \times 1000}{\sqrt{3} \times 6.3 \times 380} \times 100 \fallingdotseq 99$ %

(Heating) $\frac{3.50 \times 1000}{\sqrt{3} \times 5.4 \times 380} \times 100 \fallingdotseq 98$ %

2.3 EXTERIOR DIMENSIONS
(1) Indoor units
(a) Ceiling cassette-4 way type (FDT) .....See page 68
(b) Ceiling suspended type (FDE) .....See page 75
(2) Outdoor units .....See page 80
(3) Remote control (Option parts) .....See page 81
2.4 ELECTRICAL WIRING
(1) Indoor units
(a) Ceiling cassette-4 way type (FDT) .....See page 84
(b) Ceiling suspended type (FDE) .....See page 90
(2) Outdoor units .....See page 93
2.5 NOISE LEVEL
(1) Indoor units
(a) Ceiling cassette-4 way compact type (FDT) .....See page 95
(b) Ceiling suspended type (FDE) .....See page 98
(2) Outdoor units .....See page 100
2.6 TEMPERATURE AND VELOCITY DISTRIBUTION
(1) Indoor units
(a) Ceiling cassette-4 way type (FDT) .....See page 107
(b) Ceiling suspended type (FDE) .....See page 112
2.7 PIPING SYSTEM .....See page 116
2.8 RANGE OF USAGE & LIMITATIONS .....See page 118
2.9 SELECTION CHART .....See page 122
2.10 APPLICATION DATA
2.10.1 Installation of indoor unit
(1) Ceiling cassette-4 way type (FDT) .....See page 156
(2) Ceiling suspended type (FDE) .....See page 182
2.10.2 Electric wiring work installation .....See page 195
2.10.3 Installation of wired remote control (Option parts) .....See page 199
2.10.4 Installation of outdoor unit .....See page 211
2.10.5 Instructions for branching pipe set (DIS-WA1,WB1,TA1,TB1) .....See page 215
2.10.6 Safety precautions in handling air-conditioners with flammable refrigerants.....See page 218
2.11 TECHNICAL INFORMATION
(1) Ceiling cassette-4 way type (FDT) .....See page 245
(2) Ceiling suspended type (FDE) .....See page 317

3. OPTION PARTS

CONTENTS

3.1 WIRELESS KIT 354
3.1.1 FDT series (RCN-T-5AW-E2) 354
3.1.2 FDTC series (RCN-TC-5AW-E2) 362
3.1.3 FDU,FDUM series (RCN-KIT4-E2) 370
3.1.4 FDE series (RCN-E-E3) 378
3.2 MOTION SENSOR KIT 386
3.2.1 FDT series (LB-T-5W-E) 386
3.2.2 FDTC series (LB-TC-5W-E) 390
3.2.3 FDU,FDUM series (LB-KIT) 394
3.2.4 FDE series (LB-E) 400
3.2.5 User's manual 404
3.3 SIMPLE WIRED REMOTE CONROL (RCH-E3) 406
3.4 OA SPACER (FDTC series) 412
3.5 DUCT JOINT (FDTC series) 416
3.6 FILTER KIT (FDUM series) 417
3.7 INTERFACE KIT (SC-BIKN2-E) 419
3.7.1 Cable connection for SRK twin/triple installation 423
3.8 SUPERLINK E BOARD (SC-ADNA-E) 424

3.1 WIRELESS KIT

3.1.1 FDT series (RCN-T-5AW-E2)

Notes:
Following function of FDT indoor unit series are not able to be set with this wireless remote control (RCN-T-5AW-E2).
1. Individual flap control system

PJF012D035 B

Safety precautions

●Please read this manual carefully before starting installation work to install the unit properly.
Every one of the followings is important information to be observed strictly.
⚠WARNING Failure to follow these instructions properly may result in serious consequences such as death, severe injury, etc.
⚠CAUTION Failure to follow these instructions properly may cause injury or property damage. It could have serious consequences depending on the circumstances.
●The following pictograms are used in the text.

⃠	Never do.	❗	Always follow the instructions given.

●Keep this manual at a safe place where you can consult with whenever necessary. Show this manual to installers when moving or repairing the unit. When the ownership of the unit is transferred, this manual should be given to a new owner.

⚠WARNING

- **Consult your dealer or a professional contractor to install the unit.**
  Improper installation made on your own may cause electric shocks, fire or dropping of the unit.
- **Installation work should be performed properly according to this installation manual.**
  Improper installation work may result in electric shocks, fire or break-down.
- **Be sure to use accessories and specified parts for installation work.**
  Use of unspecified parts may result in drop, fire or electric shocks.
- **Install the unit properly to a place with sufficient strength to hold the weight.**
  If the place is not strong enough, the unit may drop and cause injury.
- **Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.**
  Power source with insufficient and improper work can cause electric shock and fire.
- **Shut OFF the main power source before starting electrical work.**
  Otherwise, it could result in electric shocks, break-down or malfunction.
- **Do not modify the unit.**
  It could cause electric shocks, fire, or break-down.
- **Be sure to turn OFF the power circuit breaker before repairing/inspecting the unit.**
  Repairing/inspecting the unit with the power circuit breaker turned ON could cause electric shocks or injury.
- **Do not install the unit in appropriate environment or where inflammable gas could generate, flow in, accumulate or leak.**
  If the unit is used at places where air contains dense oil mist, steam, organic solvent vapor, corrosive gas (ammonium, sulfuric compound, acid, etc) or where acidic or alkaline solution, special spray, etc. are used, it could cause electric shocks, break-down, smoke or fire as a result of significant deterioration of its performance or corrosion.
- **Do not install the unit where water vapor is generated excessively or condensation occurs.**
  It could cause electric shocks, fire, or break-down.
- **Do not use the unit in a place where it gets wet, such as laundry room.**
  It could cause electric shocks, fire, or break-down.
- **Do not operate the unit with wet hands.**
  It could cause electric shocks.

⚠WARNING

- **Do not wash the unit with water.**
  It could cause electric shocks, fire, or break-down.
- **Use the specified cables for wiring, and connect them securely with care to protect electronic parts from external forces.**
  Improper connections or fixing could cause heat generation, fire, etc.
- **When installing the unit at a hospital, telecommunication facility, etc., take measures to suppress electric noises.**
  It could cause malfunction or break-down due to hazardous effects on the inverter, private power generator, high frequency medical equipment, radio communication equipment, etc.
  The influences transmitted from the remote control to medical or communication equipment could disrupt medical activities, video broadcasting or cause noise interference.
- **Do not leave the remote control with its PCB case removed.**
  If dew, water, insect, etc. enters through the hole, it could cause electric shocks, fire or break-down.

⚠CAUTION

- Do not install the wireless kit at the following places in order to avoid malfunction.
  It could cause break-down or deformation of remote control.
  (1) Places exposed to direct sunlight
  (2) Places near heat devices
  (3) High humidity places
  (4) Hot surface or cold surface enough to generate condensation
  (5) Places exposed to oil mist or steam directly
  (6) Uneven surface
  (7) Places affected by the direct air flow of the AC unit
  (8) Places where the receiver is influenced by the fluorescent lamp (especially inverter type) or sunlight
  (9) Places where the receiver is affected by infrared rays of any other communication devices
  (10) Places where some object may obstruct the communication with the remote control

①Accessories

Please make sure that you have all of the following accessories.

① Receiver		1
② Parts set (A)		1
③ Installation manual		1

① Wireless remote control (RCN-E2)		1
② Remote control holder		1
③ Screw for holder		2
④ AAA dry cell battery (LR03)		2
⑤ User's manual		1

②Preparation before installation

Setting on site

PCB on the receiver has the following switches to set the function.
Default setting is shown with ☐ mark.

SW1	Prevents interference during plural setting	☐ ON : Normal	OFF : Customized
SW2	Receiver master/ slave setting	☐ ON : Master	OFF : Slave
SW3	Buzzer	☐ ON : Valid	OFF : Invalid
SW4	Auto restart	ON : Valid	☐ OFF : Invalid

② Preparation before installation (continued)

To change setting

1. Remove the cover by unscrewing two screws from the back of receiver.
2. Change the setting by the switch on PCB.



Master/Slave setting when using plural remote controls

Up to two receiver or wired remote control can be installed in one indoor unit group.
When two receiver or wired remote control are used, it is necessary to change SW on the PCB to set it as slave.

3. When SW1 is turned to OFF position, change the wireless remote control setting.
   For the method of changing the setting, refer to Setting to avoid mixed communication of ④ Wireless remote control .

   *The receivable area of the signal refer to ⑤ Receiver .

③ How to install the receiver

The receiver can be installed by replacing with a corner panel on the applicable decorative panel.

Preparation before installation

① Attach the decorative panel onto the air-conditioner according to the installation manual for the panel.
② Remove the air return grille.
③ Remove a corner panel located on the refrigerant pipes side.
④ Remove three screws and detach the cover (indicated as shadowed area) from the control box of the air- conditioner.



③ How to install the receiver(continued)

Installation of the receiver

① Loosen the bolts which fix the panel and make a gap between the panel and the indoor unit.
② Put the wiring of the receiver through the opening.
③ Put the wiring on the notch on the control box so as not to be pinched by the control box and lid as shown below.
④ Connect the wiring to the terminal block provided in the control box. (No polarity)
⑤ Attach the receiver to the panel according to the panel installation manual.
⑥ Fix the wiring with the clamp so that the wiring do not contact the edge of control box's metal sheet.
⑦ Reattach the control box lid with 3 screws removed.



④ Wireless remote control

Installation tips for the remote control holder

Fix the remote control holder using the screws supplied with this product.

* Precautions for installing the holder
- Adjust the position so that it is upright.
- Ensure that the screw heads are not protruding.
- Do not attach the holder on plaster wall



How to insert batteries

1. Detach the back lid.
2. Insert the batteries. (two AAA batteries)
3. Reattach the back lid.



Setting to avoid mixed communication

1. Detach the back lid, and remove the batteries.
2. Cut off the switching wire in the battery compartment using nippers.
3. Insert the batteries, and attach the back lid.



Changing the remote control setting

How to change the Auto Run setting
The Auto Run mode is not available on the building air-conditioning and gas heat pump series (excluding the cooling/heating free multi system).
When using the remote control to operate those models, set the remote control to disable the Auto Run mode.
To disable the Auto Run mode, press the ACL switch while holding down the MODE button, or insert batteries while holding down the MODE button.

* Note: Once the batteries are removed, the setting is reset to the factory default. When the batteries are removed, repeat the steps described above.



Indoor function settings

1. How to set indoor functions
   ① Press the ON/OFF button to stop the unit.
   ② Press the desired one of the buttons shown item **2.** while holding down the FUNCTION SETTING switch.
   ③ Use the selection buttons, ▲ and ▼, to change the setting.
   ④ Press the SET button.
   The buzzer on the remote control signal receiver beeps twice, and the LED lamp flashes four times at two-second intervals.



④ Wireless remote control (continued)

2. Setting details
   The following functions can be set.

Button	Number indicator	Function setting
FAN SPEED	00	Fun speed setting : Standard
	01	Fun speed setting : Setting 1 *
	02	Fun speed setting : Setting 2 *
MODE	00	Room heating temperature adjustment : Disable
	01	Room heating temperature adjustment : +1°C
	02	Room heating temperature adjustment : +2°C
	03	Room heating temperature adjustment : +3°C
FILTER	00	Filter sign display : OFF
	01	Filter sign display : 180 hours
	02	Filter sign display : 600 hours
	03	Filter sign display : 1000 hours
	04	Filter sign display : Operation stop after 1000 hours have elapsed
U/P	00	Anti draft setting : Disable
	01	Anti draft setting : Enable
SILENT	00	Infrared sensor setting (Motion sensor setting) : Disable
	01	Infrared sensor setting (Motion sensor setting) : Enable
HI POWER	00	Infrared sensor control (Motion sensor control) : Disable
	01	Infrared sensor control (Motion sensor control) : Power control only
	02	Infrared sensor control (Motion sensor control) : Auto OFF only
	03	Infrared sensor control (Motion sensor control) : Power control and Auto OFF
ON TIMER	00	Cooling fan residual-period running : Disable
	01	Cooling fan residual-period running : 0.5 hours
	02	Cooling fan residual-period running : 2 hours
	03	Cooling fan residual-period running : 6 hours
OFF TIMER	00	Heating fan residual-period running : Disable
	01	Heating fan residual-period running : 0.5 hours
	02	Heating fan residual-period running : 2 hours
	03	Heating fan residual-period running : 6 hours
NIGHT SETBACK	00	Remote control signal receiver LED : Brightness High
	01	Remote control signal receiver LED : Brightness Low
	02	Remote control signal receiver LED : OFF

* Refer to service manual.

⑤ Receiver

1 Control plural indoor units with one remote control

Up to 16 indoor units can be connected.

1. Connect the XY terminal with 2 cores wire. As for the size, refer to the following note.
2. For Packaged air-conditioner series, set the indoor unit address with SW2 on the indoor unit PCB from [0] to [F] so as not to duplicate.

Restrictions on the thickness and length of wire (Maximun total extension 600m.)

Standard	Within 0.3 mm² × 100m
	Within 0.5 mm² × 200m
	Within 0.75mm² × 300m
	Within 1.25mm² × 400m
	Within 2.0 mm² × 600m

For the shop series

For VRF series, set the indoor unit address with SW1, SW2 and SW5-2 on the indoor unit PCB from [000] to [127] so as not to duplicate.



For the building air-conditioning and gas heat pump series

Set the indoor unit and outdoor unit numbers by manually specifying the addresses.
Use the rotary switches SW1 and SW2 provided on the indoor unit PCB (printed circuit board) to set the indoor unit numbers so that they are not duplicated.

Master/Slave setting when using plural remote control

Up to two receivers can be installed in one indoor unit group.



Switch	Setting	Function
SW2	ON	Master
	OFF	Slave

Wireless remote control's operable area

1. Standard reachable area of the signal
   [condition] Illuminance at the receiver: 300lux
   (when no lighting is installed within 1m of the receiver in an ordinary office.)



⑤ Receiver (continued)

2. Correlation between illuminance at the receiver and reachable area of the signal in a plain view. The drawing in the right shows the correlation between the reachable area of the signal and illuminance at the receiver when the remote control is operated at 1.0m high under the condition of ceiling height of 2.4m. When the illuminance becomes double, the area is narrowed down to two thirds.



3. Installation tips when several receivers are installed close
   Minimum distance between the indoor units which can avoid cross communication is 5m under the condition of 300lux of illuminance at the receiver.
   (When no lighting is installed within 1m of the receiver in an ordinary office)

Backup switch

A backup switch is provided on the receiver. Even when the operation from the wireless remote control is not possible (due to flat batteries, control lost, or control failure), still it possible to operate as temporary means. Press the switch directly when operating it.

1. The air-conditioner starts the operation with the condition of Auto mode, 23°C of set point, High fan speed and horizontal louver position.
2. The air-conditioner stops the operation when the switch is pressed when in operation.



Cooling test run operation

- After safety confirmation, turn on the power.
- Transmit a cooling operation command with the wireless remote control unit, while the backup switch on the receiver is depressed.
- If the backup switch on the receiver is pressed during a test run, it will end the test run.
- If you cannot operate the unit properly during a test run, please check wiring by consulting with inspection guides.

How to read the 2-digit display

On the receiver of a wireless kit, a two-digit (7-segment) display is provided.

1. An indication will be displayed for one hour after power on.
2. An indication will be displayed for 3.5 seconds after transmitting a “STOP” command from the wireless remote control or the operation of the backup switch to stop the unit.
3. An indication appearing in (1) or (2) above will go off as soon as the unit starts operation.
4. When there are no error records to indicate, addresses of all the connected units are displayed.
5. When there are some error records remaining, the error records are displayed.
6. Error records can be cleared by transmitting a "STOP" command from the wireless remote control, while the backup button is pressed.

3.1.2 FDTC series (RCN-TC-5AW-E2)

Safety precautions

•Please read this manual carefully before starting installation work to install the unit properly.
All of the following are important information to be observed strictly.
⚠WARNING Failure to follow these instructions properly may result in serious consequences such as death, severe injury, etc.
⚠CAUTION Failure to follow these instructions properly may cause injury or property damage. It could have serious consequences depending on the circumstances.
•The following symbols are used in the text.

⃠	Never do.	❗	Always follow the instructions given.

•Keep this manual at a safe place where you can consult with whenever necessary. Show this manual to installers when moving or repairing the unit. When the ownership of the unit is transferred, this manual should be given to the new owner.

⚠WARNING

- **Consult your dealer or a professional contractor to install the unit.**
  Improper installation made on your own may cause electric shocks, fire or dropping of the unit.
- **Installation work should be performed properly according to this installation manual.**
  Improper installation work may result in electric shocks, fire or break-down.
- **Be sure to use accessories and specified parts for installation work.**
  Use of unspecified parts may result in drop, fire or electric shocks.
- **Install the unit properly to a place with sufficient strength to hold the weight.**
  If the place is not strong enough, the unit may drop and cause injury.
- **Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.**
  Power source with insufficient and improper work can cause electric shock and fire.
- **Shut OFF the main power source before starting electrical work.**
  Otherwise, it could result in electric shocks, break-down or malfunction.
- **Do not modify the unit.**
  It could cause electric shocks, fire, or break-down.
- **Be sure to turn OFF the power circuit breaker before repairing/inspecting the unit.**
  Repairing/inspecting the unit with the power circuit breaker turned ON could cause electric shocks or injury.
- **Do not install the unit in appropriate environment or where inflammable gas could generate, flow in, accumulate or leak.**
  If the unit is used at places where air contains dense oil mist, steam, organic solvent vapor, corrosive gas (ammonium, sulfuric compound, acid, etc) or where acidic or alkaline solution, special spray, etc. are used, it could cause electric shocks, break-down, smoke or fire as a result of significant deterioration of its performance or corrosion.
- **Do not install the unit where water vapor is generated excessively or condensation occurs.**
  It could cause electric shocks, fire, or break-down.
- **Do not use the unit in a place where it gets wet, such as laundry room.**
  It could cause electric shocks, fire, or break-down.
- **Do not operate the unit with wet hands.**
  It could cause electric shocks.

⚠WARNING

- **Do not wash the unit with water.**
  It could cause electric shocks, fire, or break-down.
- **Use the specified cables for wiring, and connect them securely with care to protect electronic parts from external forces.**
  Improper connections or fixing could cause heat generation, fire, etc.
- **When installing the unit at a hospital, telecommunication facility, etc., take measures to suppress electric noises.**
  It could cause malfunction or break-down due to hazardous effects on the inverter, private power generator, high frequency medical equipment, radio communication equipment, etc.
  The influences transmitted from the remote control to medical or communication equipment could disrupt medical activities, video broadcasting or cause noise interference.
- **Do not leave the remote control with its PCB case removed.**
  If dew, water, insect, etc. enter through the hole, it could cause electric shocks, fire or break-down.

⚠CAUTION

- Do not install the wireless kit at the following places in order to avoid malfunction.
  It could cause break-down or deformation of remote control.
  (1) Places exposed to direct sunlight
  (2) Places near heat-generating devices
  (3) High humidity places
  (4) Hot surface or cold surface enough to generate condensation
  (5) Places exposed to oil mist or steam directly
  (6) Uneven surface
  (7) Places affected by the direct air flow of the AC unit
  (8) Places where the receiver is influenced by fluorescent lamp (especially inverter type) or sunlight
  (9) Places where the receiver is affected by infrared rays of any other communication devices
  (10) Places where some object may obstruct the communication with the remote control

① Accessories

Please make sure that you have all of the following accessories.

① Receiver		1
② PCB		1
③ PCB mounting support		2
④ Bracket (Sheet metal)		1

⑤ Bracket mounting screw		1
⑥ Wiring (For communication)		1
⑦ Wiring (For receiving)		1
⑧ Installation manual		1
⑨ Parts set		1

① Wireless remote control (RCN-E2)		1
② Remote control holder		1
③ Screw for holder		2
④ AAA dry cell battery (LR03)		2
⑤ User's manual		1

② Preparation before installation

Setting of PCB

Accessory PCB has the following switches to set the functions. Default setting is shown with ☐ mark.

SW1	Prevents interference during multiple setting	☐ ON : Normal	OFF : Remote
SW2	Receiver master/slave setting	☐ ON : Master	OFF : Slave
SW3	Buzzer	☐ ON : Valid	OFF : Invalid
SW4	Auto restart	ON : Valid	☐ OFF : Invalid

② Preparation before installation (continued)

To change setting

1. Change the setting of switches on the accessory PCB.



Master/Slave setting when using multiple remote controls

Up to two receivers or wired remote controls can be installed on one indoor unit group. In such occasion, it is necessary to change the setting to slave on either one.
To change the setting on the receiver, refer to the instruction manual of the receiver.

2. When SW1 is turned to OFF position, change the wireless remote control setting.
   For the method of changing the setting, refer to Setting to avoid mixed communication of ④ Wireless remote control .
   *For the receivable area of the signal, refer to ⑤ Receiver .

③ How to install the receiver

It is possible to install the receiver by replacing the corner lid on the panel.

Preparation before installation

① Remove the inlet grille according to the installation manual of the panel.
② Remove the corner lid at the refrigerant pipe side.
③ Loosen screws (2 pcs) on the control box of the unit.
④ Slide the control lid in the arrow direction, and remove it.



③ How to install the receiver(continued)

Installation of the receiver

① Connect the wire connector (Communication) to CNB on PCB.
② Connect the wire connector (Receiver) to CN3 on PCB.
③ Install the PCB mounting supports on the bracket (Sheet metal).
④ Install PCB on the PCB mounting supports.
⑤ Insert the bracket (Sheet metal) in one side of control box, and fix the other side with screws as shown in the figure.
⑥ Connect round terminals of wires (Communication) to the terminal block (X, Y) in the control box. The wires have no polarity.
⑦ Fix wires with bands as shown in the figure.
⑧ Cut off the half-blanks on the panel (at 4 places) as shown in the figure.
⑨ Pass the wiring (Communication) through the opening on the panel.
⑩ Connect connectors of the wiring (Communication) and the receiver.
⑪ Install the receiver on the panel according to the installation manual of the panel.
⑫ Install the control box lid with care not to pinch wires, and fix with screws (2 pcs).



Installation of ④, ⑤ brackets (Sheet metal)



Cut off at 4 places.

④ Wireless remote control

Installation tips for the remote control holder

Fix the remote control holder using the screws supplied with this product.

* Precautions for installing the holder
- Adjust the position so that it is upright.
- Ensure that the screw heads are not protruding.
- Do not attach the holder on plaster wall.



How to insert batteries

1. Detach the back lid.
2. Insert the batteries. (two AAA batteries)
3. Reattach the back lid.



Setting to avoid mixed communication

1. Detach the back lid, and remove the batteries.
2. Cut off the switching wire in the battery compartment using nippers.
3. Insert the batteries, and attach the back lid.



Changing the remote control setting

How to change the Auto Run setting
The Auto Run mode is not available on the building air-conditioning and gas heat pump series (excluding the cooling/heating free multi system).
When using the remote control to operate those models, set the remote control to disable the Auto Run mode.
To disable the Auto Run mode, press the ACL switch while holding down the MODE button, or insert batteries while holding down the MODE button.

* Note: Once the batteries are removed, the setting is reset to the factory default.
When the batteries are removed, repeat the steps described above.



Indoor function settings

1. How to set indoor functions
   ① Press the ON/OFF button to stop the unit.
   ② Press the desired one of the buttons shown item **2.** while holding down the FUNCTION SETTING switch.
   ③ Use the selection buttons ▲ and ▼ to change the setting.
   ④ Press the SET button.
   The buzzer on the remote control signal receiver beeps twice, and the LED lamp flashes four times at two-second intervals.



④ Wireless remote control (continued)

2. Setting details
   The following functions can be set.

Button	Number indicator	Function setting
FAN SPEED	00	Fun speed setting : Standard
	01	Fun speed setting : Setting 1 *
	02	Fun speed setting : Setting 2 *
MODE	00	Room heating temperature adjustment : Disable
	01	Room heating temperature adjustment : +1°C
	02	Room heating temperature adjustment : +2°C
	03	Room heating temperature adjustment : +3°C
FILTER	00	Filter sign display : OFF
	01	Filter sign display : 180 hours
	02	Filter sign display : 600 hours
	03	Filter sign display : 1000 hours
	04	Filter sign display : Operation stop after 1000 hours have elapsed
U/P (Up/Down)	00	Anti draft setting : Disable
	01	Anti draft setting : Enable
SILENT	00	Infrared sensor setting (Motion sensor setting) : Disable
	01	Infrared sensor setting (Motion sensor setting) : Enable
HI POWER	00	Infrared sensor control (Motion sensor control) : Disable
	01	Infrared sensor control (Motion sensor control) : Power control only
	02	Infrared sensor control (Motion sensor control) : Auto OFF only
	03	Infrared sensor control (Motion sensor control) : Power control + Auto OFF
ON TIMER	00	Cooling fan residual-period running : Disable
	01	Cooling fan residual-period running : 0.5 hours
	02	Cooling fan residual-period running : 2 hours
	03	Cooling fan residual-period running : 6 hours
OFF TIMER	00	Heating fan residual-period running : Disable
	01	Heating fan residual-period running : 0.5 hours
	02	Heating fan residual-period running : 2 hours
	03	Heating fan residual-period running : 6 hours
NIGHT SETBACK	00	Remote control signal receiver LED : Brightness High
	01	Remote control signal receiver LED : Brightness Low
	02	Remote control signal receiver LED : OFF

* Refer to service manual.

⑤ Receiver

1 Control multiple indoor units with one remote control

Up to 16 indoor units can be connected.

1. Connect the XY terminal with 2 cores wire. As for the size, refer to the note on the right.
2. For Packaged air-conditioner series, set the indoor unit address with SW2 on the indoor unit PCB from [1] to [F] so as not to duplicate.

Restrictions on the thickness and length of wire (Maximum length is 600m.)

Standard	Within	0.3 mm² × 100m
	Within	0.5 mm² × 200m
	Within	0.75mm² × 300m
	Within	1.25mm² × 400m
	Within	2.0 mm² × 600m

For the shop series

For VRF series, set the indoor unit address with SW1, SW2 and SW5-2 on the indoor unit PCB from [000] to [127] so as not to duplicate.



For the building air-conditioning and gas heat pump series

Set the indoor unit and outdoor unit numbers by manually specifying the addresses.
Use the rotary switches SW1 and SW2 provided on the indoor unit PCB (printed circuit board) to set the indoor unit numbers so that they are not duplicated.

Master/Slave setting when using multiple remote control

Up to two receivers can be installed in one indoor unit group.



Switch	Setting	Function
SW2	ON	Master
	OFF	Slave

Wireless remote control's operable area

1. Standard reachable area of the signal

[Condition] Illuminance at the receiver: 300lux
(When no lighting is installed within 1m of the receiver in an ordinary office)



⑤ Receiver (continued)

2. Correlation between illuminance at the receiver and reachable area of the signal in a plain view.
   The drawing in the right shows the correlation between the reachable area of the signal and illuminance at the receiver when the remote control is operated at 1m high under the condition of ceiling height of 2.4m.
   When the illuminance becomes double, the area is narrowed down to two thirds.



3. Installation tips when several receivers are installed close to one another.
   Minimum distance between the indoor units which can avoid cross communication is 5m under the condition of 300lux of illuminance at the receiver.
   (When no lighting is installed within 1m of the receiver in an ordinary office)

Backup switch

A backup switch is provided on the receiver section of the panel surface.
When operation from the wireless remote control unit is not possible (due to flat batteries, a mislaid unit, a unit failure), you can use it as an emergency means. You should operate this switch manually.



1. If pressed while the air-conditioner is in a halt, it will cause the air-conditioner to start operation in the automatic mode (In case of cooling only, it is in the cooling mode).
   Wind speed: Hi fan, Temperature setting: 23°C, Louver: horizontal
2. If pressed while the air-conditioner is in operation, it will stop the air-conditioner.

Cooling test run operation

- After safety confirmation, turn on the power.
- Transmit a cooling operation command with the wireless remote control unit, while the backup switch on the receiver is pressed.
- If the backup switch on the receiver is pressed during a test run, it will end the test run.
- If you cannot operate the unit properly during a test run, please check wiring by consulting with inspection guides.

How to read the two-digit display

On the receiver of a wireless kit, a two-digit (7-segment) display is provided.

1. An indication will be displayed for one hour after power on.
2. An indication will be displayed for 3.5 seconds after transmitting a “STOP” command from the wireless remote control or the operation of the backup switch to stop the unit.
3. An indication appearing in (1) or (2) above will go off as soon as the unit starts operation.
4. When there are no error records to indicate, addresses of all the connected units are displayed.
5. When there are some error records remaining, the error records are displayed.
6. Error records can be cleared by transmitting a “STOP” command from the wireless remote control, while the backup button is pressed.

3.1.3 FDU,FDUM series (RCN-KIT4-E2)

PJZ012D112Ⓐ

Safety precautions

●Please read this manual carefully before starting installation work to install the unit properly.
Every one of the followings is important information to be observed strictly.
⚠WARNING Failure to follow these instructions properly may result in serious consequences such as death, severe injury, etc.
⚠CAUTION Failure to follow these instructions properly may cause injury or property damage. It could have serious consequences depending on the circumstances.
●The following pictograms are used in the text.

⃠	Never do.	❗	Always follow the instructions given.

●Keep this manual at a safe place where you can consult with whenever necessary. Show this manual to installers when moving or repairing the unit. When the ownership of the unit is transferred, this manual should be given to a new owner.

⚠WARNING

- **Consult your dealer or a professional contractor to install the unit.**
  Improper installation made on your own may cause electric shocks, fire or dropping of the unit.
- **Installation work should be performed properly according to this installation manual.**
  Improper installation work may result in electric shocks, fire or break-down.
- **Be sure to use accessories and specified parts for installation work.**
  Use of unspecified parts may result in drop, fire or electric shocks.
- **Install the unit properly to a place with sufficient strength to hold the weight.**
  If the place is not strong enough, the unit may drop and cause injury.
- **Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.**
  Power source with insufficient and improper work can cause electric shock and fire.
- **Shut OFF the main power source before starting electrical work.**
  Otherwise, it could result in electric shocks, break-down or malfunction.
- **Do not modify the unit.**
  It could cause electric shocks, fire, or break-down.
- **Be sure to turn OFF the power circuit breaker before repairing/inspecting the unit.**
  Repairing/inspecting the unit with the power circuit breaker turned ON could cause electric shocks or injury.
- **Do not install the unit in appropriate environment or where inflammable gas could generate, flow in, accumulate or leak.**
  If the unit is used at places where air contains dense oil mist, steam, organic solvent vapor, corrosive gas (ammonium, sulfuric compound, acid, etc) or where acidic or alkaline solution, special spray, etc. are used, it could cause electric shocks, break-down, smoke or fire as a result of significant deterioration of its performance or corrosion.
- **Do not install the unit where water vapor is generated excessively or condensation occurs.**
  It could cause electric shocks, fire, or break-down.
- **Do not use the unit in a place where it gets wet, such as laundry room.**
  It could cause electric shocks, fire, or break-down.
- **Do not operate the unit with wet hands.**
  It could cause electric shocks.

⚠WARNING

- **Do not wash the unit with water.**
  It could cause electric shocks, fire, or break-down.
- **Use the specified cables for wiring, and connect them securely with care to protect electronic parts from external forces.**
  Improper connections or fixing could cause heat generation, fire, etc.
- **When installing the unit at a hospital, telecommunication facility, etc., take measures to suppress electric noises.**
  It could cause malfunction or break-down due to hazardous effects on the inverter, private power generator, high frequency medical equipment, radio communication equipment, etc.
  The influences transmitted from the remote control to medical or communication equipment could disrupt medical activities, video broadcasting or cause noise interference.
- **Do not leave the remote control with its PCB case removed.**
  If dew, water, insect, etc. enters through the hole, it could cause electric shocks, fire or break-down.

⚠CAUTION

- Do not install the wireless kit at the following places in order to avoid malfunction.
  It could cause break-down or deformation of remote control.
  (1) Places exposed to direct sunlight
  (2) Places near heat devices
  (3) High humidity places
  (4) Hot surface or cold surface enough to generate condensation
  (5) Places exposed to oil mist or steam directly
  (6) Uneven surface
  (7) Places affected by the direct air flow of the AC unit
  (8) Places where the receiver is influenced by the fluorescent lamp (especially inverter type) or sunlight
  (9) Places where the receiver is affected by infrared rays of any other communication devices
  (10) Places where some object may obstruct the communication with the remote control

① Accessories

Please make sure that you have all of the following accessories.

① Receiver		1
② Wiring (3m)		1
③ Parts set (A)		1
④ Parts set (B)		1
⑤ Parts set (C)		1
⑥ Installation manual		1

① Wireless remote control (RCN-E2)		1
② Remote control holder		1
③ Screw for holder		2
④ AAA dry cell battery (LR03)		2
⑤ User"s manual		1

① Screw for receiver		2
② Fixing band		1
③ Clamp		5
④ Screw for clamp		5

① Receiver installation bracket		1
② Screw for the bracket		2
③ Installation fitting		2

② Preparation before installation

Setting on site

PCB on the receiver has the following switches to set the function. Default setting is shown with ☐ mark.

SW1	Prevents interference during plural setting	☐ ON : Normal	OFF : Customized
SW2	Receiver master/ slave setting	☐ ON : Master	OFF : Slave
SW3			
SW4	Auto restart	ON : Valid	☐ OFF : Invalid

② Preparation before installation (continued)

To change setting

1. Remove one screws located on the under of the receiver and detach the board.
2. Change the setting by the switch on PCB.





Default settings

3. When SW1 is turned to OFF position, change the wireless remote control setting. For the method of changing the setting, refer to Setting to avoid mixed communication of ④ Wireless remote control .

*The receivable area of the signal refer to ⑤ Receiver .

Master/Slave setting when using plural remote controls

Up to two receiver or wired remote control can be installed in one indoor unit group.
When two receiver or wired remote control are used, it is necessary to change SW on the PCB to set it as slave.

③ How to install the receiver

The following two methods can be used to install the receiver onto a ceiling or a wall.
Select a method according to the installation position.

<Installation position> (A) Direct installation onto the ceiling with wood screws.
(B) Installation with accessory's bracket

(1) Drilling of the ceiling (ceiling opening)

Drill the receiver installation holes with the dimensions shown right at the ceiling position where wires can be connected.



(A) Direct installation onto the ceiling with wood screws.	88mm(H)×101mm(W)
(B) Installation with enclosed bracket	108mm(H)×108mm(W)

(2) Wiring connection of receiver



⚠ Caution
Do not connect the wiring to the power source of the terminal block. If it is connected, printed board will be damaged.

(3) Installation of the receiver

Remove the screw on the side of the receiver and sprit it into the upper case and lower case.
Install the receiver with one of the two installation methods (A) to (C) shown below.

(A) Direct installation onto the ceiling with screws



▷ Use this installation method when the ceiling is wooden, and there is no problem for strength in installing directly with wood screws.

① Put through the wiring from the back side to the hole of the lower case.

② Fit the lower case into the ceiling opening. Make sure that the clearance between the convex part of the back of the lower case and the ceiling opening must be as equal as possible on both sides.

③ Using the two installation holes shown right, fix the lower case onto the ceiling with the enclosed wood screws. (The other four holes are not used.)

④ Connect the wiring with the wiring from the upper case by the connector.

③ How to install the receiver(continued)

⑤ Take out the connector to the backside from the hole of the lower case putting through the wiring at ①.
⑥ Fit the upper case and the lower case, and tighten the screws.

(B) Installation with enclosed bracket

Use this method when installaing onto a gypsum board (7 to 18mm), etc.



① Catch the two protrusion of the enclosed bracket onto the fitting as shown above, and temporarily fix with the screws. (The bracket has an Upper/Lower and front/back orientation. Confirm the Upper/Lower protrusion positions and the positional relation of the ø10 holes on the bracket and the installation hole on the lower case with the above drawing.)
② Insert the end of the installation fitting into the back of the ceiling from the opening, and tighten the screws to fix the bracket onto the ceiling.
③ Pass the wiring from the rear side through the hole on the lower case.
④ Fit the lower case onto the bracket, and fix the lower case to the bracket using the two installation holes shown above. (The other four holes are not used.)
⑤ Follow step ① to ⑥ for (A) to complete the installation.

③ How to install the receiver (continued)

(C) Exposed installation

Use the following procedure when installing the case with the wiring exposed.





① Cut off the thin section on the side of the upper case with a pair of nippers or a knife, and remove the burrs with a file, etc. (The wiring is passed through this section.)
② Pass the enclosed band through the wiring outlet hole on the lower case.
③ Use on of the light detection adaptor installation methods (A) or (B) explained in section 3, and fix the lower case onto the wall. Do not pass the wiring through the hole on the lower case.
④ Fix the wiring using the band while leaving the wiring length from the band fixing section to the end of the wiring connector at 100mm or more.
⑤ Connect the wiring with the wiring protruding front the upper case using a connector.
⑥ Pass the connected connector and the excess wiring through the hole on the lower case.
⑦ Fit the upper case onto the lower case, and tighten the screws.
⑧ Adequately fix the wiring with the enclesed cord clamp.

④ Wireless remote control

Installation tips for the remote control holder

Fix the remote control holder using the screws supplied with this product.

* Precautions for installing the holder
- Adjust the position so that it is upright.
- Ensure that the screw heads are not protruding.
- Do not attach the holder on plaster wall.



How to insert batteries

1. Detach the back lid.
2. Insert the batteries. (two AAA batteries)
3. Reattach the back lid.



Setting to avoid mixed communication

1. Detach the back lid, and remove the batteries.
2. Cut off the switching wire in the battery compartment using nippers.
3. Insert the batteries, and attach the back lid.



④ Wireless remote control (continued)

Changing the wireless remote control setting

How to change the Auto Run setting
The Auto Run mode is not available on the building air-conditioner and gas heat pump series (excluding the cooling/heating free multi system).
When using the wireless remote control to operate those models, set the wireless remote control to disable the Auto Run mode.
To disable the Auto Run mode, press the ACL switch while holding down the MODE button, or insert batteries while holding down the MODE button.

* Note: Once the batteries are removed, the setting is reset to the factory default.
When the batteries are removed, repeat the steps described above.



Indoor function settings

1. How to set indoor functions
   ① Press the ON/OFF button to stop the unit.
   ② Press the desired one of the buttons shown below while holding down the FUNCTION SETTING switch.
   ③ Use the selection buttons, ▲ and ▼, to change the setting.
   ④ Press the SET button.
   The buzzer on the wireless remote control signal receiver beeps twice, and the LED lamp flashes four times at two-second intervals.
2. Setting details
   The following functions can be set.



Button	Number indicator	Function setting
FAN SPEED	00	Fun speed setting : Standard
	01	Fun speed setting : Setting 1 *
	02	Fun speed setting : Setting 2 *
MODE	00	Room heating temperature adjustment : Disable
	01	Room heating temperature adjustment : +1°C
	02	Room heating temperature adjustment : +2°C
	03	Room heating temperature adjustment : +3°C
FILTER	00	Filter sign display : OFF
	01	Filter sign display : 180 hours
	02	Filter sign display : 600 hours
	03	Filter sign display : 1000 hours
	04	Filter sign display : Operation stop after 1000 hours have elapsed
U/P	00	Anti draft setting : Disable
	01	Anti draft setting : Enable
SILENT	00	Infrared sensor setting (Motion sensor setting) : Disable
	01	Infrared sensor setting (Motion sensor setting) : Enable
HI POWER	00	Infrared sensor control (Motion sensor control) : Disable
	01	Infrared sensor control (Motion sensor control) : Power control only
	02	Infrared sensor control (Motion sensor control) : Auto OFF only
	03	Infrared sensor control (Motion sensor control) : Power control and Auto OFF

Button	Number indicator	Function setting
ON TIMER	00	Cooling fan residual-period running : Disable
	01	Cooling fan residual-period running : 0.5 hours
	02	Cooling fan residual-period running : 2 hours
	03	Cooling fan residual-period running : 6 hours
OFF TIMER	00	Heating fan residual-period running : Disable
	01	Heating fan residual-period running : 0.5 hours
	02	Heating fan residual-period running : 2 hours
	03	Heating fan residual-period running : 6 hours
NIGHT SETBACK	00	Remote control signal receiver LED : Brightness High
	01	Remote control signal receiver LED : Brightness Low
	02	Remote control signal receiver LED : OFF

* Refer to service manual.

⑤ Receiver

1 Control plural indoor units with one remote control

Up to 16 indoor units can be connected.

1. Connect the XY terminal with 2 cores wire. As for the size, refer to the following note.
2. For Packaged air-conditioner series, set the indoor unit address with SW2 on the indoor unit PCB from [0] to [F] so as not to duplicate.

Restrictions on the thickness and length of wire (Maximun total extension 600m.)

Standard	Within 0.3 mm² × 100m
	Within 0.5 mm² × 200m
	Within 0.75mm² × 300m
	Within 1.25mm² × 400m
	Within 2.0 mm² × 600m

⑤ Receiver (continued)

For the shop series

For VRF series, set the indoor unit address with SW1, SW2 and SW5-2 on the indoor unit PCB from [000] to [127] so as not to duplicate.



For the building air-conditioner and gas heat pump series

Set the indoor unit and outdoor unit numbers by manually specifying the addresses.
Use the rotary switches SW1 and SW2 provided on the indoor unit PCB (printed circuit board) to set the indoor unit numbers so that they are not duplicated.

Master/Slave setting when using plural remote control

Up to two receivers can be installed in one indoor unit group.



Switch	Setting	Function
SW2	ON	Master
	OFF	Slave

When installed on ceiling

1. Standard reachable area of the signal

[Condition] Illuminance at the receiver : **300lux** (when no lighting is installed within 1m of the receiver in an ordinary office.)



2. Correlation between illuminance at the receiver and reachable area of the signal in a plain view.

[Condition] Correlation between the reachable area of the signal and illuminance at the receiver when the wireless remote control is operated at 1m high under the condition of ceiling height of 2.4m. When the illuminance becomes double, the area is narrowed down to two third.

⑤ Receiver (continued)



When installed on wall

[Condition] Illuminance at the receiver : 800lux.





Backup switch

A backup switch is provided on the receiver section of the panel surface. When operation from the wireless remote control unit is not possible (due to flat batteries, a mislaid unit, a unit failure), you can use it as an emergency means. You should operate this switch manually.

1. If pressed while the air-conditioner is in a halt, it will cause the air-conditioner to start operation in the automatic mode (in the case of cooling only, in the cooling mode). Wind speed: Hi fan, Temperature setting: 23°C, Louver: horizontal
2. If pressed while the air-conditioner is in operation, it will stop the air-conditioner.



Cooling test run operation

- After safety confirmation, turn on the power.
- Transmit a cooling operation command with the wireless remote control unit, while the backup switch on the receiver is depressed.
- If the backup switch on the receiver is pressed during a test run, it will end the test run.
- If you cannot operate the unit properly during a test run, please check wiring by consulting with inspection guides.

How to read the 6-digit display

A 6-digit indicator (7-segment indicator) is provided on the receiver section.

1. An indication will be displayed for one hour after power on.
2. An indication appears for 3.5 seconds when a “Stop” command is sent from the wireless remote control unit while the air-conditioner is not running.
3. An indication appearing in (1) or (2) above will go off as soon as the unit starts operation.
4. When there are no error records to indicate, addresses are displayed for all of the connected units.
5. When there are some error records remaining, the error records are displayed.
6. Error records can be cleared by transmitting a “Stop” command from the wireless remote control unit, while the backup switch is depressed.

PFA012D635

3.1.4 FDE series (RCN-E-E3)

Safety precautions

●Please read this manual carefully before starting installation work to install the unit properly.
Every one of the followings is important information to be observed strictly.
⚠WARNING Failure to follow these instructions properly may result in serious consequences such as death, severe injury, etc.
⚠CAUTION Failure to follow these instructions properly may cause injury or property damage. It could have serious consequences depending on the circumstances.
●The following pictograms are used in the text.

⃠	Never do.	❗	Always follow the instructions given.

●Keep this manual at a safe place where you can consult with whenever necessary. Show this manual to installers when moving or repairing the unit. When the ownership of the unit is transferred, this manual should be given to a new owner.

⚠WARNING

- **Consult your dealer or a professional contractor to install the unit.**
  Improper installation made on your own may cause electric shocks, fire or dropping of the unit.
- **Installation work should be performed properly according to this installation manual.**
  Improper installation work may result in electric shocks, fire or break-down.
- **Be sure to use accessories and specified parts for installation work.**
  Use of unspecified parts may result in drop, fire or electric shocks.
- **Install the unit properly to a place with sufficient strength to hold the weight.**
  If the place is not strong enough, the unit may drop and cause injury.
- **Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.**
  Power source with insufficient and improper work can cause electric shock and fire.
- **Shut OFF the main power source before starting electrical work.**
  Otherwise, it could result in electric shocks, break-down or malfunction.
- **Do not modify the unit.**
  It could cause electric shocks, fire, or break-down.
- **Be sure to turn OFF the power circuit breaker before repairing/inspecting the unit.**
  Repairing/inspecting the unit with the power circuit breaker turned ON could cause electric shocks or injury.
- **Do not install the unit in appropriate environment or where inflammable gas could generate, flow in, accumulate or leak.**
  If the unit is used at places where air contains dense oil mist, steam, organic solvent vapor, corrosive gas (ammonium, sulfuric compound, acid, etc) or where acidic or alkaline solution, special spray, etc. are used, it could cause electric shocks, break-down, smoke or fire as a result of significant deterioration of its performance or corrosion.
- **Do not install the unit where water vapor is generated excessively or condensation occurs.**
  It could cause electric shocks, fire, or break-down.
- **Do not use the unit in a place where it gets wet, such as laundry room.**
  It could cause electric shocks, fire, or break-down.
- **Do not operate the unit with wet hands.**
  It could cause electric shocks.

⚠WARNING

- **Do not wash the unit with water.**
  It could cause electric shocks, fire, or break-down.
- **Use the specified cables for wiring, and connect them securely with care to protect electronic parts from external forces.**
  Improper connections or fixing could cause heat generation, fire, etc.
- **When installing the unit at a hospital, telecommunication facility, etc., take measures to suppress electric noises.**
  It could cause malfunction or break-down due to hazardous effects on the inverter, private power generator, high frequency medical equipment, radio communication equipment, etc.
  The influences transmitted from the remote control to medical or communication equipment could disrupt medical activities, video broadcasting or cause noise interference.
- **Do not leave the remote control with its PCB case removed.**
  If dew, water, insect, etc. enters through the hole, it could cause electric shocks, fire or break-down.

⚠CAUTION

- Do not install the wireless kit at the following places in order to avoid malfunction.
  It could cause break-down or deformation of remote control.
  (1) Places exposed to direct sunlight
  (2) Places near heat devices
  (3) High humidity places
  (4) Hot surface or cold surface enough to generate condensation
  (5) Places exposed to oil mist or steam directly
  (6) Uneven surface
  (7) Places affected by the direct air flow of the AC unit.
  (8) Places where the receiver is influenced by the fluorescent lamp (especially inverter type) or sunlight.
  (9) Places where the receiver is affected by infrared rays of any other communication devices.
  (10) Places where some object may obstruct the communication with the remote control

① Accessories

Please make sure that you have all of the following accessories.

① Receiver		1
② Parts set		1
③ Installation manual		1
④ Wiring		1

① Wireless remote control (RCN-E2)		1
② Remote control holder		1
③ Screw for holder		2
④ AAA dry cell battery (LR03)		2
⑤ User's manual		1

② Preparation before installation

Setting on site

PCB on the receiver has the following switches to set the function.
Default setting is shown with ☐ mark.

SW1	Prevents interference during plural setting	☐ ON : Normal OFF : Customized
SW2	Receiver master/slave setting	☐ ON : Master OFF : Slave
SW3	Buzzer	☐ ON : Valid OFF : Invalid
SW4	Auto restart	ON : Valid ☐ OFF : Invalid

② Preparation before installation (continued)

To change setting

1. Remove four screws located on the back of the receiver and detach the board.
2. Change the setting by the switch on PCB.



Receiver backside



Default settings

Master/Slave setting when using plural remote controls

Up to two receiver or wired remote control can be installed in one indoor unit group. When two receiver or wired remote control are used, it is necessary to change SW on the PCB to set it as slave.

3. When SW1 is turned to OFF position, change the wireless remote control setting.
   For the method of changing the setting, refer to Setting to avoid mixed communication of ⑤ Wireless remote control

   *The receivable area of the signal refer to ⑥ Receiver .

③ How to install the receiver

The receiver can be installed by replacing with a cover of the panel.

CAUTION: When installing the receiver after unit has been fixed, injury due to falling may result because of working at high place.

① **Remove the cover**
Insert a flat-blade screwdriver into the dented part (2 places), and wrench slightly so as not to damage panel surface.



② **Connect the wiring**
Connect wiring of the receiver to the wiring in the back.

ATTENTION: Do not remove the clamp fixed the wiring.





③ **Installation of the receiver**
Check direction of the receiver, and fix to the panel.

CAUTION: Connect the connectors before installing the receiver. In case of connecting after the receiver had been installed, it will be necessary to remove the panel.

④ How to connect the wiring for control box

Connect the attached wiring to the signal terminal block primary side XY (for grill side) in the control box, and connect to the CNL connector (3P white) from the receiver .

* This installation is unnecessary for indoor unit that have wiring is already connected from the signal terminal block to the receiver.



⑤ Wireless remote control

Installation tips for the remote control holder

Fix the remote control holder using the screws supplied with this product.

* Precautions for installing the holder
- Adjust the position so that it is upright.
- Ensure that the screw heads are not protruding.
- Do not attach the holder on plaster wall.



How to insert batteries

1. Detach the back lid.
2. Insert the batteries. (two AAA batteries)
3. Reattach the back lid.



Setting to avoid mixed communication

1. Detach the back lid, and remove the batteries.
2. Cut off the switching wire in the battery compartment using nippers.
3. Insert the batteries, and attach the back lid.



Changing the remote control setting

How to change the Auto Run setting
The Auto Run mode is not available on the building air conditioning and gas heat pump series (excluding the cooling/heating free multi system).
When using the remote control to operate those models, set the remote control to disable the Auto Run mode.
To disable the Auto Run mode, press the ACL switch while holding down the MODE button, or insert batteries while holding down the MODE button.

* Note: Once the batteries are removed, the setting is reset to the factory default. When the batteries are removed, repeat the steps described above.



Indoor function settings

1. How to set indoor functions
   ① Press the ON/OFF button to stop the unit.
   ② Press the desired one of the buttons shown item **2.** while holding down the FUNCTION SETTING switch.
   ③ Use the selection buttons, ▲ and ▼, to change the setting.
   ④ Press the SET button.
   The buzzer on the remote control signal receiver beeps twice, and the LED lamp flashes four times at two-second intervals.



⑤ Wireless remote control (continued)

2. Setting details
   The following functions can be set.

Button	Number indicator	Function setting
FAN SPEED	00	Fun speed setting : Standard
	01	Fun speed setting : Setting 1 *
	02	Fun speed setting : Setting 2 *
MODE	00	Room heating temperature adjustment : Disable
	01	Room heating temperature adjustment : +1°C
	02	Room heating temperature adjustment : +2°C
	03	Room heating temperature adjustment : +3°C
FILTER	00	Filter sign display : OFF
	01	Filter sign display : 180 hours
	02	Filter sign display : 600 hours
	03	Filter sign display : 1000 hours
	04	Filter sign display : Operation stop after 1000 hours have elapsed
U/P (Up/Down)	00	Anti draft setting : Disable
	01	Anti draft setting : Enable
SILENT	00	Infrared sensor setting (Motion sensor setting) : Disable
	01	Infrared sensor setting (Motion sensor setting) : Enable
HI POWER	00	Infrared sensor control (Motion sensor control) : Disable
	01	Infrared sensor control (Motion sensor control) : Power control only
	02	Infrared sensor control (Motion sensor control) : Auto OFF only
	03	Infrared sensor control (Motion sensor control) : Power control + Auto OFF
ON TIMER	00	Cooling fan residual-period running : Disable
	01	Cooling fan residual-period running : 0.5 hours
	02	Cooling fan residual-period running : 2 hours
	03	Cooling fan residual-period running : 6 hours
OFF TIMER	00	Heating fan residual-period running : Disable
	01	Heating fan residual-period running : 0.5 hours
	02	Heating fan residual-period running : 2 hours
	03	Heating fan residual-period running : 6 hours
NIGHT SETBACK	00	Remote control signal receiver LED : Brightness High
	01	Remote control signal receiver LED : Brightness Low
	02	Remote control signal receiver LED : OFF

* Refer to service manual.

⑥ Receiver

1 Control plural indoor units with one remote control

Up to 16 indoor units can be connected.

1. Connect the XY terminal with 2 cores wire. As for the size, refer to the following note.
2. For Packaged air conditioner series, set the indoor unit address with SW2 on the indoor unit PCB from [1] to [F] so as not to duplicate.

Restrictions on the thickness and length of wire (Maximun total extension 600m.)

Standard	Within 0.3 mm² × 100m
	Within 0.5 mm² × 200m
	Within 0.75mm² × 300m
	Within 1.25mm² × 400m
	Within 2.0 mm² × 600m

For the shop series

For VRF series, set the indoor unit address with SW1, SW2 and SW5-2 on the indoor unit PCB from [000] to [127] so as not to duplicate.



For the building air-conditioning and gas heat pump series

Set the indoor unit and outdoor unit numbers by manually specifying the addresses.
Use the rotary switches SW1 and SW2 provided on the indoor unit PCB (printed circuit board) to set the indoor unit numbers so that they are not duplicated.

Master/Slave setting when using plural remote control

Up to two receivers can be installed in one indoor unit group.



Switch	Setting	Function
SW2	ON	Master
	OFF	Slave

⑥ Receiver (continued)

Wireless remote control's operable area

1. Standard signal receiving range
   [Condition]
   Illuminance at the receiver area: 300 lux.
   (When no lighting fixture is located within 1m of indoor unit in an ordinary office)



2. Points for attention in connecting a plural number of indoor units
   [Condition]
   Illuminance at the receiver area: 300 lux.



Backup switch

A backup switch is provided on the receiver section of the panel surface.
When operation from the wireless remote control unit is not possible (due to flat batteries, a mislaid unit, a unit failure), you can use it as an emergency means. You should operate this switch manually.



1. If pressed while the air-conditioner is in a halt, it will cause the air-conditioner to start operation in the automatic mode (in the case of cooling only, in the cooling mode).
   Wind speed: Hi fan, Temperature setting: 23°C, Louver: horizontal.
2. If pressed while the air-conditioner is in operation, it will stop the air-conditioner.

Cooling test run operation

- After safety confirmation, turn on the power.
- Transmit a cooling operation command with the wireless remote control unit, while the backup switch on the receiver is depressed.
- If the backup switch on the receiver is pressed during a test run, it will end the test run.
- If you cannot operate the unit properly during a test run, please check wiring by consulting with inspection guides.

How to read the two-digit display

A two-digit indicator (7-segment indicator) is provided on the receiver section.

1. An indication will be displayed for one hour after power on.
2. An indication appears for 3.5 seconds when a “Stop” command is sent from the wireless remote control unit while the air-conditioner is not running.
3. An indication appearing in (1) or (2) above will go off as soon as the unit starts operation.
4. When there are no error records to indicate, addresses are displayed for all of the connected units.
5. When there are some error records remaining, the error records are displayed.
6. Error records can be cleared by transmitting a “Stop” command from the wireless remote control unit, while the backup switch is depressed.

3.2 MOTION SENSOR KIT

3.2.1 FDT series (LB-T-5W-E)

PJF012D036 B

⚠ WARNING

- Connect the wiring to the PCB in the control box on the indoor unit and hold the wiring securely so as not to apply unexpected stress on the PCB.
  Loose connection or hold will cause abnormal heat generation or fire.
- Make sure the power source is turned off when electric wiring work.
  Otherwise, electric shock, malfunction and improper running may occur.

⚠ CAUTION

- Do not install the motion sensor kit at the following places in order to aboid malfunction.
  (1) Places exposed to direct sunlight
  (2) Places near heat devices
  (3) High humidity places
  (4) Hot surface or cold surface enough to generate condensation
  (5) Places exposed to oil mist or steam directly
  (6) Places affected by the direct air flow of the Indoor unit
  (7) Places where the motion sensor is influenced by the fluorescent lamp or sunlight
  (8) Places where the motion sensor is affected by infrared rays of any other communication devices
  (9) Places where some object may obstruct the motion sensor
- Do not leave the motion sensor without the cover.
  In case the cover needs to be detached, protect the motion sensor with a packaging or bag.
  In order to keep it away from water and dust.

Attention

- Instruct the customer how to operate it correctly referring to the instruction manual.
- For the installation method of the air-conditioner itself, refer to the installation manual enclosed in the package.

① Accessories

Please make sure that you have the motion sensor.

Motion sensor		1

② Installing the motion sensor

It is possible to install the motion sensor by replacing with a corner lid on the panel.

Aim of the detectable scope



Hight of the ceiling	h[m]	2.7	3.5	4.0
Detectable scope①	ϕa[m]	about 4.5	about 6.4	about 7.6
Detectable scope②	ϕb[m]	about 6.4	about 8.3	about 9.5

Preparation before installation

① Install the panel onto the indoor unit according to the installation manual for the panel.
② Remove the inlet grille.
③ Remove the corner lid (A) located on the panel.
④ Loosen 2 screws for the control lid. (It is unnecessury to remove the screws.)
⑤ Slide the control lid, and open and remove it.



Installation of the motion sensor

① Loosen the bolts which fix the panel, and make a gap between the panel and the indoor unit.
② Pass the wiring of the motion sensor through the opening of the panel.
③ Hang the wiring on the hook which is on the panel's inside.
④ Pass the wiring through the opening of the control box.
⑤ Connect the connecter to CNL(3P,Black) on PWB in the contorl box.
⑥ Tighten the bolts which fix the panel.
⑦ Install the motion sensor on the panel.
⑧ Fix the motion sensor by the screw.
⑨ Reinstall the control lid, and tighten 2 screws.









③ Setting the motion sensor

The motion sensor will not function if it is only installed.
Set the function of the motion sensor by the wired or wireless remote control.
Refer to the manual instruction of each remote control for the setting procedure.

Note: It is not possible to set by the following remote control models or older.
Wired:RC-EX1A, RC-E5, RCH-E3
Wireless: RCN-E1R

PJF012D504

3.2.2 FDTC series (LB-TC-5W-E)

⚠ WARNING

- Connect the wiring to the PCB in the control box on the indoor unit and fix the wiring securely so as not to apply unexpected stress on the PCB.
  Loose connection or fixing will cause abnormal heat generation or fire.
- Make sure the power source is turned off during electrical wiring work.
  Otherwise, electric shock, malfunction and abnomal operation may occur.

⚠ CAUTION

- Do not install the motion sensor kit at the following places in order to avoid malfunction.
  (1) Places exposed to direct sunlight
  (2) Places near heat-generating devices
  (3) High humidity places
  (4) Hot surface or cold surface enough to generate condensation
  (5) Places directly exposed to oil mist or steam
  (6) Places affected by the direct air flow of the indoor unit
  (7) Places where the motion sensor may be influenced by fluorescent lamp or sunlight
  (8) Places where the motion sensor may be affected by infrared rays of any other communication devices
  (9) Places where some object may obstruct the motion sensor
  (10) Places where there may be impact on the motion sensor
  (11) Places with strong radio wave or static electricity
  (12) Dusty place where the motion sensor lens may become tainted or be damaged
- Do not leave the motion sensor without the cover.
  In case the cover needs to be detached, protect the motion sensor with a packaging or bag in order to keep it away from water and dust.

Attention

- Instruct the customer how to operate the motion sensor kit correctly by referring to the instruction manual.
- For the installation method of the air-conditioner itself, refer to the installation manual enclosed in the package.

① Accessories

Please make sure that all components are in the package.

Motion sensor		1

② Installing the motion sensor

It is possible to install the motion sensor by replacing the corner lid on the panel.

The detectable area



Height of the ceiling	h[m]	2.7	3.5	4.0
Detectable area①	ϕa[m]	about 4.5	about 6.4	about 7.6
Detectable area②	ϕb[m]	about 6.4	about 8.3	about 9.5

Preparation before installation

① Remove the inlet grille according to the installation manual of the panel.
② Remove the corner lid at the drain pipe side.
③ Loosen screws (2 pcs) on the control box of the unit. (It is not necessary to remove the screws.)
④ Slide the control lid in the arrow direction, and remove it.



Installation of the motion sensor

① Cut the half blanking (4 sections) of the panel as shown in the following figure.
② Pass the motion sensor wiring through the opening of the panel.
③ Connect the wiring connector to CNL (3P, black) on the PCB in the control box.
④ Fix the wiring with a band as shown below.
⑤ Install the motion sensor on the panel according to the installation manual of the panel.
⑥ Install the control lid with care not to pinch the wiring, and reinstall the control lid with screws (2 pcs.).





③ Setting the motion sensor

The motion sensor will not function if it is only installed.
Set the function of the motion sensor by the wired or wireless remote control.
Refer to the manual instruction of each remote control for the setting procedure.

Note: It is not possible to set by the following remote control models or older ones.
Wired:RC-EX1A, RC-E5, RCH-E3
Wireless: RCN-E1R

PJZ012D122 A

3.2.3 FDU, FDUM series (LB-KIT)

⚠ WARNING

- Connect the wiring to the PCB in the control box on the indoor unit and hold the wiring securely so as not to apply unexpected stress on the PCB.
  Loose connection or hold will cause abnormal heat generation or fire.

- Make sure the power source is turned off when electric wiring work.
  Otherwise, electric shock, malfunction and improper running may occur.

⚠ CAUTION

- Do not install the motion sensor kit at the following places in order to avoid malfunction.

(1) Places exposed to direct sunlight
(2) Places near heat devices
(3) High humidity places
(4) Hot surface or cold surface enough to generate condensation
(5) Places exposed to oil mist or steam directly
(6) Places affected by the direct air flow of the Indoor unit
(7) Places where the motion sensor is influenced by the fluorescent lamp or sunlight
(8) Places where the motion sensor is affected by infrared rays of any other communication devices
(9) Places where some object may obstruct the motion sensor
(10) Place that the motion sensor have a shock
(11) Place with the strong radio wave or Static electricity
(12) Place that motion sensor lens become tainted or have damaged. Dusty place
(13) Place where it runs in parallel with strong voltage lines such as power source wiring

- Do not leave the motion sensor without the cover.
  In case the cover needs to be detached, protect the motion sensor with a packaging or bag.
  In order to keep it away from water and dust.

Attention

- This manual describes how to install the motion sensor kit.
- Instruct the customer how to operate it correctly referring to the instruction manual.
- For the installation method of the air-conditioner itself, refer to the installation manual enclosed in the package.

① Accessories

Please make sure that all components are in the package.

Motion sensor	Wiring <1>	Wiring <2>	2 screws	Manual
	In case of CnL connector on the indoor unit PCB (FDT/FDK/FDTC)	In case of CnL connector is not on the indoor unit PCB		

※ Please prepare a relay wiring for connecting the motion sensor and indoor unit on site. (0.2 mm^2 or thicker, triplex (red, white and black) cable for communication, with the maximum length of 8 m.)

② Installing the motion sensor

- The recommended height is lower than 4000 mm for motion sensor. When the installation height is higher, motion detection accuracy might be reduced.
- Sensor will detect the object with a different temperature from the surrounding.
- Motion sensor is more sensitive to motions in the direction of ⇔ mark.
- Sensor may not detect small children or infants with little motion.
- Although motion sensor can be installed on a wall, it is recommended to install it on the ceiling plane.
- If the sensor is installed on the wall, the sensing distance in the front direction is about 5 m, covering the angle of about 100 degrees.



Side of screws for fixing the case

The detectable area



Height of the ceiling h (m)	2.7	3.5	4.0
Detectable area ϕ A (m)	4.5	6.4	7.6
Detectable area ϕ B (m)	6.4	8.3	9.5

Installing the motion sensor

There are the following 3 methods to install the motion sensor on the ceiling plane or wall surface (hereinafter called “ceiling plane”). Select the method according to the installation position.

<How to install>

(A) Direct installation by screws to the ceiling plane with the wiring in the ceiling space.

(B) Direct installation by screws to the ceiling plane with the wiring in the room.

(C) Installation with switch box (prepare at the site)



Positional relation for pulling out relay wiring hole and installing holes.

Option (A)

►Select this method if the ceiling plane has sufficient strength to install the motion sensor directly with screws.



① Prepare a relay wiring on site and lay out the wiring in advance.
② Remove the screw at the side of the motion sensor and slide the upper case in the direction of the arrow.
③ Pull the wiring of the motion sensor as below.



④ Pass the relay wiring through the hole on the lower case.
⑤ When fixing the lower case to the ceiling plane, tighten it in 2 locations of the installing holes (4 locations) with the attached screws.





⑥ Using a crimping terminal, etc., connect the same color to the relay wiring (prepare on site) and the wiring of motion sensor.



⑦ Place the connecting part inside of the ceiling space.
⑧ Seal the wiring hole on the lower case with putty.
⑨ Taking care not to pinch the wirings, slip the upper case into the lower case, and tighten the screws.



Caution:
In order to prevent tracking, be sure to perform construction so as not to clog up the connecting part with dust, etc.

Option (B)

►Select this method if the ceiling plane has sufficient strength to install the motion sensor directly with screws.

① Remove the screw at the side of the motion sensor and slide the upper case in the direction of the arrow. (The same as ② of Option (A))
② Pull the wiring of the motion sensor toward the side. Cut off the thinner part of the upper case.



③ When fixing the lower case to the ceiling plane, tighten it in 2 locations of the installing holes (4 locations) with the attached screws. (The same as ⑤ of Option (A))
④ Using a crimping terminal, etc., connect the same color to the relay wiring (prepare on site) and the wiring of motion sensor.
(The same as ⑥ of Option (A))
⑤ Taking care not to pinch the wirings, slip the upper case into the lower case, and tighten the screws.
(The same as ⑨ of Option (A))
⑥ Seal the cut part at Step ② with putty.



Option (C)

① Set up the switch box and relay wiring (prepare on site) in advance.
Seal the relay wiring inlet with putty.



Positional relation for the switch box and installing holes



② Remove the screw at the side of the motion sensor and slide the upper case in the direction of the arrow. (The same as ② of Option (A))

③ Pull the wiring of the motion sensor. (The same as ③ of Option (A))

④ Pass the relay wiring through the hole on the lower case from switch box.



⑤ Fix the lower case to switch box using the installing hole (1 place).



⑥ Connect the same color to the relay wiring (prepare on site) and the wiring of motion sensor. (The same as ⑥ of Option (A))

⑦ Place the connecting part between switch box and the hole of the lower case through passed the wiring at step ④ .



⑧ Taking care not to pinch the wirings, slip the upper case into the lower case, and tighten the screws. (The same as ⑨ of Option (A))



Wiring connection in the control box of indoor unit

CAUTION: Attached wirings to the motion sensor vary depending on the model of the indoor unit. Make sure your model before installing.

<In case of the CnL connector is on the indoor unit PCB (FDT/FDK/FDTC)>

① Connect the same color to the relay wiring (prepare on site) and the attached wiring <1>.
② Remove the control box cover from the indoor unit.
③ Connect CnL connector (3P, black) to the PCB.



<Incase of the CnL connector is not on the indoor unit PCB>

① Connect the same color to the relay wiring (prepare on site) and the attached wiring <2>.
② Remove the control box cover from the indoor unit.
③ Connect CnG connector (4P, blue) to the PCB.
④ Connect CnV2 connector (4P, black) to the PCB.



<For FDT>



<For FDTC>



<For FDK>



<For the other indoor units>



③ Setting the motion sensor

The motion sensor will not function if it is only installed.
Set the function of the motion sensor by the wired or wireless remote control. Refer to the manual instruction of each remote control for the setting procedure.

Note: It is not possible to set by the following remote control models or older.
Wired:RC-EX1A, RC-E5, RCH-E3
Wireless: RCN-E1R

PFA012D633 A

3.2.4 FDE series (LB-E)

⚠ WARNING

- Connect the wiring to the PCB in the control box on the indoor unit and hold the wiring securely so as not to apply unexpected stress on the PCB.
  Loose connection or hold will cause abnormal heat generation or fire.

- Make sure the power source is turned off when electric wiring work.
  Otherwise, electric shock, malfunction and improper running may occur.

⚠ CAUTION

- Do not install the motion sensor kit at the following places in order to avoid malfunction.

(1) Places exposed to direct sunlight
(2) Places near heat devices
(3) High humidity places
(4) Hot surface or cold surface enough to generate condensation
(5) Places exposed to oil mist or steam directly
(6) Places affected by the direct air flow of the Indoor unit
(7) Places where the motion sensor is influenced by the fluorescent lamp or sunlight
(8) Places where the motion sensor is affected by infrared rays of any other communication devices
(9) Places where some object may obstruct the motion sensor
(10) Place that the motion sensor have a shock
(11) Place with the strong radio wave or Static electricity
(12) Place that motion sensor lens become tainted or have damaged. Dusty place

- Do not leave the motion sensor without the cover.
  In case the cover needs to be detached, protect the motion sensor with a packaging or bag.
  In order to keep it away from water and dust.

Attention

- This manual describes how to install the motion sensor kit.
- Instruct the customer how to operate it correctly referring to the instruction manual.
- For the installation method of the air-conditioner itself, refer to the installation manual enclosed in the package.

① Accessories

Please make sure that all components are in the package.

Motion sensor (※)	Manual
Attached wiring to the motion sensor kit  ※ Wiring from the motion sensor and the attached wiring to the motion sensor kit have been connected when shipped from the factory. Remove the connector at the position of ○ mark and connect it to the attached wiring to the indoor unit before use.	

② Installing the motion sensor

- It is possible to install the motion sensor by replacing the indoor unit.
- The recommended height is lower than 4000 mm for motion sensor. When the installation height is higher, motion detection accuracy might be reduced.
- Sensor will detect the object with a different temperature from the surrounding.
- Sensor may not detect small children or infants with little motion.
- Use the separate motion sensor so that person's activity can be detected when the detectable area differs from the person's activity area.
- Use the separate motion sensor when using both wireless remote control and motion sensor together.



The detectable area



Height of the ceiling	h (m)	2.7	3.5	4.0
Detectable area	A (m)	2.9	3.9	4.5
Detectable area	ϕ A (m)	4.5	6.4	7.6
Detectable area	B (m)	3.9	4.8	5.4
Detectable area	ϕ B (m)	6.4	8.3	9.5

Installing the motion sensor (before installing the unit)

Motion sensor can be installed by replacing with a cover of the panel.

CAUTION: Install the motion sensor before installing the unit.
When installing the motion sensor after unit has been fixed, injury due to falling may result because of working at high place.

① Remove the connector that connects the motion sensor and the wiring.



② Insert a tool into the dented part (2 places) of the panel cover, and wrench slightly not to damage the paintwork of the panel to remove the cover.

③ Connect the wiring from the panel's hole (attached to the indoor unit, color of the wiring: white, red and black, connector: 3P, white) to the wiring from the motion sensor. Make sure to install the motion sensor in the correct direction.

CAUTION: Do not remove the clamp fixed the wiring.





④ Install the motion sensor
Place the connector under the panel and install it to the panel with careful attention to the direction of the motion sensor.

CAUTION: Connect the connectors before installing the motion sensor.
In case of connecting after the motion sensor has been installed, it will be necessary to remove the panel.

Wiring connection in the control box

① Connect the wiring from the motion sensor (attached to the indoor unit, color of the wiring: white, red and black, connector: 3P, white) to the attached wiring to the motion sensor kit.

② Fix the wiring with clips (6 places).

③ Connect CnG connector (4P, blue) to the PCB.

④ Connect CnV2 connector (4P, black) to the PCB.



③ Setting the motion sensor

The motion sensor will not function if it is only installed.
Set the function of the motion sensor by the wired or wireless remote control. Refer to the manual instruction of each remote control for the setting procedure.

Note: It is not possible to set by the following remote control models or older.
Wired:RC-EX1A, RC-E5, RCH-E3
Wireless: RCN-E1R

PJZ012A164

3.2.5 User's manual

SAFETY PRECAUTIONS

⚠ WARNING

● **If a child, person with disease or other persons needed for assist uses this product, people around the person should take sufficient care.**
A halt of the air-conditioner due to abnormal situation or motion sensor's control may cause a feeling of sickness or accident.

ATTENTION

- The sensor may not detect a person near the border of detection range.
- Installation near an object with a different temperature from the surrounding may cause a false detection of human.
- Due to correction of temperature setting, some people may feel chilly.

This product uses infrared sensor to detect person's activity level to support control of air-conditioner.
Please set the control you like from the remote control.

Indoor unit control	Detective situation	Description of control	Display of eco touch remote control
① Power control	Activity level is large	Lower the indoor temperature setting for comfort.	Power control ON
	Activity level is small	Raise the indoor temperature setting for energy-saving.	Power control ON
② Auto-off	No one is detected for 1 hour	Stop operation and stand by	In auto-off mode
	No one is detected for 12 hours	Stop operation	-
① + ②	Any combination of the above	Any of the above	Any of the above
All disabled (default setting)	-	Standard control	-

If the sensor is disconnected or defective, the control will be set as if it no detects (or less) activity level.

Refer to the next section for setting method.



- When power control is enabled
  The amount of human motion is detected by a motion sensor to adjust the Set temp.
  During power control, "Power control ON" will be displayed on the message display.



- When auto-off is enabled
  The unit will enter the "Operation wait" state when an hour has elapsed since the last time a human presence was detected and will be in "Complete stop" state after another 12 hours.

"Operation wait"...The unit stops but will resume operation when human presence is detected. When the unit is in "Complete stop", "In auto-off mode" will be displayed on the message display.

"Complete stop"...When auto-off is enabled, the unit stops. The unit will not resume operation even when human presence is detected.
The message "In auto-off mode" will disappear from the message display, and the operation lamp will turn off.

Control setting (from eco touch remote control)

● Refer to the installation manual for eco touch remote control to activate the infrared sensor (motion sensor).
TOP screen **Menu** ⇨ **Service setting** ⇨ **Installation settings** ⇨ **Service password**







● Refer to the installation manual for eco touch remote control to set control mode.

■ Infrared sensor (motion sensor) control (for IUs with motion sensors)
Presence of humans and the amount of motion are detected by a motion sensor to perform various controls.

■ When the R/C is set as the sub R/C, the infrared sensor (motion sensor) control cannot be set.



Tap the **Menu** button on the TOP screen and select **Energy-saving setting** ⇨ **Infrared sensor control** or **Motion sensor control**.

The Infrared sensor control screen and contents of the current settings are displayed.

① Enable/disable power control.
② Enable/disable auto-off.
③ After you set each item, tap the **Set** button.
The display returns to the Energy-saving setting menu screen.

Control setting (from wireless remote control)

● Refer to the installation manual for wireless remote control to enable motion sensor in **Indoor function settings**

Indoor function settings

1. How to set indoor functions
① Press the ON/OFF button to stop the unit.
② Press the desired one of the buttons shown item **2.** while holding down the FUNCTION SETTING switch.
③ Use the selection buttons, ▲ and ▼, to change the setting.
④ Press the SET button.
The buzzer on the remote control signal receiver beeps twice, and the LED lamp flashes four times at two-second intervals.



2. Setting details

Button	Number indicator	Function setting
SILENT	00	Infrared sensor setting (Motion sensor setting) : Disable
	01	Infrared sensor setting (Motion sensor setting) : Enable
HI POWER	00	Infrared sensor control (Motion sensor control) : Disable
	01	Infrared sensor control (Motion sensor control) : Power control only
	02	Infrared sensor control (Motion sensor control) : Auto OFF only
	03	Infrared sensor control (Motion sensor control) : Power control and Auto OFF

3.3 SIMPLE WIRED REMOTE CONTROL (RCH-E3)

Note:
Following functions of FDU indoor unit series are not able to be set with this simple wired remote control (RCH-E3).
1. 4-fan speed setting (P-Hi/Hi/Me/Lo) → 3-fan speed setting (Hi/Me/Lo)

Names and functions of sections





Installation of remote control

Do not install the remote control at the following places in order to avoid malfunction.

(1) Places exposed to direct sunlight
(2) Places near heat devices
(3) High humidity places
(4) Hot surface or cold surface enough to generate condensation
(5) Places exposed to oil mist or steam directly
(6) Uneven surface

PJZ000Z272

Remote control installation dimensions



Note: Installation screw for remote control
M4 screw (2 pieces)

In case of embedding wiring



In case of exposing wiring



The remote control wiring can be extracted from the upper center.
After the thin part in the upper side of the remote control upper case is scraped with a nipper or knife, remove burr with a file.



The peeling length of each wiring is as follows:

X wiring : 160mm Y wiring : 150mm



Wiring specifications

(1) Wiring of remote control should use 0.3mm² × 2 cores wires or cables. (on-site configuration)
(2) Maximum prolongation of remote control wiring is 600m.
If the prolongation is over 100m, change to the size below.
But, the wiring in the remote control case should be 0.3mm² (recommended) to 0.5mm².
Change the wire size outside of the case according to wire connecting. Waterproof treatment is necessary at the wire connecting section. Be careful about contact failure.

Unit:mm

Length	Wiring thickness
100 to 200m	0.5mm² × 2 cores
Under 300m	0.75mm² × 2 cores
Under 400m	1.25mm² × 2 cores
Under 600m	2.0mm² × 2 cores

Adapted to **RoHS** directive

Simple Remote Control Installation Manual

PJZ012D069Ⓐ

Read together with indoor unit's installation manual.

⚠WARNING

- **Fasten the wiring to the terminal securely and hold the cable securely so as not to apply unexpected stress on the terminal.**
  Loose connection or hold will cause abnormal heat generation or fire.
- **Make sure the power source is turned off when electric wiring work.**
  Otherwise, electric shock, malfunction and improper running may occur.

⚠ CAUTION

- **Do not install the remote control at the following places in order to avoid malfunction.**
  (1) Places exposed to direct sunlight
  (2) Places near heat devices
  (3) High humidity places
  (4) Hot surface or cold surface enough to generate condensation
  (5) Places exposed to oil mist or steam directly
  (6) Uneven surface
- **Do not leave the remote control without the upper case.**
  In case the upper cace needs to be detached, protect the remote control with a packaging box or bag in order to keep it away from water and dust.

Accessories	Remote control, wood screw (ϕ 3.5×16) 2 pieces
Prepare on site	Remote control cord (2 cores) (Refer to [2. Installation and wiring of remote control]) [In case of embedding cord] Electrical box, M4 screw (2 pieces) [In case of exposing cord] Cord clamp (if needed)

1. Installation procedure

In case of embedding cord

(1) Make certain to remove the screw on the bottom surface of the remote control.



(2) Remove the upper case of the remote control.
Insert a flat-blade screwdriver to a concave portion of the bottom surface of the remote control and slightly twist it, and the case is removed.



(3) Pre-bury the electrical box and remote control cord.



(4) Prepare two M4 screws (recommended length: 12 – 16mm), and install the lower case to the electrical box.
Do not use a screw whose screw head is larger than the height of the wall around the screw hole.



(5) Connect the remote control cord to the terminal block.
Connect the terminals (X and Y) of the remote control and the terminals (X and Y) of the indoor unit. (No polarity of X and Y)

(6) Mount the upper case for restoring to its former state so as not to crimp the remote control cord, and secure with the removed screw.

In case of exposing cord

(1) Make certain to remove a screw on the bottom surface of the remote control.



(2) Remove the upper case of the remote control.
Insert a flat-blade screwdriver to a concave portion of the bottom surface of the remote control and slightly twist it, and the case is removed.



(3) The remote control cord can be extracted from the upper center.
After the thin part in the upper side of the remote control upper case is scraped with a nipper or knife, remove burr with a file.



(4) The lower case of the remote control is mounted to a flat wall with two accessory wood screws.



(5) Connect the remote control cord to the terminal block.
Connect the terminals (X and Y) of the remote control and the terminals (X and Y) of the indoor unit. (No polarity of X and Y)
The wiring route is as shown in the right.



The wiring in the remote control case should be 0.3 mm^2 (recommended) to 0.5 mm^2 at maximum.
Further, peel off the sheath.
The peeling length of each wiring is as follows:

X wiring : 160mm
Y wiring : 150mm



(6) Mount the upper case for restoring to its former state so as not to crimp the remote control cord, and secure with the removed screw.

(7) In the case of exposing installation, secure the remote control cord to the wall surface with a cord clamp so as not to loosen the remote control cord.

2. Installation and wiring of remote control

(1) Wiring of remote control should use 0.3mm^2 × 2 cores wires or cables. (on-site configuration)
(2) Maximum prolongation of remote control wiring is 600 m.
If the prolongation is over 100m, change to the size below.
But, the wiring in the remote control case should be 0.3mm^2 (recommended) to 0.5mm^2.
Change the wire size outside of the case according to wire connecting. Waterproof treatment is necessary at the wire connecting section. Be careful about contact failure.

100 - 200m·····0.5mm^2 × 2 cores
Under 300m·····0.75mm^2 × 2 cores
Under 400m·····1.25mm^2 × 2 cores
Under 600m·····2.0mm^2 × 2 cores

3. Master/ slave setting when more than one remote control are used

(1) Up to two remote controls can be connected to one unit (or one group) of indoor unit.

Switch	Setting	Function detail
SW1-1	ON	Slave remote control
	OFF	Master remote control



(2) Set the switch SW1-1 of the slave remote control is "Slave" (ON). The factory default is set as "Master" (OFF).

(Note) • The remote control temperature sensor enabled setting can be set only to the master remote control.
• Install the master remote control at the position to detect room temperature.
• The air-conditioner operation follows the last operation of the remote control in case of the master / slave setting.



4. The indication when power source is supplied

(1) At the time of turning the power source on, after the light is on for the first 2 seconds, the display becomes as shown below.
The number displayed on the upper side of LCD in the remote control is the software number, and this is not an error code.



Software number
(The number in the left is one example. Another number may be shown.)

(2) Then, "88.0 °C" blinks on the remote control until the communication between the remote control and the indoor unit is established.

(3) In the case of connecting one remote control with one unit (or one group) of indoor unit, make certain to set the master remote control (factory default).
If the slave remote control is set, a communication cannot be established.

(4) If a state where the communication between the remote control and the indoor unit cannot be established continues about for 30 minutes, "E" is displayed. Confirm the wiring of the indoor unit and the outdoor unit and master/slave setting of the remote control.

5. Confirmation method for return air temperature

Return air temperature can be confirmed by the remote control operation.

(1) **Press AIR CON No. button for over 5 seconds.**
"88" blinks on the temperature setting indicator.
("88" blinks for approximately 2 seconds while data is read.)
↓
Then, the return air temperature is displayed.
(Example) return air temperature: "27 °C" (blinking)

(Note) For the return air temperature, in the normal case, the return air temperature of the indoor unit is displayed; however, in the case that the remote control temperature sensor is effective, detected temperature by the remote control temperature sensor is displayed.

(2) **Press ⏻ ON/OFF button.**
End.

[In the case that the remote temperature sensor is ineffective and plural indoor units are connected to one remote control]

(1) **Press AIR CON No. button for over 5 seconds.**
indoor unit No. indicator: "U 000" (blinking)
(Among the connected indoor units, the lowest number is displayed.)



(2) **Press TEMP△ or TEMP▽ button.**
Select the indoor unit No.

(3) **Press MODE button.**
Dectder the indoor unit No.
(Example) indoor unit No. indicator: "U 000"
"88" blinks on the temperature setting indicator. (blinking for approximately 2 to 10 seconds while data is read) Then, the return air temperature is displayed. When **AIR CON No.** is pressed, return to the indoor unit selection display (example, "U 000").

(4) **Press ⏻ ON/OFF button.**
End.

6. Function setting

Each function of the remote control and the indoor unit is automatically set to the initial setting, which is the standard use, on the occasion of connecting the remote control with the indoor unit. In the case of the standard use, the setting change is unnecessary. However, if you whould like to change the initial setting " ○ ", change the setting for only the item of the function number. **Record the setting contents and stored them.**

(1) Function setting item by switch on PCB

Switch No.	Setting	Setting detail	Initial setting
SW1-1	ON	Slave remote control	
	OFF	Master remote control	○
SW1-2	ON	Remote control temperature sensor enabled	
	OFF	Remote control temperature sensor disabled	○
SW1-3	ON	"MODE" button prohibited	
	OFF	"MODE" button enabled	○
SW1-4	ON	"ON/OFF" button prohibited	
	OFF	"ON/OFF" button enabled	○

Switch No.	Setting	Setting detail	Initial setting
SW1-5	ON	"TEMP" button prohibited	
	OFF	"TEMP" button enabled	○
SW1-6	ON	"FAN SPEED" button prohibited	※ Note 1
	OFF	"FAN SPEED" button enabled	※ Note 1
SW1-7	ON	Auto restart function enabled	
	OFF	Auto restart function disabled	○
SW1-8, 9, 0	ON	Not used	
	OFF		



- As for the slave remote control, function setting is impossible other than SW1-1.
- In the indoor unit with only one fan speed, "FAN SPEED" button cannot be enabled.

(2) Function setting item by button operation

Classification	Function No.	Function	Setting No.	Setting	Initial setting	Remarks
Remote control function	01	Indoor unit fan speed	01	Fan speed: three steps	※ Note 1	The fan speed is three steps, ❋■■■ - ❋■■ - ❋■ .
			02	Fan speed: two steps (Hi-Lo)	※ Note 1	The fan speed is two steps, ❋■■■ - ❋■ .
			03	Fan speed: two steps (Hi-Me)		The fan speed is two steps, ❋■■■ - ❋■■ .
			04	Fan: one step	※ Note 1	The fan speed is fixed to one step.
	03	Remote control thermistor at the time of cooling	01	Remote control temperature sensor: no offset	○	
			02	Remote control temperature sensor: +3.0 °C		At the time of cooling, in the case of remote control temperature sensor enabled, offset temperature at +3.0°C.
			03	Remote control temperature sensor: +2.0 °C		At the time of cooling, in the case of remote control temperature sensor enabled, offset temperature at +2.0°C.
			04	Remote control temperature sensor: +1.0 °C		At the time of cooling, in the case of remote control temperature sensor enabled, offset temperature at +1.0°C.
			05	Remote control temperature sensor: -1.0 °C		At the time of cooling, in the case of remote control temperature sensor enabled, offset temperature at -1.0°C.
			06	Remote control temperature sensor: -2.0 °C		At the time of cooling, in the case of remote control temperature sensor enabled, offset temperature at -2.0°C.
			07	Remote control temperature sensor: -3.0 °C		At the time of cooling, in the case of remote control temperature sensor enabled, offsett temperature at -3.0°C.
	04	Remote control thermistor at the time of heating	01	Remote control temperature sensor: no offset	○	
			02	Remote control temperature sensor: +3.0 °C		At the time of heating, in the case of remote control temperature sensor enabled, offset temperature at +3.0°C.
			03	Remote control temperature sensor: +2.0 °C		At the time of heating, in the case of remote control temperature sensor enabled, offset temperature at +2.0°C.
			04	Remote control temperature sensor: +1.0 °C		At the time of heating, in the case of remote control temperature sensor enabled, offset temperature at +1.0°C.
			05	Remote control temperature sensor: -1.0 °C		At the time of heating, in the case of remote control temperature sensor enabled, offset temperature at -1.0°C.
			06	Remote control temperature sensor: -2.0 °C		At the time of heating, in the case of remote control temperature sensor enabled, offset temperature at -2.0°C.
			07	Remote control temperature sensor: -3.0 °C		At the time of heating, in the case of remote control temperature sensor enabled, offset temperature at -3.0°C.
	05	Ventilation setting	01	No ventilator connection	○	
			02	Ventilator links air-conditioner		In case of Single split series, by connecting ventilation device to CNT of the indoor printed circuit board (in case of VRF series, by connecting it to CND of the indoor printed circuit board), the operation of ventilation device is linked with the operation of indoor unit.
	06	"Auto" operation setting	01	"Auto" operation enabled	※ Note 1	
			02	"Auto" operation disabled	※ Note 1	"Auto" operation disabled
Indoor unit function	07	Operation permission/ prohibition	01	Disabled	○	
			02	Enabled		Operation permission/prohibition control is enabled.
	08	External input	01	Level input	○	
			02	Pulse input		
	09	Fan speed setting	01	Standard	※ Note 2	
			02	High speed 1	※ Note 2	
			03	High speed 2	※ Note 2	
	10	Fan remaining operation at the time of cooling	01	No remaining operation	○	After cooling stopped, no fan remaining operation
			02	0.5 hours		After cooling stopped, fan remaining operation for 0.5 hours
			03	1 hour		After cooling stopped, fan remaining operation for 1 hour
			04	6 hours		After cooling stopped, fan remaining operation for 6 hours
	11	Fan remaining operation at the time of heating	01	No remaining operation	○	After heating stopped or after heating thermostat OFF, no fan remaining operation
			02	0.5 hours		After heating stopped or after heating thermostat OFF, fan remaining operation for 0.5 hours
			03	2 hours		After heating stopped or after heating thermostat OFF, fan remaining operation for 2 hours
			04	6 hours		After heating stopped or after heating thermostat OFF, fan remaining operation for 6 hours
	12	Setting temperature offset at the time of heating	01	No offset	○	
			02	Setting temperature offset + 3.0 °C		The setting temperature at the time of heating is offset by +3.0 °C.
			03	Setting temperature offset + 2.0 °C		The setting temperature at the time of heating is offset by +2.0 °C.
			04	Setting temperature offset + 1.0 °C		The setting temperature at the time of heating is offset by +1.0 °C.
	13	Heating fan controller	01	Low fan speed	※ Note 1	At the time of heating thermostat OFF, operate with low fan speed.
			02	Setting fan speed		At the time of heating thermostat OFF, operate with the setting fan speed.
			03	Intermittent operation	※ Note 1	At the time of heatingr thermostat OFF, intermittently operate.
			04	Fan off		At the time of heating thermostat OFF, a fan will be stopped. When the remote control thermistor is enabled, automatically set to "Fan off". Do not set at the time of the indoor unit temperature sensor.
	14	Return air temperature offset	01	No offset	○	
			02	Return air temperature offset +2.0 °C		Offset the return air temperature of the indoor unit by +2.0 °C.
			03	Return air temperature offset +1.5 °C		Offset the return air temperature of the indoor unit by +1.5 °C.
			04	Return air temperature offset +1.0 °C		Offset the return air temperature of the indoor unit by +1.0 °C.
			05	Return air temperature offset -1.0 °C		Offset the return air temperature of the indoor unit by -1.0 °C.
			06	Return air temperature offset -1.5 °C		Offset the return air temperature of the indoor unit by -1.5 °C.
			07	Return air temperature offset -2.0 °C		Offset the return air temperature of the indoor unit by -2.0 °C.

Note 1: The symbol " ※ " in the initial setting varies depending upon the indoor unit and the outdoor unit to be connected, and this is automatically determined as follows:

Swith No. Function No.	Function	Setting	Product model
SW1-6	"FAN SPEED" button	"FAN SPEED" button prohibited	Product model whose indoor fan speed is only one step
		"FAN SPEED" button enabled	Product model whose indoor fan speed is two steps or three steps
Remote control function 01	Indoor unit fan speed	Fan speed: three steps	Product model whose indoor unit fan speed is three steps
		Fan speed: two steps (Hi-Lo)	Product model whose indoor unit fan speed is two steps
		Fan speed: two steps (Hi-Me)	
		Fan: one step	Product model whose indoor unit fan speed is only one step
Remote control function 06	"Auto" operation setting	"Auto" operation enabled	Product model where "Auto" mode is selectable
		"Auto" operation disabled	Product model without "Auto" mode
Indoor unit function 13	Heating fan control	Low fan speed	Product model except FDUS
		Intermittent operation	FDUS

Note 2: Fan speed of "High speed" setting

Fan speed setting	Indoor unit fan speed setting		
	❋■■■ - ❋■■ - ❋■	❋■■■ - ❋■	❋■■■ - ❋■■
Standard	Hi — Mid — Lo	Hi — Lo	Hi — Mid
High speed 1・2	UHi — Hi — Mid	UHi — Mid	UHi — Hi

Initial setting of some indoor unit is "High speed".

Note 3: As for plural indoor unit, set indoor functions to each master and slave indoor unit.
But only master indoor unit is received the setting change of indoor unit function "07 Operation permission/ prohibition" and "08 External input".

7. How to set functions by button operation

(1) **Stop air-conditioner, and simultaneously press AIR CON No. and MODE buttons at the same time for over three seconds.**
The function number "01" blinks in the upper right.





(2) **Press TEMP△ or TEMP▽ button.**
Select the function number.

(3) **Press MODE button.**
Decide the function number.

(4) **[In the case of selecting the remote control function (01-06)]**
① The current setting number of the selected function number blinks
(Example)
Function number: "01" (lighting)
Setting number: "01" (blinking)



② **Press TEMP△ or TEMP▽ button.**
Select the setting number.

③ **Press MODE button.**
The setting is completed.
Light is on for approximately 3 to 20 seconds while data of the decided function No. and setting No. is transmitted.
(Example)
Function number: "01" (lighting for 3 to 20 seconds)
Setting number: "01" (lighting for 3 to 20 seconds)



Then, the screen goes back to the function number blinking indication (1), if the setting is sequentially conducted, continue with the same procedures. If the setting is finished, proceed to (5).

(5) **Press ON/OFF button.**
The setting is completed.

[In the case of selecting the indoor unit function (07-14)]
① **"88" blinks on the temperature setting indicators.**
(blinking for approximately 2 to 10 seconds while data are read)
↓
After that, the current setting number of the selected function number blinks.
(Example)
Function number: "07" (lighting)
Setting number: "01" (blinking)



Proceed to ② .

[Note]
a. In the case of connecting one remote control to plural indoor units, the display will be as follows:
Indoor unit No. display: "U 000" (blinking)
(Display the lowest number among the connected indoor units.)



b. Press TEMP△ or TEMP▽ button.
Select the indoor unit No. to be set.
If "U ALL" is selected, the same setting can be set to all units.

c. Press MODE button.
Decide the indoor unit No.
"88" blinks on the temperature setting indicators. (blinking for 2 to 10 seconds while data is read)
When AIR CON No. button is pressed, go back to the indoor unit selection display (for example, "U 000" blinking).

② **Press TEMP△ or TEMP▽ button.**
Select the setting number

③ **Press MODE button.**
The setting is completed.
Light is on for approximately 3 to 20 seconds while data of the decided function No. and setting No. is transmitted.
(Example)
Indoor unit No.: "U 000" (lighting for 3 to 20 seconds)
Function number: "07" (lighting for 3 to 20 seconds)
Setting number: "01" (lighting for 3 to 20 seconds)



Then, the screen goes back to the function number blinking indication (1), if the setting is sequentially conducted, continue with the same procedures. If the setting is finished, proceed to (5).

- Even if ON/OFF button is pressed during setting, the setting is ended. However, any details where the setting has not been completed will be ineffective.
- The setting contents are stored in the control, and even if the power failure occur, this will not be lost.

[Confirmation method for current setting]
According to the operation, the "setting number" displayed first after selecting "function number" and pressing MODE button is the currently set content.
(However, in the case of selecting "U ALL" (all units), the setting number of the lowest number among the indoor units is displayed.)

3.4 OA SPACER (FDTC series)

This manual describes the installation methods for OA spacer (TC-OAS-E2) and the duct joint (TC-OAD-E).
◎This OA spacer is designed for assembling on the indoor unit (FDTC Series), not for be using independently.

PJZ012D125

Application model	FDTC15-56KXZE1 FDTC25-60VH

◎Prepare the duct (size: ø75) and the booster fan at site.
◎For the installation of indoor unit, refer to the installation manual attached to the indoor unit.

SAFETY PRECAUTIONS

● Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.

⚠WARNING

- **Installation should be performed by the specialist.**
  If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Install the system correctly according to these installation manuals.**
  Improper installation may cause explosion, injury, water leakage, electric shock, and fire.
- **Use the genuine accessories and the specified parts for installation.**
  If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overturn of the unit.
- **Turn off the power source during servicing or inspection work.**
  If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.
- **Shut off the power before electrical wiring work.**
  It could cause electric shock, unit failure and improper running.

⚠CAUTION

- **Do not install and use the unit where corrosive gas (such as sulfurous acid gas etc.) or flammable gas (such as thinner, petroleum etc.) may be generated or accumulated, or volatile flammable substances are handled.**
  It could cause the corrosion of heat exchanger, breakage of plastic parts etc. And inflammable gas could cause fire.

① Before installation

● Confirm the following parts are included:

OA spacer (TC-OAS-E2)

Spacer	Bracket 1	Bracket 2	Bracket 3	Bracket 4	Bolt
					
1	2	2	2	2	8

Duct joint (TC-OAD-E)

Duct Joint	Screw	Insulation 1 (120 × 54)	Insulation 2 (40 × 60)
			
1	6	1	2

② Prior study before installation (Usage limitation)

(1) Temperature conditions for OA spacer

- Adjust the temperature conditions of mixed air with outdoor air and indoor air within the usage range of suction air temperature for the air-conditioner.
- The usage temperature conditions of intake outdoor air and indoor air around the ducts are shown in the following table.
- If the temperature conditions of intake outdoor air do not meet, process the outdoor air before intaking.

Operation mode	Usage temperature conditions	
	Intake outdoor air	Indoor air around the ducts
In heating	5ºC DB or higher	18.5ºC WB or lower and 60% RH or lower
In cooling	29ºC DB or lower and 80% RH or lower	20ºC DB or higher



(2) Intake outdoor air volume

- Intake outdoor air volume is 3.0 m³/min at the maximum (when two sets of duct joints are used).
  Up to two sets of duct joint can be installed on OA spacer.
  In case one set of duct joint is installed: 1.5 m³/min max.
  In case two sets of duct joint is installed: 3.0 m³/min max.

(3) Selection of booster fan

- Select the booster fan based on the duct resistance plus the pressure loss at the duct joint. (See the figure)

(4) Other conditions

- Determine the capacity of air conditioner based on the calculation of air-conditioning load including the heat load of intake outdoor air.
- Install the filter for the intake outdoor air and the reverse flow prevention dumper during the duct work at site.
- Insulate the duct and duct joint in order to prevent dewing.
- Interlock the operation of booster fan with ON/OFF operation of the indoor unit. (See Section 7.)





③ Installation of duct joint (TC-OAD-E) onto OA spacer

•There are two places where the duct joint can be installed.

When installing one duct joint

Install OA spacer at either one of two installation places on the duct joint.



To install the duct joint, screw it in as shown at left.



When installing the duct joint at the lid side, remove the lid and reinstall it at the other end before installing the duct joint.

When installing two duct joints



Remove the lid and then install two pieces of duct joint.

④ Installation of OA spacer on the indoor unit

OA spacer can be installed regardless whether the indoor unit has already been hanged or not.
(It is recommended to install before hanging the unit for convenience of installation.)

1-1. When installing OA spacer before hanging the indoor unit

① Placing OA spacer on the indoor unit, fix the brackets 1 and 2 (2 pieces each) with bolts.
Install OA spacer in the appropriate position that the duct joint side of OA spacer becomes opposite to the control box of indoor unit (FDTC).



② Fix the brackets 3 and 4 (2 pieces each) with bolts.



1-2. When installing OA spacer after hanging the indoor unit

① After hanging the indoor unit (*), fix the bracket 1 (2 pieces) temporarily with bolt by 2 turns as shown in the figure.
* For the height (position) of hanging the indoor unit, refer to Section 5.



② Install OA spacer.
i. Install it in the way that the recess of OA spacer will fit on the bracket 1 fixed temporarily at the step ①.
ii. Tighten the bolt of bracket 1.
iii. Fix the bracket 2 with bolt. (Tighten up)



③ Fix the brackets 3 and 4 (2 pieces each) with bolts.



2. Applying insulation

Applying the insulation attached to duct joint set (TC-OAD-E)
① Applying the insulation 1 as shown in the figure.
② Applying the insulation 2 as shown in the figure.
* Be sure to cover the entire surface of sheet metal of the duct joint with the insulation.





⑤ Installation of indoor unit

Work procedure

1. This units is designed for 2 × 2 grid ceiling.
   If necessary, please detach the T bar temporarily before you install it.
   If it is installed on a ceiling other than 2 × 2 grid ceiling, provide an inspection port on the control box side.
2. Arrange the suspension bolt at the right position (530mm530mm).
3. Make sure to use four suspension bolts and fix them so as to be able to hold 500N load.
4. Ensure that the lower end of the suspension bolt should be 102mm above the ceiling plane. Temporarily put the four lower nuts 182mm above the ceiling plane and the upper nuts on distant place from the lower nuts in order not to obstruct hanging the indoor unit or adjust the indoor unit position, and then hang the indoor unit.
5. Adjust the indoor unit position after hanging it by inserting the level gauge (Packed together with the indoor unit.) attached on the package into the air supply port and checking if the gap between the ceiling plane and the indoor unit is appropriate. (*) In order to adjust the indoor unit position, adjust the lower nuts while the upper nuts are put on distant place. Conrm there is no backlash between the hanger plate for suspension bolt and the lower nut and washer.
   * Use the level gauge only when OA spacer has been installed before hanging (④ 1-1 only).









⑥ Installation of panel



Tighten the panels to the brackets 3 and 4 with bolts.
For further details, refer to the installation manual of panel.

(Caution) Connect the connector of lover motor within the control box.

⑦ Interlocking with the indoor unit fan

◎Connect the Single split series and the VRF series to CNT on the indoor PCB and to CND on the indoor PCB respectively. If a ventilation device is connected been geared with the motion of indoor device (ON: DC12V output, OFF: 0V output), the ventilation device is operated/stopped.

◎Set it at "VENT LINK" by selecting "No. 11 VENT LINK SET" from the functional setting by remote control. For details, refer to the "ELECTRIC WIRNG WORK INSTRUCTION" of indoor unit.



(Caution) Although the indoor unit fan stops during the defrosting or oil return operation, the booster fan is operating.
Use a total heat exchanger, if necessary.

3.5 DUCT JOINT (FDTC series)

PJZ012D073

● This product is used by assembling on the spacer (TC-OAS-E2)

1.Before installation

- Confirm the following parts are included:

Duct joint	Screw	Insulation 1 (120 × 54)	Insulation 2 (40 × 60)
			
1	6	1	2

2.Regarding the use of this product

- Fix the product on the spacer (TC-OAS-E2) as shown below.
- For the installation method, refer to the installation manual of the spacer.



3.6 FILTER KIT (FDUM series)

PJZ012D076A△A

This manual contains installation points and operating instructions for the filter kit manufactured by MHI.
Carry out the work following the instructions below.
This manual also contains information on the usage after installation,
so keep this manual properly with USER'S MANUAL provided with the indoor unit.

⚠ CAUTION

- After unpacking, carry out this work on the ground.
- Do not carry out the work during operation, or there is a danger of being entangled in the rotating parts and getting injured.
- Clean the air filter regularly.
- Be sure to entrust qualified serviceman to performance on the air filter.
- Be sure to cut off the power and stop the unit before performing maintenance.

1. Table of filter kit parts No. and corresponding object models

	Small model	Medium model	Large model
Single type	**40, 50**	60, 71	100 - 140
Multi type	22 - 56	71, 90	112 - 160
Filter Kit	UM-FL1EF	UM-FL2EF	UM-FL3EF

2. Parts list of filter kit

Filter	Rail	Insulation
 1 pc.	 2 pcs.	 2 pcs.

Bracket	Parts set(screw)	
1 pc.	 small and medium model : 5 pcs.	large model : 7 pcs. 1 pc.

3. Installation Points

(1) Stick the insulation on both inner sides of the duct, leaving no space up and down.





(*) After unpacking, bottom side of the unit is located at the upper side.

(2) Install the rail on both inner sides of the duct with the screw.



(3) Install the air filter on the rails.





Installation procesure

(4) Install the bracket on the rail with the screw.



(**) When the unit is installed, bottom side of the unit is located at the lower side.

3.7 INTERFACE KIT (SC-BIKN2-E)

※ When RC-EX3A is connected, please use SC-BIKN2-E by all means.

RKZ012A099

Accessories included in package

Be sure to check all the accessories included in package.

No.	Part name	Quantity
①	Indoor unit's connection cable (cable length: 1.8m)	1
②	Wood screws (for mounting the interface: ø4x 25)	2
③	Tapping screws (for the cable clump and the interface mounting bracket)	3
④	Interface mounting bracket	1
⑤	Cable clamp (for the indoor unit's connection cable)	1
⑥	CnT terminal connection cable (total cable length: 0.5m)	1

Safety precautions

Before use, please read these Safety precautions thoroughly before installation.

- All the cautionary items mentioned below are important safety related items to be taken into consideration, so be sure to observe them at all times.

⚠Warning	Incorrect installation could lead to serious consequences such as death, major injury or enviromental destruction.

- Symbols used in these precautions

❗	Always go along these instruction.

- After completed installation, carry out trial operation to confirm no anomaly, and ask the user to keep this installation manual in a good place for future reference.

⚠ Warnings

❗

- **Installation must be carried out by a qualified installer.**
  If you install it by yourself, it may cause an electric shock, fire and personal injury , as a result of a system malfunction.
- **Install it in full accordance with the installation manual.**
  Incorrect installation may cause an electric shock, fire and personal injury.
- **Electrical work must be carried out by a qualified electrician in accordance with the technical standard for electrical equipment, the indoor wiring standard and this installation manual.**
  Incorrect installation may cause an electric shock, fire and personal injury.
- **Use the specific cables for wiring. And connect all the cables to terminals or connectors securely and clamp them with cable clamps in order for external forces not to be transmitted to the terminals directly.**
  Incomplete connection may cause malfunction, and lead to heat generation and fire.
- **Use the original accessories and specified components for installation.**
  If the parts other than those prescribed by us are used, it may cause an electric shock, fire and sersonal injury.

Connecting the indoor unit's connection cable to the interface

①Remove the upper case of the interface.
- Remove 2 screws from the interface casing before removal of upper casing.

②Connect the indoor unit's connection cable to the interface.
- Connect the connector of the indoor unit connection cable to the connector on the interface's circuit board.

③Fix the indoor unit's connection cable with the cable clamp.
- Cable can be brought in from the top or from the back.
- Cut out the punch-outs for the connection cables running into the casing with cutter.

④Connect the indoor unit's connection cable to the indoor control PCB.
- Connect the indoor unit's connection cable to the indoor control PCB securely.
- Clamp the connection cable to the indoor control box securely with the cable clamp provided as an accessory.
- Regarding the cable connection to the indoor unit, refer to the installation manual for indoor unit.



Name of each part of the interface



*Either the connection cables of Superlink E board (SC-ADNA-E) or of wired remote control is connectable.

Switch	Setting	Function	Switch	Setting	Function
SW2-1	ON**	CnT level input	SW2-3	ON**	External input (CnT input)
	OFF	CnT pulse input		OFF	Operation permission/prohibition (CnT input)
SW2-2	ON**	Wired remote control : Enable	SW2-4	ON**	Annual cooling : Enable***
	OFF	Wired remote control : Disable		OFF	Annual cooling : Disable***

** Factory setting

*** Indoor fan control at low outdoor air temperature in cooling

Installation of the interface

- Install the interface within the range of the connection cable length (approximately 1.3m) from the indoor unit.
- Be sure not to extend the connection cable on site. If the connection cable is extended, malfunction may occur.
- Fix the interface on the wall, pillar or the like.

●Don't install the interface and wired remote control at the following places.

○Places exposed to direct sunlight
○Places near heating devices
○High humidity places
○Surfaces where are enough hot or cold to generate condensation
○Places exposed to oil mist or steam directly
○Uneven surface



Mounting the interface directly on a wall

①Mount the lower casing of the interface on a flat surface with wood screws provided as standard accessory.
②Mount the upper casing.



Recessing the interface in the wall

①Recess the electrical box (procured locally) and connection cables in the wall.
②Mount the lower casing of the interface to the electrical box with M4 screws (procured locally).
③Mount the upper casing.



Mounting the interface with the mounting bracket

①Mount the upper casing.
②Mount the mounting bracket to the interface with tapping screws provided as standard accessory.
③Mount the mounting bracket on wall or the like with wood screws provided as standard accessory.



Installation check items

☐ Are the connection cables connected securely to the terminal blocks and connectors?
☐ Are the thickness and length of the connection cables conformed with the standard?

Functions of CnT connector

It is available to operate the air-conditioner and to monitor the operation status with the external control unit (remote display) by sending the input/output signal through CnT connector on the indoor control PCB.

①Connect a external remote control unit (procured locally) to CnT terminal.
②In case of the pulse input, switch OFF the DIP switch SW2-1 on the interface PCB.
③When setting operation permission/prohibition mode, switch OFF the DIP switch SW2-3 on the interface PCB.



Input/ Output	Function	Output signal		Content
		Relay	ON/OFF	
Output 1	Operation output	XR_1	ON	During air-conditioner operation
Output 2	Heating output	XR_2	ON	During heating operation
Output 3	Compressor operation output	XR_3	ON	During compressor running
Output 4	Malfunction output	XR_4	ON	During anomalous stop

- $XR_{1\text{-}4}$ are for the DC 12V relay
- XR_5 is a DC 12/24V or AC 220-240V relay
- CnT connector (local) maker, model

Connector	Molex	5264-06
Terminals	Molex	5263T

Input/ Output	Function	SW2-1		SW2-3				Air-conditioner	Operation by remote control
		Setting		Setting	Input signal		Content		
					Level/Pulse	XR_5			
Input	External control input	ON*	Level input	ON*	Level	OFF→ON	External input	ON	Allowed
						ON→OFF		OFF	
				OFF		OFF→ON	Operation permission	OFF	
						ON→OFF	Operation prohibition	OFF	Not allowed
		OFF	Pulse input	ON*	Pulse	OFF→ON	External input	OFF→ON	Allowed
								ON→OFF	
				OFF	Level	OFF→ON	Operation permission	ON	
						ON→OFF	Operation prohibition	OFF	Not allowed

* Factory setting



In case of the remote control (RC-EX3 or later model), the external outputs (1 – 4) and the external input can be changed using the function setting of remote control. For the setting method, refer to the installation manual.
Also refer to the technical manual to know how it is adapted to the function setting for the external outputs and input, at the indoor unit side.

Connection of Superlink E board

Regarding the connection of Superlink E board, refer to the installation manual of Superlink E board.
For electrical work, power source for all of units in the Superlink system must be turned OFF.

①Switch ON the DIP switch SW2-2 (Factory setting: ON) on the interface PCB.
Caution: Wireless remote control attached to the indoor unit can be used in parallel, after connecting the wired remote control. However, some of functions other than the basic functions such as RUN/STOP, temperature setting, etc. may not work properly and may have a mismatch between the display and the actual behavior.



②Wiring connection between the interface and the Superlink E board.



No.	Names of recommended signal wires
1	Shielded wire
2	Vinyl cabtyre round cord
3	Vinyl cabtyre round cable
4	Vinyl insulated wire vinyl sheathed cable for control

Within 200 m 0.5 mm² × 2 cores
Within 300 m 0.75 mm² × 2 cores
Within 400 m 1.25 mm² × 2 cores
Within 600 m 2.0 mm² × 2 cores

③Clamp the connection cables with cable clamps.

Connection of wired remote control



Regarding the connection of wired remote control, refer to the installation manual of wired remote control.

①Switch ON the DIP switch SW2-2 (Factory setting : ON) on the interface PCB.

Caution: Wireless remote control attached to the indoor unit can be used in parallel, after connecting the wired remote control. However, some of functions other than the basic functions such as RUN/STOP, temperature setting, etc. may not work properly and may have a mismatch between the display and the actual behavior.

②Wiring connection between the interface and the wired remote control.

Installation and wiring of wired remote control

Ⓐ Install the wired remote control with reference to the attached installation manual of wired remote control.
Ⓑ 0.3mm² x 2 cores cable should be used for the wiring of wired remote control.
Ⓒ Maximum length of wiring is 600m.
If the length of wiring exceeds 100m, change the size of cable as mentioned below.
100m-200m: 0.5mm² x 2 cores, 300m or less: 0.75mm² x 2 cores, 400m or less: 1.25mm² x 2 cores, 600m or less: 2.0mm² x 2 cores
However, cable size connecting to the terminal of wired remote control should not exceed 0.5mm². Accordingly if the size of connection cable exceeds 0.5mm², be sure to downsize it to 0.5mm² at the nearest section of the wired remote control and waterproof treatment should be done at the connecting section in order to avoid contact failure.
Ⓓ Don't use the multi-core cable to avoid malfunction.
Ⓔ Keep the wiring of wired remote control away from grounding (Don't touch it to any metal frame of building, etc.).
Ⓕ Connect the connection cables to the terminal blocks of the wired remote control and the interface securely (No polarity).

③Clamp the connection cables with cable clamps.

Control of multiple units by a single wired remote control

Multiple units (up to 16) can be controlled by a single wired remote control.
In this case, all units connected with a single wired remote control will operate under the same mode and same setting temperature.

①Connect all the interface with 2 cores cables of wired remote control line.
②Set the address of indoor unit for remote control communication from "0" to "F" with the rotary switch SW1 on the interface PCB.
③After turning the power ON, the address of indoor unit can be displayed by pressing AIR CON No. button on the wired remote control.
Make sure all indoor units connected are displayed in order by pressing ▲ or ▼ button.



Master/Slave setting wired when 2 of wired remote control are used

Maximum two wired remote control can be connected to one indoor unit (or one group of indoor units)

①Set the DIP switch SW1 on the wired remote control to "Slave" for the slave remote control. (Factory setting : Master)
○ Caution : Remote control sensor of the slave remote control is invalid.



●When using the wireless remote control in parallel with the wired remote control;
Since temperature setting range of wired remote control is different from that of wireless remote control, please adjust the setting range of wired remote control to be the same setting range of wireless remote control by following procedure. (The set temperature may not be displayed correctly on the wireless remote control, unless change of temperature setting range is done.)
Changing procedure of temperature setting range is as follows.

How to set upper and lower limit of temperature setting range

1. Stop the air-conditioner, and press (SET) and (MODE) button at the same time for 3 seconds or more.
The indication changes to"FUNCTION SET▼"
2. Press▼button once, and change to the "TEMP RANGE ▲" indication.
3. Press (SET) button, and enter the temperature range setting mode.
4. Confirm that the "Upper limit ▼ " is shown on the display.
5. Press (SET)button to fix.
6. ①Indication: "∨ ∧ SET UP"→"UPPER 28℃ ∨ ∧"
②Select the upper limit value 30℃ with temperature setting button △."UPPER30℃∨ " (blinking)
③Press (SET) button to fix. "UPPER 30℃" (Displayed for two seconds)
After the fixed upper limit value displayed for two seconds, the indication will return to"UPPER LIMIT▼".
7. Press▼button once, "LOWER LIMIT ▲ " is selected, press (SET) button to fix.
①Indication: "∨ ∧ SET UP" → "LOWER 20℃∨ ∧"
②Select the lower limit value 18℃ with temperature setting button ▽."LOWER18℃∧ " (blinking)
③Press (SET) button to fix. "LOWER 18℃" (Displayed for two seconds)
After the fixed lower limit value displayed for two seconds, the indication will return to"LOWER LIMIT▼"
8. Press ON/OFF button to finish.

Temperature setting range

Mode	Temperature setting range
Cooling, Heating, Dry, Auto	18-30℃



- It is possible to quit in the middle by pressing ON/OFF button, but the change of setting is incompleted.
- During setting, if pressing (RESET) button, it returns to the previous screen.

3.7.1 Cable connection for SRK twin/triple installation

①Connect the same pairs number of terminal block "①,②,and ③"and " Ⓧ and Ⓨ " between master and slave indoor units.

②Do the same address setting of all inside units belong to same refrigerant system by rotary switch SW1 on SC-BIKN2-E's PCB (Printed circuit board).

③Set slave indoor unit as "slave 1" through" slave 2" by address switch SW3-1, 3-2 on SC-BIKN2-E's PCB.

④When the AIR CON No. button on the remote control unit is pressed after turning on the power, an indoor unit's address number will be displayed. Do not fail to confirm that the connected indoor unit's numbers are displayed on the remote control unit by pressing the ▲ or ▼ button.



Method of setting Master/Slave of SC-BIKN2-E

(Factory setting: "Master")

SC-BIKN2-E		Master	Slave 1	Slave 2
PCB switch	SW3-1	OFF	OFF	ON
	SW3-2	OFF	ON	OFF



RKZ012A092

3.8 SUPERLINK E BOARD (SC-ADNA-E)

PJZ012D029K

- Read and understand the instructions completely before starting installation.
- Refer to the instructions for both indoor and outdoor units.

Safety precautions

- Carefully read "Safety precautions" first. Follow the instructions for installation.
- Precautions are grouped into "Warning⚠" and "Caution⚠". The "Warning⚠" group includes items that may lead to serious injury or death if not observed. The items included in the "Caution⚠" group also may lead to serious results under certain conditions. Both groups are crucial for safety installation. Read and understand them carefully.
- After installation, conduct the test operation of the device to check for any abnormalities. Describe how to operate the device to the customer following the installation instruction manual. Instruct the customer to keep this installation instruction for future reference.

⚠Warning

- This device should be installed by the dealer where you purchase the device or a licensed professional shop. If the device is incorrectly installed by the customer, it may result in electric shock or fire.
- Install the device carefully following the installation instruction. If the device is incorrectly installed, it may result in electric shock or fire.
- Use the accessory parts and specified parts for installation. If any parts that do not match the specifications are used, it may result in electric shock or fire.
- A person with the electrical service certification should conduct the service based on the "Technical standards for electrical facilities", "Electrical Wiring Code", and the installation instruction. If the work is done incorrectly, it may result in electric shock or fire.
- Wiring should be securely connected using the specified types of wire. No external force on the wire should be applied to any terminals. If a secure connection is not achieved, it may result in electric shock or fire.

⚠Caution

- Provide ground connection.
  The ground line should never be connected to the gas supply piping, the water supply piping, the lightning conductor rod, nor the telephone ground.If the grounding is improper, it may result in electric shock.
- Do not install the device in the following locations.
  1.Where there is mist/spray of oil or steam such as kitchens.
  2.Where there is corrosive gases such as sulfurous acid gas.
  3.Where there is a device generating electromagnetic waves.
  These may interfere with the control system resulting in the device becoming uncontrollable.
  4.Where flammable volatile materials such as paint thinner and gasoline may exist or where they are handled. This may cause a fire.

1 Application

Indoor-to-outdoor three core communication specification type 3 (since October 2007)

2 Accessories

SL E board	Metal box	Metal cover	Screw for ground
			M4×8L 2 pieces
Pan head screws	Locking supports	Binding band	Grommet
ø4×8L 2 pieces	To secure the print board and the metal box Made of nylon 4 pieces		

3 Function

Allowing the central control SL1N-E, SL2NA-E, and SL4-AE/BE to control and monitor the commercial air-conditioner unit.

4 Control switching

Settings can be changed by the DIP switch SW3 on the SL E board as in the following.

Switch	Symbol	Switch	Remarks
SW3	1	ON	Master
		OFF (default)	Slave
	2	ON	Fixed previous protocol
		OFF (default)	Automatic adjustment of Superlink protocol
	3	ON	Indicates the forced operation stop when abnormality has occurred.
		OFF (default)	Indicates the status of running/stop as it is, when abnormality has occurred.
	4	ON	The hundredth address activated "1"
		OFF (default)	The hundredth address activated "0"

5 Connection outline

Note for setting the address

- Set the address between 00 and 47 for the previous Superlink connection and between 000 and 127 for the new Superlink connection. (*1)
- Do not set the address overlapping with those of the other devices in the network. (The default is 000)



(*1) Whether the actual link is either the new Superlink or the previous Superlink depends on the models of the connected outdoor and indoor units. Consult the agent or the dealer.

Signal line specification

Communication method	Previous Superlink	New Superlink
Line type	MVVS	MVVS
Line diameter	0.75 - 1.25mm²	0.75/1.25mm²
Signal line (total length)	up to 1000m	up to 1500/1000m (*2)
Signal line (maximum length)	up to 1000m	up to 1000m

(*2) Up to 1500 m for 0.75 mm², and up to 1000 m for 1.25 mm².
Do not use 2.0 mm². It may cause an error.

(*3) Connect grounding on both ends of the shielding wire.
For the grounding method, refer to the section "6 Installation".

(1) Set the Superlink network address with SW1 (tens place), SW2 (ones place), and SW3 (hundreds place).
(2) Set the SL E board SW3-1 to be ON (Master) when using this without any remote control (no wired remote controller nor wireless remote control).
(3) Set up the plural master/slave device using the DIP switches on the indoor unit board.
(4) Set up the remote control master/slave device using the slide switch on the remote control board.
(5) Set up "0" to "F" using the address rotary switch on the indoor unit board when controlling the indoor unit with the multiple remote control.



6 Installation

1. When using the metal box (mounted on the indoor unit / mounted on the back of the remote control):
   (1) Mount the SL E board in the metal box using the locking supports.
   (2) Wiring should go through the provided grommet since then through the wiring to the hole on the Metal box.
   Secure the grommet after inserting the grommet into the Metal box as shown in below figure, then tie the wiring at the outlet of the unit using a binding band.



▲ When installed outside the indoor unit, put the metal cover on.



▲ When installed on the back of the remote control, mount it directly on the remote control bottom case.



Connect grounding. Connect grounding for the power line to Ground ①, and grounding for the signal line to Ground ② or to the Ground on the indoor unit control box.



2. When connecting to the indoor unit control box (ceiling-concealed type and FDT type only):
   (1) Mount the SL E board in the control box using the locking supports.
   (2) Remove 6 bands from the box and put the wiring through the bands to be secured.



Electrical shock hazard! make sure to turn the power off for servicing. Be cautious so that no abnormal force should be applied to the wiring. Do not let the SL E board hung by the wiring. Do not damage the board with a screw driver.
The board is sensitive to static electricity. Release the static electricity of your body before servicing.
(You can do this by touching the control board which is grounded).

Location of installation

Install the device at the location where there are no electromagnetic waves nor where there is water and dust. The specified temperature range of the device is 0 to 40°C. Install the device at the location where the ambient temperature stays within the range. If it exceeds the specification, make sure to provide solution such as installing a cooling fan. When used outside of the range, it may cause abnormal operation.

7 Indicator display

Check the LED 3 (green) and LED 2 (red) on the SL E board for flashing.

SL E board LEDs		Inspection mode	Display on the integrated network control device
Red	Green		
Off	Flashing	Normal communication	
Off	Off	• Disconnection in the remote control communication line (X or Y) • Short-circuit in the remote control communication line (between X and Y) • Faulty indoor unit remote control power • Faulty remote control communication circuit • Faulty CPU on SL E board	No corresponding unit number
One flash	Flashing	• Disconnection in the Superlink signal line (A or B) • Short-circuit in the Superlink signal line (between A and B) • Faulty Superlink signal circuit	
Two flashes	Flashing	• Faulty address setting for the SL E board (Set up the address for previous SL E board : more than 48 new SL E board : more than 128)	
Three flashes	Flashing	• SL E board parent not set up when used without a remote control • Faulty remote control communication circuit	E1
Four flashes	Flashing	• Address overlapping for the SL E board and the Superlink network connected indoor unit	E2
Off	Flashing	• Number of connected devices exceeds the specification for the multiple indoor unit control	E10

MICRO INVERTER PACKAGED AIR-CONDITIONERS

MITSUBISHI HEAVY INDUSTRIES

MITSUBISHI HEAVY INDUSTRIES THERMAL SYSTEMS, LTD.
16-5 Konan 2-chome, Minato-ku, Tokyo, 108-8215, Japan
http://www.mhi-mth.co.jp/en/

Because of our policy of continuous improvement, we reserve the right to make changes in all specifications without notice.
© Copyright MITSUBISHI HEAVY INDUSTRIES THERMAL SYSTEMS, LTD.