




REFRIGERATION AND
AIR CONDITIONING

Instructions Battery module type EKA 181C

084R9988

084R9988



EKA 181C
Battery module

1) Power off

2)

3) Power on

EKC 202
AK-CC 210
AK-CC 250

Danfoss
84R22515.10