

Data sheet - Spare parts and accessories

Safety relief valves SFA and SFV

Compressor overflow valve POV + BSV

Size	Description	Pos. #	Qty.	Code no.
Fig. 1 - SFA 10 Repair kit				
SFA 10	Repair Kit 10 – 27 bar*	all pos.	1	148F3069
SFA 10H	Repair Kit 28 – 65 bar*	all pos.	1	148F3070
SFA 10(H)	SFA 10(H) G Inlet weld connector	-	1	148F3075
SFA 10(H)	SFA 10(H) NPT Inlet weld connector	-	1	148F3076
Fig. 2 - SFA 15 Repair kit				
15	Cone complete	1	1	148F3036
15	Gaskets	2, 3, 4	4	
Fig. 2 - SFA 15-50 Repair kit				
15	Cone complete	1	1	148F3150
15	Gaskets	2, 3, 4	4	
SFA 10, SFA 15/SFV 15 - Nipples and gaskets				
10, 15	Nipples + gaskets set for SFA 10, SFA 15/SFV 15**	-	2	148F3019
Fig. 3 - SFV Repair kit				
20	Cone complete	1	1	2453+082
20	Gaskets	2, 3, 4	4	
25	Cone complete	1	1	2453+083
25	Gaskets	2, 3, 4	4	
SFV - Flanges and gaskets				
20	Flanges + gaskets set for SFV 20	-	1	148F3020
25	Flanges + gaskets set for SFV 25	-	1	148F3021
POV+BSV fittings				
Set of fittings for system POV+BSV		-	1	148H3453

* Inspection kit 148F3068 (see DSV 10) should be ordered with any SFA 10 repair kit.
** Weld nipple for SFA 10 inlet (G ½") not included in 148F3019.
(additional order 148F3075 needed).