AVTB, Direct Acting Thermostatic Water Valve



Applications:




AVTB is a direct acting thermostatic temperature controller used to regulate the water temperature in hot water tanks, heat exchangers, oil preheaters, etc. The non-electric thermostatic controller closes on rising temperature.

The thermostatic controller is a three part assembly consisting of the valve body, the thermostatic element and an adjustment assembly.

Features:

- For water
- Self-acting
- Closes on rising temperature
- Can be fitted in the supply or return
- Pressure range PN 16 (232 psi/16 bar)

Typical Application:



Ordering Information:

Code No.	Model	Connection (FNPT)	Capillary Tube Length	Max. Sensor Temperature °F (°C)	C _v	Temperature Range °F (°C)	
003N6032				130 (55)		32-86 (0-30)	
003N6252	AVTB 15	1/2"		190 (90)	2.2	70-140 (20-60)	
003N6272				255 (125)		125-190 (50-90)	
003N7032				130 (55)		32-86 (0-30)	
003N7252	AVTB 20	3/4"	6′6″ (2.0 m)	190 (90)	4.0	70-140 (20-60)	
003N7272			(2.0111)	255 (125)		125-190 (50-90)	
003N8032					130 (55)		32-86 (0-30)
003N8252	AVTB 25	1"	1" 190 (90) 6.4 70-	70-140 (20-60)			
003N8272				255 (125)		125-190 (50-90)	

AVTB, Direct Acting Thermostatic Water Valve



Ordering Information (Cont.):

Accessories

Code No.	Components
003N0056	Capillary tube gland
003N0418	Gasket for capillary tube gland
AVTBWELL	Sensor pocket, 3/4" NPT, brass
003N0053	Sensor pocket, 3/4" NPT, stainless steel


^{1.} Include gasket for capillary tube gland

Spare Parts

Code No.	Con	nponents	Cap. tube length ft. (m.)		
003N0075 ^{1.}	Thermost 32-85°F (0	tatic element 0-30°C)			
003N0078 ^{1.}		tatic element (20-60°C)	6′6 (2)		
003N0062 ^{1.}		tatic element F (50-90°C)			
003N4006	AVTB 15	Repair set: Two			
003N4007	AVTB 20		ne rubber cone,		
003N4008	AVTB 25	one tube of grease and eight valve cover crews			
003N6100	1/2"				
003N7100	3/4"	Brass AVT body	y and lob, less element		
003N8100	1″	- adjustificiti kilob, less element			
003N0520	AVT spare	e handle			

Design:

- 1. Handle for temperature setting
- 2. Spring housing
- 3. Setting spring
- **4.** O-ring
- 5. Diaphragm6. Spindle
- 7. Valve body
- 8. Valve coné
- 9. Bellows
- 10. Bellows stop **11.** Pressure stem
- **12.** Temperature sensor
- 13. Capillary tube gland



Materials, parts in contact with water:

Valve body: Ms 58, hot-pressed

Other metal parts: Ms 58

EPDM rubber Diaphragms:

(alt. NBR rubber for mineral oils)

Capillary tube gland: NBR rubber

Valve cone: NBR rubber

Valve seat: CR Ni steel

Sensor: Cu

Sensor pocket: Ms 63

Specifications:


Supply temperature range:	-13°F to 266°F (-25°C to 130°C)
Maximum working pressure:	232 psi (16 bar)
Maximum differential pressure:	100 psi (7 bar)
Maximum test pressure:	365 psi (25 bar)

^{2.} Ø 0.4" (Ø 9.5 mm) sensor

AVTB, Direct Acting Thermostatic Water Valve



Sizing:



Example:

Regulation of hot water temperature. Primary medium: water.

Given

Load:

63,000 BTU/h (18.5 kW)

Primary temperature drop Δt : 72°F (40°C[K])

Differential pressure Δp across valve: 2.2psi (0.15 bar)

Maximum hot water temperature: 130°F (55°C)

Volume:

Q =
$$\frac{\text{load [BTU/h]}}{\Delta t [^{\circ}F] \times 500} = \frac{63,000}{72 \times 500} = 1.75 \text{ GPM}$$

= (0.4 m³/h)

Required

The correct valve size.

Temperature range and P-band.

Method

Using the AVTB diagram, connect points Q = 1.75 GPM (0.4 m³h) and $\Delta p_{\nu} = 2.2$ psi (0.15 bar). Extend the line to intersect the C_{ν} -scale (k_{ν} -scale) and read the C_{ν} -value (k_{ν} -value); in this case 1.2 GPM (1.0m³/h). From this point, take a line horizontally to insect the X_{ν} columns. The selection is an AVTB 15 and the P-band of this temperature regulator at the selected capacity is approximately 11°F (6°C). If a smaller P-bands is required, an AVTB 20 can be chosen. The P-band is then approximately 7°F (4°C).

In this example a max. hot water temperature of $130^{\circ}F$ ($55^{\circ}C$) is required. According to page 1 an AVTB 15 (code no. 003N7032) with a temperature range 70-140°F ($20-60^{\circ}C$) will be suitable for this application.

Note: To ensure the most stable regulation in connection with heat exchangers a P-band of 11-14°F (6-8°C) is recommended.

Setting:

Relation between scale numbers 1-5 and the closing temperature. The values given are approximate.


Scale setting	1	2	3	4	5 I	
Closing temperatu	re	1 1	ı	'	'	ļ
(0 30 °C)		0 3	15	23	30	°C
(20 60 °C)	20	35	50	60	70	
(30 100 °C)30	35	55	75	95	120	
(3285°F)		32 39	60	73	85	 °F
(77150°F)	77	95	122	140	158	
(125190°F)	125	150	176	194	210	

AVTB, Direct Acting Thermostatic Water Valve



Installation:


The valve can normally be fitted in the supply or return, in any position, provided the flow is always in the direction indicated by the arrow. Elments with a small sensor Ø 0.4" (9.5 mm) ("sensor warmer") must always have the valve houing fitted in the return.




The sensor can be mounted where the system temperature is either warmer or colder than the temperature in the valve body

Dimensions:

Tuno	H,	Η,	L	L,	L2	L3	L4	a
Type	in (mm)	in (mm)	in (mm)	in (mm)	in (mm)	in (mm)	in (mm)	(int. thread)
AVTB 15	8.54 (217)	5.24 (133)	2.84 (72)	0.56 (14)	5.6 (141)	5.87 (149)	2.95 (75)	1/2" NPT
AVTB 20	8.54 (217)	5.24 (133)	3.55 (90)	0.63 (16)	6.06 (154)	6.45 (164)	3.15 (80)	34" NPT
AVTB 25	8.54 (227)	5.43 (138)	3.74 (95)	0.75 (19)	6.61 (168)	6.57 (167)	3.27 (83)	1" NPT







Danfoss can accept no responsibility for possible errors in printed materials and reserves the right to alter its products without notice.

All trademarks in this material are property of the respective companies. Danfoss and Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.



Danfoss

Toronto, ON Toll Free: 866-375-HVAC (4822) Tel.: 905-285-2050, Fax: 905-285-2055 www.na.heating.danfoss.com

Danfoss

Baltimore, MD Toll Free: 866-375-HVAC (4822) Tel.: 443-512-0266, Fax: 443-512-0270 www.na.heating.danfoss.com